FBW A380X

PRE FLIGHT

VATSIM Flightplan filed? Volanta/VA Tracking Started? Simbreif Flightplan Imported?

Preliminary Cockpit Preparation

ENGINE MASTER SWITCHES	OFF
PARKING BRAKE(OR CHOCKS)	ON
SPEED BRAKE LEVER	RETRACTED
FLAPS LEVER	RETRACTED
WEATHER RADAR	OFF
ENGINE MODE SELECTOR	NORM
THRUST LEVERS	IDLE
GEAR LEVER	DOWN
WIPERS(BOTH)	OFF

POWER UP

BATTERY VOLTAGE	WITHIN LIMITS
ALL BATTERIES	ON
EXTERNAL POWER	ON
COCKPIT LIGHTING	AS REQ

Fire Test and APU Start

RMP 1 and 2	ON
STANDBY RADIO NAVIGATION	OFF
COMMUNICATION FREQUENCIES	TUNE
INTERPHONE RECEPTION	ADJUST
APU FIRE	IN and GUARDED
APU AGENT	OFF
ENGINE 1/2/3/4 FIRE	CHECK IN and GUARDED
ENGINE AGENTS 1 and 2	OFF
FIRE TEST	PRESS
APU MASTER SWITCH	ON
APU START	ON
EXTERNAL POWER	AS REQ

recommended to keep the external power units to ON to reduce the APU load in hot weather conditions

Overhead Panel Left (bottom to top)

ALL WHITE LIGHTS	OFF
RECORDER GROUND CTL	ON
EVAC CAPT/CAPT & PURS	CAPT
PROBE & WINDOW HEAT	AUTO
ADIRS ALL IR MODE	NAV
ELT (INOP)	ARMED

Overhead Panel Center (bottom to top)

STROBE	AUTO
BEACON	OFF
REMAINING EXTERIOR LIGHTS	AS REQ

CONSIDER REFUELING IN-PROGRESS

SEATBELTS	ON
NO MOBILE	AUTO
EMERGENCY EXIT LIGHTS	ARM
ENGINE STARTER	NORM
APU BLEED	ON
XBLEED	AUTO
AIRFLOW	NORM
CKPT	AS REQ
CABIN	PURS SEL
TRIM TK FEED	AUTO
MAINTENCE PANEL LIGHTS	ALL OFF

Overhead Panel Right (bottom to top)

CARGO AIR COND	AS REQ
RADIO MANGMENT PANEL 3	ON
STBY RAD NAV	OFF
CVR TEST	PRESS

Main Instrument Panel

SWITCHING PANEL	NORM
INTEGRATED STANDBY INSTRUMENT SYSTEM	CHECK
GRAVITY GEAR SYSTEM	OFF
CLOCK	CHECK & SET
ANTI AKID (A-SKID)	ON

Pedestal

PARK BRAKE	ON
BODY ACCUMULATOR PRESSURE (INOP)	CHECK
THRUST LEVERS	IDLE
THRUST REVERSE	STOWED
ENGINE MASTERS	OFF
COCKPIT DOOR	NORM

OBTAIN AN IFR CLEARANCE
PREP CHARTS

MFD SURVEILLANCE DEFAULT	SELECT

Initialise FMS

At this point, the Flight Management System (FMS) should be initialised.

Glareshield & Lateral Consoles

INTEGRAL LIGHTS	AS REQ
BAROMETRIC REFERENCE	SET
ND MODE AND RANGE	AS REQ
WX RADAR	AS REQ
OTHER EFIS OPTIONS	AS REQ
FD	ON
NORTH REF	MAG
SPD, HDG, V/S	DEFAULTS
ALT	INITIAL CLIMB
OXYGEN MASKS	TEST
DOOR SD PAGE REGUL PR LO	CHECK NOT DISPLAYED
FLIGHTDECK WINDOWS	CHECK LOCKED
TAKEOFF BREIFING	PERFORM

Before Push & Start

IFR clearance obtained
The aircraft is secure
APU is available

EXT POWER	DISCONNECT and CHECK AVAIL
EXTERNAL POWER DISCONNECTION	REQUEST
LOW PRESSURE GROUND CARTS	CHECK DISCONNECTED

OBTAIN PUSH & START CLEARANCE

BEACON	ON
DOORS & WINDOWS	CLOSED
SLIDES	ARMED
THRUST LEVERS	IDLE
PARKING BRAKE & CHOCKS	OFF & REMOVED
BEFORE START CHKL	COMPLETE

COMMENCE PUSH

Engine Start

ENGINE START selector	IGN START
START ENGINES 1 and 2	ANNOUNCE
ENGINE MASTER 1 then 2	ON
WHEN AVAIL: ENGINE IDLE PARAMETERS	CHECK NORMAL
START ENGINES 3 and 4	ANNOUNCE
ENGINE MASTER 3 then 4	ON
WHEN AVAIL: ENGINE IDLE PARAMETERS	CHECK NORMAL

After Engine Start

ENGINE START selector	NORM
APU BLEED	OFF
ANTI ICE	AS REQ
APU	OFF
GROUND SPOILERS	ARM
RUDDER TRIM	ZERO
TO FLAPS	SET
TRIM	CHECK
ECAM STATUS	CHECK
DISCONNECT GROUND CREW, HAND SIGNALS RECIEVED	
FLIGHT CONTROLS	CHECK
TUG	CLEAR
AFTER START CHKL	COMPLETE

Taxi

TAXI CLEARANCE	OBTAIN
ND RANGE	AS REQ
NOSE LIGHTS	TAXI
RWY TURN OFF	AS REQ
PARK BRAKE	OFF
BRAKES	CHECKED
NW Steering	AS REQ
ATC CLEARANCE	CONFIRM
consider SUPER status, ensure taxi route is appropriate	

Before takeoff

SELECTED RUNWAY AND INPUT DATA	CHECK
F-PLN (SID, TRANS)	REVISE OR CHECK
INITIAL CLIMB SPEED AND SPEED LIMIT	MODIFY OR CHECK
CLEARED ALTITUDE ON FCU	SET
HDG ON FCU	IF REQUIRED, PRESET
FLIGHT DIRECTOR	CHECK SELECTED ON
PFD/ND	CHECK
MFD	CHECK
V1/VR/V2/THR RATING	CHECK (BOTH)
TAKEOFF BRIEFING	CONFIRM
FLIGHT INSTRUMENTS	CONFIRM
SPLRS	ARM
FLAPS	T.O
AUTOBRAKE RTO	ARM
SIGNS	AS NEEDED
T.O CONFIG	TEST
T.O MEMO	NO BLUE LINE
CABIN	READY
BEFORE TAKEOFF CHECKLIST (TAXI - down to the line)	COMPLETE

Lineup

OBTAIN TAKEOFF OR LINEUP CLEARANCE

CABIN CREW	ADVISE
PACKS 1 and 2	AS REQ
EXTERIOR LIGHTS	SET
ND RANGE	SET
EFIS	SET
TRAF	ON
APPROACH PATH	CLEAR
STROBES	ON
TAKEOFF RWY	CONFIRM (RAAS)
SLIDING TABLE	STOWED
TCAS	TA/RA
BEFORE TAKEOFF CHECKLIST (Line-Up - below the line	COMPLETE

Takeoff

TAKEOFF CLEARANCE RECIEVED

PARK BRAKE	OFF
BRAKES	PRESS & HOLD
TAKEOFF	ANNOUNCE
THRUST	25%
BRAKES	RELEASE
THRUST LEVERS	FLX/MCT or TOGA
CRONO	START

After Takeoff

THRUST LEVERS	CLIMB
A/THR	CHECK ACTIVE
PACKS	ON
AP	AS REQ
AT F SPEED	FLAPS 1
AT S SPEED	FLAPS 0
EXTERIOR LIGHTS	OFF
GROUND SPOILERS	DISARM
APU	CONFIRM OFF
TCAS	CONFIRM TA/RA
ANTI ICE	AS REQ

Climb

Aircraft is Climbing to or is at Initially CLRD FL
Complete After Takeoff Checklist

ATC has cleared further climb	action
Cruise FL	AS REQ
ANTI ICE	AS REQ
ON PASSING 10,000ft	
Landing Lights	OFF
SEATBELTS	CONSIDER OFF
EFIS	AS REQ
ECAM MEMO	REVIEW
consider optimal/max altitude	
BARO	STD

Cruise

ALT CRZ	CONFIRM
ECAM MEMO	REVEIW
SD PAGES	REVIEW
Monitor flight progress, fuel etc	

Before TOD

WEATHER AND LANDING INFORMATION	OBTAIN
LANDING ELEVATION	CHECK
BARO	PRE SET
LANDING PERFORMANCE	CHECK
IN FMS	
FMS ACTIVE/F-PLN/ARRIVAL PAGE	INSERT/CHECK
DES PANEL OF THE FMS ACTIVE/PERF PAGE	INSERT/CHECK
APPR PANEL OF THE FMS ACTIVE/PERF PAGE	INSERT/CHECK
GA PANEL OF THE FMS ACTIVE/PERF PAGE	CHECK
FMS POSITIONAL/NAVAIDS PAGE	CHECK
LANDING BRIEF	PERFROM

OANS and BTV if AVAIL

RUNWAY SHIFT	AS REQUIRED
ND MODE	PLAN
ND RANGE	ZOOM
RUNWAY	SELECT
RUNWAY EXIT	SELECT
AUTO BRAKE/BTV	SELECT, AS REQUIRED
OANS RWY LENGTH/CHARTS RWY LENGTH	CROSSCHECK
LANDING BRIEF	PERFORM

Descent

DESCENT CLEARANCE	OBTAIN
CLEARED ALTITUDE/FL	SET
ANTI-ICE	AS REQ
DESCENT	INITIATE
CREW	ADVISE
20,000ft	
CABIN CREW	ADVISE
TER & WX RADAR	AS REQ
10,000ft	
LANDING LIGHTS	ON
LANDING DATA	SET
SEATBELTS	ON
Consider turning seatbelts on sooner, huge cabin to secure	
CSTR & LS BUTTON	PUSH
NAVAIDS	AS REQ
APPROACH CHECKLIST	COMPLETE

Before Intercepting ILS

ALTIMETER	SET
APPROACH PHASE	CHECK/ACTIVATE
MANAGED SPEED	CHECK
SPEEDBRAKES	AS REQ

ILS Approach

ILS FREQUENCY	VERIFY
LS	CHECK ON
ALTITUDE	VERIFY
ATC APPROACH CLEARANCE	
SPEED MODE	MANAGED
APPR MODE	PRESS
AUTOPILOT 1+2	ON
FLIGHT MODE ANNUNCIATOR	CHECK
FLAPS 1 (at V~FE~ -15)	SET
TCAS MODE	TA/RA
LOC CAPTURE	MONITOR
ATC CONTACT	TOWER
GO AROUND ALTITUDE	SET
FLAPS 2 (~2.500ft and below V~FE~)	SET

Landing

Below 2,000ft	
LANDING GEAR	DOWN
AUTO BRAKE	CONFIRM
GROUND SPOILERS	ARM
FLAPS 3 (after L/G down and below V~FE~)	SET
WHEEL SYSTEM DISPLAY PAGE	CHECK
FLAPS (below V~FE~)	FULL
AUTOTHRUST	CHECK IN SPEED MODE OR OFF
LANDING MEMO	NO BLUE LINE
CABIN	READY
LANDING CHECKLIST	COMPLETE

The A380 should be flared at ~40ft agl

After Landing

REVERSE LEVERS	STOW
AUTOBRAKE	DISARM
SPOILER	DISARM
FLAPS	RETRACT
APU MASTER	ON
APU START	ON
ENGINE START SELECTOR	CHECK NORM
ANTI-ICE	AS REQ
LANDING LIGHTS	OFF
STROBE	AUTO
OTHER EXTERIOR LIGHTS	AS REQ
NOSE LIGHT	TAXI
RUNWAY TURN OFF LIGHTS & CAMERA	AS REQ

Taxi In

AIRPORT NAVIGATION DISPLAY	ZOOM, AS APPROPRIATE
EFIS TAXI	AS REQ
WX RADAR	CHECK OFF
WX Radar left on will cause ground crew serious health side effects	
BRAKE TEMP	MONITOR

Turning into gate & Engine Shut Down

NOSE LIGHTS	OFF
RWY TURN OFF LIGHTS	OFF
ANTI-ICE	OFF
APU BLEED	ON
PARKING BRAKE	ON
ENGINE MASTERS	OFF
SEATBELTS	OFF
SLIDES	DISARM
After engine N1 <5%	
BEACON	OFF
GROUND CONTACT	ESTABLISH
	call GSX
FUEL PUMPS	OFF
FUEL QUANTITY	CHECK
PARKING CHECKLIST	COMPLETE

Securing the Aircraft

PARKING BRAKE & CHOCKS	ON, SET
OXYGEN CREW SUPPLY	OFF
ADIRS	OFF
EXTERIOR LIGHTS	OFF
APU BLEED	OFF
EXTERNAL POWER	OFF
APU MASTER	OFF
EMERGENCY LIGHTS	OFF
NO SMOKING/DEVICES	OFF
SECURING THE AIRCRAFT CHECKLIST	COMPLETE
ALL BATT	OFF