PMDG Boeing 777 Flows

Power Up & Pre-Flight FMC Setup	
Flap Handle	Verify UP
Gear Handle	Verify DOWN
Speed Brake	Verify STOWED
Fuel Ctrl Switches	Verify CUTOFF
Battery	ON
External Power	Verify both primary and secondary AVAIL ⇒ PRIMARY to ON ⇒ 2 second wait ⇒ SECONDARY to ON ⇒ Approx 60s wait for aircraft to power up
ADIRU	ON
POS INIT (FMC)	Click and paste GPS position into SET INTERTIAL POS *Optionally input airport ICAO and verify position marries up*
ROUTE (FMC)	ROUTE REQUEST (once Simbrief route has been imported into EFB) ⇒ ACTIVATE ⇒ EXEC *Optionally SET FUEL and SET PAYLOAD on the ROUTE REQUEST screen, or load via GSX, etc.*
PERF INIT (FMC)	Enter ZFW ⇒ Confirm CRZ ALT, Cost Index, Reserves ⇒ ACCEPT Perf Init Data
DEPP ARR (FMC)	Select departing runway and SID ⇒ EXEC ⇒ INDEX Select expected arrival runway and STAR/Transition ⇒ EXEC *Optionally check DTG on PROG page to confirm route distance marries up*
LEGS (FMC)	Step through and check for discontinuities, fix where required
Overhead Panel	
ADIRU	Verify ON
IFE/Pass Seats	ON
Cabin/Utility	ON
Emergency Lights	Close cover
Window Heat	All four to ON
Hydraulic Pumps	Verify 8x FAULT annunciations ⇒ R Elec to AUTO ⇒ Verify brake pressure climb
Passenger Signs	Verify NO SMOKING is ON SEAT BELTS as required
Fire Test	Press and hold FIRE/OVHT TEST Verify '10 Things and a Noise' ⇒ 2x engine fire handles illuminate ⇒ 2x fuel control switches illuminate ⇒ 2x master warnings illuminate ⇒ 2x cargo fire warning illuminate ⇒ APU fire handle illuminate ⇒ Fire Test Pass on EICAS ⇒ Fire bell
Engine Start Switches	Verify both NORM
Fuel Pumps	Verify 4x PRESS annunciations on FWD and AFT pumps
Anti-Icing	Verify all AUTO
Nav Lights	ON
Indicator Lights	Set to TEST ⇒ Verify all lights annunciate Set to BRT
Air Conditioning	Verify all AUTO or ON
Bleed Air	Verify all AUTO or ON
Pressurization	Verify outflow valves set to AUTO
MCP & Pedestal	
Altimeters	Set current pressure
EFIS	Optionally ensure that ARPT, TERR and TFC are selected
Flight Directors	Both to ON
Heading	Set to departure runway heading
Altitude	Set to initial cleared altitude
LNAV	ON
VNAV	ON
Autobrake	RTO
Transponder	Set squawk
Radios	Tune as required
Oxygen	Check notch is at 100% ⇒ Press button and confirm flow ⇒ Repeat for FO side
Preflight Checklist	
Display Select Panel	Select CHKL synoptic page
Checklist	Complete ⇒ Select NORMAL to load next checklist

Takeoff Data & Pre-Start	
Performance Calculations	Complete via EFB ⇒ Flaps 5 standard for TO ⇒ Flaps 15 or 20 for abnormal/gusty
INIT REF (FMC)	THRUST LIM ⇒ Insert SEL temp ⇒ Select rate (TO/TO 1/TO 2) TAKEOFF ⇒ Insert TO flaps ⇒ Insert CG% ⇒ Insert SEL into THRUST *Confirm V Speeds marry up with performance calculation* NEXT PAGE ⇒ Insert EO ACCEL, ACCEL and THR REDUC heights (not *altitudes*)
Trim	Set per TAKEOFF page *Optionally confirm correct STAB value on FCTL synoptic page*
IAS	Set V2 speed
APU	ON ⇒ Confirm L FWD Fuel Pump PRESS extinguished START ⇒ Watch EICAS for APU Running message ⇒ Confirm Secondary EXT PWR displaying AVAIL
Doors	Confirm all closed and armed via DOOR synoptic page
External Power	Set PRIMARY to OFF ⇒ Dismiss GPU
Transponder	Set to XPDR
Hydraulic Pumps	*Draw a C (counter-clockwise)* ⇒ C2 ELEC to ON ⇒ C1 ELEC to ON ⇒ L ELEC DEMAND to AUTO ⇒ C1 AIR to AUTO ⇒ C2 AIR to AUTO
Fuel Pumps	L PUMPS and R PUMPS all to ON ⇒ CENTER PUMPS to ON *if there is over 10,500lb / 4700kg in Center Tank.*
Passenger Signs	Verify SEAT BELTS signs ON
Before Start Checklist	
Display Select Panel	Select CHKL synoptic page
Checklist	Complete ⇒ Select NORMAL to load next checklist ⇒ Display ENG synoptic page for engine start
Parking Brake	Confirm SET and pressurized
Chocks	Remove
EICAS	Confirm TCAS OFF and ENG SHUTDOWN messages before pushback

Engine Start & Taxi	
Pushback	Commence
Engine Start	L ENGINE switch to START L Fuel Control to RUN ⇒ Verify oil pressure rising ⇒ Watch for red notch on EGT gauge to disappear to verify start is successful Repeat for R Engine
Flaps	Set TO flaps
Anti-Icing	Set as necessary
APU	Set to OFF
Flight Controls Check	Complete ⇒ Optionally display FCTL synoptic page
Before Taxi Checklist	
Display Select Panel	Select CHKL synoptic page
Checklist	Complete ⇒ Select NORMAL to load next checklist
Taxi Light	ON
Thrust	Maximum 35% N1 breakaway thrust
Transponder	TA/RA before entering runway
Before Takeoff Checklist	
Display Select Panel	Select CHKL synoptic page
Checklist	Complete ⇒ Select NORMAL to load next checklist
Takeoff & Climb	
Lights	Landing Lights ⇒ ON Runway Turnoff Lights ⇒ ON Wing Lights ⇒ ON Strobe Lights ⇒ ON *If dark* Logo Lights ⇒ ON
Recall	Confirm no EICAS messages
Thrust	N1 to 55% and stable, then TO/GA *TO/GA click spot on screw between EFIS and Left F/D*
Pitch	Approx 1-2 degrees per second, 10 seconds to 15 degree pitch up
Landing Gear	UP at positive rate ⇒ Confirm UP after a few moments on MFD below EICAS
Flaps	Retract in line with IAS flags *Note that 'clean speed' may be >250kt*

After Takeoff Checklist	
Display Select Panel	Select CHKL synoptic page
Checklist	Complete ⇒ Select NORMAL to load next checklist
10,000ft	
No Smoking	Cycle to alert cabin crew
Seat Belts	AUTO once stable in climb
Lights	Landing Lights ⇒ OFF between 10,000ft and 18,000ft Wing Lights ⇒ OFF Taxi and Runway Turnoff Lights ⇒ OFF
Screen Setup	COMM synoptic page on lower center screen. Optionally, to display 'compressed' engine data on upper MFD; ⇒ Inboard Display Selector to EICAS ⇒ Display Selector to L INBD ⇒ Select ENG ⇒ Inboard Display Selector to MFD
Cruise & Descent Preparation	
Waypoints	Check timings and arrivals against OFP
Fuel Management	When FUEL LOW CENTER EICAS message appears ⇒ Display FUEL synoptic page ⇒ Left CENTER pump to OFF ⇒ Confirm flow transferred to L TANK ⇒ Right CENTER pump to OFF ⇒ Confirm flow transferred to R TANK
Step Climbs	As required. Set Auto Steps in EFB, or step climb manually (refer to VNAV page for suggested step climbs).
Landing Performance	Calculate approaching TOD with expected runway and weather. ⇒ Add 1/2 headwind component + full gust component to expected VREF (minimum 5kt, maximum 15kt) ⇒ Flaps 25 or Flaps 30
Altitude	Select lowest constraint on STAR or desired altitude before reaching top of descent
Descent, Approach & Landing	
Descent and Approach Checklists	
Display Select Panel	Select CHKL synoptic page
Checklist	Complete ⇒ Select NORMAL to load next checklist ⇒ Complete Approach Checklist at transition altitude

Lower MFD	Display ENG synoptic page for descent
Seat Belts	ON before 10,000ft
Lights	Landing Lights ⇒ ON Wing Lights ⇒ ON Taxi and Runway Turnoff Lights ⇒ ON *If dark* Logo Lights ⇒ ON
Speed	Manage during descent with use of speedbrake and landing gear if need be.
RNP RNAV Approach	
RAD NAV (FMC)	Verify ILS is set to PARK
PROG Page 4 (FMC)	Enter RNP minimum into LSK2 Enter 125 into RSK2
Altitude	Do not lower to field elevation until en-route to final approach point.
ILS Approach	
RAD NAV (FMC)	Verify ILS course and frequency displayed
Final Approach	No more than 30 degree angle for intercept of final approach course ⇒ Arm APP mode
Altitude	Once on final descent ⇒ Set Missed Approach altitude
Flaps	Extend on schedule ⇒ Before green tick speeds on PFD speed tape ⇒ Below placarded flap limit speeds
Landing Gear	Extend gear before Flaps 25 ⇒ Verify DOWN annunciation on MFD below EICAS
Flaps 25/30	Extend as required below 190kt ⇒ *Aim to be configured before final approach for speed management*
Speed	Slow to VREF + wind correction speed
Landing Checklist	
Display Select Panel	Select CHKL synoptic page
Checklist	Complete ⇒ Select NORMAL to load next checklist
Landing	At 30ft altitude ⇒ Very slight flare to check descent rate ⇒ Allow the plane to settle down itself

Taxi-In & Shutdown	
Lights	Landing Lights ⇒ OFF Runway Turnoff Lights ⇒ OFF Wing/Logo Lights ⇒ OFF Strobe Lights ⇒ OFF
Flight Directors	Both to OFF
Autobrake	Set to OFF
Speedbrake	Stowed
Flaps	Retracted
Transponder	Set to XPDR
APU	When approaching Apron, set to ON ⇒ Wait a beat ⇒ Set to START
Taxi Light	OFF before turning onto ramp
Parking Brake	SET
Fuel Ctrl Switches	Both to CUTOFF
Seat Belts	OFF
Hydraulic Pumps	*Reverse the C (clockwise)* ⇒ C2 AIR to OFF ⇒ C1 AIR to OFF ⇒ L ELEC DEMAND to OFF ⇒ C1 ELEC to OFF ⇒ C2 ELEC to OFF ⇒ R ELEC DEMAND to OFF
Fuel Pumps	All to OFF
Beacon Light	OFF
Transponder	STBY
Shutdown Checklist	
Display Select Panel	Select CHKL synoptic page
Checklist	Complete

Transcribed from FilbertFlies MSFS Tutorial: PMDG Boeing 777 with a Real World Pilot. With thanks to my Official Ghostwriter Books (Liam) for his assistance in putting these together.