Tera Term Installation

Download link: https://teratermproject.github.io/index-en.html or https://github.com/TeraTermProject/teraterm/releases


Version Install: 5.4.0

Installation Steps:


1. Step 1: Skip to step 3 if this doesn't pop.




2. Step 2:




3. Step 3: Accept the agreement for installation.




4. Step 4: Set installation path.




5. Step 5: Select full installation.




6. Step 6: Select preferred language.




7. Step 7: Select if you need it in Start menu.




8. Step 8: Tick all the additional tasks.




9. Step 9: Select install.



10. Step 10: When connecting with the UART module, select File>New Connection> Serial. Select COM port.



11. Step 11: Go to Setup> Terminal > Select Local echo. This is for printing the inputs provided by you.



12. Step 12: Go to Setup>Serial Port> Set the baud rate as required.

