

OEM-PUMP-02 — Boiler Feed Pump — Operation & Maintenance Manual

Plant: Shakti Petrochem Unit-2 | **Equipment Type:** Boiler Feed Pump | **Asset:** P-204A

Vibration Limits

Normal operating vibration at drive-end (DE) bearing: ≤ 4.5 mm/s RMS.

Alarm threshold: 4.5 mm/s. Trip / immediate inspection: 7.1 mm/s.

Sustained readings above alarm indicate misalignment, bearing wear, or seal distress.

Mechanical Seal

The cartridge mechanical seal must be replaced as a unit; do not re-lap faces in situ.

After any seal replacement, perform laser shaft-alignment and record a post-repair vibration reading.

Seal weepage at the gland indicates face wear; investigate coupling alignment as a root cause.

Bearings & Coupling

Check coupling alignment to 0.05 mm concentricity after maintenance.

Inspect DE/NDE bearing housings for temperature and lubrication at each PM.