

SOP-15 — Hot Work Permit

Plant: Shakti Petrochem Unit-2 | **Applies To:** All | **Revision:** Rev 3 | **Last Reviewed:** 2025-05-11

Procedure Steps

1. Obtain a hot-work permit and confirm a valid gas test in the work area.
2. Provide fire watch during and 30 minutes after hot work.