

HydroWorx – Taylor Test Kit Troubleshooting Guide

TAYLOR TEST KIT – COLOR TROUBLESHOOTING GUIDE

1. Total Alkalinity (TA) - Blue instead of green: High chlorine. Add extra R-0007. - Purple: Very low TA (<40 ppm).
- Yellowish: Old R-0008. - Stays green: Dilute 50/50.
2. Calcium Hardness (CH) - Red → clear: Metals. Add extra R-0012 first. - Purple: Magnesium interference. -
Never blue: Very high CH or bad indicator. - Fades: Cold water.
3. pH - Purple: High chlorine. Add R-0007. - Yellow: Sample contamination. - Grey/muddy: Dirty block/cloudy
water.
4. Chlorine (DPD) - No pink: High chlorine bleaching; add R-0007. - Dark purple: High chlorine; dilute. - Pink
fades: Combined chlorine. - Orange: Bromine.
5. CYA - No cloud: Wrong ratio. - Slow cloud: Cold water. - Always zero: Clarifier or floc.