

Technical Publication

Diesel Engine
8V 2000 Gx0
Application group 3A

Maintenance Schedule
M050624/02E

DETROIT DIESEL



Printed in Germany

© 2004 Copyright MTU Friedrichshafen GmbH

Diese Veröffentlichung einschließlich aller ihrer Teile ist urheberrechtlich geschützt. Jede Verwertung oder Nutzung bedarf der vorherigen schriftlichen Zustimmung der MTU Friedrichshafen GmbH. Das gilt insbesondere für Vervielfältigung, Verbreitung, Bearbeitung, Übersetzung, Mikroverfilmungen und die Einspeicherung und / oder Verarbeitung in elektronischen Systemen, einschließlich Datenbanken und Online-Diensten.

Das Handbuch ist zur Vermeidung von Störungen oder Schäden beim Betrieb zu beachten und daher vom Betreiber dem jeweiligen Wartungs- und Bedienungspersonal zur Verfügung zu stellen.
Änderungen bleiben vorbehalten.

Printed in Germany

© 2004 Copyright MTU Friedrichshafen GmbH

This Publication is protected by copyright and may not be used in any way whether in whole or in part without the prior written permission of MTU Friedrichshafen GmbH. This restriction also applies to copyright, distribution, translation, microfilming and storage or processing on electronic systems including data bases and online services.

This handbook is provided for use by maintenance and operating personnel in order to avoid malfunctions or damage during operation. Subject to alterations and amendments.

Imprimé en Allemagne

© 2004 Copyright MTU Friedrichshafen GmbH

Tout droit réservé pour cet ouvrage dans son intégralité. Toute utilisation ou exploitation requiert au préalable l'accord écrit de MTU Friedrichshafen GmbH. Ceci s'applique notamment à la reproduction, la diffusion, la modification, la traduction, l'archivage sur microfiches, la mémorisation et / ou le traitement sur des systèmes électroniques, y compris les bases de données et les services en ligne.

Le manuel devra être observé en vue d'éviter des incidents ou des endommagements pendant le service. Aussi recommandons-nous à l'exploitant de le mettre à la disposition du personnel chargé de l'entretien et de la conduite.

Modifications réservées.

Impreso en Alemania

© 2004 Copyright MTU Friedrichshafen GmbH

Esta publicación se encuentra protegida, en toda su extensión, por los derechos de autor. Cualquier utilización de la misma, así como su reproducción, difusión, transformación, traducción, microfilmación, grabación y/o procesamiento en sistemas electrónicos, entre los que se incluyen bancos de datos y servicios en línea, precisa de la autorización previa de MTU Friedrichshafen GmbH.

El manual debe tenerse presente para evitar fallos o daños durante el servicio, y, por dicho motivo, el usuario debe ponerlo a disposición del personal de mantenimiento y de servicio.

Nos reservamos el derecho de introducir modificaciones.

Stampato in Germania

© 2004 Copyright MTU Friedrichshafen GmbH

Questa pubblicazione è protetta dal diritto d'autore in tutte le sue parti. Ciascun impiego o utilizzo, con particolare riguardo alla riproduzione, alla diffusione, alla modifica, alla traduzione, all'archiviazione in microfilm e alla memorizzazione o all'elaborazione in sistemi elettronici, comprese banche dati e servizi on line, deve essere espressamente autorizzato per iscritto dalla MTU Friedrichshafen GmbH.

Il manuale va consultato per evitare anomalie o guasti durante il servizio, per cui va messo a disposizione dall'utente al personale addetto alla manutenzione e alla condotta.

Con riserva di modifiche.

Impresso na Alemanha

© 2004 Copyright MTU Friedrichshafen GmbH

A presente publicação, inclusive todas as suas partes, está protegida pelo direito autoral. Qualquer aproveitamento ou uso exige a autorização prévia e por escrito da MTU Friedrichshafen GmbH. Isto diz respeito em particular à reprodução, divulgação, tratamento, tradução, microfilmagem, e a memorização e/ou processamento em sistemas eletrônicos, inclusive bancos de dados e serviços on-line.

Para evitar falhas ou danos durante a operação, os dizeres do manual devem ser respeitados. Quem explora o equipamento economicamente consequentemente deve colocá-lo à disposição do respectivo pessoal da conservação, e à disposição dos operadores. Salvo alterações.

1.1 Preface

General

Low operating and maintenance costs as well as operational reliability and availability depend on maintenance and servicing being carried out in compliance with our specifications and instructions. The overall system, of which the engine is an integral part, must be maintained in such a way as to ensure trouble-free operation. For this purpose always:

- ensure that sufficient fuel of specified quality is available
- combustion air is dry and clean

Preventive maintenance instructions:

- Keep all machinery and plant in a clean and serviceable condition at all times to facilitate early detection of any leaks and prevent subsequent damage.
- Protect rubber and synthetic components from oil and fuel, never treat with organic detergents. Wipe with a dry cloth only.
- Always replace all seals and gaskets.

Our Service partner will always be available should assistance be required.

MTU maintenance concept

The maintenance system for MTU products is a preventive maintenance concept. Preventive maintenance facilitates advance planning and ensures a high degree of equipment availability.

The maintenance schedule is based on the load profile specified below. The time intervals at which the maintenance work is to be carried out, and the relevant checks and tasks involved, are average results based on operational experience and therefore represent guidelines only. Specific operating conditions may require modifications to the Maintenance Schedule. Exchange parts (reliabilt®) are available for components to be replaced.

Notes

The maintenance task matrix covers all tasks up to a major overhaul. After a major overhaul, the maintenance tasks must continue to be performed in accordance with the specified schedule.

The task number quoted in the task list also appears on the spare parts tag and serves as a cross-reference to the parts required.

The specification of fluids and lubricants, guidelines for maintenance and change intervals as well as a list of approved fluids and lubricants are provided in the MTU Fluids and Lubricants Specification A001061 and the component manufacturers' fluids and lubricants specifications. Use only fluids and lubricants which comply with the MTU Fluids and Lubricants Specification / are approved by the relevant component manufacturer.

The user/customer must perform the following additional maintenance tasks:

- Fuel prefilter:
Maintenance depends on fuel quality (purity). The filter elements of the fuel prefilter must be replaced every 2 years at the latest.
- Battery:
Maintenance depends on load and ambient conditions of the batteries. The specifications of the battery manufacturer are binding.

Out-of-service periods

If the engine is to remain out of service for more than 1 month, carry out engine preservation procedures according to the Fluids and Lubricants Specification, MTU Publication No. A001061.

Application group

3A Continuous operation, unrestricted, load factor: 100%

Load profile

Load-profile table

Load factor

Corresponding operating time

1.2 Maintenance schedule matrix

0-5.250 Operating hours

Item	Limit, years	Operating hours [h]																
		Daily	250	500	750	1.000	1.250	1.500	1.750	2.000	2.250	2.500	2.750	3.000	3.250	3.500	3.750	4.000
Engine operation	-	X																
Engine oil filters	2																	
Crankcase ventilation	-		X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
Crankcase ventilation	-			X		X		X		X		X		X		X		X
Valve gear	-			X		X		X		X		X		X		X		X
Fuel filter	2			X		X		X		X		X		X		X		X
Engine coolant cooler	-					X				X				X				X
Belt drive	2													X				
Air filters	3													X				
Fuel injectors	-																X	
Combustion chambers	4																X	
Fuel injection pumps	-																	
Component maintenance	-																	
Cylinder heads	-																	
Fuel pressure maintaining valve	18																	
Extended component maintenance	18																	

5.500-10.750 Operating hours

Item	Limit, years	Operating hours [h]																							
		5.500	5.750	6.000	6.250	6.500	6.750	7.000	7.250	7.500	7.750	8.000	8.250	8.500	8.750	9.000	9.250	9.500	9.750	10.000	10.250	10.500	10.750		
Engine operation	-																								
Engine oil filters	2																								
Crankcase ventilation	-	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	
Crankcase ventilation	-	X		X		X		X		X		X		X		X		X		X		X			
Valve gear	-	X		X		X		X		X		X		X		X		X		X		X			
Fuel filter	2	X		X		X		X		X		X		X		X		X		X		X			
Engine coolant cooler	-			X				X				X				X				X					
Belt drive	2			X												X									
Air filters	3			X												X									
Fuel injectors	-											X													
Combustion chambers	4											X													
Fuel injection pumps	-											X													
Component maintenance	-																								
Cylinder heads	-																								
Fuel pressure maintaining valve	18																								
Extended component maintenance	18																								