

Maintenance Schedule

Gas Engine

20V4000S24N

Application group 4A

MS50288/00E



Power. Passion. Partnership.

Engine model	kW/cyl.	Application group
20V4000S24N	130 kW/cyl.	4A, continuous operation, unrestricted

Table 1: Applicability

Table of contents

1	Maintenance Schedule		
1.1	Preface	4	
1.2	Additional notes on the maintenance of gas engines	5	
1.3	Checks by the operator		6
1.4	Noncyclical maintenance tasks		8
1.5	Maintenance Schedule Matrix 63000 HRS		9
1.6	Cyclical maintenance tasks 63000 HRS		13

DocID: 0000000000 - 000

1 Maintenance Schedule

1.1 Preface

In the case of emission-certified products, nonobservance of the maintenance instructions can result in violation of the statutory specifications. Modification or removal of mechanical or electronic components or the installation of additional mechanical or electronic components as well as the execution of calibration processes that might affect the emission characteristics of the engine are prohibited by emission regulations. Components relevant to emissions may only be serviced, replaced or repaired if components approved by MTU are used. Components relevant to emissions include e.g. control units, data records, sensors, injectors, exhaust flaps and all components of exhaust after-treatment systems.

The maintenance system for MTU products is based on a preventive maintenance concept. Preventive maintenance facilitates advance operational planning and ensures a high level of equipment availability. The maintenance intervals as well as the required scopes of maintenance tasks are based on operational experience and therefore to be considered as recommendations. Additional maintenance work and/or changes to the maintenance intervals may be required in the case of difficult operational and ambient conditions.

Adherence to the specified maintenance intervals is essential to maintain product safety.

The intervals according to which the maintenance tasks have to be carried out are specified as operating hours and time limits. Whichever value is reached first shall apply.

The individual maintenance intervals are assigned to the qualification levels QL1 to QL4.

QL1: Operational monitoring and maintenance work which does not require disassembly of the product.

QL2: Exchange of components and parts (corrective only, not part of the maintenance schedule).

QL3: Maintenance work which requires partial disassembly of the product.

QL4: Maintenance work which requires complete disassembly of the product.

Additional notes on maintenance and preservation:

For the change intervals for fluids and lubricants and for information on preservation, refer to the relevant specifications of the component manufacturers and the MTU Fluids and Lubricants Specifications. The latest version for drive systems is available at: <http://www.mtu-online.com>, for power generation at: <http://www.mtuonsiteenergy.com>.

Components which are not listed in this maintenance schedule must be serviced in accordance with Manufacturer's Instructions.

This maintenance schedule does not apply to engines with an EPA/CARB emissions certificate.

1.2 Additional notes on the maintenance of gas engines

General information

The maintenance schedule matrix normally finishes with extended component maintenance or with engine overhaul. Following this, maintenance work is to be continued at the intervals indicated.

The numbers stated in the task list serve as a reference for the scope of parts required.



Repairs tasks on the gas engine, for which the gas-conducting area is opened, and leak or stress tests must only be carried out by specialized companies. As a rule these are companies that are approved for the gas industry with qualified personnel who have been trained for technical gas applications.



Specifications for fluids and lubricants, guideline values for their maintenance and change intervals and lists of recommended fluids and lubricants are contained in the MTU Fluids and Lubricants Specifications and in the fluids and lubricants specifications produced by the component manufacturers. They are therefore not included in the maintenance schedule (exception: deviations from the Fluids and Lubricants Specifications). All fluids and lubricants used must meet MTU specifications and be approved by the relevant component manufacturer.

Among other items, the operator/customer must carry out the following additional maintenance work:

- Protect components made of rubber or synthetic material from oil. Never treat them with organic detergents. Wipe with a dry cloth only.
- Gas filter:
The maintenance interval depends on gaseous fuel quality (purity). Fuel filters upstream of the engine must be regularly cleaned and renewed if necessary.
- Battery:
Battery maintenance depends on duty and ambient conditions. The specifications of the battery manufacturer apply.

Items listed in this maintenance schedule but which are not included in the MTU scope of supply may be disregarded.

Maintenance of non-MTU components

Please refer to the Operating Instructions provided by the relevant component manufacturer for the intervals for these maintenance tasks.

Maintenance tasks

The respective maintenance tasks to be carried out are based on operating hours (see the following pages).

1.3 Checks by the operator



Always observe the safety instructions.



Non-observance of these instructions may lead to damage to the system!



When the object of delivery is used abroad or in other special regions, MTU Friedrichshafen GmbH is not responsible for observance of the statutory and other specifications / standards applicable at the place of use.

Recommended daily checks – System

- Check exhaust gas piping for condensate leaks (visual inspection)
- Check condensate collecting tank downstream of condensate drain (if fitted)
- Carry out visual inspection of engine and plant for leaks / damage (bellows, hoses etc.)
- Check gas supply / gas system for damage (visual inspection)
- Check fleece of air filter for contamination, replace if necessary
- Oil temperature
- Oil pressure
- Leaks
- Oil level
- Noise, vibrations

Recommended daily checks – Control system

The following measured values and functions are monitored by the control system to protect the plant. These messages can also be called up via remote access (option) and can be monitored by the customer in the display.

- Power
- Lube oil level
- Lube oil pressure
- Coolant temperature
- Coolant pressure
- Battery voltage
- Smooth running of engine
- Exhaust gas temperature
- Engine coolant supply and return temperature (option)
- Oil bleed system function (option)

Recommended weekly checks

- Check air filter box for cracks
- Check air filter box for leak-tight seating on engine
- Check air filter for leak-tight seating on air filter box
- Lube oil consumption or content of fresh oil tank
- Engine room temperature
- Check of operating hours
- Check of number of starts
- General visual inspection of module / engine-generator set

Additional checks

The operator's gas installation (upstream of twin solenoid valve) must be inspected for leaks at the following intervals:

- Every year for engines with turbocharger

The following checks are to be carried out at appropriate intervals, depending on the degree of contamination:

- Check room air fan and fresh air filter for contamination
- Check filter or air-conditioning unit for control cabinet for contamination
- Check recoler for contamination

Electrical systems

Electrical systems and operating equipment must be checked prior to initial commissioning, after repairs, prior to re-commissioning and at regular intervals. The intervals are to be so arranged that defects, which are to be expected, are detected at an early stage.

Here, among others, the following requirements apply:

- Accident prevention regulations BGV A3 "Electrical Systems and Operating Equipment"
- Technical rules for operational safety TRBS 2131 "Electrical Hazards"
- Industrial Safety Directive (BetrSichV)
- DIN VDE 0701/0702 Repairs, modifications and testing of electrical equipment/repeat tests on electrical units
- DIN EN 60204-1 Safety of machinery - Electrical equipment of machines

The operating company has the responsibility to see that these tests are carried out correctly. Electrical systems and fixed electrical operating equipment must be tested at appropriate intervals by a qualified electrician for their correct condition. The test is to include the following:

- Visual inspection and testing of protective equipment
- Testing of protective conductor resistance, insulation resistance, leakage current replacement, protective conductor current and differential current
- Carrying out fault diagnoses
- Preparation of test reports and inspection stickers

The industrial safety regulations, the technical rules for operational safety and the BGV A3 are fundamental with regard to adherence to the protective measures for "Electrical Systems and Operating Equipment". The operating company is accordingly obligated to care for the safety of electrical systems and operating equipment.

	Designation
DIN	Deutsches Institut für Normung (Federal German Standards Institute)
EN	Europäische Normung (European Standards)
ISO	International Standards Organization
VDE	Verband der Elektrotechnik, Elektronik und Informationstechnik (Association for electrical engineering, electronics and information technology)
BGV	Berufsgenossenschaftliche Vorschriften (Trade association regulations)
TRBS	Technische Regeln für Betriebssicherheit (Technical rules for operational safety)

Table 2: Designations for standards and regulations



These regulations are contained in the manufacturers' instructions, legal requirements and technical guidelines valid in the individual countries. Since there can be major differences from country to country, it is not possible to provide a universally applicable statement on the rules to be observed within the framework of this maintenance schedule.

The user of the product mentioned herein is obligated to inform him-/herself about the provisions applicable in his/her country. MTU Friedrichshafen GmbH accepts no liability whatsoever for improper or illegal use of the electrical system, which it has approved.

1.4 Noncyclical maintenance tasks

No.	Qualification	Task	Maintenance tasks	Reference task	Offset	Value	Unit	Option
0010	QL1	WM00781	Clean gas filter. Initial cleaning after 100 operating hours		0	100	HRS	
0020	QL1	WM00094	Check valve clearance, adjust if necessary. ATTENTION! First adjustment after 1,000 operating hours on a new engine and after 1,000 operating hours following each cylinder head overhaul		0	1000	HRS	
Reference task: Name of the maintenance task the offset refers to Offset: Interval of a maintenance task which depends on another interval Value: Fixed value for binding execution of a maintenance task								

1.5 Maintenance Schedule Matrix 63000 HRS

0 to 27000 Operating hours

Task	Limit	Operating hours [HRS]																													
		Daily	100	1000	2000	3000	4000	5000	6000	7000	8000	9000	10000	10500	11000	12000	13000	14000	15000	16000	17000	18000	19000	20000	21000	22000	23000	24000	25000	26000	27000
WM00428	1 WK																														
WM00296	1 MON																														
WM00286	-	X																													
WM00427	-	X																													
WM00426	-	X																													
WM00779	18 YR				X		X		X		X			X		X		X		X		X		X		X		X		X	
WM00511	1 YR					X		X		X				X		X		X		X		X		X		X		X		X	
WM00050	1 YR					X		X		X				X		X		X		X		X		X		X		X		X	
WM00136	1 YR					X		X		X				X		X		X		X		X		X		X		X		X	
WM00509	2 YR					X		X		X				X		X		X		X		X		X		X		X		X	
WM00067	2 YR					X		X		X				X		X		X		X		X		X		X		X		X	
WM00510	3 YR					X		X		X				X		X		X		X		X		X		X		X		X	
WM00076	3 YR					X		X		X				X		X		X		X		X		X		X		X		X	
WM00126	6 MON					X		X		X				X		X		X		X		X		X		X		X		X	
WM00780	18 YR					X		X		X				X		X		X		X		X		X		X		X		X	
WM00434	18 YR					X		X		X				X		X		X		X		X		X		X		X		X	
WM00094	18 YR			X		X		X		X				X		X		X		X		X		X		X		X		X	
WM00150	18 YR					X		X		X				X		X		X		X		X		X		X		X		X	
WM00433	3 YR							X						X				X				X				X					
WM00098	18 YR									X										X											X
WM00573	6 YR											X													X						
WM00447	6 YR																								X						
WM00431	18 YR																								X						
WM00792	6 YR																														
WM00442	18 YR											X													X						
WM00783	4 YR																								X						
WM00108	18 YR																								X						
WM00430	18 YR																								X						
WM00444	18 YR																								X						
WM00099	18 YR																								X						
WM00093	18 YR																								X						
WM00082	18 YR																								X						
WM00443	18 YR																								X						
WM00782	18 YR																								X						
WM00448	18 YR																								X						
WM00005	18 YR																								X						
WM00439	18 YR																														
WM00097	18 YR																														
WM00001	18 YR																														
WM00002	18 YR																														
WM00111	18 YR																														

WK = Weeks

MON = Months

YR = Years

HRS = Hours

Task	Limit	Operating hours [HRS]																													
		Daily	100	1000	2000	3000	4000	5000	6000	7000	8000	9000	10000	10500	11000	12000	13000	14000	15000	16000	17000	18000	19000	20000	21000	22000	23000	24000	25000	26000	27000
WM00104	18 YR																														
WM00103	18 YR																														
WM00095	18 YR																														
WM00092	18 YR																														
WM00070	18 YR																														
WM00127	18 YR																														
WM00137	18 YR																														
WM00781	1 YR		X	X	X	X	X	X	X	X	X	X		X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
WM00464	2 YR					X			X			X			X			X			X			X			X				X
WM00499	1 YR								X						X					X							X				
WM00383	3 YR											X									X										X
WK = Weeks																															
MON = Months																															
YR = Years																															
HRS = Hours																															

28000 to 55000 Operating hours

Task	Limit	Operating hours [HRS]																														
		28000	29000	30000	31000	31500	32000	33000	34000	35000	36000	37000	38000	39000	40000	41000	42000	43000	44000	45000	46000	47000	48000	49000	50000	51000	52000	52500	53000	54000	55000	
WM00428	1 WK																															
WM00296	1 MON																															
WM00286	-																															
WM00427	-																															
WM00426	-																															
WM00779	18 YR	X		X		X		X		X		X		X		X		X		X		X		X		X		X		X		
WM00511	1 YR			X			X			X			X			X			X			X			X				X			
WM00050	1 YR			X			X			X			X			X			X			X			X				X			
WM00136	1 YR			X			X			X			X			X			X			X			X				X			
WM00509	2 YR			X			X			X			X			X			X			X			X				X			
WM00067	2 YR			X			X			X			X			X			X			X			X				X			
WM00510	3 YR			X			X			X			X			X			X			X			X				X			
WM00076	3 YR			X			X			X			X			X			X			X			X				X			
WM00126	6 MON			X			X			X			X			X			X			X			X				X			
WM00780	18 YR			X			X			X			X			X			X			X			X				X			
WM00434	18 YR			X			X			X			X			X			X			X			X				X			
WM00094	18 YR			X			X			X			X			X			X			X			X				X			
WM00150	18 YR			X			X			X			X			X			X			X			X				X			
WM00433	3 YR			X						X					X						X								X			
WM00098	18 YR									X									X											X		
WM00573	6 YR					X									X													X				
WM00447	6 YR														X																	
WM00431	18 YR														X																	
WM00792	6 YR					X																										
WM00442	18 YR					X									X													X				
WK = Weeks																																
MON = Months																																
YR = Years																																
HRS = Hours																																

TIM-ID: 0000000000 - 000