

FG	FG DESIGNATION
004	LABELS AND MISCELLANEOUS MATERIALS
011	CRANKCASE
014	OIL PAN
015	ENGINE MOUNTING
016	END HOUSING, MAIN PTO END AND AUX PTO END
018	CRANKCASE BREATHER
024	GEARCASE, AUX PTO END
031	CRANKSHAFT
032	CRANKSHAFT SUPPORT BEARINGS, MAIN PTO END
035	CRANKSHAFT, PTO, AUX PTO END
036	CRANKSHAFT TRANSPORTATION LOCKING DEVICE
037	PISTON
038	CONROD
041	CYLINDER HEAD
051	CAMSHAFT
055	VALVE DRIVE
073	INJECTION PUMP / HP PUMP
075	FUEL INJECTOR
077	HP FUEL LINE / HP LINE
081	FUEL PIPEWORK BEFORE DELIVERY PUMP
083	FUEL FILTER
101	TURBOCHARGER (H.P)
111	CHARGE AIR COOLING, IF REQUIRED, LEFT SIDE
121	AIR FILTER
123	AIR SYSTEM
124	AIR SUPPLY TO CYLINDERS
126	AIR TRANSFER, LEFT - RIGHT SIDE, MAIN PTO END
128	CONTROL BLOCK FOR AIR AND EXHAUST FLOW CONTROL FLAPS
142	CONSTANT-PRESSURE EXHAUST MANIFOLD
143	CARRIER HOUSING
144	EXHAUST FLOW CONTROL FLAP WITH CONTROLS
146	EXHAUST SYSTEM AFTER ENGINE
172	ELECTRIC STARTING
173	AIR STARTER
181	LUBE OIL PUMP AND DRIVE
183	OIL FILTRATION/COOLING
185	TURBOCHARGER OIL SUPPLY
202	HIGH-TEMPERATURE CIRCUIT
203	LOW-TEMPERATURE CIRCUIT
204	HEAT EXCHANGER PLATES
206	COOLANT PIPEWORK WITH THERMOSTAT
207	RAW WATER PUMP WITH CONNECTIONS
208	COOLANT EXPANSION TANK
231	ENGINE MOUNTING
251	STEEL-SPRING COUPLING
255	BENDING-RESILIENT COUPLING
301	GENERAL ACCESSORIES

TYPE: 16V4000M90
SERIAL NO.: 527101900

527101900

FG/FGS:
BOM NO.: 16V4000M90

FG FG DESIGNATION

365 EXHAUST SYSTEM
507 GENERAL WIRING, ENGINE/GEARBOX/PLANT
508 ENGINE GOVERNOR (ELECTRONIC) CONTROL SYSTEM
511 ALARM SYSTEM
515 PRESSURE/TEMPERATURE MONITORING SYSTEMS (EXCL. EXHAUST GAS)
517 EMERGENCY INSTRUMENTATION (CONTROL STAND)




PLATE ENGLISH
000.00897

00400027a




PLATE
010.00055

E0043001a0





PLATE
010.00056

E0043002a0



PLATE
010.00057


E0043003a0



00400027a

POS.	PART NO.	DESIGNATION	QTY.	UNITS	MEASUREMENT	STANDARD
10	700425000158	"PLATE"	1	PC	04.13	MMN425

10



E0043001a0

POS.	PART NO.	DESIGNATION	QTY.	UNITS	MEASUREMENT	STANDARD
10	700425000039	"PLATE"	1	PC	36	MMN425

10

Achtung! Motorenöl nur bis zur oberen Markierung am Ölmeßstab einfüllen

ATTENTION! Fill engine oil only up to the upper mark on dipstick

ATTENTION! Ne remplir de l'huile-moteur que jusqu'au repère supérieur sur la jauge d'huile

Atención! Rellenar aceite motor sólo hasta la marcación superior de la varilla indicadora del nivel de aceite

Atenção! Encher óleo de motor só até á marcação superior da vareta medidora do nível de óleo

Attenzione! Introdurre olio motore solo fino alla graduazione superiore dell'asta livello olio


Dikkat! Motor yáginı, yág seviyesi ölçme çubugunun sadece üst isaretine kadar doldurunuz

61 MMN 425

E0043002a0

POS.	PART NO.	DESIGNATION	QTY.	UNITS	MEASUREMENT	STANDARD
10	700425000115	"PLATE"	1	PC	61	MMN425

10




E0043003a0

POS.	PART NO.	DESIGNATION	QTY.	UNITS	MEASUREMENT	STANDARD
10	700425000052	"PLATE"	1	PC	36.1	MMN425

GROUP NUMBER (FG)


GROUP NAME

BOM NO.




CRANKCASE
010.00476

01100744s




INSPECT PORT COVER
010.00021

E01130480t



INSPECT PORT COVER ABS ACCEPTANCE
010.00223

E0113042b0



OIL FILLER NECK LEFT
010.00002

E0113046b0

TYPE: 16V4000M90
SERIAL NO.: 527101900


527101900

FG/FGS: 011
BOM NO.:

GROUP NUMBER (FG)

GROUP NAME

BOM NO.




OIL DIPSTICK LEFT
010.00022

TYPE: 16V4000M90
SERIAL NO.: 527101900

CRANKCASE

FG/FGS: 011 05
BOM NO.: 010.00476




01100744a

TYPE: 16V4000M90
SERIAL NO.: 527101900

CRANKCASE

FG/FGS: 011 05
BOM NO.: 010.00476



Business Portal Online Print 18-01-2017

01300318a