

EQUIPMENT TYPE

PRODUCT TYPE
SERIAL NUMBER

Engine

16V4000G63
527109370

Automation

AUTOMATION
1201059000_000005

EQUI TYPE: Engine

PRODUCT TYPE: 16V4000G63
DIESEL ENGINE

SERIAL NUMBER: 527109370
FG/FGS:
BOM-No.:

DESCRIPTION
SYSTEM

FG FG DESIGNATION**004 LABELS AND AUXILIARY MATERIALS****011 CRANKCASE****014 OIL PAN****015 ENGINE MOUNTING****016 END HOUSING, DRIVING END AND FREE END****018 CRANKCASE BREATHER****024 GEARCASE, AUX PTO END****031 CRANKSHAFT WITH BEARINGS****032 CRANKSHAFT, PTO ON DRIVING END****035 CRANKSHAFT, PTO ON AUX PTO END****036 TRANSPORT LOCK/LOCK FOR CRANKSHAFT****037 PISTON****038 CONNECTING ROD****041 CYLINDER HEAD****051 CAMSHAFT****055 VALVE DRIVE****073 INJECTION PUMP / HP PUMP****075 FUEL INJECTOR****077 INJECTION LINE / HP FUEL LINE****081 FUEL PIPEWORK BEFORE DELIVERY PUMP****082 FUEL PIPEWORK FROM DELIVERY PUMP TO FILTER****083 FUEL FILTER****086 LEAK-OFF FUEL LINE / FUEL RETURN****100 TURBOCHARGING (EXHAUST TURBOCHARGER / COMPRESSOR)****110 CHARGE-AIR COOLING****121 AIR FILTER****124 AIR SUPPLY TO CYLINDERS****125 AIR ROUTING BETWEEN TURBOCHARGER AND CHARGE-AIR COOLER****141 EXHAUST SYSTEM AFTER CYLINDER HEAD****142 CONSTANT-PRESSURE EXHAUST MANIFOLD****146 EXHAUST DUCTING AFTER ENGINE (TO END OF EXH. AFTERTREATMENT)****172 ELECTRIC STARTING****181 LUBE OIL PUMP AND DRIVE****183 OIL FILTRATION/COOLING****184 CRANKCASE-INTERNAL OIL SUPPLY****185 TURBOCHARGER OIL SUPPLY****202 COOLANT CIRCUIT, GENERAL, HT CIRCUIT****203 LOW-TEMPERATURE CIRCUIT****206 COOLANT PIPEWORK WITH THERMOSTAT****207 RAW WATER PUMP WITH CONNECTIONS****213 GENERATOR****231 ENGINE MOUNTING****369 AIR SUPPLY SYSTEM**

GROUP NUMBER (FG)

GROUP NAME


BOM-No.

PLATE

000.00899



00400053a



NAMEPLATE


X00027331



00400086a

NON-EPA LABEL


XS524000.00019



00400106a

PLACARD POS. EXPL: HAZARD

XS524000.00104



00400107a

EQUI TYPE: Engine

PRODUCT TYPE: 16V4000G63
LABELS AND AUXILIARY MATERIALS

SERIAL NUMBER: 527109370

FG/FGS: 004

BOM-No.:


GROUP NUMBER (FG)

GROUP NAME


BOM-No.

PLACARD

XSD01000.00004




00403146



00400053a

POS.	PART NO.	DESIGNATION	QTY.	UNITS	WEIGHT	MEASUREMENT	STANDARD
10	700425000155	PLATE	1	PC	1 G	70	MMN425

100




200



00400086a

POS.	PART NO.	DESIGNATION	QTY.	UNITS	WEIGHT	FN	MEASUREMENT	STANDARD
100	700425000169	PLATE	1	PC	3,400 G	EM	04.14	MMN425
200	700425000170	PLATE	1	PC	2,800 G	EM	04.15	MMN425


100



00400106a

POS.	PART NO.	DESIGNATION	QTY.	UNITS	FN	MEASUREMENT	STANDARD
100	700425000182	EMI-LABEL NON-EPA	1	PC	EM	66.8	MMN425

150



00400161

POS.	PART NO.	DESIGNATION	QTY.	UNITS	WEIGHT	MEASUREMENT	STANDARD
150	700425000039	PLATE	4	PC	3,100 G	36	MMN425

100



Achtung! Motor nicht ohne Schutzblech starten oder betreiben.
Vor dem Abbau des Schutzbleches muss die
Energieversorgung der Anlasser unterbrochen werden.

Warning! Do not start or run engine without guard plate.
Before demounting guard plate the power supply of the
starters have to be disconnected.

00400146

POS.	PART NO.	DESIGNATION	QTY.	UNITS	WEIGHT
100	XD0100400001	PLACARD	2	PC	10 G