




E0005741a0

FG	FG DESIGNATION
000	MAJOR DOCUMENTATION
010	CRANKCASE AND ATTACHMENTS
020	GEAR TRAIN, BELT DRIVE
030	RUNNING GEAR
040	CYLINDER HEAD
050	VALVE GEAR
070	FUEL SYSTEM (HIGH PRESSURE)
080	L.P. FUEL SYSTEM; (ALTO GAS ENGINES)
100	EXHAUST TURBOCHARGER
110	CHARGE-AIR COOLING
120	AIR SYSTEM / AIR DUCTING
140	EXHAUST SYSTEM
170	STARTING EQUIPMENT
180	LUBRICATING OIL SYSTEM
200	COOLANT SYSTEM
210	ELEKTRIC POWER SUPPLY, ENGINE-SIDE
230	MOUNTING SYSTEM
250	MAIN AND AUXILIARY PTO SYSTEMS (COUPLINGS)
300	ACCESSORIES
340	DRIVE, ELECTRIC POWER AND SAFETY SYSTEMS
360	AUXILIARY SYSTEMS - ADDITIONAL EQUIPMENT

FG FG DESIGNATION

500 **MONITORING AND CONTROL SYSTEM, GENERAL ELECTRICAL**


510 **MONITORING SYSTEMS**

520 **MEASURING, CONTROL AND SUPPLY SYSTEMS (OPERATIONAL VOLTAGE)**


530 **SIMULATION, TRAINING, TEST AND MAINTENANCE SYSTEMS**

FG FG DESIGNATION


004 LABELS AND MISCELLANEOUS MATERIALS




E0043000a0




E0043001a0



E0043003a0



E0043002a0



00400001b

1



Dieselmotor

MTU Motoren- und Turbinen-Union
Friedrichshafen GmbH

Made in Germany


Typ		
Motor Nr.		
Baujahr		
Leistung		kW
Drehzahl		1/min
Masse		kg

04 MMN 425

E0043000a0

POS.	PART NO.	DESIGNATION	QTY.	UNITS	FN	MEASUREMENT	STANDARD	DES. ADDITION
01	700425000005	INSTRUCTION PLATE	1	EA		04		

1



E0043001a0

POS.	PART NO.	DESIGNATION	QTY.	UNITS	FN	MEASUREMENT	STANDARD	DES. ADDITION
01	700425000039	INSTRUCTION PLATE	1	EA		36		

1

Achtung

Dieser Anlage ist ein ausführliches Bedienungshandbuch beigelegt, welches wichtige Anweisungen für Betrieb und sichere Handhabung enthält. Vor der Inbetriebnahme ist dieses Handbuch sorgfältig zu lesen. Die Nichtbeachtung der Anweisungen kann zu schweren Schäden an der Anlage oder Verletzungen des Betriebspersonals führen.

Warning

This unit is shipped with a detailed operator's manual containing important information on equipment operation and safe use. Carefully read the manual prior to starting, as failure to adhere to the instructions may cause serious equipment damage or injury to personnel.

Ersatz-Handbücher können angefordert werden bei:
For replacement manuals please contact:

MTU Motoren- und Turbinen-Union Friedrichshafen GmbH,
Postfach/P.O. Box, D-7990 Friedrichshafen/West Germany

36.1 MAN 428

E0043003a0

POS.	PART NO.	DESIGNATION	QTY.	UNITS	FN	MEASUREMENT	STANDARD	DES. ADDITION
01	700425000052	INSTRUCTION PLATE	1	EA		36.1		

1

Achtung! Motorenöl nur bis zur oberen Markierung am Ölmeßstab einfüllen

ATTENTION! Fill engine oil only up to the upper mark on dipstick

ATTENTION! Ne remplir de l'huile-moteur que jusqu'au repère supérieur sur la jauge d'huile

Atención! Rellenar aceite motor sólo hasta la marcación superior de la varilla indicadora del nivel de aceite

Atenção! Encher óleo de motor só até a marcação superior da vareta medidora do nível de óleo

Attenzione! Introdurre olio motore solo fino alla graduazione superiore dell'asta livello olio

Dikkat! Motor yágini, yág seviyesi ölçme çubugunun sadece üst isaretine kadar doldurunuz

61 MMN 425

E0043002a0

POS.	PART NO.	DESIGNATION	QTY.	UNITS	FN	MEASUREMENT	STANDARD	DES. ADDITION
01	700425000115	INSTRUCTION PLATE	1	EA		61		

1



00400001b

POS.	PART NO.	DESIGNATION	QTY.	UNITS	FN	MEASUREMENT	STANDARD	DES. ADDITION
01	700425000128	INSTRUCTION PLATE	1	EA		66		

FG	FG DESIGNATION
011	CRANKCASE
013	CYLINDER LINER
014	OIL PAN
015	ENGINE MOUNTING
016	END HOUSING, MAIN PTO END AND AUX PTO END
018	CRANKCASE BREATHER