

Aenderungsbeschreibung/Description of Revision war kZ				Kommt vor/Frequency	
Buchst./Rev.Ltr. -12		Aenderungs-Nr./Revision Notice No. PR047868		Bearbeitungsstatus/Lifecycle Released	
Changes from Var1 Ed 01.00 to Var1 Ed 01.02					
Corrections:					
Reg 1205/1206 and 2634/2636 from HI to LO (P-FuelPrefilter)					
SCR alarms/measuring points renamed					
New measuring points added:					
Reg 220 added (T-ExhaustSCROutlet2)					
Reg 295 added (MMS Errorcodes)					
New limits added:					
Reg 1221 Item added (LM AL RA Tank Level Empty)					
Reg 1100 added (LM LOLO P-Raw Water)					
New alarms added:					
AL Permanent Injection Rail2 AL MMS Combined Red AL MMS Combined Yel AL RA Tank Level Empty SD Lube Oil Level Switch LOLO P-Raw Water AL Gas Inclusion SD P-Coolant Intercooler LO P-Coolant Intercooler LOLO P-Coolant Intercooler SD P-Intake Air After FilterA LO P-Intake Air After FilterA LOLO P-Intake AirAfterFilterA SD P-Intake Air After FilterB LO P-Intake Air After FilterB LOLO P-Intake AirAfterFilterB SD T-Coolant Intercooler HI T-Coolant Intercooler HIHI T-Coolant Intercooler AL Inj. Drift Limit 1 Cyl.A1 AL Inj. Drift Limit 1 Cyl.A2 AL Inj. Drift Limit 1 Cyl.A3 AL Inj. Drift Limit 1 Cyl.A4 AL Inj. Drift Limit 1 Cyl.A5 AL Inj. Drift Limit 1 Cyl.A6 AL Inj. Drift Limit 1 Cyl.A7 AL Inj. Drift Limit 1 Cyl.A8 AL Inj. Drift Limit 1 Cyl.A9 AL Inj. Drift Limit 1 Cyl.A10 AL Inj. Drift Limit 2 Cyl.A1 AL Inj. Drift Limit 2 Cyl.A2 AL Inj. Drift Limit 2 Cyl.A3 AL Inj. Drift Limit 2 Cyl.A4 AL Inj. Drift Limit 2 Cyl.A5 AL Inj. Drift Limit 2 Cyl.A6 AL Inj. Drift Limit 2 Cyl.A7 AL Inj. Drift Limit 2 Cyl.A8 AL Inj. Drift Limit 2 Cyl.A9 AL Inj. Drift Limit 2 Cyl.A10					
Allgemeintoleranzen/General Tolerances ISO 2768-mK				Masse/Mass kg	
Tolerierung/Tolerancing ISO 8015		Masse/Size ISO 14405		Format/Size A4	
Ausf. u.Lieferung Tech. Characteristics		Oberflaechenangaben nach MTN5033		Werkstoff Material	
Oberflaechenschutz Surface Protection		Allgemeine Fertigungsvorschriften nach MMN332		Halbzeug,Modell Gesenk Semifinished Product Pattern, Die	
Verwendbar f.Type Applicable to Model		GLNG Release 10		Material-Nr./Material No.	
Projekt-/Auftrags-Nr. Project/Order No.		Production Specification per MMN 332		XZ00E52000017	
Ref.-Nr./ Ref. No. Type1 Var01 ED01_00		Emission ID		Benennung/ Title /	
Alle Rechte aus Schutzrechtsanmeldungen vorbehalten. Weitergabe, Vervielfältigung oder sonstige Verwertung ohne Zustimmung nicht gestattet. Zuwiderhandlungen verpflichten zum Schadensersatz. All industrial property rights reserved. Disclosure, reproduction or use for any other purpose is prohibited unless our express permission has been given. Any infringement results in liability to pay damages.		WORD		Datum/Date	
		Erstell. Drawn		2018-09-10 12:21:47	
		Bearb. Change		2019-09-11 09:45:08	
		Norm Std.		2019-09-11 09:45:08	
		Gepr. Checked		2019-09-11 09:45:08	
		Name		Genoline NewGeneration	
		schaeppers		DOKUMENTATION	
		schaeppers		GLNG Fremdschnittstelle Modbus RTU	
		ihmor stef		DOCUMENTATION	
		ihmor stef		GLNG Foreign MCS Modbus RTU	
 MTU Friedrichshafen GmbH		Zeichnungs-Nr./Drawing No.			Blatt/ Sheet
		Beschreibung/Description			von/of
		ZNG00019139			1
		Type1 Var01 ED01_02			26

T-468-0107

Aenderungsbeschreibung/Description of Revision war kZ		Kommt vor/Frequency
Buchst./Rev.Ltr. -12	Aenderungs-Nr./Revision Notice No. PR047868	Bearbeitungsstatus/Lifecycle Released
AL Inj. Drift Limit 1 Cyl.B1 AL Inj. Drift Limit 1 Cyl.B2 AL Inj. Drift Limit 1 Cyl.B3 AL Inj. Drift Limit 1 Cyl.B4 AL Inj. Drift Limit 1 Cyl.B5 AL Inj. Drift Limit 1 Cyl.B6 AL Inj. Drift Limit 1 Cyl.B7 AL Inj. Drift Limit 1 Cyl.B8 AL Inj. Drift Limit 1 Cyl.B9 AL Inj. Drift Limit 1 Cyl.B10 AL Inj. Drift Limit 2 Cyl.B1 AL Inj. Drift Limit 2 Cyl.B2 AL Inj. Drift Limit 2 Cyl.B3 AL Inj. Drift Limit 2 Cyl.B4 AL Inj. Drift Limit 2 Cyl.B5 AL Inj. Drift Limit 2 Cyl.B6 AL Inj. Drift Limit 2 Cyl.B7 AL Inj. Drift Limit 2 Cyl.B8 AL Inj. Drift Limit 2 Cyl.B9 AL Inj. Drift Limit 2 Cyl.B10 HI ETC Idle Speed LO RA Concentration LOLO RA Concentration SD RA Concentration HI RA Concentration HIHI RA Concentration LO RA Quality HI P-Exhaust Diff SCR2 HIHI P-Exhaust Diff SCR2 SD T-Exhaust SCR Outlet2 HI T-Exhaust SCR Outlet2 HIHI T-Exhaust SCR Outlet2 AL PFM Leak Check Failed HI T-Reducing Agent SUDU F1 HI T-Reducing Agent SUDU F2 AL Hydraulics Fault SUDU1 AL Hydraulics Fault SUDU2 AL Hydraulics Fault SUDU3 AL Hydraulics Fault SUDU4 AL Hydraulics Fault SUDU5 AL Hydraulics Fault SUDU6 AL SD-Card Unaccessible SD Eng.Speed Crankshaft SaSy TD Engine Speed Crankshaft AL Coolant Leakage LT SD Coolant Leakage LT AL Oil Refill Tank Empty SD Oil Refill Tank Empty AL Com Lost NOx EGAT Outlet 2 SD NOx EGAT Outlet 2 AL Perm. Injection Detection		
 MTU Friedrichshafen GmbH		Zeichnungs-Nr./Drawing No. ZNG00019139 Blatt/ Sheet 2 von/of 26
Alle Rechte aus Schutzrechtsanmeldungen vorbehalten. Weitergabe, Vervielfältigung oder sonstige Verwertung ohne Zustimmung nicht gestattet. Zuwiderhandlungen verpflichten zum Schadensersatz. All industrial property rights reserved. Disclosure, reproduction or use for any other purpose is prohibited unless our express permission has been given. Any infringement results in liability to pay damages.		

war kZ

Buchst./Rev.Ltr.
-12Aenderungs-Nr./Revision Notice No.
PR047868Bearbeitungsstatus/Lifecycle
Released

MCS Analog Measuring Points

Function Code	03 Holding Register
	16 Write Holding Register
Minimum Cycle Time	200ms
Missing Data:	0x7FFF
Sensor Defect	0x8001
Sensor Defect Combined Registers (32Bit)	0x80000001

Register	Denomination	Min	Max	Unit	Scaling	Read/Write
0	Engine Speed	0	3000	rpm	10	R
1	Engine Speed SaSy	0	3000	rpm	10	R
2	Engine Speed Camshaft	0	3000	rpm	10	R
3	Engine Speed Crankshaft	0	3000	rpm	10	R
4	Idle Speed	0	3000	rpm	10	R
5	Nominal Speed	0	3000	rpm	10	R
6	Feedback Speed Demand	0	3000	rpm	10	R
7	Feedback Speed Demand Eff.	0	3000	rpm	10	R
11	ETC 1 Speed	0	100	krpm	100	R
12	ETC 2 Speed	0	100	krpm	100	R
13	ETC 3 Speed	0	100	krpm	100	R
14	ETC 4 Speed	0	100	krpm	100	R
24	Power Supply EIM/Starter Bat.	0	50	V	100	R
25	ECU Power Supply Voltage	0	35	V	100	R
26	U-SPU Main Power Supply	0	50	V	100	R
27	U-SPU Emerg. Power Supply	0	50	V	100	R
30	P-Lube Oil aft. Filter (ECU)	0	10	bar	100	R
31	P-Lube Oil aft. Filter SaSy	0	10	bar	100	R
32	P-Lube Oil A-Side ETCs	0	120	bar	100	R
33	P-Lube Oil B-Side ETCs	0	120	bar	100	R
34	P-Oil after Level Pump	0	10	bar	100	R
35	P-Lube Oil last bearing	0	10	bar	100	R
36	P-Piston Cooling Oil	0	6	bar	100	R
37	P-Piston Cool.Oil Filter Diff.	0	10	bar	100	R
38	P-Lube Oil before Filter (ECU)	0	10	bar	100	R
39	P-Oil Filter Difference	0	16	bar	100	R
42	P-Oil Refill Pump	0	6	bar	100	R
43	P-Coolant	0	6	bar	100	R
44	P-Raw Water before Pump	0	6	bar	100	R
45	P-Raw Water	0	6	bar	100	R
46	P-Fuel	0	15	bar	100	R
47	P-Fuel before Filter (ECU)	0	10	bar	100	R
48	P-Fuel Prefilter Diff.	0	10	bar	100	R
49	P-Fuel Filter Difference	0	16	bar	100	R
50	P-Fuel Common Rail A	0	2500,00	bar	10	R
51	P-Fuel Common Rail B	0	2500,00	bar	10	R
52	P-Fuel Common Rail A SaSy	0	2500,00	bar	10	R
53	P-Fuel Common Rail B SaSy	0	2500,00	bar	10	R
54	P-Crankcase	-70	70	mbar	100	R
55	P-Intake Air B	-70	70	mbar	100	R
56	P-Charge Air A	0	6	bar	100	R
57	P-Charge Air B	0	6	bar	100	R
58	P-Control Air	0	10	bar	100	R
59	P-Start Air	0	50	bar	100	R
60	P-Exhaust back	0	200	bar	100	R
62	UTC Seconds	0	59	digit	1	R
63	UTC Minutes	0	59	digit	1	R
64	UTC Hour	0	23	digit	1	R
65	Month	1	12	digit	1	R
66	Day	1	31	digit	1	R
67	Year	1970	2060	digit	1	R
70	T-Lube Oil	-20	120	degC	10	R
71	T-Lube Oil ETC	-20	120	degC	10	R
75	T-Fuel bef.Low Press Pump	-20	120	degC	10	R
76	T-Fuel Common Rail A	-20	120	degC	10	R
77	T-Fuel Common Rail B	-20	120	degC	10	R
78	T-Coolant (ECU)	-20	120	degC	10	R
79	T-Coolant SaSy	-20	120	degC	10	R
80	T-Raw Water	-20	120	degC	10	R
81	T-Intake Air	-20	120	degC	10	R



MTU Friedrichshafen GmbH

Zeichnungs-Nr./Drawing No.

ZNG00019139

Blatt/ Sheet

3

von/of

26

Alle Rechte aus Schutzrechtsanmeldungen vorbehalten. Weitergabe, Vervielfältigung oder sonstige Verwertung ohne Zustimmung nicht gestattet. Zuwiderhandlungen verpflichten zum Schadensersatz.

All industrial property rights reserved. Disclosure, reproduction or use for any other purpose is prohibited unless our express permission has been given. Any infringement results in liability to pay damages.

war kZ

Buchst./Rev.Ltr.
-12Aenderungs-Nr./Revision Notice No.
PR047868Bearbeitungsstatus/Lifecycle
Released

Register	Denomination	Min	Max	Unit	Scaling	Read/Write
82	T-Charge Air A	-20	120	degC	10	R
83	T-Charge Air B	-20	120	degC	10	R
84	T-Charge Air Seq Ctrl Valve	0	1000	degC	10	R
85	T-Exhaust Combined A	-20	800	degC	10	R
86	T-Exhaust before ETC (Combined B)	-20	800	degC	10	R
87	T-Exhaust Combined C	-20	1000	degC	10	R
88	T-Exhaust Combined D	-20	1000	degC	10	R
89	T-Exhaust A1	0	1000	degC	10	R
90	T-Exhaust A2	0	1000	degC	10	R
91	T-Exhaust A3	0	1000	degC	10	R
92	T-Exhaust A4	0	1000	degC	10	R
93	T-Exhaust A5	0	1000	degC	10	R
94	T-Exhaust A6	0	1000	degC	10	R
95	T-Exhaust A7	0	1000	degC	10	R
96	T-Exhaust A8	0	1000	degC	10	R
97	T-Exhaust A9	0	1000	degC	10	R
98	T-Exhaust A10	0	1000	degC	10	R
99	T-Exhaust B1	0	1000	degC	10	R
100	T-Exhaust B2	0	1000	degC	10	R
101	T-Exhaust B3	0	1000	degC	10	R
102	T-Exhaust B4	0	1000	degC	10	R
103	T-Exhaust B5	0	1000	degC	10	R
104	T-Exhaust B6	0	1000	degC	10	R
105	T-Exhaust B7	0	1000	degC	10	R
106	T-Exhaust B8	0	1000	degC	10	R
107	T-Exhaust B9	0	1000	degC	10	R
108	T-Exhaust B10	0	1000	degC	10	R
109	T-Exhaust Mean	0	1000	degC	10	R
110	T-Bearing 1	0	200	degC	10	R
111	T-Bearing 2	0	200	degC	10	R
112	T-Bearing 3	0	200	degC	10	R
113	T-Bearing 4	0	200	degC	10	R
114	T-Bearing 5	0	200	degC	10	R
115	T-Bearing 6	0	200	degC	10	R
116	T-Bearing 7	0	200	degC	10	R
117	T-Bearing 8	0	200	degC	10	R
118	T-Bearing 9	0	200	degC	10	R
119	T-Bearing 10	0	200	degC	10	R
120	T-Bearing 11	0	200	degC	10	R
121	T-Bearing Mean	0	200	degC	10	R
122	T-Splash Oil B1	-40	150	degC	10	R
123	T-Splash Oil B2	-40	150	degC	10	R
124	T-Splash Oil B3	-40	150	degC	10	R
125	T-Splash Oil B4	-40	150	degC	10	R
126	T-Splash Oil B5	-40	150	degC	10	R
127	T-Splash Oil B6	-40	150	degC	10	R
128	T-Splash Oil B7	-40	150	degC	10	R
129	T-Splash Oil B8	-40	150	degC	10	R
130	T-Splash Oil B9	-40	150	degC	10	R
131	T-Splash Oil B10	-40	150	degC	10	R
132	T-Splash Oil Mean	-40	150	degC	10	R
133	T-ECU	0	100	degC	10	R
135	T-Exhaust after Engine	0	400	degC	10	R
140	ECU Failure Codes	0	5000	digit	1	R
141	Torque Limitation Code	-2147483646	2147483646	digit	1	R
142	SPU Interface Version HI	-2147483646	2147483646	digit	1	R
143	SPU Interface Version LO	-2147483646	2147483646	digit	1	R
144	MCS Version HI	-2147483646	2147483646	digit	1	R
145	MCS Version LO	-2147483646	2147483646	digit	1	R
146	SPU Alarm Groups coded static HI	-2147483646	2147483646	digit	1	R
147	SPU Alarm Groups coded static LO	-2147483646	2147483646	digit	1	R
148	SPU Alarm Groups coded dyn. HI	-2147483646	2147483646	digit	1	R
149	SPU Alarm Groups coded dyn. LO	-2147483646	2147483646	digit	1	R
150	Alarm Counter	0	65535	digit	1	R
152	Status Start Procedure HI	-2147483646	2147483646	digit	1	R
153	Status Start Procedure LO	-2147483646	2147483646	digit	1	R
155	Trip Fuel Consumption HI	0	200000000	l	1	R
156	Trip Fuel Consumption LO	0	200000000	l	1	R
157	Total Fuel Consumption HI	0	200000000	l	1	R
158	Total Fuel Consumption LO	0	200000000	l	1	R
159	Actual Fuel Consumption	0	3000	l/h	10	R
160	Mean Trip Fuel Consumption	0	3000	l/h	10	R



MTU Friedrichshafen GmbH

Zeichnungs-Nr./Drawing No.

ZNG00019139

Blatt/ Sheet

4

von/of

26

Alle Rechte aus Schutzrechtsanmeldungen vorbehalten. Weitergabe, Vervielfältigung oder sonstige Verwertung ohne Zustimmung nicht gestattet. Zuwiderhandlungen verpflichten zum Schadensersatz.

All industrial property rights reserved. Disclosure, reproduction or use for any other purpose is prohibited unless our express permission has been given. Any infringement results in liability to pay damages.

war kZ

Buchst./Rev.Ltr.
-12Aenderungs-Nr./Revision Notice No.
PR047868Bearbeitungsstatus/Lifecycle
Released

Register	Denomination	Min	Max	Unit	Scaling	Read/Write
161	Fuel Consumption Max	0	3000	l/h	10	R
162	Fuel Consumption Act	0	100	%	100	R
163	Fuel Consumption Mean Trip	0	100	%	100	R
165	Injection Limitation 0-120%	0	120	%	100	R
166	Injection in Relation to DBR	0	120	%	100	R
170	ECU Operat.Hours HI	0	100000	h	1	R
171	ECU Operat.Hours LO					
172	Trip Duration HI					
173	Trip Duration LO	0	100000	h	1	R
176	Engine Load Reserve	0	120	%	100	R
178	Injection Quantity 0-120	0	120	%	100	R
183	User Instruction	0	65535	digit	1	R
204	Cylinder Cutout Mask HI	-2147483646	2147483646	digit	1	R
205	Cylinder Cutout Mask LO					
206	T-Exhaust SCR Inlet1	0	1000	degC	10	R
207	T-Exhaust SCR Inlet2	0	1000	degC	10	R
208	T-Exhaust SCR Outlet1	0	1000	degC	10	R
209	P-Exhaust Diff SCR1	0	10	bar	100	R
210	P-RA Filter Out at PFM	0	10	bar	100	R
211	T-Reducing Agent at PFM	0	1000	degC	10	R
212	RA Tank Level Norm	0	100	%	100	R
213	P-Fuel Prefilter	0	10	bar	100	R
220	T-Exhaust SCR Outlet 2	0	1000	degC	10	R
221	Power Actual Gen	0	2000	kW	10	R
231	T-Bearing GenDE	-50	200	degC	10	R
232	T-Bearing GenNDE	-50	200	degC	10	R
233	T-AirInlet Gen	-50	200	degC	10	R
234	T-AirOutlet Gen	-50	200	degC	10	R
236	T-WindingL1 Gen	-50	200	degC	10	R
237	T-WindingL2 Gen	-50	200	degC	10	R
238	T-WindingL3 Gen	-50	200	degC	10	R
239	T-WindingL4 Gen	-50	200	degC	10	R
246	T-Coolant Gen Out	-50	200	degC	10	R
247	T-Coolant Gen In	-50	200	degC	10	R
295	MMS Errorcodes	0	2147483646	digit	1	R
506	Cmd Voltage Demand Gen	0	1000	V	10	W
507	Cmd Current Demand Gen	0	3000	A	10	W
508	Cmd Power Demand Gen	0	2000	kW	10	W



MTU Friedrichshafen GmbH

Zeichnungs-Nr./Drawing No.

ZNG00019139

Blatt/ Sheet

5

von/of

26

Alle Rechte aus Schutzrechtsanmeldungen vorbehalten. Weitergabe, Vervielfältigung oder sonstige Verwertung ohne Zustimmung nicht gestattet. Zuwiderhandlungen verpflichten zum Schadensersatz.

All industrial property rights reserved. Disclosure, reproduction or use for any other purpose is prohibited unless our express permission has been given. Any infringement results in liability to pay damages.

war KZ

Buchst./Rev.Ltr.
-12Aenderungs-Nr./Revision Notice No.
PR047868Bearbeitungsstatus/Lifecycle
Released

MCS Alarms

Function Code		01 Read Coils
Minimum Cycle Time for synchronisation and initialisation		5000ms
Analog-Register 150 (Alarm Counter) is being changed if new Alarm occurs or Alarm disappears. If Register-Value has changed since last request, read all Alarm-Informations at once.		
2 Bits per Alarm		
High-Bit	Low-Bit	
0	0	No Alarm
0	1	Acknowledged Alarm
1	0	Spare/not used
1	1	Unacknowledged Alarm

Register	Denomination	Alarm Priority	Alarm Description
1002	LOLO Engine Speed	Yellow (3)	Engine is being stalled. The engine speed of the normally operating engine dropped below the limit from parameter 2.2500.027 Limit Engine Speed Low without any stop request. For safety reason the engine is stopped when this event occurs.
1004	HIHI Engine Overspeed (EIM)	Red (2)	Highest Limit of engine overspeed
1006	HIHI Engine Overspeed SaSy	Red (2)	An engine overspeed was detected by the safety system. This alarm will normally cause an automatic emergency stop.
1008	SD Engine Speed Camshaft	Yellow (4)	Sensor defect on camshaft. ==> short circuit or cable breakage ==> Check sensor and cable (B1), if necessary replace it. After Engine restart follows curing of failure.
1010	SD Engine Speed Crankshaft	Yellow (4)	Sensor defect on crankshaft. ==> short circuit or cable breakage ==> Check sensor and cable (B13), if necessary replace it. After Engine restart follows curing of failure.
1018	SD ETC 1 Speed	Yellow (4)	Speed-sensor of basic charger defect. ==> short circuit or cable breakage ==> Check sensor and cable (B44.1), if necessary replace it.
1020	HIHI ETC 1 Overspeed	Red (2)	Speed of basic charger too high (limit 2).
1022	HI ETC 1 Speed	Yellow (3)	Speed of basic charger too high (limit 1).
1024	SD ETC 2 Speed	Yellow (4)	Speed-sensor of switching charger defect. ==> short circuit or cable breakage ==> Check sensor and cable (B44.2), if necessary replace it.
1026	HIHI ETC 2 Overspeed	Red (2)	Speed of 1st switchable charger too high (limit 2).
1028	HI ETC 2 Speed	Yellow (3)	Speed of 1st switchable charger too high (limit 1).
1030	SD ETC 3 Speed	Yellow (4)	Speed-sensor of switching charger defect. ==> short circuit or cable breakage ==> Check sensor and cable (B44.2), if necessary replace it.
1032	HIHI ETC 3 Overspeed	Red (2)	Speed of 2nd switchable charger too high (limit 2).
1034	HI ETC 3 Speed	Yellow (3)	Speed of 2nd switchable charger too high (limit 1).
1036	SD ETC 4 Speed	Yellow (4)	Speed-sensor of switching charger defect. ==> short circuit or cable breakage ==> Check sensor and cable (B44.4), if necessary replace it.
1038	HIHI ETC 4 Overspeed	Red (2)	Speed of 3rd switchable charger too high (limit 2).
1040	HI ETC 4 Speed	Yellow (3)	Speed of 3rd switchable charger too high (limit 1).
1048	HI ETC Speed Difference	Yellow (4)	Speed deviation between basic turbo charger and one of the switchable chargers.
1110	LO Starter Supply Voltage	Yellow (4)	The starter supply voltage is below the minimum limit. The starter supply voltage is not monitored during the start procedure.
1112	SD ECU Power Supply Voltage	Yellow (4)	Internal ECU error. ==> electronic defect.
1114	HIHI ECU Power Supply Voltage	Red (2)	Power supply voltage too high (limit 2) ==> Check battery / generator
1116	HI ECU Power Supply Voltage	Yellow (4)	Power supply voltage too high (limit 1) ==> Check battery / generator
1118	LO ECU Power Supply Voltage	Yellow (4)	Power supply voltage too low (limit 1) ==> Check battery / generator
1120	LOLO ECU Power Supply Voltage	Red (2)	Power supply voltage too low (limit 2) ==> Check battery / generator
1122	SD U-Power Driver Unit	Yellow (4)	Sensor defect of Injector Power driver unit. ==> Internal error of ECU7. Change ECU7.
1124	HIHI U-Power Driver Unit	Yellow (3)	Power driver voltage (injectors) too high (limit 2).
1126	HI U-Power Driver Unit	Yellow (3)	Power driver voltage (injectors) too high (limit 1).
1128	LO U-Power Driver Unit	Yellow (4)	Power driver voltage (injectors) too low (limit 1).
1130	LOLO U-Power Driver Unit	Red (2)	Power driver voltage (injectors) too low (limit 2).
1132	HI U-SPU Main Power Supply	Yellow (3)	The voltage of the SPU main power supply is too high.
1134	LO U-SPU Main Power Supply	Yellow (3)	The voltage of the SPU main power supply is too low.



MTU Friedrichshafen GmbH

Zeichnungs-Nr./Drawing No.

ZNG00019139

Blatt/ Sheet

6

von/of

26

Alle Rechte aus Schutzrechtsanmeldungen vorbehalten. Weitergabe, Vervielfältigung oder sonstige Verwertung ohne Zustimmung nicht gestattet. Zuwiderhandlungen verpflichten zum Schadensersatz.

All industrial property rights reserved. Disclosure, reproduction or use for any other purpose is prohibited unless our express permission has been given. Any infringement results in liability to pay damages.

Aenderungsbeschreibung/Description of Revision war kZ		Kommt vor/Frequency
Buchst./Rev.Ltr. -12	Aenderungs-Nr./Revision Notice No. PR047868	Bearbeitungsstatus/Lifecycle Released

Register	Denomination	Alarm Priority	Alarm Description
1136	HI U-SPU Emerg.Power Supply	Yellow (3)	The voltage of the SPU emergency power supply is too high.
1138	LO U-SPU Emerg.Power Supply	Yellow (3)	The voltage of the SPU emergency power supply is too low.
1140	LO U-SPU Real Time Clock	Yellow (3)	The voltage of backup battery for time and date in the LOP is too low, logging features may have an incorrect time stamp. Replace the battery located in the SPU/LOP!
1142	AL EMU 11V	Yellow (4)	The internal 11V power supply of the engine monitoring extension unit (EMU) is out of range. This could cause improper readings of measured data and malfunctioning safety functions.
1144	AL EMU 7V	Yellow (4)	The internal -7V power supply of the engine monitoring extension unit (EMU) is out of range. This could cause improper readings of measured data and malfunctioning safety functions.
1146	AL U-SPU Main Power Supply/Fail	Yellow (4)	The main power supply of the LOP/SPU failed. The system is still full operative and is feed through the emergency power supply.
1148	AL U-SPU Emerg. Power Supply Fail	Yellow (4)	The emergency power supply of the LOP/SPU failed. The system is still full operative and is feed through the emergency power supply.
1150	SD P-Lube Oil (ECU)	Yellow (4)	Lube oil pressure-sensor defect. ==> short circuit or cable breakage ==> Check sensor and cable (B5), if necessary replace it.
1152	LO P-Lube Oil (ECU)	Yellow (3)	Pressure of lube oil too low (limit 1).
1154	LOLO P-Lube Oil (ECU)	Red (2)	Pressure of lube oil too low (limit 2).
1156	SD P-Lube Oil SaSy	Yellow (4)	The safety system sensor signal for lube oil pressure is outside the defined sensor signal range. The safety system lube oil pressure information is not available anymore for indication or monitoring. The safety functions related to this signal are not available anymore.
1158	LO P-Lube Oil SaSy	Yellow (3)	A low engine lube oil pressure was detected by the safety system. A worsening situation could trigger a safety reaction.
1160	LOLO P-Lube Oil SaSy	Red (2)	A very low engine lube oil pressure was detected by the safety system. This alarm will normally cause an automatic security shutdown. The safety reaction is alarmed with an separate alarm.
1162	TD P-Lube Oil	Yellow (4)	The pressure difference between the redundant lube oil pressure sensors is too high.
1164	SD P-Lube Oil A-Side ETCs	Yellow (4)	Lube oil pressure-sensor of ETC on engine A-Side is defect. ==> short circuit or cable breakage ==> Check sensor and cable if necessary replace it.
1166	LO P-Lube Oil A-Side ETCs	Yellow (3)	A low lube oil pressure of the engine turbo charger on the A-side was detected. A worsening situation could trigger a safety reaction. This is the warning level.
1168	LOLO P-Lube Oil A-Side ETCs	Red (2)	A very low lube oil pressure of the engine turbo charger on the A-side was detected. A worsening situation could trigger a safety reaction. This is the warning level. This alarm will normally cause an automatic security shutdown. The safety reaction is alarmed with a separate alarm.
1170	SD P-Lube Oil B-Side ETCs	Yellow (4)	Lube oil pressure-sensor of ETC on engine B-side is defect. ==> short circuit or cable breakage ==> Check sensor and cable if necessary replace it.
1172	LO P-Lube Oil B-Side ETCs	Yellow (3)	A low lube oil pressure of the engine turbo charger on the B-side was detected. A worsening situation could trigger a safety reaction. This is the warning level.
1174	LOLO P-Lube Oil B-Side ETCs	Red (2)	A very low lube oil pressure of the engine turbo charger on the B-side was detected. A worsening situation could trigger a safety reaction. This is the warning level. This alarm will normally cause an automatic security shutdown. The safety reaction is alarmed with an separate alarm.
1176	SD P-Oil after Level Pump	Yellow (4)	Sensor defect of lube oil pressure after level pump
1178	LO P-Oil after Level Pump	Yellow (3)	Low Limit of lube oil pressure after level pump
1180	SD P-Oil Before HP Pump A	Yellow (4)	Sensor defect of lube oil pressure before high pressure pump in A
1182	LO P-Oil Before HP Pump A	Yellow (3)	Low Limit of lube oil pressure before high pressure pump A
1184	SD P-Oil Before HP Pump B	Yellow (4)	Sensor defect of lube oil pressure before high pressure pump in B
1186	LO P-Oil Before HP Pump B	Yellow (3)	Low Limit of lube oil pressure before high pressure pump B
1204	SD P-Lube Oil before Filter	Yellow (4)	Pressure sensor for lube oil before filter defect. ==> short circuit or cable breakage ==> Check sensor and cable (B5.3), if necessary replace it.
1206	SD P-Oil Filter Difference	Yellow (4)	Sensor for differential pressure of lube oil defect. ==> short circuit or cable breakage ==> Check sensor and cable (B5), if necessary replace it.
1208	HIHI P-Oil Filter Difference	Red (2)	Differential pressure of oil filter too high (limit 2).
1210	HI P-Oil Filter Difference	Yellow (3)	Differential pressure of oil filter too high (limit 1).
1226	SD P-Oil Refill Pump	Yellow (4)	The pressure sensor signal for the oil refill pump pressure monitoring is outside the defined sensor signal range. This measuring point is not available anymore for indication or monitoring. Configured (safety) functions related to this signal are not available anymore.
1228	LO P-Oil Refill Pump	Yellow (3)	The oil pressure after the oil refill pump which is pumping oil out and back into the oil pan was low for a certain period (several minutes). As long as the pump is able to pump oil out and back into the oil pan, there is enough oil in the engine. If the oil level is below the end of the "pump snorkel" the pump will not produce pressure within a certain time and this alarm will be triggered.
1232	SD P-Coolant	Yellow (4)	Coolant pressure-sensor defect. ==> short circuit or cable breakage ==> Check sensor and cable (B16), if necessary replace it.
1234	LO P-Coolant	Yellow (3)	Coolant pressure too low (limit 1) ==> check cooling cycle.
1236	LOLO P-Coolant	Red (2)	Coolant pressure too low (limit 2) ==> Engine stop or limitation of the injection quantity ==> check cooling cycle
1242	SD P-Raw Water	Yellow (4)	The pressure sensor signal for the raw water pressure monitoring is outside the defined sensor signal range. This measuring point is not available anymore for indication or monitoring. Configured (safety) functions related to this signal are not available anymore.
1244	LO P-Raw Water	Yellow (3)	The raw water pressure after the pump is too low
1246	SD P-Fuel after Filter	Yellow (4)	Fuel pressure-sensor defect. ==> short circuit or cable breakage ==> Check sensor and cable (B34), if necessary replace it.
1248	LO P-Fuel	Yellow (3)	Fuel supply pressure too low (limit 1) ==> Check filter, fuel on low-pressure side

 MTU Friedrichshafen GmbH		Zeichnungs-Nr./Drawing No. ZNG00019139	Blatt/ Sheet 7 von/of 26
Alle Rechte aus Schutzrechtsanmeldungen vorbehalten. Weitergabe, Vervielfältigung oder sonstige Verwertung ohne Zustimmung nicht gestattet. Zuwiderhandlungen verpflichten zum Schadensersatz. All industrial property rights reserved. Disclosure, reproduction or use for any other purpose is prohibited unless our express permission has been given. Any infringement results in liability to pay damages.			

Aenderungsbeschreibung/Description of Revision war kZ		Kommt vor/Frequency
Buchst./Rev.Ltr. -12	Aenderungs-Nr./Revision Notice No. PR047868	Bearbeitungsstatus/Lifecycle Released

Register	Denomination	Alarm Priority	Alarm Description
1250	LOLO P-Fuel	Red (2)	Fuel supply pressure too low (limit 2) ==> Check filter (low-pressure side)
1252	SD P-Fuel before Filter	Yellow (4)	Fuel pressure-sensor defect. ==> short circuit or cable breakage ==> Check sensor and cable (B5.3), if necessary replace it.
1254	SD Fuel Prefilter 1	Yellow (4)	The self test function of the fuel prefilter sensor 1 detected that the sensor does not respond as specified. The sensor might be defect or the wiring is defective. The SD alarm is reset if a successful self test was carried out. A self test is typically performed every 15min (the exact time might vary).
1256	SD Fuel Prefilter 2	Yellow (4)	The self test function of the fuel prefilter sensor 2 detected that the sensor does not respond as specified. The sensor might be defect or the wiring is defective. The SD alarm is reset if a successful self test was carried out. A self test is typically performed every 15min (the exact time might vary).
1258	HI P-Fuel Int. Filter Diff.	Yellow (3)	Fuel Prefilter Difference to high
1260	SD P-Fuel Filter Difference	Yellow (4)	Sensor for differential pressure of fuel defect. ==> only if SD-Alarms Fuel b. Filter or Fuel after Filter
1262	HI P-Fuel Filter Difference	Yellow (3)	Differential pressure of fuel filter too high (limit 1).
1264	SD P-Fuel Before LP Pump	Yellow (4)	Sensor defect of fuel pressure before low pressure pump
1266	LO P-Fuel Before LP Pump	Yellow (3)	Low Limit of fuel pressure before low pressure pump
1268	SD P-Fuel Common Rail	Yellow (4)	Rail pressure-sensor defect. ==> High-pressure controller emergency operation ==> short circuit or cable breakage ==> Check sensor and cable (B48), if necessary replace it.
1270	HI P-Fuel Common Rail	Yellow (3)	Rail pressure > set point value ==> DBR reduction, shift of start of injection delayed (==> interphase transformer sticks or connections of the interphase transformer)
1272	LOLO P-Fuel Common Rail	Red (2)	Rail pressure < setpoint value ==> DBR reduction (==> interphase transformer defective or leakage in high-pressure system)
1274	LO P-Fuel Common Rail	Yellow (3)	Rail pressure < set point value ==> DBR reduction (==> interphase transformer defective or leakage in high-pressure system)
1276	SD P-Fuel Common Rail B	Yellow (4)	Rail pressure-sensor defect. ==> High-pressure controller emergency operation ==> short circuit or cable breakage ==> Check sensor and cable (B48), if necessary replace it.
1278	HI P-Fuel Common Rail B	Yellow (3)	High Limit of fuel pressure in rail B
1280	LOLO P-Fuel Common Rail B	Red (2)	Rail pressure on Rail B < setpoint value ==> DBR reduction (==> interphase transformer defective or leakage in high-pressure system)
1282	LO P-Fuel Common Rail B	Yellow (3)	Rail pressure < setpoint value ==> DBR reduction (==> interphase transformer defective or leakage in high-pressure system)
1296	SD P-Fuel Return Path	Yellow (4)	Sensor defect of fuel pressure in return path
1298	HI P-Fuel Return Path	Yellow (3)	High Limit of fuel pressure in return path
1300	SD P-Crankcase	Yellow (4)	Crankcase pressure-sensor defect. ==> short circuit or cable breakage ==> Check sensor and cable (B50), if necessary replace it.
1302	HIHI P-Crankcase	Red (2)	Crankcase pressure too high (limit 2).
1304	HI P-Crankcase	Yellow (3)	Crankcase pressure too high (limit 1).
1306	LO P-Intake Air After FilterB	Yellow (3)	Low Limit of intake air pressure B reached
1308	SD P-Charge Air A	Yellow (4)	Charge air pressure-sensor defect. ==> short circuit or cable breakage ==> Check sensor and cable (B10), if necessary replace it.
1310	HIHI P-Charge Air A	Red (2)	Pressure of charge air too high (limit 2).
1312	HI P-Charge Air A	Yellow (3)	Pressure of charge air too high (limit 1).
1314	SD P-Charge Air B	Yellow (4)	Charge Air Pressur B-Side defect. ==> short circuit or cable breakage ==> Check sensor and cable (B10.11), if necessary replace it. After Engine restart follows curing of failure.
1316	HIHI P-Charge Air B	Red (2)	Highest Limit of charge air pressure in B reached
1318	HI P-Charge Air B	Yellow (3)	High Limit of charge air pressure in B reached
1324	SD P-Start Air	Yellow (4)	The pressure sensor signal for the start air pressure monitoring is outside the defined sensor signal range. This measuring point is not available anymore for indication or monitoring. Configured (safety) functions related to this signal (start interlock if start air pressure is too low) are not available anymore.
1326	LO P-Start Air	Yellow (4)	The pressure for the air starter is too low.
1328	LOLO P-Start Air	Yellow (3)	The pressure for the air starter is very low and a start is interlocked. The limit for that alarm should be set in a way that air for at least one start is remaining. This is to prevent emptying the air supply by (automatic) repeated starts. The start interlock can be disabled by activating "Override"
1386	SD T-Lube Oil	Yellow (4)	Lube oil temperature-sensor defect. ==> short circuit or cable breakage ==> Check sensor and cable (B7), if necessary replace it.
1388	HIHI T-Lube Oil	Red (2)	Lube oil temperature to high (limit 2).
1390	HI T-Lube Oil	Yellow (3)	Lube oil temperature too high (limit 1).
1394	SD T-Lube Oil ETCs	Yellow (4)	T-Lube Oil turbo charger sensor defect. ==> short circuit or cable breakage ==> Check sensor and cable, if necessary replace it.
1396	HIHI T-Lube Oil ETCs	Red (2)	Lube oil temperature of the basic charger is too high (above second limit).
1398	HI T-Lube Oil ETCs	Yellow (3)	Lube oil temperature of the basic charger is too high (above first limit).
1418	SD T-Fuel bef.Low Press.Pump	Yellow (4)	T-Fuel before Engine sensor defect. ==> short circuit or cable breakage ==> Check sensor and cable, if necessary replace it.

 MTU Friedrichshafen GmbH		Zeichnungs-Nr./Drawing No. ZNG00019139	Blatt/ Sheet 8 von/of 26
Alle Rechte aus Schutzrechtsanmeldungen vorbehalten. Weitergabe, Vervielfältigung oder sonstige Verwertung ohne Zustimmung nicht gestattet. Zuwiderhandlungen verpflichten zum Schadensersatz. All industrial property rights reserved. Disclosure, reproduction or use for any other purpose is prohibited unless our express permission has been given. Any infringement results in liability to pay damages.			

war kZ

Buchst./Rev.Ltr.
-12Aenderungs-Nr./Revision Notice No.
PR047868Bearbeitungsstatus/Lifecycle
Released

Register	Denomination	Alarm Priority	Alarm Description
1420	HIHI T-Fuel before LP Pump	Red (2)	Highest Limit of fuel temperature before low pressure pump reached
1422	HI T-Fuel before LP Pump	Yellow (3)	Fuel temperature before the low pressure fuel pump is too high.
1424	SD T-Fuel	Yellow (4)	Fuel temperature-sensor defect. ==> short circuit or cable breakage ==> Check sensor and cable (B33), if necessary replace it.
1426	HIHI T-Fuel	Red (2)	Fuel temperature too high (limit 2).
1428	HI T-Fuel	Yellow (3)	Fuel temperature too high (limit 1)
1430	SD T-Fuel Common Rail B	Yellow (4)	Sensor defect of fuel temperature in Rail B
1432	HIHI T-Fuel Common Rail B	Red (2)	Highest Limit of fuel temperature in rail B reached
1434	HI T-Fuel Common Rail B	Yellow (3)	High Limit of fuel temperature in rail B reached
1436	SD T-Coolant (ECU)	Yellow (4)	Coolant temperature-sensor defect. ==> short circuit or cable breakage ==> Check sensor and cable (B6), if necessary replace it.
1438	HIHI T-Coolant (ECU)	Red (2)	Coolant temperature too high (limit 2) ==> Check circulation of coolant
1440	HI T-Coolant (ECU)	Yellow (3)	Coolant temperature too high (limit 1) ==> Check circulation of coolant
1442	SD T-Coolant SaSy	Yellow (4)	The safety system sensor signal for coolant temperature is outside the defined sensor signal range. The safety system coolant temperature information is not available anymore for indication or monitoring. The safety functions related to this signal are not available anymore.
1444	HIHI T-Coolant SaSy	Red (2)	A very high engine coolant temperature was detected by the safety system. This alarm will normally cause an automatic safety function. The safety reaction is alarmed with an separate alarm.
1446	HI T-Coolant SaSy	Yellow (4)	A high engine coolant temperature was detected by the safety system. A worsening situation could trigger a safety reaction.
1448	TD T-Coolant	Yellow (4)	The temperature difference between the redundant coolant temperature sensors is too high.
1450	SD T-Raw Water after Pump	Yellow (4)	Sensor defect of raw water temperature after pump
1452	HI T-Raw Water after Pump	Yellow (3)	High Limit of raw water temperature after pump reached
1454	SD T-Intake Air	Yellow (4)	Intake air temperature-sensor defect. ==> short circuit or cable breakage ==> Check sensor and cable (B3), if necessary replace it.
1456	HIHI T-Intake Air	Red (2)	Highest Limit of intake air temperature reached
1458	HI T-Intake Air	Yellow (3)	Intake Air temperature too high (limit 1).
1460	SD P-Intake Air After FilterB	Yellow (4)	Intake air pressure sensor and cable , if necessary replace it.
1464	SD T-Charge Air	Yellow (4)	Charge air temperature-sensor defect. ==> short circuit or cable breakage ==> Check sensor and cable (B9), if necessary replace it.
1466	HIHI T-Charge Air	Red (2)	Charge air temperature too high (limit 2) ==> Check Intercooler
1468	HI T-Charge Air	Yellow (3)	Charge air temperature too high (limit 1) ==> Check Intercooler
1470	SD T-Charge Air B	Yellow (4)	Charge Air B temperature-sensor defect. ==> short circuit or cable breakage ==> Check sensor and cable (B3), if necessary replace it.
1472	HIHI T-Charge Air B	Red (2)	Highest Limit of charge air temperature in B reached
1474	HI T-Charge Air B	Yellow (3)	High Limit of charge air temperature in B reached
1476	SD T-Charge Air Seq. Ctrl. Valve	Yellow (4)	Temperature-sensor of recirculated charge air defect. ==> short circuit or cable breakage ==> Check sensor and cable (B49), if necessary replace it.
1478	HIHI T-Charge Air Seq. Ctrl. Val	Red (2)	Umblasen' temperature too high (limit 2).
1480	HI T-Charge Air Seq. Ctrl. Valve	Yellow (3)	Umblasen' temperature too high (limit 1).
1482	SD T-Exhaust Combined A	Yellow (4)	Exhaust gas temperature-sensor on A-side defect. ==> short circuit or cable breakage ==> Check sensor and cable (B4.21), if necessary replace it.
1484	HIHI T-Exhaust Combined A	Red (2)	Exhaust gas temperature (A-side) too high (limit 2).
1486	HI T-Exhaust Combined A	Yellow (3)	Exhaust gas temperature (A-side) too high (limit 1).
1488	SD T-Exhaust Combined B	Yellow (4)	Exhaust gas temperature-sensor on B-side defect. ==> short circuit or cable breakage ==> Check sensor and cable (B4.22), if necessary replace it.
1490	HIHI T-Exhaust Combined B	Red (2)	Exhaust gas temperature (B-side) too high (limit 2).
1492	HI T-Exhaust Combined B	Yellow (3)	Exhaust gas temperature (B-side) too high (limit 1).
1494	SD T-Exhaust Combined C	Yellow (4)	Exhaust gas temperature-sensor on C-side defect. ==> short circuit or cable breakage ==> Check sensor and cable (B4.23), if necessary replace it. After Engine restart follows curing of failure.
1496	HIHI T-Exhaust Combined C	Red (2)	Exhaust gas temperature (C-side) too high (limit 2).
1498	HI T-Exhaust Combined C	Yellow (3)	Exhaust gas temperature (C-side) too high (limit 1).



MTU Friedrichshafen GmbH

Zeichnungs-Nr./Drawing No.

ZNG00019139

Blatt/ Sheet

9

von/of

26

Alle Rechte aus Schutzrechtsanmeldungen vorbehalten. Weitergabe, Vervielfältigung oder sonstige Verwertung ohne Zustimmung nicht gestattet. Zuwiderhandlungen verpflichten zum Schadensersatz.

All industrial property rights reserved. Disclosure, reproduction or use for any other purpose is prohibited unless our express permission has been given. Any infringement results in liability to pay damages.

war kZ

Buchst./Rev.Ltr.
-12Aenderungs-Nr./Revision Notice No.
PR047868Bearbeitungsstatus/Lifecycle
Released

Register	Denomination	Alarm Priority	Alarm Description
1500	SD T-Exhaust Combined D	Yellow (4)	Exhaust gas temperature-sensor on D-side defect. ==> short circuit or cable breakage ==> Check sensor and cable (B4.24), if necessary replace it. After Engine restart follows curing of failure.
1502	HIHI T-Exhaust Combined D	Red (2)	Exhaust gas temperature (D-side) too high (limit 2).
1504	HI T-Exhaust Combined D	Yellow (3)	Exhaust gas temperature (D-side) too high (limit 1).
1506	SD T-Exhaust A1	Yellow (4)	The sensor signal for the single exhaust temperature of the specified cylinder is outside the defined sensor signal range. This measuring point is not available anymore for indication or monitoring. Configured safety functions related to this signal are not available anymore.
1508	HI T-Exhaust A1	Yellow (3)	The temperature of cylinder A1 compared to the average exhaust temperature is too high.
1510	LO T-Exhaust A1	Yellow (3)	The temperature of cylinder A1 compared to the average exhaust temperature is too low.
1512	SD T-Exhaust A2	Yellow (4)	The sensor signal for the single exhaust temperature of the specified cylinder is outside the defined sensor signal range. This measuring point is not available anymore for indication or monitoring. Configured safety functions related to this signal are not available anymore.
1514	HI T-Exhaust A2	Yellow (3)	The temperature of cylinder A2 compared to the average exhaust temperature is too high.
1516	LO T-Exhaust A2	Yellow (3)	The temperature of cylinder A2 compared to the average exhaust temperature is too low.
1518	SD T-Exhaust A3	Yellow (4)	The sensor signal for the single exhaust temperature of the specified cylinder is outside the defined sensor signal range. This measuring point is not available anymore for indication or monitoring. Configured safety functions related to this signal are not available anymore.
1520	HI T-Exhaust A3	Yellow (3)	The temperature of cylinder A3 compared to the average exhaust temperature is too high.
1522	LO T-Exhaust A3	Yellow (3)	The temperature of cylinder A3 compared to the average exhaust temperature is too low.
1524	SD T-Exhaust A4	Yellow (4)	The sensor signal for the single exhaust temperature of the specified cylinder is outside the defined sensor signal range. This measuring point is not available anymore for indication or monitoring. Configured safety functions related to this signal are not available anymore.
1526	HI T-Exhaust A4	Yellow (3)	The temperature of cylinder A4 compared to the average exhaust temperature is too high.
1528	LO T-Exhaust A4	Yellow (3)	The temperature of cylinder A4 compared to the average exhaust temperature is too low.
1530	SD T-Exhaust A5	Yellow (4)	The sensor signal for the single exhaust temperature of the specified cylinder is outside the defined sensor signal range. This measuring point is not available anymore for indication or monitoring. Configured safety functions related to this signal are not available anymore.
1532	HI T-Exhaust A5	Yellow (3)	The temperature of cylinder A5 compared to the average exhaust temperature is too high.
1534	LO T-Exhaust A5	Yellow (3)	The temperature of cylinder A5 compared to the average exhaust temperature is too low.
1536	SD T-Exhaust A6	Yellow (4)	The sensor signal for the single exhaust temperature of the specified cylinder is outside the defined sensor signal range. This measuring point is not available anymore for indication or monitoring. Configured safety functions related to this signal are not available anymore.
1538	HI T-Exhaust A6	Yellow (3)	The temperature of cylinder A6 compared to the average exhaust temperature is too high.
1540	LO T-Exhaust A6	Yellow (3)	The temperature of cylinder A6 compared to the average exhaust temperature is too low.
1542	SD T-Exhaust A7	Yellow (4)	The sensor signal for the single exhaust temperature of the specified cylinder is outside the defined sensor signal range. This measuring point is not available anymore for indication or monitoring. Configured safety functions related to this signal are not available anymore.
1544	HI T-Exhaust A7	Yellow (3)	The temperature of cylinder A7 compared to the average exhaust temperature is too high.
1546	LO T-Exhaust A7	Yellow (3)	The temperature of cylinder A7 compared to the average exhaust temperature is too low.
1548	SD T-Exhaust A8	Yellow (4)	The sensor signal for the single exhaust temperature of the specified cylinder is outside the defined sensor signal range. This measuring point is not available anymore for indication or monitoring. Configured safety functions related to this signal are not available anymore.
1550	HI T-Exhaust A8	Yellow (3)	The temperature of cylinder A8 compared to the average exhaust temperature is too high.
1552	LO T-Exhaust A8	Yellow (3)	The temperature of cylinder A8 compared to the average exhaust temperature is too low.
1554	SD T-Exhaust A9	Yellow (4)	The sensor signal for the single exhaust temperature of the specified cylinder is outside the defined sensor signal range. This measuring point is not available anymore for indication or monitoring. Configured safety functions related to this signal are not available anymore.
1556	HI T-Exhaust A9	Yellow (3)	The temperature of cylinder A9 compared to the average exhaust temperature is too high.
1558	LO T-Exhaust A9	Yellow (3)	The temperature of cylinder A9 compared to the average exhaust temperature is too low.
1560	SD T-Exhaust A10	Yellow (4)	The sensor signal for the single exhaust temperature of the specified cylinder is outside the defined sensor signal range. This measuring point is not available anymore for indication or monitoring. Configured safety functions related to this signal are not available anymore.
1562	HI T-Exhaust A10	Yellow (3)	The temperature of cylinder A10 compared to the average exhaust temperature is too high.
1564	LO T-Exhaust A10	Yellow (3)	The temperature of cylinder A10 compared to the average exhaust temperature is too low.
1566	SD T-Exhaust B1	Yellow (4)	The sensor signal for the single exhaust temperature of the specified cylinder is outside the defined sensor signal range. This measuring point is not available anymore for indication or monitoring. Configured safety functions related to this signal are not available anymore.
1568	HI T-Exhaust B1	Yellow (3)	The temperature of cylinder B1 compared to the average exhaust temperature is too high.
1570	LO T-Exhaust B1	Yellow (3)	The temperature of cylinder B1 compared to the average exhaust temperature is too low.
1572	SD T-Exhaust B2	Yellow (4)	The sensor signal for the single exhaust temperature of the specified cylinder is outside the defined sensor signal range. This measuring point is not available anymore for indication or monitoring. Configured safety functions related to this signal are not available anymore.



MTU Friedrichshafen GmbH

Zeichnungs-Nr./Drawing No.

ZNG00019139

Blatt/ Sheet

10
 von/of
26

Alle Rechte aus Schutzrechtsanmeldungen vorbehalten. Weitergabe, Vervielfältigung oder sonstige Verwertung ohne Zustimmung nicht gestattet. Zuwiderhandlungen verpflichten zum Schadensersatz.

All industrial property rights reserved. Disclosure, reproduction or use for any other purpose is prohibited unless our express permission has been given. Any infringement results in liability to pay damages.