

Diesel Engines
R 183 TD 13 H
V 183 TC 13, TD 13**Maintenance Schedule**
M050548/02E

MTU Motoren- und Turbinen-Union Friedrichshafen GmbH
88040 Friedrichshafen / Germany
Telephone (07541) 90-0
Telex 734 280-0 mt d
Telefax (07541) 90-3928

Low operating and maintenance costs as well as operational reliability and availability depend on maintenance and servicing being carried out in compliance with our specifications and instructions.

The overall system, of which the engine is an integral part, must be maintained in such a way as to ensure trouble-free engine operation at all times. For this purpose always:

- ensure that sufficient fuel is available,
- ensure that the combustion air is dry and clean,
- use only dry, clean compressed air,
- use only clean, filtered raw water.

Moreover, it is essential that:

- maintenance tasks be completed by trained personnel,
- suitable tools be used,
- genuine spare parts and fluids and lubricants as per the current MTU Fluids and Lubricants Specification A001061 be used.

Our Product Support Service will always be available should assistance be required.

Preventive maintenance instructions.

- Special care should be taken to keep the machinery plant in a clean and serviceable condition at all times to facilitate early detection of possible leaks and prevent subsequent damage.
- Protect rubber and synthetic components from oil and fuel, never treat with organic detergents. Wipe with a dry cloth only.
- Always replace all seals and gaskets.

MTU Maintenance Concept

The maintenance concept is a preventive maintenance concept and features the maintenance echelons W1 to W6 as outlined below.

Preventive maintenance facilitates advance planning and ensures a high degree of equipment availability.

Main features of the maintenance echelons:

- W1: Operational checks
- W2, W3 and W4: Periodic maintenance tasks to be performed during out-of-service periods without the need for engine disassembly.
- W5: .
- W6: Major overhaul. This echelon requires complete engine disassembly.

The time intervals according to which the Maintenance Echelons and the relevant checks and tasks involved are to be completed are based on operational experience. They have been determined so as to ensure correct engine operation until the next scheduled maintenance echelon.

Use of a maintenance predictor can mean changes to the operating hours given in the Maintenance Frequency Chart.

Specific operational conditions may require modification of the Maintenance Schedule.

NOTE:

The codes on the following pages refer to the groups and subgroups of the Task Descriptions in Part G of the Engine Operation Manual.

This Maintenance Schedule may refer to parts which are not installed on your engine, these may be disregarded.

Application Group

2A: Rail Traction

Maintenance Frequency Chart¹⁾

Maintenance Echelon	W1: Operational checks, daily	X
	W2: Operating hours	250
	Limit, year	1
	W3: Operating hours	1 000
	Limit, year	1
	W4: Operating hours	2 000
	Limit, year(s)	2
	W6: Operating hours	18 000
	Limit, year(s)	10

Maintenance Task Schedule -Overall System-

See page 4

Maintenance Task Schedule -Engine-

Code No.	One-time operations after the first 50 operating hours. – With a new engine, after W5 maintenance echelon, or after W6 major overhaul	
G00.049	Attachments	Check tightness of securing screws and nuts
G06.101	Valve gear	Check clearances, adjust if necessary
G12.311	Fuel pre-filter	Clean
G12.321	Fuel duplex filter	Replace filter elements
G14.012	Engine coolant	Take sample and analyse
G19.011	Engine mounts	Check condition of rubber mounts
		Check tightness of securing screws and nuts
G88.911	Belt drive	Check condition and tension, re-tension if necessary

Code No.	Maintenance Echelon W1 – Operational checks	
G10.051	Exhaust system	Check exhaust gas colour Drain condensate (if drain valve provided)
G10.211	Air filter	Check restriction indicator, replace filter if necessary
G14.011	Engine coolant	Check level
G16.002	Engine oil	Check level
— — —	Monitoring and control system	Check control lamps and defect-code display (see manufacturer's documentation)
G84.002	Engine operation	Check running noises, Check engine and external pipework for leaks, Check speeds, pressures and temperatures - if gauges are provided

¹⁾ Maintenance echelons are based on the standard load profile.