

Maintenance Schedule

Diesel Engine

6R1600Bx0x

8V/10V/12V1600Bx0x

Application Group 3A

MS50108/01E



Power. Passion. Partnership.

© 2016 Copyright MTU Friedrichshafen GmbH

This publication is protected by copyright and may not be used in any way, whether in whole or in part, without the prior written consent of MTU Friedrichshafen GmbH. This particularly applies to its reproduction, distribution, editing, translation, micro-filming and storage or processing in electronic systems including databases and online services.

All information in this publication was the latest information available at the time of going to print. MTU Friedrichshafen GmbH reserves the right to change, delete or supplement the information provided as and when required.

1 Maintenance Schedule

1.1 Preface

In the case of emission-certified products, nonobservance of the maintenance specifications can result in a violation of the statutory emission regulations. Modification or removal of mechanical or electronic components or the installation of additional components as well as the execution of calibration processes that might affect the emission characteristics of the product are prohibited by emission regulations. Emission-relevant components may only be maintained, exchanged or repaired if the components used for this purpose are approved by MTU or equivalent components. Emission-relevant components are for instance control units, data records, sensors, injectors, exhaust flaps and all components of exhaust aftertreatment systems.

The maintenance system for MTU products is based on a preventive maintenance concept. Preventive maintenance facilitates advance planning and ensures a high degree of equipment availability. The maintenance intervals and required maintenance scopes are based on operational experience and must therefore be regarded as recommendations. In the event of difficult operational and ambient conditions, additional maintenance tasks and/or changes to the maintenance intervals may be necessary.

Maintenance activities are specified with intervals based on hours in operation and time limits. The limit which occurs first is applicable.

The individual maintenance intervals are assigned to the qualification levels QL1 to QL4.

QL1: Operational checks and maintenance work that does not require disassembly of the product.

QL2: Component replacement (corrective, and thus not an element of the maintenance schedule).

QL3: Maintenance work that requires partial disassembly of the product.

QL4: Maintenance work that requires complete disassembly of the product.

Supplementary information on maintenance and preservation:

Change intervals for fluids and lubricants and details on preservation can be obtained in the relevant specifications of the component manufacturers and MTU Fluids and Lubricants Specifications. The latest version is also available at: <http://www.mtu-online.com>, for engine-generator sets at: <http://www.mtuonsiteenergy.com>.

Components which are not listed in this maintenance schedule must be serviced in accordance with Manufacturer's Instructions.

This maintenance schedule does not apply to engines with an EPA/CARB emission certificate.