CIT 303 MODULE 1

UNIT 1 ANALOG SIGNAL PROCESSING

CONTENTS

- 1.0 Introduction
- 2.0 Objectives
- 3.0 Main Content
 - 3.1 Tools used in Analog Signal Processing
 - 3.2 Domains
- 3.3 Signals
- 3.4 Systems
- 4.0 Conclusion
- 5.0 Summary
- 6.0 TMA
- 7.0 Reference & Further Reading

1.0 Introduction

Analog signal processing is any signal processing conducted on analog signals by analog means. "Analog" indicates something that is mathematically represented as a set of continuous values. This differs from "digital" which uses a series of discrete quantities to represent signal. Analog values are typically represented as a voltage, electric current, or electric charge around components in the electronic devices. An error or noise affecting such physical quantities will result in a corresponding error in the signals represented by such physical quantities.

Examples of analog signal processing include crossover filters in loudspeakers, "bass", "treble" and "volume" controls on stereos, and "tint" controls on TVs. Common analog processing elements include capacitors, resistors, inductors and transistors.

2.0 Objectives

At the end of this unit, you should be able to;

- Explain Analog Signal processing
- Discus tools used in analog signal processing
- Discuss Domains
- Explain Signals
- Discuss Systems

23.1 Tools used in analog signal processing

A system's behavior can be mathematically modeled and is represented in the time domain as h(t) and in the <u>frequency domain</u> as H(s), where s is a <u>complex number</u> in the form of s = a+ib, or s = a+jb in electrical engineering terms (electrical engineers use j because current is

represented by the variable i). Input signals are usually called x(t) or X(s) and output signals are usually called y(t) or Y(s).

3.1.1 Convolution

Convolution is the basic concept in signal processing that states an input signal can be combined with the system's function to find the output signal. It is the integral of the product of two waveforms after one has reversed and shifted; the symbol for convolution is *.

$$y(t) = (x * h)(t) = \int_{a}^{b} x(\tau)h(t - \tau) d\tau$$

That is the convolution integral and is used to find the convolution of a signal and a system; typically $a = -\infty$ and $b = +\infty$.

Consider two waveforms f and g. By calculating the convolution, we determine how much a reversed function g must be shifted along the xaxis to become identical to function f. The convolution function essentially reverses and slides function g along the axis, and calculates the integral of their (f and the reversed and shifted g) product for each possible amount of sliding. When the functions match, the value of (f*g) is maximized. This occurs because when positive areas (peaks) or negative areas (troughs) are multiplied, they contribute to the integral.

3.1.2 Fourier transform

The Fourier transform is a function that transforms a signal or system in the time domain into the frequency domain, but it only works for certain ones. The constraint on which systems or signals can be transformed by the Fourier Transform is that:

$$\int_{-\infty}^{\infty} |x(t)| \, dt < \infty$$

This is the Fourier transform integral:
$$X(j\omega)=\int_{-\infty}^{\infty}x(t)e^{-j\omega t}\,dt$$

Most of the time the Fourier transform integral isn't used to determine the transform. Usually a table of transform pairs is used to find the Fourier transform of a signal or system. The inverse Fourier transform is used to go from frequency domain to time domain:

$$x(t) = \frac{1}{2\pi} \int_{-\infty}^{\infty} X(j\omega) e^{j\omega t} d\omega$$

Each signal or system that can be transformed has a unique Fourier transform; there is only one time signal and one frequency signal that goes together.

3.1.3 Laplace transform

The Laplace transform is a generalized Fourier transform. It allows a transform of any system or signal because it is a transform into the complex plane instead of just the j ω line like the Fourier transform. The major difference is that the Laplace transform has a region of convergence for which the transform is valid. This implies that a signal CIT 303 MODULE 1

in frequency may have more than one signal in time; the correct time signal for the transform is determined by the region of convergence. If the region of convergence includes the $j\omega$ axis, $j\omega$ can be substituted into the Laplace transform for s and it's the same as the Fourier transform. The Laplace transform is:

The Laplace transform is:
$$X(s) = \int_{-\infty}^{\infty} x(t)e^{-st} dt$$

and the inverse Laplace transform is:

$$x(t) = \frac{1}{2\pi} \int_{-\infty}^{\infty} X(s)e^{st} ds$$

3.1.4 Bode plots

Bode plots are plots of magnitude vs. frequency and phase vs. frequency for a system. The magnitude axis is in Decibel (dB). The phase axis is in either degrees or radians. The frequency axes are in a logarithmic scale. These are useful because for sinusoidal inputs, the output is the input multiplied by the value of the magnitude plot at the frequency and shifted by the value of the phase plot at the frequency.

3.2 Domains

3.2.1 Time domain

This is the domain that most people are familiar with. A plot in the time domain shows the magnitude of a signal at a point in time.

3.2.12 Frequency domain

This is the domain that engineers are glad exists. It's unfamiliar to most people, but makes the math associated with analog signal processing much easier than if it's analyzed in the time domain. A plot in the frequency domain shows either the phase shift or magnitude of a signal at each frequency that it exists at. These can be found by taking the Fourier transform of a time signal and are plotted similarly to a bode plot.

3.3 Signals

While any signal can be used in analog signal processing, there are many **types of signals** that are used very frequently.

3.3.1 Sinusoids

Sinusoids are the building block of analog signal processing. Theorem states that all real world signals can be represented by a sum of

sinusoids. A sinusoid can be represented by a complex exponential, e^{st} .

3.3.2 Impulse

An impulse (Dirac delta function) is defined as a signal that has an infinite magnitude and an infinitesimally narrow width with an area under it of one, centered at zero. An impulse can be represented as an infinite sum of sinusoids that includes all possible frequencies. It is not, in reality, possible to generate such a signal, but it can be sufficiently approximated with a large amplitude, narrow pulse, to produce the theoretical impulse response in a network to a high degree of accuracy. The symbol for an impulse is $\delta(t)$. If an impulse is used as an input to a system, the output is known as the impulse response. The impulse response defines the system because all possible frequencies are represented in the input.

3.3.3 Step

A unit step function, also called the <u>Heaviside step function</u>, is a signal that has a magnitude of zero before zero and a magnitude of one after zero. The symbol for a unit step is u(t). If a step is used as the input to a system, the output is called the step response. The step response shows how a system responds to a sudden input, similar to turning on a switch. The period before the output stabilizes is called the transient part of a signal. The step response can be multiplied with other signals to show how the system responds when an input is suddenly turned on.

The unit step function is related to the Dirac delta function by;

$$\mathbf{u}(t) = \int \delta(t).dt$$

3.4 Systems

3.4.1 Linear time-invariant (LTI)

Linearity means that if you have two inputs and two corresponding outputs, if you take a linear combination of those two inputs you will get a linear combination of the outputs. An example of a linear system is a first order low-pass or high-pass filter. Linear systems are made out of analog devices that demonstrate linear properties. These devices don't have to be entirely linear, but must have a region of operation that is linear. An operational amplifier is a non-linear device, but has a region of operation that is linear, so it can be modeled as linear within that region of operation. Time-invariance means it doesn't matter when you start a system, the same output will result. For example, if you have a system and put an input into it today, you would get the same output if

CIT 303 MODULE 1

you started the system tomorrow instead. There aren't any real systems that are LTI, but many systems can be modeled as LTI for simplicity in determining what their output will be. All systems have some dependence on things like temperature, signal level or other factors that cause them to be non-linear or non-time-invariant, but most are stable enough to model as LTI. Linearity and time-invariance are important because they are the only types of systems that can be easily solved using conventional analog signal processing methods. Once a system becomes non-linear or non-time-invariant, it becomes a non-linear differential equations problem, and there are very few of those that can actually be solved. (Haykin & Van Veen 2003)

3.4.2 Common systems

Some common systems used in everyday life are filters, AM/FM radio, electric guitars and musical instrument amplifiers. Filters are used in almost everything that has electronic circuitry. Radio and television are good examples of everyday uses of filters. When a channel is changed on an analog television set or radio, an analog filter is used to pick out the carrier frequency on the input signal. Once it's isolated, the television or radio information being broadcast is used to form the picture and/or sound. Another common analog system is an electric guitar and its amplifier. The guitar uses a magnet with a coil wrapped around it (inductor) to turn the vibration of the strings into a small electric current. The current is then filtered, amplified and sent to a speaker in the amplifier. Most amplifiers are analog because they are easier and cheaper to make than making a digital amplifier. There are also many analog guitar effects pedals, although a large number of pedals are now digital (they turn the input current into a digitized value, perform an operation on it, then convert it back into an analog signal).

4.0 Conclusion

Analog" indicates something that is mathematically represented as a set of continuous values. This differs from "digital" which uses a series of discrete quantities to represent signal. Analog values are typically represented as a <u>voltage</u>, <u>electric current</u>, or <u>electric charge</u> around components in the electronic devices.

5.0 Summary

Input signals are usually called x(t) or X(s) and output signals are usually called y(t) or Y(s).

Convolution is the basic concept in signal processing that states an input signal can be combined with the system's function to find the output signal.