

Microprocessor Interfacing & Programming

LECTURE 26 & 27

PIC18 Interrupts

- ▶ A single microcontroller can serve several devices. There are 2 methods by which devices receive service from the microcontroller:
 1. Interrupts
 2. Polling
- ▶ In the interrupt method, whenever any device needs the microcontroller's service, the device notifies it by sending an interrupt signal. Upon receiving an interrupt signal, the microcontroller stops whatever it is doing and serves the device.
- ▶ The program associated with the interrupt is called the interrupt service routine (ISR) or interrupt handler.
- ▶ In polling, the microcontroller continuously monitors the status of a given device; when the status condition is met, it performs the service.

Pros and Cons

- ▶ Polling is not the efficient use, it cannot assign priority because it checks all the devices in a round-robin fashion.
- ▶ In interrupt method, the microcontroller can also ignore/mask a device request for service. This is not possible with the polling method.
- ▶ The major disadvantage of polling is that it wastes much of the microcontroller's time by polling devices that do not need service.

Interrupt service routine

- ▶ For every interrupt, there must be an interrupt service routine (ISR) or interrupt handler.
- ▶ When an interrupt is invoked, the microcontroller runs the ISR.
- ▶ In most microprocessors, for every interrupt there is a fixed location in memory that hold the address of its ISR.
- ▶ The group of memory locations set aside to hold the addresses of ISRs is called the interrupt vector table.
- ▶ In PIC18, there are only two locations for interrupt vector table.

Interrupt	ROM Location (Hex)
Power-on Reset	0000
High Priority Interrupt	0008 (Default upon power-on reset)
Low Priority Interrupt	0018 (See Section 11.6)

Steps in executing an interrupt

Upon activation of an interrupt, the microcontroller goes through the following steps:

1. It finishes the instruction it is executing and saves the address of the next instruction (program counter) on the stack.
2. It jumps to a fixed location in memory called the interrupt vector table. The interrupt vector table directs the microcontroller to the address of the interrupt service routine (ISR).
3. The microcontroller gets the address of the ISR from the interrupt vector table and jumps to it. It starts to execute the interrupt service subroutine until it reaches the last instruction of the subroutine, which is RETFIE (return from interrupt exit).
4. Upon executing the RETFIE instruction, the microcontroller returns to the place where it was interrupted. First, it gets the program counter (PC) address from the stack by popping the top bytes of the stack into the PC. Then it starts to execute from that address.

Sources of interrupts in PIC18


1. There is an interrupt set aside for each of the timers.
2. External hardware interrupts. INT0, INT1, INT2 respectively.
3. Serial communication's USART has two interrupts, one for receive and one for transmit.
4. ADC and many more.

How interrupts work in PIC18:

1. Interrupt occurs
2. CPU automatically jumps to the vector at 0x0008 or 0x0018 (in ROM)
3. These locations contain a GOTO to the ISR (also in ROM)
4. CPU executes ISR from ROM

Enabling an interrupt

- ▶ Upon reset, all interrupts are disabled (masked).
 - ▶ The interrupts must be enabled (unmasked) by software in order for the microcontroller to respond to them.
 - ▶ D7 bit of the INTCON register is responsible for enabling and disabling the interrupts globally.



Steps in enabling an interrupt

To enable any one of the interrupts, we take the following steps:

1. Bit D7 (GIE) of the INTCON register must be set to HIGH to allow the interrupts to happen. This is done with the “BSF INTCON, GIE” instruction.
2. If GIE = 1, each interrupt is enabled by setting to HIGH the interrupt enable (IE) flag bit for that interrupt. Because there are a large number of interrupts in the PIC18, we have many registers holding the interrupt enable bit. Figure 11-2 shows that the INTCON has interrupt enable bits for Timer0 (TMR0IE) and external interrupt 0 (INT0IE). As we study each of peripherals throughout the book we will examine the registers holding the interrupt enable bits. It must be noted that if GIE = 0, no interrupt will be responded to, even if the corresponding interrupt enable bit is high. To understand this important point look at Example 11-1.
3. As shown in Figures 11-2 and 11-3, for some of the peripheral interrupts such as TMR1IF, TMR2IF, and TXIF, we have to enable the PEIE flag in addition to the GIE bit.

Example

Show the instructions to (a) enable (unmask) the Timer0 interrupt and external hardware interrupt 0 (INT0), and (b) disable (mask) the Timer0 interrupt, then (c) show how to disable (mask) all the interrupts with a single instruction.

Solution:

- (a) BSF INTCON,TMR0IE ;enable(unmask) Timer0 interrupt
 BSF INTCON,INT0IE ;enable external interrupt 1(INT0)
 BSF INTCON,GIE ;allow interrupts to come in

We can perform the above actions with the following two instructions:

```
MOVLW B'10110000' ;GIE = 1, TMR0IF = 1, INTIF0 = 1  
MOVWF INTCON ;load the INTCON reg
```


- (b) BCF INTCON,TMR0IE ;mask (disable) Timer0 interrupt
- (c) BCF INTCON,GIE ;mask all interrupts globally

Programming Timer Interrupts

Rollover timer flag and interrupt:

- ▶ We can use interrupts instead of polling method to avoid tying down the controller.
- ▶ If the timer interrupt in the interrupt register is enabled, TMROIF is raised whenever the timer rolls over and the microcontroller jumps to the interrupt vector table to service the ISR.
- ▶ In this way, the microcontroller can do other things until it is notified that the timer has rolled over.

Interrupt	Flag Bit	Register	Enable Bit	Register
Timer0	TMR0IF	INTCON	TMR0IE	INTCON
Timer1	TMR1IF	PIR1	TMR1IE	PIE1
Timer2	TMR2IF	PIR1	TMR2IE	PIE1
Timer3	TMR3IF	PIR3	TMR3IE	PIE2



- ▶ Assume that PORTC is connected to 8 switches and PORTD to 8 LEDs. This program uses Timer0 to generate a square wave on pin RB5, while at the same time the data is being transferred from PORTC to PORTD.

```

ORG 0000H
GOTO MAIN      ;bypass interrupt vector table
;--on default all interrupts land at address 00008
ORG 0008H      ;interrupt vector table
BTFSS INTCON,TMR0IF ;Timer0 interrupt?
RETFIE          ;No. Then return to main
GOTO T0_ISR    ;Yes. Then go Timer0 ISR
;--main program for initialization and keeping CPU busy
ORG 00100H     ;after vector table space
MAIN BCF TRISB,5 ;PB5 as an output
CLRF TRISD     ;make PORTD output
SETF TRISC     ;make PORTC input

```

```

        MOVLW 0x08      ;Timer0,16-bit,
        MOVWF T0CON    ;no prescale,internal clk
        MOVLW 0xFF      ;TMR0H = FFH, the high byte
        MOVWF TMR0H    ;load Timer0 high byte
        MOVLW 0xF2      ;TMR0L = F2H, the low byte
        MOVWF TMR0L    ;load Timer0 low byte
        BCF INTCON,TMR0IF;clear timer interrupt flag bit
        BSF T0CON,TMROON ;start Timer0
        BSF INTCON,TMROIE ;enable Timer 0 interrupt
        BSF INTCON,GIE   ;enable interrupts globally
;--keeping CPU busy waiting for interrupt
OVER MOVFF PORTC,PORTD ;send data from PORTC to PORTD
        BRA OVER        ;stay in this loop forever
;-----ISR for Timer 0
T0_ISR
        ORG 200H
        MOVLW 0xFF      ;TMR0H = FFH, the high byte
        MOVWF TMR0H    ;load Timer0 high byte
        MOVLW 0xF2      ;TMR0L = F2H, the low byte
        MOVWF TMR0L    ;load Timer0 low byte
        BTG  PORTB,5    ;toggle RB5
        BCF INTCON,TMR0IF ;clear timer interrupt flag bit
EXIT RETFIE ;return from interrupt (See Example 11-2)
        END

```

In the MAIN program, we initialize the Timer0 register and then enter an infinite loop to keep the CPU busy. This could be a real-world application being executed by the CPU. In this case, the loop gets data from PORTC and sends it to PORTD. While the PORTC data is brought in and issued to PORTD continuously, the TMR0IF flag is raised as soon as Timer0 rolls over, and the microcontroller gets out of the loop and goes to 00008H to execute the ISR associated with Timer0. At this point, the PIC18 clears the GIE bit (D7 of INTCON) to indicate that it is currently serving an interrupt and cannot be interrupted again; in other words, no interrupt inside the interrupt. In Section 11.6, we show how to allow an interrupt inside an interrupt.

The ISR for Timer0 is located starting at memory location 00200H because it is too large to fit into address space 08–17H, the address allocated to high-priority interrupts.

In the ISR for Timer0, notice that the “BCF INTCON, TMR0IF” instruction is needed before the RETFIE instruction. This will ensure that a single interrupt is serviced once and is not recognized as multiple interrupts.

RETFIE must be the last instruction of the ISR. Upon execution of the RETFIE instruction, the PIC18 automatically enables the GIE (D7 of the INTCON register) to indicate that it can accept new interrupts.

RETURN vs RETFIE

What is the difference between the RETURN and RETFIE instructions? Explain why we cannot use RETURN instead of RETFIE as the last instruction of an ISR.

Solution:

Both perform the same actions of popping off the top bytes of the stack into the program counter, and making the PIC18 return to where it left off. However, RETFIE also performs the additional task of clearing the GIE flag, indicating that the servicing of the interrupt is over and the PIC18 now can accept a new interrupt. If you use RETURN instead of RETFIE as the last instruction of the interrupt service routine, you simply block any new interrupt after the first interrupt, because the GIE would indicate that the interrupt is still being serviced.

Program 11-2 uses Timer0 and Timer1 interrupts to generate square waves on pins RB1 and RB7 respectively, while data is being transferred from PORTC to PORTD.

```
; Program 11-2
    ORG    0000H
    GOTO  MAIN           ;bypass interrupt vector table
;--on default all interrupts land at address 00008
    ORG    0008H           ;interrupt vector table
    GOTO  CHK_INT        ;go to an address with more space
;--check to see the source of interrupt
    ORG    0040H           ;we got here from 0008
CHK_INT
    BTFSC INTCON,TMROIF   ;Is it Timer0 interrupt?
    BRA   TO_ISR          ;Yes. Then branch to TO_ISR
    BTFSC PIR1,TMR1IF     ;Is it Timer1 interrupt?
    BRA   T1_ISR          ;Yes. Then branch to T1_ISR
    RETFIE
;--main program for initialization and keeping CPU busy
    ORG    0100H           ;somewhere after vector table space
MAIN  BCF   TRISB,1      ;PB1 as an output
    BCF   TRISB,7      ;PB7 as an output
    CLRF  TRISD          ;make PORTD output
    SETF  TRISC          ;make PORTC input
    MOVLW 0x08            ;Timer0,16-bit,
                           ;no prescale,internal clk
    MOVWF TOCON          ;load TOCON reg
    MOVLW 0xFF            ;TMROH = FFH, the high byte
    MOVWF TMR0H          ;load Timer0 high byte
    MOVLW 0xF2            ;TMR0L = F2H, the low byte
    MOVWF TMR0L          ;load Timer0 low byte
    BCF  INTCON,TMROIF;clear Timer0 interrupt flag bit
    MOVLW 0x00            ;Timer1,16-bit,
                           ;no prescale,internal clk
    MOVWF T1CON          ;load T1CON reg
    MOVLW 0xFF            ;TMR1H = FFH, the high byte
    MOVWF TMR1H          ;load Timer1 high byte
    MOVLW 0xF2            ;TMR1L = F2H, the low byte
    MOVWF TMR1L          ;load Timer1 low byte
    BCF  PIR1,TMR1IF;clear Timer1 interrupt flag bit
    BSF   INTCON,TMROIE   ;enable Timer0 interrupt
    BSF   PIE1,TMR1IE     ;enable Timer1 interrupt
    BSF   INTCON,PEIE     ;enable peripheral interrupts
    BSF   INTCON,GIE      ;enable interrupts globally
    BSF   TOCON,TMROON    ;start Timer0
    BSF   T1CON,TMR1ON    ;start Timer1
;--keeping CPU busy waiting for interrupt
OVER  MOVFF PORTC,PORTD ;send data from PORTC to PORTD
    BRA  OVER             ;stay in this loop forever
;-----ISR for Timer 0
TO_ISR
    ORG  200H
```

```
    MOVLW 0xFF      ;TMR0H = FFH, the high byte
    MOVWF TMR0H      ;load Timer0 high byte
    MOVLW 0xF2      ;TMR0L = F2H, the low byte
    MOVWF TMR0L      ;load Timer0 low byte
    BTG  PORTB,1    ;toggle PB1
    BCF INTCON,TMR0IF ;clear timer interrupt flag bit
    GOTO CHK_INT

;-----ISR for Timer1
T1_ISR
    ORG 300H
    MOVLW 0xFF      ;TMR1H = FFH, the high byte
    MOVWF TMR1H      ;load Timer1 high byte
    MOVLW 0xF2      ;TMR1L = F2H, the low byte
    MOVWF TMR1L      ;load Timer1 low byte
    BTG  PORTB,7
    BCF PIR1,TMR1IF ;clear Timer1 interrupt flag bit
    GOTO CHK_INT
END
```

```

//Program 11-2C (C version of Program 11-2)
#include <p18F458.h>
#define myPB1bit PORTBbits.RB1
#define myPB7bit PORTBbits.RB7

void T0_ISR(void);
void T1_ISR(void);

#pragma interrupt chk_isr //used for high-priority
                         //interrupt only

void chk_isr (void)
{
    if (INTCONbits.TMR0IF==1) //Timer0 causes interrupt?
        T0_ISR();           //Yes. Execute Timer0 ISR
    if(PIR1bits.TMR1IF==1)   //Or was it Timer1?
        T1_ISR();           // Yes. Execute Timer1 ISR
}

TMR1H=0x35;                //load TH0
TMR1L=0x00;                //load TL0
PIR1bits.TMR1IF=0;          //clear TF1
}

```

```

#pragma code
void main(void)
{
    TRISBbits.TRISB1=0;      //RB1 = OUTPUT
    TRISBbits.TRISB7=0;      //RB7 = OUTPUT
    TRISC = 255;             //PORTC = INPUT
    TRISD = 0;                //PORTD = OUTPUT
    T0CON=0x0;               //Timer 0, 16-bit mode, no prescaler
    TMR0H=0x35;              //load TH0
    TMR0L=0x00;              //load TL0
    T1CON=0x88;              //Timer 1, 16-bit mode, no prescaler
    TMR1H=0x35;              //load TH1
    TMR1L=0x00;              //load TL1
    INTCONbits.TMR0IF=0;      //clear TF0
    PIR1bits.TMR1IF=0;        //clear TF1
    INTCONbits.TMR0IE=1;       //enable Timer0 interrupt
    INTCONbits.TMR0IE=1;       //enable Timer1 interrupt
    T0CONbits.TMR0ON=1;        //turn on Timer0
    T1CONbits.TMR1ON=1;        //turn on Timer1
    INTCONbits.PEIE=1; //enable all peripheral interrupts
    INTCONbits.GIE=1; //enable all interrupts globally
    while(1) //keep looping until interrupt comes
    {
        PORTD=PORTC; //send data from PORTC to PORTD
    }
}


void T0_ISR(void)
{
    myPB1bit=~myPB1bit;      //toggle PORTB.1
    TMR0H=0x35;              //load TH0
    TMR0L=0x00;              //load TL0
    INTCONbits.TMR0IF=0;      //clear TF0
}

void T1_ISR(void)
{
    myPB7bit=~myPB7bit;      //toggle PORTB.7
}

```

External Hardware Interrupts


- ▶ PIC18 has 3 external hardware interrupts.
- ▶ Pins RB0, RB1 and RB2 are designated as INT0, INT1 and INT2.
- ▶ Upon activation of these pins, PIC18 gets interrupted in whatever it is doing and jumps to the vector table to perform ISR.
- ▶ They must be enabled before they can take effect.



Interrupt (Pin)	Flag bit	Register	Enable bit	Register
INT0 (RB0)	INT0IF	INTCON	INT0IE	INTCON
INT1 (RB1)	INT1IF	INTCON3	INT1IE	INTCON3
INT2 (RB2)	INT2IF	INTCON3	INT2IE	INTCON3

- Upon power-on reset, PIC18 makes INT0, INT1 and INT2 rising (positive) edge-triggered interrupts.

Program 11-4 connects a switch to INT0 and an LED to pin RB7. In this program, every time INT0 is activated, it toggles the LED, while at the same time data is being transferred from PORTC to PORTD.



```


    ORG 0000H
    GOTO MAIN          ;bypass interrupt vector table
;--on default all interrupts go to to address 00008
    ORG 0008H          ;interrupt vector table
    BTFSS INTCON,INT0IF ;Did we get here due to INT0?
    RETFIE             ;No. Then return to main
    GOTO INT0_ISR      ;Yes. Then go INT0 ISR
;--the main program for initialization
    ORG 00100H
MAIN BCF TRISB,7        ;PB7 as an output
        BSF TRISB,INT0   ;make INT0 an input pin
        CLRF TRISD        ;make PORTD output
        SETF TRISC        ;make PORTC input
        BSF INTCON,INT0IE  ;enable INT0 interrupt
        BSF INTCON,GIE    ;enable interrupts globally
OVER MOVFF PORTC,PORTD  ;send data from PORTC to PORTD
        BRA OVER           ;stay in this loop forever
;-----ISR for INT0
INT0_ISR
    ORG 200H
    BTG PORTB,7          ;toggle PB7
    BCF INTCON,INT0IF    ;clear INT0 interrupt flag bit
    RETFIE               ;return from ISR
    END
  
```

Negative edge-triggered interrupts

	INTEDG0	INTEDG1	INTEDG2				
--	---------	---------	---------	--	--	--	--

INTEDGx External Hardware Interrupt Edge trigger bit
0 = Interrupt on negative (falling) edge
1 = Interrupt on positive (rising) edge (Default for power-on reset)

In Program 11-5 we assume that pin RB1 (INT1) is connected to a pulse generator and the pin RB7 is connected to an LED. The program will toggle the LED on the falling edge of the pulse. In other words, the LED is turned on and off at the same rate as the pulses are applied to the INT1 pin.



```
ORG 0000H
GOTO MAIN          ;bypass interrupt vector table
;--on default all interrupts go to address 00008
ORG 0008H          ;interrupt vector table
BTFSS INTCON3,INT1IF ;Did we get here due to
                      ;INT1 interrupt?
RETFIE             ;No. Then return to main
GOTO INT1_ISR      ;Yes. Then go INT1 ISR
;--the main program for initialization
ORG 00100H
MAIN BCF TRISB,7    ;PB7 as an output
BSF TRISB,INT1     ;make INT1 an input pin

BSF INTCON3,INT1IE ;enable INT1 interrupt
BCF INTCON2,INTEDG1 ;make it negative
                      ;edge-triggered
BSF INTCON,GIE     ;enable interrupts globally
OVER BRA OVER       ;stay in this loop forever
;-----ISR for INT1
INT1_ISR
    ORG 200H
    BTG PORTB,7        ;toggle on RB7
    BCF INTCON3,INT1IF ;clear INT1 interrupt flag bit
    RETFIE
END
```