

## WPAN Technologies for IoT

This image is giving you a **big-picture comparison of wireless technologies used in IoT**. Here's the simple idea:

### ◇ What is WPAN?

- **WPAN (Wireless Personal Area Network)** is for **very short-range communication**
- Used in IoT devices like sensors, wearables, smart home gadgets
- Key features:
  - Short range (10–100 m)
  - Low power consumption
  - Low cost

**Examples shown:**

- Bluetooth
- Zigbee
- UWB (Ultra-Wideband)

### ◇ The Bigger Picture (3 Network Types)

The diagram compares **three wireless network categories**:

#### 1. WPAN (left side)

- Short range
- Low power
- Used for device-to-device communication  
Example: Bluetooth in smartwatches

#### 2. WLAN (middle)

- Medium range (100–1000 m)
- Higher data rates  
Example: WiFi (your home internet)

#### 3. WWAN (right side)

- Long range (5–100 km)
- Used for wide-area IoT and telecom  
Example: LTE-M, NB-IoT, LoRaWAN

#### ◇ What the diagram is showing overall

- As you move **left → right**:
  - Range increases 📶
  - Power consumption increases ⚡
  - Cost and complexity also increase

#### ◇ Simple takeaway

- **WPAN** = small, cheap, low-power (IoT sensors)
  - **WLAN** = home/office networks (WiFi)
  - **WWAN** = large-scale communication (cellular IoT)
- 

## IEEE 802.15.4 (LR-WPAN)

#### ◇ What is IEEE 802.15.4 (LR-WPAN)?

- It is a **wireless standard** for **Low-Rate Wireless Personal Area Networks (LR-WPAN)**
- Designed specifically for **IoT devices** that need **low power** and **low data rate**

#### ◇ Key Features

##### ✓ Supports many devices (Star topology)

- One central device (coordinator) connects many nodes
- Example: one hub controlling multiple sensors

##### ✓ Low power consumption

- Devices can run for months/years on battery
- Perfect for IoT like smart homes, agriculture sensors

## ✓ Reliable communication

- Stable for small data transmission (not heavy data like video)

### ◇ What does the standard define?

- **Physical Layer (PHY)** → how data is transmitted (frequency, signals)
- **MAC Layer (Medium Access Control)** → how devices share the wireless channel (who sends data and when)


### ◇ Simple idea

IEEE 802.15.4 = “**foundation technology**” for IoT networks

(It is used by technologies like Zigbee, Thread, etc.)

### ◇ One-line summary

It enables many low-power IoT devices to communicate efficiently over short distances.



This diagram is showing **how IEEE 802.15.4 fits into the network layer structure** (especially the **Data Link Layer**). Here's a quick and clear breakdown:

### ◇ Two Main Parts of Data Link Layer

The right side shows that the **Data Link Layer** has two sublayers:

1. **LLC (Logical Link Control)**
2. **MAC (Medium Access Control)**

### ◇ What IEEE 802.15.4 Does

IEEE 802.15.4 mainly defines:

#### ✓ MAC Layer (Medium Access Control)

- Controls **how devices share the wireless channel**
- Decides **who transmits and when**

#### ✓ Physical Layer (PHY)

- Handles **actual signal transmission** (frequency, modulation, etc.)

These two (MAC + PHY) are shown in green at the bottom.

### ◇ What About Upper Layers?

- **IEEE 802.2 (LLC)** sits above MAC
- It provides a **common interface** to higher-level protocols
- **Convergence sublayer** connects different technologies (like Zigbee) to 802.15.4

### ◇ Simple Flow

Upper layers (apps, protocols)



LLC (IEEE 802.2)



MAC (802.15.4) → controls access



Physical layer → sends signals over air


### ◇ One-line summary

**IEEE 802.15.4 handles how IoT devices access the channel and transmit data, while upper layers handle the actual application logic.**

## IEEE 802.15 WPAN

### IEEE 802.15 WPAN

- ▶ **MAC (Media Access Control)**  
Controls how devices access the medium
  - ▶ Frame transmission
  - ▶ MAC addresses
  - ▶ Channel access (CSMA/CA, etc.)
- ▶ **LLC (Logical Link Control)**  
Provides interface to upper layers
  - ▶ Flow control
  - ▶ Error control
  - ▶ Multiplexing protocols



This slide explains the **working layers of IEEE 802.15 (WPAN)** in a simple way:

### ◇ 1. MAC (Media Access Control)

- Controls **how devices use the wireless channel**
- Main functions:
  - **Frame transmission** → sending data packets
  - **MAC addressing** → unique ID for each device
  - **Channel access (CSMA/CA)** → avoids collisions (devices don't talk at the same time)

In short: **decides who can send data and when**

### ◇ 2. LLC (Logical Link Control)

Provides interface to upper layers

- Acts as a **bridge to upper layers (applications, protocols)**
- Main functions:
  - **Flow control** → manages data speed
  - **Error control** → detects/fixes errors
  - **Multiplexing** → allows multiple protocols to use the same link

In short: **manages data reliability and communication with higher layers**

### ◇ 3. Physical Layer (shown in diagram)

- Handles **actual transmission of signals over air** 

### ◇ Overall Flow

Upper layers (apps)



LLC → MAC → Physical layer



Data transmitted over wireless

### ◇ One-line summary

MAC controls access, LLC ensures smooth communication, and PHY sends the data physically.

---

## IEEE 802.15.4

This is a **comparison of IEEE wireless standards** used for different types of networks. Here's a simple explanation:

### ◇ IEEE 802.15.4 (Important one)

- Designed for **IoT and sensor networks**
- Features:
  - Very **low power consumption**
  - **Low data rate**
  - Short-range communication
- Defines:
  - **PHY layer (Physical)**
  - **MAC layer (Medium Access Control)**

Used in: **Zigbee, 6LoWPAN (IoT systems)**

### ◇ Other IEEE Standards (Comparison)

#### 1) IEEE 802.11 → WiFi

- High data rate 
- Medium range
- Used for internet (home, office)

#### 2) IEEE 802.15.1 → Bluetooth

- Short range
- Low power
- Device-to-device communication (earbuds, phones)

#### 3) IEEE 802.15.4 → Zigbee / 6LoWPAN

- Very low power + low data rate
- Sensor networks and IoT devices

#### 4) IEEE 802.16 → WiMAX

- **Metropolitan area networks**
- Long range broadband wireless
- Like city-wide internet access

##### ◇ Simple Comparison Idea

| Standard Technology Use |              |                         |
|-------------------------|--------------|-------------------------|
| 802.11                  | WiFi         | Internet                |
| 802.15.1                | Bluetooth    | Short device connection |
| 802.15.4                | Zigbee / IoT | Sensors, smart devices  |
| 802.16                  | WiMAX        | City-wide broadband     |

##### ◇ Final Summary

IEEE standards define different wireless technologies based on **range, speed, and power usage**:

- WiFi = fast internet
- Bluetooth = small device communication
- 802.15.4 = low-power IoT networks
- WiMAX = long-distance broadband

---

## MAC Functions

These are the **main MAC (Medium Access Control) functions** in IEEE 802.15.4, explained simply:

### 1. Beacon Management

- The coordinator sends **beacon signals**
- Beacons help devices:
  - Know the network is active
  - Sync their timing

- Used in **low-power IoT networks**

**Simple idea:** *"Hello, network is alive" signal*

## 2. Channel Access

- Decides **who can use the wireless channel**
- Uses methods like **CSMA/CA**
  - Devices listen before sending data
- Prevents **data collisions**

**Simple idea:** *"Wait your turn before talking"*

## 3. Frame Formatting

- Organizes data into **frames (packets)**
- Adds:
  - Source address
  - Destination address
  - Control info

**Simple idea:** *"Properly packing data for sending"*

## 4. Acknowledgments (ACK)

- Confirms if data is received successfully
- Receiver sends **ACK signal**
- If no ACK → data is resent

**Simple idea:** *"Yes, I got your message"*

## 5. Network Topology

- Defines how devices are arranged:
  - Star topology ★ (common in 802.15.4)
  - Mesh topology (multi-hop in some IoT systems)

**Simple idea:** *"How devices are connected in the network"*



## ◇ Final Summary

MAC layer in IEEE 802.15.4 handles:

- Communication timing (beacons)
- Channel sharing (access control)
- Data packaging (frames)
- Delivery confirmation (ACKs)
- Network structure (topology)



---

## Key Characteristics of IEEE 802.15.4

Here's a **simple and clear explanation** of the key characteristics of **IEEE 802.15.4**:

### 1. Low Data Rate

- It sends **small amounts of data only**
- Speed is usually **few Kbps to a few hundred Kbps**
- Best for **sensor data (temperature, humidity, etc.)**

Idea: *Not for video or heavy data, only small packets*

### 2. Low Power Consumption

- Designed to **save battery power**
- Devices stay in **sleep mode most of the time**
- Wake up only when sending/receiving data

Idea: *Perfect for battery-powered IoT devices*

### 3. Short-Range Communication

- Works within **10 to 100 meters**
- Suitable for **small areas like rooms or buildings**

Idea: *Not for long-distance communication*

These key characteristics collectively make IEEE 802.15.4 an excellent choice for applications where conserving power, achieving low data rates, and maintaining short-range communication are essential. Examples of such applications include wireless sensor networks, industrial automation, home automation (smart home devices), and various IoT deployments. IEEE 802.15.4's efficiency in addressing these specific requirements contributes to its widespread adoption in these domains.

### ◇ Overall Purpose

IEEE 802.15.4 is designed for:

- IoT devices
- Sensor networks
- Smart homes
- Industrial monitoring

### ◇ Final Simple Summary

**IEEE 802.15.4 = low speed + low power + short range = perfect for IoT sensors**

---

## Network Topologies in IEEE 802.15.4

### ◇ 1. Star Topology ★

#### Description:

- All devices connect to **one central coordinator (hub)**
- Devices **cannot talk directly** to each other

#### Advantages:

- Easy to set up
  - Simple control
  - Fast communication with coordinator
- . Use Cases: Home automation, sensor networks in small areas, smart lighting systems.

#### Example:

Smart home sensors → send data to one hub

### 2. Peer-to-Peer (P2P) 🔗

- Devices communicate **directly with each other**
- No central controller needed

#### Advantages:

- No single point of failure
  - Low delay
- Use Case:  
Device to Device,  
ad-hoc networks,  
short-range data transfer

- Flexible communication

**Example:**

Two devices transferring data directly

### 3. Mesh Topology

- Devices are **interconnected**
- Data can travel through **multiple paths**
- Devices help relay data for others

**Advantages:**

- Very reliable (self-healing)
- Long range coverage

**Use Case:**

Wireless sensor networks,  
industrial automation  
smart city application



If one link fails, another works

**Example:**

Smart city or large sensor networks

### 4. Cluster Tree Topology star + mesh

- Combination of **star + hierarchy**
- Structure:
  - Main coordinator (root)
  - Cluster heads
  - Leaf nodes

Each cluster head, in turn,  
communicates with leaf nodes

**Advantages:**

- Good for large networks
- Efficient power usage
- Organized structure

**Use Case:**

Zigbee-based smart home networks,  
industrial control systems

**Example:**

Industrial monitoring systems

---

## 5. Hybrid Topology

- Mix of multiple topologies (star, mesh, etc.)
- Designed based on needs

### Advantages:

- Very flexible
- Optimized for complex systems

### Example:

Large IoT systems (smart cities, factories) + complex industrial automation systems

### ◇ Final Simple Summary

IEEE 802.15.4 supports different network structures:

-  Star → simple & centralized
-  P2P → direct communication
-  Mesh → reliable & long range
-  Cluster Tree → hierarchical large networks
-  Hybrid → combination of all

---

## Applications of IEEE 802.15.4

### 1. Wireless Sensor Networks (WSN)

- Uses small sensor nodes to **collect and send data wirelessly**
- Data is sent to a central system

### Used in:

- Temperature, humidity, air quality monitoring
- Agriculture and wildlife tracking + structural health monitoring

## 2. Industrial Automation

- Connects sensors, machines, and controllers in factories

-  • Helps in real-time monitoring and control

Used in:

- Factory automation
- Predictive maintenance
- Equipment monitoring

## 3. Smart Home (Home Automation)

- Connects smart devices wirelessly in homes
- Improves comfort and energy efficiency

Used in:

- Smart lights
- Smart locks
- Security systems
- Thermostats

## 4. Healthcare & Medical Monitoring

- Used in wearable or medical devices
-  • Sends patient data wirelessly to doctors

Used in:

- Heart rate monitoring
- Fall detection
- Remote patient tracking

## 5. Environmental Monitoring

- Collects data from remote or dangerous areas
- Works in places where human access is difficult

### Used in:

- Forest fire detection
- Air quality monitoring
- Water pollution monitoring

### ◇ Final Summary


IEEE 802.15.4 is mainly used in **low-power IoT systems** like:

- Smart homes 🏠
- Industry 🏭
- Healthcare 🏥
- Environment 🌍
- Sensor networks 📡

## 802.15.4

### 802.15.4


- ▶ 802.15.4 uses carrier-sense multiple access with collision avoidance (CSMA/CA).



Here's a **brief and simple explanation** of your IEEE 802.15.4 notes:

### ◇ CSMA/CA (Channel Access Method)

- IEEE 802.15.4 uses **CSMA/CA (Carrier Sense Multiple Access with Collision Avoidance)**
- Devices first **listen to the channel before sending data**
- If channel is busy → they wait



**Simple idea:** “Check before you talk to avoid collision”

---

## Nodes of 802.15.4

### ◇ PAN Coordinator

- Main **central device of the network**
- Each network has **only ONE PAN coordinator**
- It:
  - 4 ○ Creates the network
  - Selects **RF channel**
  - Assigns **PAN ID (network ID)**

Other devices must **request permission (association request)** to join

### ◇ FFD (Full Function Device)

- Powerful devices in the network
- Can:
  - Send and receive data
  - **Relay (forward) messages**
  - Act as coordinator or router

✦ Used as **network backbone nodes**

### ◇ RFD (Reduced Function Device)

- Simple, low-power devices
- Can only:
  - Send and receive data (not routing)

**Usually:**

- Sleep most of the time 🪫
- Work as **end/leaf nodes** (like sensors)

T  
in  
  
T  
co  
  
C  
th  
re  
  
A  
the PAN coordinator or any FFD as their parent

Reduced Function Devices (RFD):

They cannot route messages.

Usually, their receivers are switched off except during transmission.

They can be attached to the network only as leaf nodes.

Each network, identified by its PAN ID, is called a cluster

### ◇ Network Structure Idea

- PAN Coordinator → starts network
- FFD → helps expand and route network
- RFD → simple end devices

Each network (PAN ID) = called a **cluster**


### ◇ Final Summary

IEEE 802.15.4 network works like this:

- CSMA/CA avoids collisions
- PAN coordinator controls the network
- FFDs help route data
- RFDs act as simple sensors

---

## Two topologies in 802.15.4





## Access Control Methods

### ◆ Access Control Methods (MAC Layer)

IEEE 802.15.4 uses **two ways to control** how devices access the channel:

#### 1. Beacon-Enabled (Slotted CSMA/CA)

- PAN coordinator sends **beacons periodically**
- Network is divided into a superframe
  - Beacon → time slots → optional sleep period
- Devices transmit only in their assigned time slots

##### Advantages:

- Organized communication
- Low power (devices sleep in inactive period)

**Idea:** *Scheduled communication like a timetable*

#### 2. Non-Beacon Enabled (Unslotted CSMA/CA)

- No regular beacons
- Devices use **CSMA/CA** (listen before talk)
- Coordinator sends beacon only if requested

##### Advantages:

- Simple and flexible
- Used in **Zigbee and 6LoWPAN**

**Idea:** *Free access, but still avoid collisions*

- All nodes access the network using CSMA/CA. The coordinator provides a beacon only when requested by a node
-

## Uses of 802.15.4

### ◇ What IEEE 802.15.4 provides

- Gives **MAC + PHY layer support**
- Helps higher protocols (like Zigbee, 6LoWPAN) to send data **securely**
- Handles **basic wireless communication**

### ◇ Limitations

- No **fragmentation & reassembly** (large data must be handled by upper layers)
- Very **low bandwidth**
- Cannot send data continuously (not for streaming)

### ◇ So where is it used?

Because of these limits, it is mainly used for:

**Sensor networks**

**IoT devices**

**Industrial automation**

**Smart monitoring systems**

**1)** 802.15.4 provides all the MAC and PHY level mechanisms required by higher level protocols to exchange packets securely.

**2)** It does not provide a fragmentation and reassembly mechanism.

**3)** Bandwidth is also very limited, Packets cannot be sent continuously.

**4)** With these limitations in mind, 802.15.4 is clearly targeted at sensor and automation applications.

---

## Zigbee

### ◇ What is Zigbee?

- A wireless communication technology based on IEEE 802.15.4
- Designed for IoT applications

## ◇ Key Features

Low power consumption

- Uses sleep modes → long battery life

Low data rate

- Suitable for small data (sensor readings)

Supports mesh networks

- Devices can relay data → increases range & reliability

Low-duty cycle

- Devices stay OFF most of the time → save energy

## ◇ Comparison

- Zigbee vs Wi-Fi → Zigbee uses much less power
- Zigbee vs Bluetooth → Zigbee is better for large networks

☞ Wi-Fi & Bluetooth = higher power

☞ Zigbee = energy-efficient IoT solution

## ◇ Communication Type

- Supports two-way communication

- Sensor → controller
- Controller → sensor



Zigbee is primarily used for two-way communication between a sensor and a control system

## ◇ Uses

Smart homes (lights, locks)

Industrial automation

Sensor networks

## ◇ Final Summary

☞ Zigbee = low power + low data rate + mesh networking → ideal for IoT devices

---

## Features of Zigbee

### 1. Low Power Consumption

- Devices use very little energy
- Can run on batteries for months or years

### 2. Mesh Networking

- Devices can relay data through each other
- Increases range and reliability

### 3. Large-Scale Deployments

- Can support many devices (hundreds or thousands)
- Suitable for big IoT systems

### 4. Security

- Provides encryption and authentication
- Keeps data safe from unauthorized access

### 5. Interoperability

- Devices from different manufacturers can work together
- Ensures compatibility in IoT systems

#### ◇ Important Point


Zigbee works on top of IEEE 802.15.4

- 802.15.4 → provides PHY + MAC layers
- Zigbee → adds network + application layers

#### ◇ Final Summary

Zigbee = secure, low-power, scalable, mesh-based IoT communication protocol built on IEEE 802.15.4

---



Here's a **simple and brief explanation** of your **Zigbee + IEEE 802.15.4** layers and topologies:

### ◇ Zigbee Protocol Stack (Layers)

Zigbee works in layers, built **on top of IEEE 802.15.4**:

#### 1. Application Layer

- Top layer
- Handles **user applications** (smart home, sensors, etc.)

#### 2. Network Layer

- Responsible for **routing and network formation**
- Manages how data travels between devices
- Enables **mesh networking**

#### 3. Data Link Layer (MAC)

- Uses **CSMA/CA** (avoid collisions)
- Controls **how devices access the channel**

#### 4. Physical Layer

- Handles **actual transmission**
- Works at **2.4 GHz frequency**
- Data rate up to **250 kbps**

#### ◇ Relation with IEEE 802.15.4

- IEEE 802.15.4 provides:

- PHY layer
- MAC layer

- Zigbee adds:

- Network layer
- Application layer

So Zigbee = **complete protocol stack for IoT**

#### ◇ Zigbee Network Topologies

**Star** → central coordinator

**Mesh (Peer-to-Peer)** → devices relay data

**Cluster Tree** → hierarchical structure

#### ◇ Final Summary

IEEE 802.15.4 = lower layers (PHY + MAC)


Zigbee = adds network + application → complete IoT system

## Network Topologies

### Network Topologies

#### ▪ Star

- Network controlled and initiated by central PAN (Personal Area Network)
- End Devices communicate directly with Coordinator




#### ▪ Tree

- Tree structure rooted at the PAN coordinator
- Coordinator initiates network
- Children route through Parents in strict hierarchy
- Not always appropriate for low-latency applications



#### ▪ Mesh

- Messages may be routed from any source to any destination
- Every fixed function device can be a router for its neighbors
- Multi-hop topology extends range of the network
- High reliability achieved through multiple paths



● Coordinator  
● Full Function Device (FFD)  
○ Reduced Function Device (RFD)

### 1. Star Topology

- Network is controlled by a **PAN Coordinator**
- All **end devices connect directly to the coordinator**
- No communication between devices

✓ Simple and easy

✓ Low delay (fast response)

**Best for:** small networks (smart homes)

### 2. Tree Topology

- Hierarchical structure:
  - **PAN Coordinator (root)**
  - Parent devices
  - Child devices
- Data flows **parent → child (fixed path)**

✓ Organized and scalable

✗ Can have delay (not good for low-latency)

**Best for:** structured large networks

### 3. Mesh Topology

- Devices can **communicate with any other device**
- Each **FFD acts as a router** for its neighbors
- Data travels via **multiple paths (multi-hop)**

✓ Very reliable (self-healing)

✓ Extended range

**Best for:** smart cities, industrial IoT

#### ◇ Device Types in Network

- **Coordinator (C)** → starts and manages network
- **FFD (Full Function Device)** → can route data

- **RFD (Reduced Function Device)** → simple end device (no routing)

#### ◇ Final Summary

- Star → simple, central control
  - Tree → hierarchical, structured
  - Mesh → flexible, reliable, long-range
- 

## Zigbee Architecture

- Zigbee uses a **layered architecture**
- Each layer has a specific function and works together to provide communication

#### ◇ Why this architecture is important

These layers make Zigbee very useful for IoT because it provides:

##### 1) Low cost

- Simple hardware → affordable devices

##### 2) Easy implementation

- Simple design → easy to develop and deploy

##### 3) Reliable data transfer

- Uses acknowledgments and routing for stable communication

##### 4) Short-range operation

- Designed for nearby devices (home, office, industry)

##### 5) Very low power consumption

- Devices can run for long time on batteries

##### 6) Security

- Supports encryption and secure communication



## ◇ Simple Idea

Zigbee's layered design helps it become:

**cheap + simple + reliable + energy-efficient = perfect for IoT**

---

## Zigbee Device Types

### 1. Coordinator (ZC)

- **Main device of the network**
- **Starts and manages the network**
- **Assigns addresses to other devices**

. It is the root of network tree and a bridge to other network

. Able to store information about the network

✓ **Only one coordinator in each network**

### 2. Full Function Device (FFD)

- **Can perform all functions**
- **Can:**
  - **Send/receive data**
  - **Act as a router**
  - **Communicate with any device**

✓ **Helps extend network range**

### 3. Reduced Function Device (RFD)

- **Simple, low-power device**
- **Can only:**
  - **Send/receive data**
- **Cannot route data**

. Device capable of talking in the network  
. It cannot relay data from other devices  
. Less memory  
. Cheaper than FFD

✓ **Works as end device (leaf node)**

✓ **Sleeps most of the time to save battery** 

### ◇ Simple Network Idea

- Coordinator → controls network
- FFD → routes and forwards data
- RFD → simple sensor devices

### ◇ Final Summary

Zigbee devices are:

- Coordinator → brain
  - FFD → routers
  - RFD → end devices
- 

## Zigbee Coordinator Node (ZCN):

- It is the main/root device of the network
- Starts and forms the network (like a master device)

### ◇ Key Functions

#### 1) Root of network tree

- All devices connect directly or indirectly through it

#### 2) Bridge to other networks

- Can connect Zigbee network to other systems (e.g., internet)

#### 3) Stores network information

- Keeps details about devices, addresses, and structure

#### 4) Only one coordinator

- Each Zigbee network has exactly one ZC

#### 5) Security manager

- Stores and manages security keys
- Ensures secure communication between devices

### ◇ Simple Idea

Zigbee Coordinator = “brain + manager + security center” of the network

### ◇ Final Summary

It initializes the network, manages devices, stores data, and handles security making it the most important node in Zigbee.

---

## Zigbee Full Function Device (FFD)

- Acts as an **intermediate router**
- Can **send, receive, and forward data**

### Features:

- Can work in **all topologies** (star, mesh, tree)
- Can **relay messages** for other devices
- Can even act as a **coordinator (if needed)**
- **Less memory & cost than coordinator**, but more than RFD

**Simple idea:** “Router of the Zigbee network”

---



## Zigbee Reduced Function Device (RFD)

- Simple **end device**
- Can only **send and receive data**

### Features:

- Cannot relay/route data
- Uses **very little memory**
- **Cheaper than FFD**
- Communicates only with **parent (usually coordinator or FFD)**
- Sleeps most of the time → saves power

Simple idea: "Simple sensor device"



## Characteristics

Here's a **brief and simple explanation** of these Zigbee (or IEEE 802.15.4) **Characteristics**:

### ◇ Key Characteristics



#### 1) Low Power Consumption

- Devices use very little energy
- Battery life can last **months to years**

#### 2) High Node Density

- Can support **many devices in one network**
- Suitable for large IoT systems

#### 3) Low Cost

- Simple hardware → cheaper devices
- Ideal for mass deployment

#### 4) Simple Implementation

- Easy to design and install
- Less complex compared to WiFi

#### 5) Low Data Rate

- Sends **small amounts of data only**
- Not suitable for heavy data (video, audio)

#### 6) Small Packet Size

- Data is sent in **small packets**
- Perfect for sensor readings

#### ◇ Final Summary

**Zigbee = low power + low cost + many devices + small data → ideal for IoT systems**

---

