
### IA-32 Architecture

# Computer Organization and Assembly Languages

#### Virtual machines



#### Abstractions for computers

High-Level Language

Level 5

Assembly Language

Level 4

Operating System

Level 3

Instruction Set Architecture

Level 2

Microarchitecture

Level 1


Digital Logic

Level 0

#### Truth tables


• Example:  $(Y \land S) \lor (X \land \neg S)$ 


X	Y	S	$(\mathbf{Y} \wedge \mathbf{S}) \vee (\mathbf{X} \wedge \neg \mathbf{S})$
F	F	F	F
F	Т	F	F
Т	F	F	T
Т	T	F	T
F	F	T	F
F	Т	Т	Т
Т	F	Т	F
Т	Т	Т	Т




Two-input multiplexer


### Combinational logic










### Sequential logic






### Memory





8K 8-bit memory

#### Virtual machines



#### Abstractions for computers

High-Level Language

Assembly Language

Level 4

Level 5

Operating System

Level 3

Instruction Set Architecture

Level 2


Microarchitecture

Level 1

Digital Logic

Level 0


### Instruction set



OPCODE	MNEMONIC	OPCODE	MNEMONIC	
0	NOP	A	CMP addr	
1	LDA addr	В	JG addr	
2	STA addr	С	JE addr	
3	ADD addr	D	JL addr	
4	SUB addr			
5	IN port			
6	OUT port			
7	JMP addr			
8	JN addr			
9	HLT			

OPCODE	OPERAND
4	12

#### Virtual machines




#### Abstractions for computers

High-Level Language Level 5 Assembly Language Level 4 Operating System Level 3 Instruction Set Level 2 Architecture Microarchitecture Level 1 Digital Logic Level 0


### Basic microcomputer design




- clock synchronizes CPU operations
- control unit (CU) coordinates sequence of execution steps
- ALU performs arithmetic and logic operations




### Basic microcomputer design




- The memory storage unit holds instructions and data for a running program
- A bus is a group of wires that transfer data from one part to another (data, address, control)



#### Clock





- synchronizes all CPU and BUS operations
- machine (clock) cycle measures time of a single operation
- clock is used to trigger events



- Basic unit of time, 1GHz→clock cycle=1ns
- A instruction could take multiple cycles to complete, e.g. multiply in 8088 takes 50 cycles


### Instruction execution cycle







- Fetch
- Decode
- Fetch operands
- Execute
- Store output


### A simple microcomputer







### **ALU** and Flag







### **Flags**







### Control signals (20 in total)







# LDA (execution cycle 1): IR<sub>RD</sub>







# LDA (execution cycle 2): $MEM_{RD}$







# LDA (execution cycle 3): ACC<sub>WR</sub>







### **ALU** and Flag







# ADD (execution cycle 1): $IR_{RD}$







# ADD (execution cycle 2): $MEM_{RD}$







# ADD (execution cycle 3): $B_{WR}$







# ADD (execution cycle 4): $ALU_{10}$ , $ACC_{WR}$







### **Flags**







# JMP (execution cycle 1): IR<sub>RD</sub>







# JMP (execution cycle 2): PC<sub>WR</sub>







# JG (execution cycle 1): $IR_{RD}$ , $FLAG_{RD}$







# JG (execution cycle 2): FLAG<sub>01</sub>







### Microcode sequence







#### Decoder






### Control and sequencing unit






## Control and sequencing unit



		PC <sub>RD</sub>	$MEM_{RD}$	MEM <sub>v</sub>	$_{ m WR}$ ${ m IR}_{ m WR}$	$PC_{INC}$		
NOP	0000	1	0	0	0	0	0	
fetch	0001	0	1	0	0	0		
	0002	0	0	0	1	1		
docada	0003	$IR_{RD}$						
decode	0004	DEC	ODER <sub>RD</sub>					
	0005	μPC <sub>ν</sub>	ODER <sub>RD</sub>					
LDAfetch decode								
exec	0006	$IR_{RD}$						
	0007	MEM	RD					
	8000	ACC,	VR					
	000F							
L								


#### Virtual machines



#### Abstractions for computers


High-Level Language Level 5 Assembly Language Level 4 Operating System Level 3 Instruction Set Level 2 Architecture Microarchitecture Level 1 Digital Logic Level 0

### X=min of X,Y,Z



```
. DATA
int X=7; Y=2; Z=9;
                                  X 007
                                  Y 002
if (X>Y) then
                                  z 009
  if (Y>Z) then
                                  . CODE
                                     LDA X
    X=Z;
                                     CMPY
                                     JG L1
  else
                                     CMPZ
    X=Y;
                                     JL LO
                                     JMP
                                           END
                      compiler
  end
                                  LO LDAZ
else
                                     STAX
                                  L1 LDAY
  if (X<Z) then
                                     CMPZ
                                     JG L2
    X=Z;
                                     STAX
  end
                                     JMPEND
                   else?
                                  L2 LDAZ
end
                                     STAX
                                  ENDHLT
```


#### Virtual machines




#### Abstractions for computers


High-Level Language Level 5 Assembly Language Level 4 Operating System Level 3 Instruction Set Level 2 Architecture Microarchitecture Level 1 Digital Logic Level 0

## Memory layout






# X=min of X,Y,Z



. Di	ATA	
X	007	
Y	002	
Z	009	
. Co	ODE	
	LDA	X
	CMP	Y
	JL	L1
	LDA	Y
L1	CMP	Z
	JL L2	
	LDA	Z
<b>L2</b>	STA	X
	HLT	

. D	ATA	
X	007	
Y	002	
Z	009	
. C	ODE	
	LDA	Y
	CMP	Z
	JL	L1
	LDA	Z
L1	CMP	X
	JG	END
	STA	X
EN	D HI	T

# X=min of X,Y,Z




	. DATA								
	X	007							
	Y	002							
	Z	009							
	.C	ODE							
0		LDA	Y						
1		CMP	Z						
2		JL	L1						
3		LDA	Z						
4	L1	CMP	X						
5		JG	END						
6		STA	X						
7	EN	D HL	T						

1401
A402
D004
1402
<b>A400</b>
B007
2400
9000


Х	400
Y	401
Z	402

L1	4
END	7



### Advanced architecture

### Multi-stage pipeline




- Pipelining makes it possible for processor to execute instructions in parallel
- Instruction execution divided into discrete stages

# Stages S1 S2 S3 S4

Example of a non-pipelined processor. For example, 80386.
Many wasted cycles.

	S1	S2	S3	S4	S5	S6
1	I-1					
2		I-1				
3			I-1			
4				I-1		
5					I-1	
6						I-1
7	I-2					
8		I-2				
9			I-2			
10				I-2		
11					I-2	
12						I-2

### Pipelined execution



 More efficient use of cycles, greater throughput of instructions: (80486 started to use pipelining)

Stages

	U	7
ł	1	)
	C	5
	-	_
1	_	
(	_	)


	S1	S2	S3	S4	S5	S6
1	I-1					
2	I-2	I-1				
3		I-2	I-1			
4			I-2	I-1		
5				I-2	I-1	
6					I-2	I-1
7						I-2

For *k* stages and *n* instructions, the number of required cycles is:

$$k + (n - 1)$$

compared to k\*n

### Wasted cycles (pipelined)



 When one of the stages requires two or more clock cycles, clock cycles are again wasted.

Stages

exe


	S1	S2	S3	S4	S5	S6
1	I-1					
2	I-2	I-1				
3	I-3	I-2	I-1			
4		I-3	I-2	I-1		
5			I-3	I-1		
6				I-2	I-1	
7				I-2		I-1
8				I-3	I-2	
9				I-3		I-2
10					I-3	
11						I-3

For *k* stages and *n* instructions, the number of required cycles is:

$$k + (2n - 1)$$

Cycles

### Superscalar



A superscalar processor has multiple execution pipelines. In the following, note that Stage S4 has left and right pipelines (u and v).

S.	tag	jes
----	-----	-----

0.1

		54 —						
_		S1	S2	S3	u	٧	S5	S6
	1	I-1						
	2	I-2	I-1					
	3	I-3	I-2	I-1				
	4	I-4	I-3	I-2	I-1			
	5		I-4	I-3	I-1	I-2		
	6			I-4	I-3	I-2	I-1	
	7				I-3	I-4	I-2	I-1
	8					I-4	I-3	I-2
	9						I-4	I-3
	10							I-4


For *k* states and *n* instructions, the number of required cycles is:

$$k + n$$


Pentium: 2 pipelines

Pentium Pro: 3


### Reading from memory



 Multiple machine cycles are required when reading from memory, because it responds much more slowly than the CPU. The four steps are:



### Cache memory



- High-speed expensive static RAM both inside


  Because conventional memory is so much slower than the CPU, computers use


  and outside the CPU high-speed cache memory to hold the most recently used instructions and data.

  The first time a program reads a block of data, it leaves a copy in the cache. If
  the program needs to read the same data a second time, it looks for the data in
  - Level-1 cache: inside the CPU
  - Level-2 cache: outside the CPU
- Cache hit: when data to be read is already in


  A cache hit indicates the data is in cache; a cache miss indicates the data is not in cache and must be read from conventional memory. In general, cache memory has a noticeable effect on improving access to data, particularly when the cache is large.
- Cache miss: when data to be read is not in cache memory. When? compulsory, capacity and conflict.
- Cache design: cache size, n-way, block size, replacement policy

#### How a program runs






### Multitasking



- OS can run multiple programs at the same time.
- Multiple threads of execution within the same program.
- Scheduler utility assigns a given amount of CPU time to each running program.
- Rapid switching of tasks
  - gives illusion that all programs are running at once
  - the processor must support task switching
  - scheduling policy, round-robin, priority


### IA-32 Architecture

#### IA-32 architecture



- From 386 to the latest 32-bit processor, P4
- From programmer's point of view, IA-32 has not changed substantially except the introduction of a set of high-performance instructions

### Modes of operation



Protected mode

Protected mode is the native state of the processor, in which all instructions and features are available. Programs are given separate memory areas named segments, and the processor prevents programs from referencing memory outside their assigned segments.

- native mode (Windows, Linux), full features, separate memory
- Virtual-8086 mode

if an MS-DOS program crashes or attempts to write data into the system memory area, it will not affect other programs running at the same time.


- hybrid of Protected
- each program has its own 8086 computer
- Real-address mode

Real-address mode implements the programming environment of the Intel 8086 processor with a few extra features, such as the ability to switch into other modes.

- native MS-DOS
- System management mode
  - power management, system security, diagnostics


System Management mode (SMM) provides an operating system with a mechanism for implementing functions such as power management and system security. These functions are usually implemented by computer manufacturers who customize the processor for a particular system setup

### Addressable memory



- Protected mode
  - 4 GB
  - 32-bit address
- Real-address and Virtual-8086 modes
  - 1 MB space
  - 20-bit address

### General-purpose registers



Named storage locations inside the CPU, optimized for speed.

#### 32-bit General-Purpose Registers

EAX	
EBX	
ECX	
EDX	

EBP	
ESP	
ESI	
EDI	

#### EFLAGS


FIP	
<u> </u>	

#### 16-bit Segment Registers


CS	
SS	
DS	

	ES	
	FS	
	GS	
$\overline{}$		

#### Accessing parts of registers




- Use 8-bit name, 16-bit name, or 32-bit name
- Applies to EAX, EBX, ECX, and EDX



32-bit	16-bit	8-bit (high)	8-bit (low)
EAX	AX	АН	AL
EBX	BX	ВН	BL
ECX	CX	СН	CL
EDX	DX	DH	DL


### Index and base registers



 Some registers have only a 16-bit name for their lower half. The 16-bit registers are usually used only in real-address mode.

32-bit	16-bit
ESI	SI
EDI	DI
EBP	BP
ESP	SP


## Some specialized register uses (1 of 2)



#### General-Purpose

- EAX accumulator (automatically used by division and multiplication)
- ECX loop counter
- ESP stack pointer (should never be used for arithmetic or data transfer)
- ESI, EDI index registers (used for high-speed memory transfer instructions)
- EBP extended frame pointer (stack)


### Some specialized register uses (2 of 2)



#### Segment


- CS code segment
- DS data segment
- SS stack segment
- ES, FS, GS additional segments
- EIP instruction pointer
- EFLAGS
  - status and control flags
  - each flag is a single binary bit (set or clear)

### Status flags




- Carry
  - unsigned arithmetic out of range
- Overflow
  - signed arithmetic out of range
- Sign
  - result is negative
- Zero
  - result is zero
- Auxiliary Carry
  - carry from bit 3 to bit 4
- Parity
  - sum of 1 bits is an even number

### Floating-point, MMX, XMM registers



- Eight 80-bit floating-point data registers
  - ST(0), ST(1), . . . , ST(7)
  - arranged in a stack
  - used for all floating-point arithmetic
- Eight 64-bit MMX registers
- Eight 128-bit XMM registers for single-instruction multiple-data (SIMD) operations



Opcode Register


# IA-32 Memory Management

#### Real-address mode




- 1 MB RAM maximum addressable (20-bit address)
- Application programs can access any area of memory
- Single tasking
- Supported by MS-DOS operating system


### Segmented memory



Segmented memory addressing: absolute (linear) address is a combination of a 16-bit segment value added to a 16-bit offset



#### Calculating linear addresses




- Given a segment address, multiply it by 16 (add a hexadecimal zero), and add it to the offset
- Example: convert 08F1:0100 to a linear address

```
Adjusted Segment value: 0 8 F 1 0
Add the offset: 0 1 0 0
Linear address: 0 9 0 1 0
```

 A typical program has three segments: code, data and stack. Segment registers CS, DS and SS are used to store them separately.

#### Example



# What linear address corresponds to the segment/offset address 028F:0030?

In real-address mode, the linear (or absolute) address is 20 bits, ranging from 0 to FFFFF hexadecimal. Programs cannot use linear addresses directly, so addresses are expressed using two 16-bit integers. A segment-offset address includes the following:

028F0 + 0030 = 02920

- A 16-bit segment value, placed in one of the segment registers (CS, DS, ES, SS)
- A 16-bit offset value

#### Always use hexadecimal notation for addresses.

The CPU automatically converts a segment-offset address to a 20-bit linear address. Suppose a variable's hexadecimal segment-offset address is 08F1:0100. The CPU multiplies the segment value by 16 (10 hexadecimal) and adds the product to the variable's offset:

08F1h \* 10h = 08F10h Adjusted Segment value: 0 8 F 1 0 Add the offset: 0 1 0 0 Linear address: 0 9 0 1 0

### Example




What segment addresses correspond to the linear address 28F30h?

Many different segment-offset addresses can produce the linear address 28F30h. For example:

28F0:0030, 28F3:0000, 28B0:0430, . . .

### Protected mode (1 of 2)



- 4 GB addressable RAM (32-bit address)
  - (0000000 to FFFFFFFh)
- Each program assigned a memory partition which is protected from other programs
- Designed for multitasking
- Supported by Linux & MS-Windows

Protected mode is the more powerful "native" processor mode. When running in protected mode, a program's linear address space is 4 GBytes, using addresses 0 to FFFFFFF hexadecimal. In the context of the Microsoft Assembler, the flat segmentation model is appropriate for protected mode programming. The flat model is easy to use because it requires only a single 32-bit integer to hold the address of an instruction or variable. The CPU performs address calculation and translation in the background, all of which are transparent to application programmers. Segment registers (CS, DS, SS, ES, FS, GS) point to segment descriptor tables, which the operating system uses to keep track of locations of individual program segments. A typical protected-mode program has three segments: code, data, and stack, using the CS, DS, and SS segment registers:


- CS references the descriptor table for the code segment
- DS references the descriptor table for the data segment
- SS references the descriptor table for the stack segment

#### Protected mode (2 of 2)




- Segment descriptor tables
- Program structure
  - code, data, and stack areas
  - CS, DS, SS segment descriptors
  - global descriptor table (GDT)
- MASM Programs use the Microsoft flat memory model


### Multi-segment model




- Each program has a local descriptor table (LDT)
  - holds descriptor for each segment used by the program




### Flat segmentation model



- All segments are mpped to the entire 32-bit physical address space, at least two, one for data and one for code in the flat segmentation model, all segments are mapped to the entire 32-bit physical address space of the computer. At least two segments are required, one for code and one for data.
   Each segment is defined by a segment descriptor, a 64-bit integer stored in a table known as the global descriptor table (GDT)
- global descriptor table (GDT)



### **Paging**



- Virtual memory uses disk as part of the memory, thus allowing sum of all programs can be larger than physical memory
- Divides each segment into 4096-byte blocks called pages
- Page fault (supported directly by the CPU) issued by CPU when a page must be loaded from disk
- Virtual memory manager (VMM) OS utility that manages the loading and unloading of pages \

x86 processors support paging, a feature that permits segments to be divided into 4,096-byte blocks of memory called pages. Paging permits the total memory used by all programs running at the same time to be much larger than the computer's physical memory.

Paging is an important solution to a vexing problem faced by software and hardware designers. A program must be loaded into main memory before it can run, but memory is expensive. Users want to be able to load numerous programs into memory and switch among them at will. Disk storage, on the other hand, is cheap and plentiful. Paging provides the illusion that memory is almost unlimited in size. Disk access is much slower than main memory access, so the more a program relies on paging, the slower it runs.


When a task is running, parts of it can be stored on disk if they are not currently in use. Parts of the task are paged (swapped) to disk. Other actively executing pages remain in memory. When the processor begins to execute code that has been paged out of memory it issues a page fault, causing the page or pages containing the required code or data to be loaded back into memory. To see how this works, find a computer with somewhat limited memory and run many large applications at the same time. You should notice a delay when switching from one program to another because the operating system must transfer paged portions of each program into memory from disk. A computer runs faster when more memory is installed because large application files and programs can be kept entirely in memory, reducing the amount of paging.

# Components of an IA-32 microcomputer

## Components of an IA-32 Microcomputer

- Motherboard
- Video output
- Memory
- Input-output ports


#### Motherboard




- CPU socket
- External cache memory slots
- Main memory slots
- BIOS chips

  BIOS (basic input-output system) computer chips, holding system software
- Sound synthesizer chip (optional)
- Video controller chip (optional)
- IDE, parallel, serial, USB, video, keyboard, joystick, network, and mouse connectors
- PCI bus connectors (expansion cards)
  - Connectors for mass-storage devices such as hard drives and CD-ROMs
  - USB connectors for external devices
  - Keyboard and mouse ports
  - PCI bus connectors for sound cards, graphics cards, data acquisition boards, and other input-output devices

#### Intel D850MD motherboard






## **Video Output**



- Video controller
  - on motherboard, or on expansion card
  - AGP (accelerated graphics port)
- Video memory (VRAM)
- Video CRT Display
  - uses raster scanning
  - horizontal retrace
  - vertical retrace
- Direct digital LCD monitors
  - no raster scanning required

## Memory



- ROM
  - read-only memory
- EPROM
  - erasable programmable read-only memory
- Dynamic RAM (DRAM)
  - inexpensive; must be refreshed constantly
- Static RAM (SRAM)
  - expensive; used for cache memory; no refresh required
- Video RAM (VRAM)
  - dual ported; optimized for constant video refresh
- CMOS RAM
  - refreshed by a battery
  - system setup information

## Input-output ports




- USB (universal serial bus)
  - intelligent high-speed connection to devices
  - up to 12 megabits/second
  - USB hub connects multiple devices
  - enumeration: computer queries devices
  - supports *hot* connections

#### Parallel

- short cable, high speed
- common for printers
- bidirectional, parallel data transfer
- Intel 8255 controller chip

## Input-output ports (cont)




#### • Serial

- RS-232 serial port
- one bit at a time
- used for long cables and modems
- 16550 UART (universal asynchronous receiver transmitter)
- programmable in assembly language


# Intel microprocessor history

## Early Intel microprocessors



- Intel 8080
  - 64K addressable RAM
  - 8-bit registers
  - CP/M operating system
  - 5,6,8,10 MHz
  - 29K transistros
- Intel 8086/8088 (1978)
  - IBM-PC used 8088
  - 1 MB addressable RAM
  - 16-bit registers
  - 16-bit data bus (8-bit for 8088)
  - separate floating-point unit (8087)
  - used in low-cost microcontrollers now

#### The IBM-AT




- Intel 80286 (1982)
  - 16 MB addressable RAM
  - Protected memory
  - several times faster than 8086
  - introduced IDE bus architecture
  - 80287 floating point unit
  - Up to 20MHz
  - 134K transistors

## Intel IA-32 Family




- Intel386 (1985)
  - 4 GB addressable RAM
  - 32-bit registers
  - paging (virtual memory)
  - Up to 33MHz
- Intel486 (1989)
  - instruction pipelining
  - Integrated FPU
  - 8K cache
- Pentium (1993)
  - Superscalar (two parallel pipelines)

## Intel P6 Family



- Pentium Pro (1995)
  - advanced optimization techniques in microcode
  - More pipeline stages
  - On-board L2 cache
- Pentium II (1997)
  - MMX (multimedia) instruction set
  - Up to 450MHz
- Pentium III (1999)
  - SIMD (streaming extensions) instructions (SSE)
  - Up to 1+GHz
- Pentium 4 (2000)
  - NetBurst micro-architecture, tuned for multimedia
  - 3.8+GHz
- Pentium D (Dual core)

#### CISC and RISC



### CISC – complex instruction set

- large instruction set
- high-level operations (simpler for compiler?)
- requires microcode interpreter (could take a long time)
- examples: Intel 80x86 family

#### RISC – reduced instruction set

- small instruction set
- simple, atomic instructions
- directly executed by hardware very quickly
- easier to incorporate advanced architecture design
- examples:
  - ARM (Advanced RISC Machines)
  - DEC Alpha (now Compaq)