VEVOR®

TOUGH TOOLS, HALF PRICE

Technical Support and E-Warranty Certificate

www.vevor.com/support

PASTE LIQUID FILLING MACHINE

USER MANUAL

We continue to be committed to provide you tools with competitive price.
"Save Half", "Half Price" or any other similar expressions used by us only represents an estimate of savings you might benefit from buying certain tools with us compared to the major top brands and does not necessarily mean to cover all categories of tools offered by us. You are kindly reminded to verify carefully when you are placing an order with us if you are actually saving half in comparison with the top major brands.

VEVOR®

TOUGH TOOLS, HALF PRICE

Paste Liquid Filling Machine

MODEL:SY-580-V1,SY-580-V2,SY-580-V3



NEED HELP? CONTACT US!

Have product questions? Need technical support? Please feel free to contact us:

Technical Support and E-Warranty Certificate
www.vevor.com/support

This is the original instruction, please read all manual instructions carefully before operating. VEVOR reserves a clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there are any technology or software updates on our product.

⚠WARNING

1. Read carefully and understand all **ASSEMBLY AND OPERATION INSTRUCTIONS** before operating.
2. Failure to follow the safety rules and other basic safety precautions may result in serious personal injury.

GENERAL SAFETY RULES

Important reminder

1.Before use, please carefully read the product manual and ensure that you understand and comply with all safety warnings and usage precautions.
2. Do not use this product for other non-designated purposes to avoid unexpected risks.
3. This product is only applicable to users within the specified age group and scope of application. Please strictly comply with relevant age restrictions and warnings.
4. If there are any abnormalities in the product, please stop using it immediately and contact the after-sales service center for consultation or to arrange for repair.

Environmental requirements for use

1. Please use in a dry and well-ventilated environment to avoid extreme environmental conditions such as water activation, high temperature, high humidity, and extremely low temperature.
2. Avoid direct sunlight or contact with fire sources to prevent product damage or fire.
3. Please ensure a stable usage environment and prevent the product from being hit or dropped to avoid damage.

Safety Operation Guidelines

1. Please use a suitable power supply and voltage, and do not use damaged power cords or plugs.
2. When using this product, do not short-circuit circuits or connect mismatched devices to avoid risks such as electric shock and fire.

3. When foreign objects are found on the surface of the product, please immediately stop using and remove the foreign objects before continuing to use.
4. When using this product continuously for a long time, please rest in good time to avoid excessive fatigue.
5. Do not apply external force to the battery to avoid safety hazards such as battery rupture and leakage.

Maintenance and upkeep

1. Regularly maintain and clean the product. Before cleaning, please disconnect the power supply and wipe it with a dry cloth. Be careful not to use alcohol, acid or alkali solutions, Corrosive substances etc.
2. When the product is not in use for a long time, please disconnect the power supply promptly to save energy and extend the product's lifespan.
3. Do not disassemble the product or replace components on your own. If you encounter any malfunctions, please contact the after-sales service center.

Emergency handling measures

1. When there are abnormal situations or accidents with the product, please stop using it as soon as possible.
If overheating, smoking, or abnormal sound are found, please immediately cut off the power supply and contact the after-sales service center.
2. If the product involves an emergency situation that may harm personal safety, please call the emergency rescue number in a timely manner.

Disclaimers


We attach great importance to the safety and quality of our products, but cannot assume responsibility for safety accidents caused by improper use or operation.

SAVE THESE INSTRUCTIONS

MODEL AND PARAMETERS

Model	SY-580-V1	SY-580-V2	SY-580-V3
Suitable liquid	All free-flowing pastes and liquids (no particles) such as Soy sauce, beverages, white wine, vinegar, milk, alcohol (less than 40%) etc		
Filling Range	10-3700ml	10-3700ml	10-3700ml
Max Flow Rate	3.7L/min		
Control Mode	Pedal Switch and Button Switch，Reserve external sensor ports		
Rating(s)	AC120V 60Hz	AC230V 50Hz	AC230V 50Hz
Power(Max.)	66W	66W	66W

STRUCTURE DIAGRAM





1. Control Panel 2. Pedal Switch 3. Filter 4. Hose


5. AC Power Socket 6. Sensor Interface 7. Pedal Switch Interface

8.Outlet 9. Inlet

COMPONENTS

Parts \ Model	SY-580-V1	SY-580-V2	SY-580-V3
Inlet Hose (with filter)	×1	×1	×1
Outlet Hose	×1	×1	×1
Power Cord(Adapter included)	×1	×1	×1
Filling Nozzle	×1(Φ8mm)		
Pedal Switch	×1	×1	×1
Rod(φ12*200mm)	×2	×2	×2
Hex Wrench	×2	×2	×2
Screw(M5*16mm)	×2	×2	×2
T-clamp	×1	×1	×1
Cross clamp	×2	×2	×2
Circular clip	×1	×1	×1
User Manual	×1	×1	×1

OPERATING INSTRUCTIONS

1.Insert the rod into the circular clip. 	2.Connect the two rods with a cross-clamp as shown. 
3.Install the T clamp on the rear plate with screws as shown. 	4.Install the above-installed rods on the T clamp as shown. 
5.Insert the filling nozzle into the outlet hose . 	6.Connect the inlet pipe and the outlet pipe to the inlet and outlet respectively. 

7.Adjust the filling nozzle height and clamp as shown.



8.Insert the power cord and pedal switch as shown.




9.Product assembly completed.



10.Clean:

After use,as needed it can be cleaned by repeated suction with a mild cleaning solution.Then it can be cleaned by repeatedly pumping water.

The operating instructions



Key Function

POWER

Power switch, needs to be turned on when working

SENSORS

sensor switch, needs to be turned on when working

INCHING

Click the switch, press it once to pump water continuously,press it again to stop water from discharging.

START

Manual switch, press once to complete one filling time.

Filling speed setting

DOWN

Means to slow down,reduce the liquid flow rate

UP

Means to accelerate, increase the liquid flow rate

Conveyor delay time setting

SET

In standby mode, press twice, the middle number flashes, Enter the conveyor delay time setting

MOVE

Move right to switch the parameters that need to be set

ADD

set the integer parameter number size o-9 cycle

Normal mode/debug mode/deceleration mode switch

MOVE

The default is normal mode, the flow rate is constant Press once to enter debug mode The filling speed shows 00, and the pump does not work Press again to enter the automatic deceleration mode The second digit of filling speed flashes Automatically decelerate in advance when filling to the end

Switch the decimal point unit

MOVE

ln standby mode, this button switches the decimal point unit

Filling time setting

SET

ln the standby state, press once, the first digit on the left flashes,Enter the filling time setting

MOVE

Move right to switch the parameters that need to be set

ADD

Set the integer parameter number size o-9 cycle

Sensor delay time setting

SET

ln standby mode, press three times, the first digit on the right flashes, Enter the conveyor delay time setting

MOVE

Move right to switch the parameters that need to be set

ADD

Set the integer parameter number size 0-9 cycle

Counter view and reset

INCHING

1.This button is jog, press the display to display the counter,correct reading method: continuous reading of filling speed + filling time

For example: 12 789 pronounced as: 12789

You can press the right shift key to set the debugging mode before viewing the counter

Press the jog button again to view the counter,so that the pump will not output.

3.Counter reset method : first press the jog button,Press the manual button again to clear the counter

MAINTENANCE

1.It is better to clean the machine with clean water after every use, which can prolong the service life of the pump.

2.Please clean the product and the filter in time after each use.

3.When the machine is not in use, please empty the liquid and store it in a ventilated and dry place.

4.Please store the product in a dry and ventilated place.

5.Please replace the following consumable parts regularly:

Hose,Filter,Filling Nozzle

TROUBLESHOOTING

Problem	Possible Cause	Possible Solution
Not absorbing water	Machine first use or long time no use, very few will not absorb water, because the pump internal dry result.	You need to add some water from the intake pipe to the pump and then start the machine.
The pump can't get the liquid out	Hose inlet and outlet are inverted	Confirm hose inlet into liquid tank.
	The power cord is not plugged in	Reconnect the power cord
	Hose folded or damaged	Smooth hose or replace hose
The control panel light is not on.	The power cord is not plugged in	Reconnect the power cord
	This product is subject to the provision of European Directive 2012/19/EC. The symbol showing a wheelie bin crossed through indicates that the product requires separate refuse collection in the European Union. This applies to the product and all accessories marked with this symbol. Products marked as such may not be discarded with normal domestic waste, but must be taken to a collection point for recycling electrical and electronic devices.	

Address： Baoshanqu Shuangchenglu 803long 11hao 1602A-1609shi Shanghai

Imported to AUS: SIHAO PTY LTD, 1 ROKEVA STREETEASTWOOD NSW 2122 Australia

Imported to USA: Sanven Technology Ltd, Suite 250, 9166 Anaheim Place, Rancho Cucamonga, CA 91730

EC	REP

SHUNSHUN GmbH
Römeräcker 9 Z2021, 76351
Linkenheim-Hochstetten, Germany

UK	REP

Pooledas Group Ltd
Unit 5 Albert Edward House, The
Pavilions Preston, United Kingdom

Made In China

VEVOR®

TOUGH TOOLS, HALF PRICE

Technical Support and E-Warranty Certificate

www.vevor.com/support