

1. types of Medium:

- 1.) wired
- 2.) wireless.

wired:

* Copper wire

* Fiber wire

wireless:

* Radio frequency.

2.7 8 pins:

1. +T

2. -T

3. +R

4. +V


5. -V

6. -R

7. -

8. -

3.) Connect UTP cable:-




Router

cross cable.



pc



4.) Explain Auto MDIX!

Auto MDIX is used for accepting cross wire connection and straight wire connection. Automatically change functions.

5.) POE Injector:-

POE is power over Ethernet it Electrical power supply for End device.

6.) Explain POE Switch!

POE Switch sends both data and electrical power over the same cable. Normal switch only sent data. POE switch also sends Electrical power.

7.) NIC types and function:-

* wired

* wireless

wired. cables converted binary to Electrical power and Electrical power to binary signal

wireless device is used to Radio signals for data conversion.