

OEM TECHNICAL MANUAL

Manufacturer: FlowControl Industries

Model: FCV-301 Globe Control Valve

Document No: FCI-MAN-2023-0847

Version 2.1

Date: 05/09/2023

PRODUCT DESCRIPTION

The FCV-301 is a globe-style control valve designed for precise flow regulation in industrial process plants. Operating pressure: 0-25 bar. Temperature range: -20°C to 250°C.

INSTALLATION REQUIREMENTS

1. Ensure pipe is flushed before installation.
2. Install valve with flow arrow in direction of process flow.
3. Provide 5x pipe diameters upstream and 3x downstream.
4. Torque body bolts to 65 Nm.

MAINTENANCE SCHEDULE

Every 6 months: Inspect packing gland, check for stem leakage.

Every 12 months: Full disassembly, inspect trim, replace packing.

Every 36 months: Replace actuator diaphragm.

TROUBLESHOOTING

Symptom: Valve won't close fully

Cause: Debris in trim

Action: Remove and clean trim assembly.

Equipment: FCV-301, FCV-302, PT-301

SPARE PARTS LIST (FCV-301)

Part No.	Description	Qty	Lead Time
FCI-001	Valve body seal kit	1	2 weeks
FCI-002	Actuator diaphragm	1	4 weeks
FCI-003	Stem packing set	2	1 week
FCI-004	Trim assembly	1	6 weeks

CONTACT: techsupport@flowcontrol.example.com

Revision History: v2.1 (2023) · Updated torque specs