

STANDARD OPERATING PROCEDURE

Equipment: Centrifugal Pump P-101

Revision 3

Date: 10/06/2023

Approved by: Engineering Manager

SCOPE

This procedure covers routine maintenance and inspection of pump P-101.

SAFETY PRECAUTIONS

- Isolate all energy sources before beginning work
- Wear PPE at all times (gloves, safety glasses, hard hat)
- Verify zero-energy state before opening pump casing

PROCEDURE

- Step 1: Shut down pump P-101 using control panel HMI.
- Step 2: Close suction valve SV-101 and discharge valve DV-101.
- Step 3: Drain pump casing via drain valve.
- Step 4: Inspect impeller for wear or damage.
- Step 5: Check mechanical seal for leaks.
- Step 6: Torque bolts to 50 Nm per specification.
- Step 7: Reconnect and perform leak test at 80% operating pressure.

SIGN-OFF

Technician: _____ Date: _____

Supervisor: _____ Date: _____

REVISION HISTORY

Rev 3 | 10/06/2023 | Updated safety section

Rev 2 | 15/03/2022 | Added drain step

Rev 1 | 01/01/2021 | Initial release

EQUIPMENT TAGS REFERENCED

P-101, SV-101, DV-101, HV-204