

Filter Cleaning Guide

1. Turn off water supply. 2. Remove filter carefully. 3. Wash with clean water. 4. Reinstall and check leakage.