musicloud
studio & technology

KARNATIK TANPURA

User Guide

Version 0.3.4 | 31 October 2026



Choose your sound

Choose a Shruthi root and either Pa-Sa-Sa-Sa or Ma-Sa-Sa-Sa. The instrument contains 24 recordings: two modes for each of the 12 roots. Click **PLAY SHRUTI** to start or stop the drone.

PLAY SHRUTI

Shape the sound

Adjust Volume, Fine Tune, Tone and Stereo Width. Choose Studio, Plate, Concert Hall or Temple reverb; Reverb Mix controls the amount and Decay controls its tail. Start with a moderate listening level.

Tempo and transport

AUTO – DAW uses your host tempo. **MANUAL** lets you select the tempo yourself. Follow DAW transport links playback to the host transport. Project settings are recalled; press PLAY SHRUTI if playback is stopped after reopening.

Export a loop

Choose 1, 2, 4, 8, 16 or 32 bars, then drag **DRAG WAV** onto an audio track. Keep the DAW tempo and time signature consistent with the export settings. Place successive regions directly against each other.

Updating from an earlier version

Version 0.3.4 warms up the export processing and compensates for crossfade energy loss. Existing WAV files do not update automatically: drag a new WAV from 0.3.4. Old regions retain the earlier silence or level dip.

If a join still sounds uneven

Use the fresh file with no additional fade first. Check that the region ends at its exact exported length and that no gap or automatic fade has been added by the DAW. Contact support with pitch, Pa/Ma mode, BPM, bar count, reverb settings and the exported WAV.

Credits and support

Tanpura Shruthi samples sourced by Hriday Goswami, X Noise Studio, Guwahati.

Support: **contact@musiccloudstudio.com.**