RISKIFY - Safe Work Method Statement

Project Information

Project Name: Ultimate Professional SWMS Test

Trade Type: Tiling

Address: 555 Professional Excellence Drive

Job Number: ULTIMATE-2025-001

Personnel Information

Principal Contractor: Excellence Construction Ltd

Project Manager: David Professional Site Supervisor: Sarah Excellence SWMS Creator: Michael Expert

Work Activities & Risk Assessment

1. Site Setup and Safety Assessment

Description: Comprehensive site preparation including safety zone establishment, equipment setup, and environmental hazard assessment for commercial bathroom renovation project Hazards:

- Slip and fall hazards from wet surfaces and debris
 - **Control Measures:**
 - Install anti-slip mats in work areas
 - Maintain clear walkways
 - Use appropriate footwear
 - Regular housekeeping
 - Warning signage placement
- Electrical hazards from power tools and wet conditions

Control Measures:

- Use RCD protection on all electrical equipment
- Keep electrical equipment away from water
- Regular equipment inspection
- Qualified electrician consultation

Risk Score: 12/20

2. Surface Preparation and Substrate Assessment

Description: Professional assessment and preparation of existing surfaces including removal of old tiles, surface cleaning, and substrate preparation for optimal adhesion Hazards:

• Dust inhalation from tile removal and surface preparation

Control Measures:

- Use dust extraction equipment
- Wear appropriate respiratory protection
- Wet cutting techniques where possible
- Adequate ventilation
- Regular air quality monitoring
- Manual handling injuries from heavy materials and equipment

Control Measures:

- Use mechanical lifting aids
- Two-person lifts for heavy items
- Proper lifting techniques training

- Regular breaks

- Ergonomic work positioning

Risk Score: 10/20

3. Premium Tile Installation and Finishing

Description: Precision installation of high-quality ceramic and porcelain tiles using advanced adhesive systems, followed by professional grouting and sealing Hazards:

- Cuts and lacerations from tile cutting and handling Control Measures:
 - Use guards on all cutting equipment
 - Wear cut-resistant gloves
 - Proper tool maintenance
 - Safe waste disposal
 - First aid readily available
- Chemical exposure from adhesives, grouts, and sealers

Control Measures:

- Read and follow MSDS
- Use in well-ventilated areas
- Wear chemical-resistant gloves
- Eye protection
- Proper storage and disposal

Risk Score: 8/20

Personal Protective Equipment (PPE)

- Hard hat
- Safety glasses
- Cut-resistant gloves
- Chemical-resistant gloves
- Non-slip footwear
- P2 dust mask
- Knee pads
- Hi-vis vest
- Long sleeve shirts

Plant & Equipment Register

• Professional wet tile saw with dust extraction

Risk Level: High

· Heavy-duty mixing paddle and drill

Risk Level: Medium

Laser level and measuring equipment

Risk Level: Low

Professional grouting and cleaning equipment

Risk Level: Low

Generated by Riskify SWMS Builder - 7/7/2025