

Aug 27 09:14:22.331:%LINEPROTO-5-UPDOWN:

The diagram shows the message "Aug 27 09:14:22.331:%LINEPROTO-5-UPDOWN:" with three brackets underneath. The first bracket, labeled "timestamp", spans "Aug 27 09:14:22.331:". The second bracket, labeled "facility", spans "%LINEPROTO-". The third bracket, labeled "mnemonic", spans "5-UPDOWN:". A red vertical line points from the word "severity" above to the "5" in the message.

timestamp                      facility                      mnemonic

Line protocol on Interface GigabitEthernet0/1, changed state to down

A green bracket underneath the message "Line protocol on Interface GigabitEthernet0/1, changed state to down" is labeled "description — the part in English".

description — the part in English

And the rest is English, which is the only part most people read and the least useful part to filter on.