

clear alarm

- After checking the alarm number of the alarm you want to clear then use the next command
- Enter command “alarm active clear alarmsn 35890”

```
NRD44#alarm active clear alarmsn 35890  
NRD44#
```

- Now check the alarm status again if the alarm has been cleared

```
NRD44#display alarm active all detail  
No alarm record according to request  
NRD44#
```