```
enable
configure terminal

hostname Switch-Brest-4
no ip domain-lookup

enable secret 123Soleil!

banner motd #
*-*-*-*-*-*-*-*-*-*-*-*SWITCH-BREST-4*-*-*-*-*-*-*-*-*-*-*-*
#

service password-encryption

line console 0
 password 123Soleil!
 login
 exec-timeout 15 0
 logging synchronous
 exit

ip domain-name nordtech.local
crypto key generate rsa




username admin privilege 15 secret 123Soleil!

line vty 0 4
 login local
 transport input ssh
 exec-timeout 15 0
 exit

ip ssh version 2

no ip http server
no ip http secure-server

ip routing

vlan 10
 name Direction
 exit
```

```
vlan 20
 name Compta
 exit
vlan 30
 name RH
 exit
vlan 40
 name DSI
 exit
vlan 50
 name Commercial
 exit
vlan 60
 name Production
 exit
vlan 70
 name Stagiaires
 exit
vlan 99
 name Management
 exit
vlan 100
 name SRV-FICHIERS
 exit
vlan 110
 name SRV-INFRA-AAA
 exit
vlan 120
 name SRV-BACKUP
 exit
vlan 999
 name Native_Unused
 exit

interface Vlan10
 description Passerelle VLAN Direction
 ip address 10.10.10.3 255.255.255.0
 ip helper-address 10.10.110.5
 standby 10 ip 10.10.10.1
 standby 10 priority 100
 standby 10 preempt
 standby 10 track GigabitEthernet1/0/22 20
 no shutdown
 exit
interface Vlan20
 description Passerelle VLAN Compta
 ip address 10.10.20.3 255.255.255.0
 ip helper-address 10.10.110.5
```

```
standby 20 ip 10.10.20.1
 standby 20 priority 100
 standby 20 preempt
 standby 20 track GigabitEthernet1/0/22 20
 no shutdown
 exit
interface Vlan30
 description Passerelle VLAN RH
 ip address 10.10.30.3 255.255.255.0
 ip helper-address 10.10.110.5
 standby 30 ip 10.10.30.1
 standby 30 priority 100
 standby 30 preempt
 standby 30 track GigabitEthernet1/0/22 20
 no shutdown
 exit
interface Vlan40
 description Passerelle VLAN DSI
 ip address 10.10.40.3 255.255.255.0
 ip helper-address 10.10.110.5
 standby 40 ip 10.10.40.1
 standby 40 priority 100
 standby 40 preempt
 standby 40 track GigabitEthernet1/0/22 20
 no shutdown
 exit
interface Vlan50
 description Passerelle VLAN Commercial
 ip address 10.10.50.3 255.255.255.0
 ip helper-address 10.10.110.5
 standby 50 ip 10.10.50.1
 standby 50 priority 100
 standby 50 preempt
 standby 50 track GigabitEthernet1/0/22 20
 no shutdown
 exit
interface Vlan60
 description Passerelle VLAN Production
 ip address 10.10.60.3 255.255.255.0
 ip helper-address 10.10.110.5
 standby 60 ip 10.10.60.1
 standby 60 priority 100
 standby 60 preempt
 standby 60 track GigabitEthernet1/0/22 20
 no shutdown
 exit
interface Vlan70
 description Passerelle VLAN Stagiaires
```

```
 ip address 10.10.70.3 255.255.255.0
 ip helper-address 10.10.110.5
 standby 70 ip 10.10.70.1
 standby 70 priority 100
 standby 70 preempt
 standby 70 track GigabitEthernet1/0/22 20
 no shutdown
 exit
interface Vlan99
 description Management
 ip address 10.10.99.7 255.255.255.0
 standby 99 ip 10.10.99.1
 standby 99 priority 100
 standby 99 preempt
 standby 99 track GigabitEthernet1/0/22 20
 no shutdown
 exit
interface Vlan100
 description Passerelle VLAN Serveurs-Fichiers
 ip address 10.10.100.3 255.255.255.0
 standby 100 ip 10.10.100.1
 standby 100 priority 100
 standby 100 preempt
 standby 100 track GigabitEthernet1/0/22 20
 no shutdown
 exit
interface Vlan110
 description Passerelle VLAN Serveurs-Infra-AAA
 ip address 10.10.110.3 255.255.255.0
 standby 110 ip 10.10.110.1
 standby 110 priority 100
 standby 110 preempt
 standby 110 track GigabitEthernet1/0/22 20
 no shutdown
 exit
interface Vlan120
 description Passerelle VLAN Serveurs-Backup
 ip address 10.10.120.3 255.255.255.0
 standby 120 ip 10.10.120.1
 standby 120 priority 100
 standby 120 preempt
 standby 120 track GigabitEthernet1/0/22 20
 no shutdown
 exit

interface g1/0/1
 description Vers-Switch-Brest-2
 switchport mode trunk
```

```
 switchport trunk native vlan 999
 switchport trunk allowed vlan 40,50,60,99,999
 no shutdown
 exit

interface g1/0/2
 description Serveur-VLAN110-1
 switchport mode access
 switchport access vlan 110
 spanning-tree portfast
 no shutdown
 exit

interface g1/0/3
 description Serveur-DHCP-BREST
 switchport mode access
 switchport access vlan 110
 spanning-tree portfast
 ip dhcp snooping trust
 no shutdown
 exit

interface g1/0/4
 description Serveur-VLAN110-3
 switchport mode access
 switchport access vlan 110
 spanning-tree portfast
 no shutdown
 exit

interface g1/0/5
 description Serveur-Fichiers
 switchport mode access
 switchport access vlan 100
 spanning-tree portfast
 no shutdown
 exit

interface g1/0/6
 description Serveur-Backup
 switchport mode access
 switchport access vlan 120
 spanning-tree portfast
 no shutdown
 exit

interface range g1/0/10 - 11
 description LACP-Vers-Switch-Brest-3
```

```
 channel-protocol lacp
 channel-group 1 mode active
 no shutdown
 exit

interface Port-channel1
 description EtherChannel-Vers-Switch-Brest-3
 switchport mode trunk
 switchport trunk native vlan 999
 switchport trunk allowed vlan 10,20,30,40,50,60,70,99,100,110,120,999
 no shutdown
 exit


interface g1/0/22
 no switchport
 description Vers-Brest-R2-Principal
 ip address 10.10.253.10 255.255.255.252
 no shutdown
 exit

interface g1/0/23
 no switchport
 description Vers-Brest-R1-Secours
 ip address 10.10.253.6 255.255.255.252
 no shutdown
 exit

interface g1/0/24
 description Vers-Switch-Brest-1
 switchport mode trunk
 switchport trunk native vlan 999
 switchport trunk allowed vlan 10,20,30,99,999
 no shutdown
 exit

interface range g1/0/7 - 9
 switchport mode access
 switchport access vlan 999
 shutdown
 exit

interface range g1/0/12 - 21
 switchport mode access
 switchport access vlan 999
 shutdown
 exit
```

```
interface range g1/1/1 - 4
 switchport mode access
 switchport access vlan 999
 shutdown
 exit


spanning-tree mode rapid-pvst

spanning-tree vlan 10,20,30,40,50,60,70,99,100,110,120 root secondary


ip route 10.20.0.0 255.255.0.0 10.10.253.9 10
ip route 10.20.0.0 255.255.0.0 10.10.253.5 20

ip dhcp snooping
ip dhcp snooping vlan 10,20,30,40,50,60,70,99,100,110,120
interface g1/0/1
 ip dhcp snooping trust
 exit
interface g1/0/24
 ip dhcp snooping trust
 exit
interface Port-channel1
 ip dhcp snooping trust
 exit

ip access-list standard MGMT-ONLY
 permit 10.10.99.0 0.0.0.255
 exit
line vty 0 4
 access-class MGMT-ONLY in
 exit
line vty 5 15
 login local
 transport input ssh
 access-class MGMT-ONLY in
 exec-timeout 15 0
 exit

end
write memory
```