






























Sheet: /YD-ESP32-S3/
File: YD-ESP32-S3.kicad_sch


Title:

Size: A4 Date:

KiCad E.D.A. 9.0.5

Rev:

Id: 8/13



Sheet: /YD-ESP32-S3/BME280/
File: BME280.kicad_sch

Title:


Size: A5


Date:

Rev:

KiCad E.D.A. 9.0.5

Id: 9/13





Sheet: /USB2-HUB/USB-AUDIO/
File: USB_AUDIO.kicad_sch

Title:

Size: A4

Date:

KiCad E.D.A. 9.0.5

Rev:

Id: 22/13