IOTWX ATMOS NODE ASSEMBLY



Agbeli Ameko, AJ Lauer, Keith Maull, NCAR/UCAR Alex Honors, Design Build Associates, LLC


MIT Opensource License

This material is based upon work supported by the National Center for Atmospheric Research, a major facility sponsored by the National Science Foundation and managed by the University Corporation for Atmospheric Research. Any opinions, findings and conclusions or recommendations expressed in this material do not necessarily reflect the views of the National Science Foundation.

This work is based on support provided by the ESIP Lab with support from the National Aeronautics and Space Administration (NASA), National Oceanic and Atmospheric Administration (NOAA) and the United States Geologic Survey (USGS).

EXPLODED COMPONENTS

The ATMOS Node allows multiple atmospheric conditions to be sampled and measured while protecting the grove sensors from harmful solar radiation.





COMPONENTS LIST

No.	Component Name	Quality
1	Top Leaf	1
2	Single Leaf	1
3	Mid Leaf	5
4	Center Screen	1
5	Screen Ring	4
6	Sensor Clip	1
7	Shaft	1
8	Fastener	2
9	Base	1
10	Base Plate	1
11	Swivel Innerlock	1
12	Swivel Ball Joint Bar	1
13	Swivel Outerlock	1

ASSEMBLY STEP 1


Attach Base Plate to Base with 2 Fasteners. Make sure Base Plate threads are lined up with Base holes.






STEP 2

Place one screen ring on top of the base.






ASSEMBLY


STEP 3

Thread the short end the Shaft into the center of the base.





Position the first Mid Leaf on top of the first Screen Ring. Line up the tongue in the Mid Leaf with the Groove in the center of the base locking the leaf in








ASSEMBLY STEP 5

Place the second screen ring on top of the fist mid leaf.





Position the second Mid Leaf on the Second screen ring repeating steps the process from step 4 to ensure the leaf is locked in place








ASSEMBLY STEP 7


Connect the grove sensor holder to the inner arms of the mid leaf.






Slot the grove Temperature Sensor into the Clip being sure to snap the sensor in place over the bump within the slot of the Clip.







ASSEMBLY STEP 9


Connect the grove cable to the sensor and run the wires down through the Leaves and out of the cylinder in the base.








Place the third Screen Ring and the third Mid Leaf on the assembly respectively.





ASSEMBLY STEP 11

Repeat step 10 for the 4th Screen Ring and Mid Leaf.





Fit the center Screen around the rim of the fourth Mid Leaf.





ASSEMBLY STEP 13


Fit the Fifth Mid Leaf into the center screen ensuring a tight fits and lock the Leaf in place by aligning the tongue and groove with the underlying leaf.






Place the Single Leaf onto the Shaft positioning the center ring into the center of the underlying Leaf.






ASSEMBLY STEP 15

Thread the Top Leaf onto the shaft until snug.





Thread the Swivel Outer-lock into the inner-lock with the Ball Joint Bar in the center. Then slot the swivel assembly onto the cylinder at the base.






ASSEMBLY STEP 17


Cut a section of 1" PVC pipe 3" or 55cm long and slot it onto the end of the swivel assembly.






Place the PVC T-joint in the smaller PVC short Arm. Be sure that the grove cable end is sticking out of the bottom of the T-Joint.






ASSEMBLY STEP 19


Insert the USB-C Power cord into the T-Joint.





Connect the grove and power cords to the microprocessor.







ASSEMBLY STEP 21

Insert the connected microprocessor into the micro holder.






Push the Micro holder up into the T-joint.






ASSEMBLY STEP 23

Cut another 3" piece of 1" PVC and insert it into the T-joint ensuring that the power cord is flowing through.





ASSEMBLY COMPLETE

The wires and assembly should be assembled as such.

