
BASIS FOR THE APPROACH

Steps:



D+

- p_t=total pressure, p=static,
 q=dynamic
- pitot tube insensitive to flow angle (<0.1%)
- orientation removes normal offset
- redundant measurements ⇒consistency
- still, an assumption

