
Table of Contents

Contents	Page No.
Part A: AHT20 with I2C	P2
Part B: RTC with I2C	P8
Part C: LCD with SPI	P12

Part A: AHT20 with I2C


- 1. In this scenario, AHT20 sensor is used to detect temperature and humidity of the surroundings. And the I2C digital signals of temperature and humidity are checked via the Logic Analyzer and Pulse View.
- 2. Hardware Required
 - a. ESP32
 - b. AHT20
 - c. Bread board
 - d. Micro USB cable
 - e. Jumper Wires
- 3. Software Required
 - a. To install Adafruit AHTX0 library, Open the Arduino IDE application, go to Tools > Manage Libraries.





4. Circuit Schematic

- a. $VIN \rightarrow 3.3 V$
- b. GND -> GND
- c. SCL -> GPIO 22
- d. SDA -> GPIO 21




5. Source Code

```
1. #include <Adafruit AHTXO.h>
Adafruit AHTXO aht;
3. void setup()
4. {
5. Serial.begin(115200);
6. Serial.println("Adafruit AHT10/AHT20 demo!");
7. Serial.println("AHT20 Temperature sensor demo done on 01/03/2022");
8. Serial.println("Ref: http://www.esp32learning.com/code/aht20-
   integrated-temperature-and-humidity-sensor-and-esp32-board-
   example.php");
9. if (! aht.begin())
10.
         Serial.println("Could not find AHT? Check wiring");
11.
12.
        while (1) delay(10);
13.
14.
         Serial.println("AHT10 or AHT20 found");
15.
16.
        void loop() {
17.
       sensors event t humidity, temp;
        aht.getEvent(&humidity, &temp);// populate temp and humidity
 objects with fresh data
19.
        Serial.print("Temperature: ");
20.
         Serial.print(temp.temperature);
```


```
Serial.println(" degrees C");
21.
         Serial.print("Humidity: ");
22.
         Serial.print(humidity.relative humidity);
23.
24.
         Serial.println("% rH");
25.
         delay(500);
26.
```

- 6. Connecting the Logic Analyzer with the circuit
 - a. SCL -> Ch1 (Logic Analyzer)
 - b. SDA -> Ch2 (Logic Analyzer)
 - c. GND -> GND

Connect the circuit with your machine and then open the Pulse View application. Then, click the "yellow and green" figure to open the "Decoder Selector" box and, choose I2C.





At the I2C, select SCL as "D0" and SDA as "D1". The total sample is 1M samples and the clock rate is 1MHz. And then, click Run and zoom out the result.




7. Results


Here is the result after you running the Pulse View. When you see the address "Data Read:1C", the following hexadecimal values are temperature and humidity values.








The following figure shows the equation how to calculate temperature and humidity from the reading I2C hexadecimal value.



According to the datasheet and the above equation,



The first 20 binary bits, or 5 hexadecimal bits are the humidity data and the following 20 binary bits, or 5 hexadecimal bits are the temperature data.

Humidity,

 $4B5D8_{hex} -> 308,696_{dec}$

According to Signal Transformation Equation,

Humidity, RH = 308,696 /2^20*100 = 29.43 %


Temperature,

 $61698_{\text{hex}} \rightarrow 399,000_{\text{dec}}$

According to Signal Transformation Equation,

Temperature, $T = 399,000/(2^20) *200 - 50 = 26.10$ degree Celsius

Here are the results from the Arduino IDE, serial monitor. We can see that the results are approximately correct. Because the sensor has a typical accuracy of +- 2% relative humidity, and +-0.3 °C.




Look at the sample video record. (PartA_AHT20_with_I2C.mp4)

Your Testing: Take a video record where you should explain and calculate to inspect temperature and humidity data by using I2C decoder measured by the Logic Analyzer.

Part B: RTC with I2C

- 1. In this scenario, RTC sensor is used to detect date, time, and temperature of the surroundings. And the I2C digital signals of its are checked via the Logic Analyzer and Pulse View.
- 2. Hardware Required
 - a. ESP32
 - b. RTC
 - c. Bread board
 - d. Micro USB cable
 - e. Jumper Wires
- 3. Circuit Schematic
 - a. VCC-> 3.3 V
 - b. GND -> GND
 - c. SCL -> GPIO 22
 - d. SDA -> GPIO 21



4. Source Code

Note that you have to change at Line No 6 and 7, WiFi SSID and password in the source code to match your selected access point.

- 1. #define _SYNC_NTP //Uncomment this if you want the synchronize RTC with the NTP server
- 2. #include <WiFi.h>
- 3. #include <time.h>

```
4. #include <DS3231.h>
5. #include <Wire.h>
6. const char* ssid = "";
7. const char* password = "";
8. const char* ntpServer = "th.pool.ntp.org";
9. //const char* ntpServer = "clock.mahidol.ac.th";
10.const long gmtOffset sec = 3600 * 7; //UTC +7.00
11. const int daylightOffset sec = 0; //0 means no DST observed; otherwise, 3600.
12.DS3231 rtc;
13.bool h12Format;
14.bool ampm;
15. bool centuryRollover;
16. struct tm timeinfo;
17. void setup()
18. {
19. Serial.begin(9600);
20. Wire.begin();
21. #ifdef SYNC NTP
22.//connect to WiFi
23. Serial.printf("Connecting to %s ", ssid);
24. WiFi.begin (ssid, password);
25.while (WiFi.status() != WL CONNECTED) {
26. delay(500);
27. Serial.print(".");
28.}
29. Serial.println(" CONNECTED");
30. Serial.print("IP Address: ");
31. Serial.println(WiFi.localIP());
32.//\text{init} and get the time
33.configTime(gmtOffset sec, daylightOffset sec, ntpServer);
34.if(!getLocalTime(&timeinfo)){
35. Serial.println("Failed to obtain time");
36. return;
37.}
38. Serial.println("M:" +
                                String(timeinfo.tm mon)
                                                                           Y:"
 String(timeinfo.tm year));
39.rtc.enableOscillator(true, true, 1);
40.rtc.setClockMode(h12Format); //24-h format
41.rtc.setDoW(timeinfo.tm wday);
42.rtc.setHour(timeinfo.tm_hour);
43. rtc.setMinute(timeinfo.tm min);
44.rtc.setSecond(timeinfo.tm sec);
45.rtc.setDate(timeinfo.tm mday);
46.rtc.setMonth(timeinfo.tm_mon + 1); //Month from NTP starts from zero
47.rtc.setYear(timeinfo.tm year - 100); //Year from NTP is an offset from 1900
48.//disconnect WiFi as it's no longer needed
49. WiFi.disconnect(true);
50. WiFi.mode (WIFI OFF);
51. #endif
52.}
53. void loop()
54. {
55. #ifdef _SYNC_NTP
56.//Show time from NTP
57.configTime(gmtOffset sec, daylightOffset sec, ntpServer);
```


```
58.if(!getLocalTime(&timeinfo)){
59. Serial.println("Failed to obtain time");
60. return;
61.}
62. Serial.println("M:" +
                                String(timeinfo.tm mon)
                                                                            Y:"
  String(timeinfo.tm year));
63. #endif
64.// Send Day-of-Week
65. Serial.print("DoW:");
66. Serial.print(rtc.getDoW());
67. Serial.print(" ");
68.// Send date
69. Serial.print("-- Date: ");
70. Serial.print(rtc.getDate(), DEC);
71. Serial.print("/");
72. Serial.print(rtc.getMonth(centuryRollover), DEC);
73. Serial.print("/");
74. Serial.print("2"); //This program is still valid until almost the next 1000 years.
75. if (centuryRollover)
76. Serial.print("1");
77.else
78. Serial.print("0");
79. Serial.print(rtc.getYear(), DEC);
80.// Send time
81. Serial.print(" -- Time: ");
82. Serial.print(rtc.getHour(h12Format, ampm), DEC);
83. Serial.print(":");
84. Serial.print(rtc.getMinute(), DEC);
85. Serial.print(":");
86. Serial.print(rtc.getSecond(), DEC);
87.//Temperature
88. Serial.print(" -- RTC Temperature: ");
89. Serial.println(rtc.getTemperature());
90. delay(1000);
91. }
```

5. Connecting the Logic Analyzer with the circuit

- a. SCL -> Ch1 (Logic Analyzer)
- b. SDA -> Ch2 (Logic Analyzer)
- c. GND -> GND

6. Results

Here is the result after you running the Pulse View. When you see the address "Address Read:68", the following "Data Read" hexadecimal values are result values.




Look at the sample video record. (PartB_RTC_with_I2C.mp4)

Your Testing: Take a video record where you should explain and calculate to inspect RTC data by using I2C decoder measured by the Logic Analyzer.

Part C: LCD with SPI

- 1. In this scenario, LCD is used to show real time clock and SPI digital signals of its are checked via the Logic Analyzer and Pulse View.
- 2. Hardware Required
 - a. ESP32
 - b. LCD
 - c. Bread board
 - d. Micro USB cable
 - e. Jumper Wires
- 3. Circuit Schematic



- **Install** TFT eSPI **library from** Tools -> Manage Libraries...
- Go to the location of the installed TFT_eSPI library
 - o **On Windows,** My Documents -> Arduino -> libraries -> TFT_eSPI
 - On Mac, Documents -> Arduino -> libraries -> TFT_eSPI
- Go to User Setups directory and create file Setup0 ESP32 ILI9341.h.
- Add the following lines to the file and save it.

```
#define ILI9341_DRIVER
#define TFT_MISO 19
#define TFT_MOSI 23
#define TFT_SCLK 18
#define TFT_SCLK 18
#define TFT_CS 15 // Chip select control pin
#define TFT_DC 2 // Data Command control pin
#define TFT_RST 4 // Reset pin (could connect to RST pin)
#define LOAD_GLCD // Font 1. Original Adafruit 8-pixel font needs ~1820 bytes
in FLASH
#define LOAD_FONT2 // Font 2. Small 16-pixel high font, needs ~3534 bytes in
FLASH, 96 characters
#define LOAD_FONT4 // Font 4. Medium 26-pixel high font, needs ~5848 bytes in
FLASH, 96 characters
```

```
#define LOAD_FONT6 // Font 6. Large 48 pixel font, needs ~2666 bytes in FLASH,
only characters 1234567890: -.apm
#define LOAD_FONT7 // Font 7. 7 segment 48 pixel font, needs ~2438 bytes in
FLASH, only characters 1234567890:
#define LOAD_FONT8 // Font 8. Large 75 pixel font needs ~3256 bytes in FLASH,
only characters 1234567890: -.
#define LOAD_GFXFF // FreeFonts. Include access to the 48 Adafruit_GFX free
fonts FF1 to FF48 and custom fonts
#define SMOOTH_FONT
```

- **Open** User_Setup_Select.h
 - o Comment the line #include <User_Setup.h>
 - o **Add line** #include <User Setups/Setup0 ESP32 ILI9341.h>
- 4. Look at Sample video record. (PartC_LCD_with_SPI.mp4)

Your Testing: Take a video record where you should test as follows

Try the programs in Files -> Examples -> TFT_eSPI -> 320 x 240

- TFT_Rainbow_one_lib
- Free_Font_Demo
- TFT Clock
- TFT Pong

And SPI data by using I2C decoder measured by the Logic Analyzer.

Connecting the Logic Analyzer with the circuit to check SPI result.

- 1. SCK -> CH1
- 2. MISO -> CH2
- 3. MOSI -> CH3