
Example 1A - Heat/Cool, closed loop, PID control without remote SP

Real world use may be to control chamber temperature.

Demonstrates use of Analog Input, Control, and Digital Output Function Blocks

Noto

Control Loop 1 must use PV 1 or Analog Input 1
Control Loop 2 must use PV 2 or Analog Input 2
Control Loop 3 must use PV 3 or Analog Input 3
Control Loop 4 must use PV 4 or Analog Input 4





EZ-ZONE RM Application Example - using function blocks Print on 11" x 17" landscape paper for best viewing User parameter settings in RED Revision A