





Webpage Views for KE2 Therm Serial Controllers

KE2 Temp + Defrost = KE2 Temp + Valve Control = KE2 Low Temp + Defrost = KE2 Adaptive Control

The Webpage screenshots show the detailed system information, setpoints, alarm notification, and device information that is availabe for KE2 Therm's Serial-ModBus controllers, when accessed through a KE2 LDA (Local Area Dashboard & Alarms).


The webpages can also be accessed through the Internet by connecting through the KE2 SmartAccess portal. See bulletin Q.5.42 for more information on connecting through KE2 Smart Access, or view our YouTube videos at www.youtube.com/user/ ke2therm.

KE2 LDA Dashboard View Below **KE2 Temp + Defrost** Page 2 Webpages | KE2 Temp + Valve Page 3 **KE2 Adaptive Control &**

KE2 Low Temp + Defrost

Page 4

The KE2 LDA Dashboard - for accessing KE2 Therm Serial-Modbus controllers




Webpage Views for KE2 Therm Serial Controllers

KE2 Temp + Defrost = KE2 Temp + Valve Control = KE2 Low Temp + Defrost = KE2 Adaptive Control

KE2 Temp + Defrost

For medium temp applications ■ air defrost ■ scheduled defrosts






Webpage Views for KE2 Therm Serial Controllers

KE2 Temp + Defrost = KE2 Temp + Valve Control = KE2 Low Temp + Defrost = KE2 Adaptive Control

KE2 Temp + Valve Control

For low or medium temp applications with EEV ■ air defrost ■





Setpoints 5 4 1

Aux Temp 4

Defrost Mode

Extreme Diff

Webpage Views for KE2 Therm Serial Controllers

KE2 Temp + Defrost = KE2 Temp + Valve Control = KE2 Low Temp + Defrost = KE2 Adaptive Control

KE2 Adaptive Control & KE2 Low Temp + Defrost

KE2 Adaptive Control : for low or medium temp applications ■ electric defrost ■ adaptive (demand) or scheduled defrosts KE2 Low Temp: for low or medium temp applications ■ electric defrost ■ scheduled defrosts

