Name:	ID:	Start Date: Wednesday, August 18, 2021
Name:	ID:	Due Date: Friday, August 20, 2021


Software and Hardware Co-Design with Zybo, Summer 2021 HUST Lab #8: Reading Two TMP101 Temperature Sensors from MIO for One and SelectIO for the Other of Zybo


This is a group lab. Each group of two students should demonstrate your I2C TMP101 reading implementation on Zybo board and submit one pdf copy of report for this lab. Late lab submission will be accepted with a grade reduction of 10% for each day that it is late.

I. Objectives

(1) Construct a Zynq 7010 circuit to implement the two I2C interfaces with the I2C controllers I2C 0 and I2C 1: I2C 0 on MIO pins 14 and 15 and I2C 1on SelectIO pins JB3 and JB4. Your block design should have just one I2C interface connection for I2C Module 1 of Zynq. This interface needs to be connected to two Select I/O pins on Zybo. The following example connects SCL pin to JB3 (pin V20) and SDA pin to JB4 (pin W20) of Pmod JB connector. You are free to use other Pmod connector pins manually through I/O Ports menu if you want to do so. A XDC file will need to be created to save this assignment.

You should verify that your I2C Module 0 is connected to MIO pins 14 and 15, which are accessible from Pmod JF of Zybo.






- (1) Connect two TMP101 breakout boards on Zybo so that they can be read by Zynq 7010 and their temperatures. You are free to set their addresses.
- (2) Develop a C program for ARM 12C modules to configure the TMP101 temperature sensors, one in 10-bit resolution and the other in 12-bit resolution and to read the TMP101 temperatures and display their temperatures in both Celsius and Fahrenheit on the series terminal of the SDK with the correct resolutions. You will need to configure your TMP101 sensors to transmit two byte temperature values of 12 bits so that the temperatures will have four digits after decimal point.
- (3) Use printf() for floating point display because xil_printf() does not support floating point. Format for floating point printing is 8.4f, where 8 is the total number of digits and 4 is the number of digits after decimal point. See an I2C example program from Xilinx in the appendix of this handout. This program can be used to test your hardware.
- (4) Submit a memo to explain how you have implemented and verified your design and implementation. Show, with screen captures, which temperature sensor has 10-bit resolution and which one has 12-bit resolution. Include relevant screen captures and your source code in your memo.



```
🖺 Problems 🧟 Tasks 📮 Console 🔲 Properties 📮 SDK Terminal 🐶 Terminal 1 🛭
Serial: (COM11, 115200, 8, 1, None, None - CLOSED) - Encoding: (ISO-8859-1)
          Read TMP101 Device on PL successfully
        TMP101B on SelectIO pMod B=
                                        30.2500 Celsius
                                                              86.4500 Fahrenheit
Read TMP101 Device on PS successfully
                                                       84.5375 Fahrenheit
                               29.1875 Celsius
TMP101PS on MIO Pmod F =
          Read TMP101 Device on PL successfully
        TMP101B on SelectIO pMod B=
                                        30.1250 Celsius
                                                              86.2250 Fahrenheit
 Read TMP101 Device on PS successfully
 TMP101PS on MIO Pmod F =
                                                       84.6500 Fahrenheit
          Read TMP101 Device on PL successfully
                                        30.1250 Celsius
        TMP101B on SelectIO pMod B=
                                                             86.2250 Fahrenheit
 Read TMP101 Device on PS successfully
 TMP101PS on MIO Pmod F =
```

Figure 1. Zybo board with two TMP101 temperature sensors on Port F and Port B. UART 1 on Zynq must be selected to be on MIO 48 and 49.

The TMP101 breakout board in Port F is connected to the PS through MIO pins and is connected to Port F are as follows: SDK on JF9 (M14) and SDA on JF10 (M15). The TMP101 on Port B is connected to the PS through SelectIO pins and is connected so that JB3 (V20) is SCL and JB4 (W20) is SDA.






Figure 16. Pmod diagram.

Pmod JA (XADC)	Pmod JB (Hi-Speed)	Pmod JC (Hi-Speed)	Pmod JD (Hi-Speed)	Pmod JE (Std.)	Pmod JF (MIO)
JA1: N15	JB1: T20	JC1: V15	JD1: T14	JE1: V12	JF1: MIO-13
JA2: L14	JB2: U20	JC2: W15	JD2: T15	JE2: W16	JF2: MIO-10
JA3: K16	JB3: V20	JC3: T11	JD3: P14	JE3: J15	JF3: MIO-11
JA4: K14	JB4: W20	JC4: T10	JD4: R14	JE4: H15	JF4: MIO-12
JA7: N16	JB7: Y18	JC7: W14	JD7: U14	JE7: V13	JF7: MIO-0
JA8: L15	JB8: Y19	JC8: Y14	JD8: U15	JE8: U17	JF8: MIO-9
JA9: J16	JB9: W18	JC9: T12	JD9: V17	JE9: T17	JF9: MIO-14
JA10: J14	JB10: W19	JC10: U12	JD10: V18	JE10: Y17	JF10: MIO-15

Assign Pin V20 to I2C 1 clock pin and Pin W20 to I2C 1 data pin.



II. Software Development


Use the I2C example program in the appendix as a starting point to read two I2C TMP101 sensors with different addresses. One sensor is configured to have 12-bit resolution and the other 10-bit resolution. Display their temperatures in both Celsius and Fahrenheit are displayed on the series terminal of the SDK.

I. Good Block Design Practice

Project file name should not be more than 256 characters and should not contain any special characters such as space, dash, etc.

I.1 Run Block Automation Right Away

After adding a zynq block to your block design, always click Run Block Automation to make sure your UART 1 is configured correctly. Do not manually change UART 1 configuration in Peripheral I/O Pins configuration menu.




I.2 Run Generate Output Products after Block Design Change

Always run Generate Output Products after each block design change and before creating the HDL wrapper. Sometimes it is better to remove the HDL wrapper before running Generate Output Products.

This is to make sure all software drivers are associated correctly with hardware IP components.

II. Possible Errors



II.1 printf() and xil_printf() should not be used together

printf() and xil_printf() are independent of each other. If they are used together, xil_printf() may display faster than printf() even if printf() is called first. Therefore, the text on display may seem to be out of order.

II.2 printf() errors

Printf() uses stack to operate. If the stack size is too small, printf() may work strangely. Make sure the stack size is at last 3KB.




II.3 An Error on I/O Standard.

If you see the following error, change the I/O standard for pin V20 and W20 to LVCMOS33.






The default I/O standard is LVCMOS18 (1.8V) but the required I2C standard should be 3.3V.




Here is the correct I/O standard: LVCOMS33



II.4 Out of Context settings error: the hardware handoff (.sysdef) does not exist

This error occurs when out of context settings is checked. Disabling "out of context settings" would fix this error.







III. Appendix xiicps_polled_master_example.c

The following example, xiicps_polled_master_example.c is from C:\Xilinx\SDK\2016.2\data\embeddedsw\XilinxProcessorIPLib\drivers\iicps v3 2\examples.

```
/* Copyright (C) 2010 - 2014 Xilinx, Inc. All rights reserved. */
* @file xiicps polled master example.c
* A design example of using the device in polled mode as master.
* The example uses buffer size 132. Please set the send buffer of the
* Aardvark device to be continuous 64 bytes from 0x00 to 0x3F.
*  MODIFICATION HISTORY:
* Ver Who Date Changes
* _____
* 1.00a jz 01/30/10 First release
#include "xparameters.h"
#include "xiicps.h"
#include "xil printf.h"
* The following constants map to the XPAR parameters created in the
* xparameters.h file. They are defined here such that a user
* can easily change all the needed parameters in one place.
#define IIC DEVICE ID
                                   XPAR XIICPS 0 DEVICE ID
/* The slave address to send to and receive from.*/
#define IIC SLAVE ADDR
                                  0x55
#define IIC SCLK RATE
                                   100000
/*The following constant controls the length of the buffers to be sent
* and received with the IIC. */
#define TEST BUFFER SIZE 132
int IicPsMasterPolledExample(u16 DeviceId);
/************* Variable Definitions *********/
XIicPs Iic:
                    /**< Instance of the IIC Device */
/* The following buffers are used in this example to send and
* receive data with the IIC. */
u8 SendBuffer[TEST_BUFFER_SIZE]; /**< Buffer for Transmitting Data */
u8 RecvBuffer[TEST BUFFER SIZE]; /**< Buffer for Receiving Data */
/****************
* Main function to call the polled master example.
* @param
            None.
* @return
            XST SUCCESS if successful, XST FAILURE if unsuccessful.
* @note
                 None.
int main(void)
     int Status;
     xil printf("IIC Master Polled Example Test \r\n");
```



```
/* Run the Iic polled example in master mode, specify the Device
* ID that is specified in xparameters.h. */
      Status = IicPsMasterPolledExample(IIC DEVICE ID);
      if (Status != XST SUCCESS) {
              xil_printf("IIC Master Polled Example Test Failed\r\n");
              return XST FAILURE;
      }
xil printf("Successfully ran IIC Master Polled Example Test\r\n");
      return XST SUCCESS;
* This function sends data and expects to receive data from
* slave as modular of 64.
* This function uses interrupt-driven mode of the device.
* @param
              DeviceId is the Device ID of the IicPs Device and is the
              XPAR <IICPS instance> DEVICE ID value from xparameters.h
* @return
              XST SUCCESS if successful, otherwise XST FAILURE.
* @note
int IicPsMasterPolledExample(u16 DeviceId)
      int Status;
      XIicPs Config *Config;
      int Index;
/* Initialize the IIC driver so that it's ready to use
* Look up the configuration in the config table, then initialize it*/
      Config = XIicPs LookupConfig(DeviceId);
      if (NULL == Config) {
              return XST FAILURE;
      Status = XIicPs CfgInitialize(&Iic, Config, Config->BaseAddress);
      if (Status != XST_SUCCESS) {
              return XST FAILURE;
/* Perform a self-test to ensure that the hardware
* was built correctly. */
      Status = XIicPs SelfTest(&Iic);
      if (Status != XST SUCCESS) {
              return XST FAILURE;
/* Set the IIC serial clock rate. */
      XIicPs SetSClk(&Iic, IIC SCLK RATE);
/* Initialize the send buffer bytes with a pattern to send and the
* the receive buffer bytes to zero to allow the receive data to be
* verified. */
      for (Index = 0; Index < TEST BUFFER SIZE; Index++) {
              SendBuffer[Index] = (Index % TEST BUFFER SIZE);
              RecvBuffer[Index] = 0;
/* Send the buffer using the IIC and ignore the number of bytes sent
* as the return value since we are using it in interrupt mode. */
      Status = XIicPs MasterSendPolled(&Iic, SendBuffer,
```



```
TEST_BUFFER_SIZE, IIC_SLAVE_ADDR);
      if (Status != XST_SUCCESS) {
              return XST FAILURE;
/* Wait until bus is idle to start another transfer. */
      while (XIicPs BusIsBusy(&Iic)) {
              /* NOP */
     Status = XIicPs MasterRecvPolled(&Iic, RecvBuffer,
                       TEST_BUFFER_SIZE, IIC_SLAVE_ADDR);
      if (Status != XST SUCCESS) {
             return XST_FAILURE;
/* Verify received data is correct. */
      for(Index = 0; Index < TEST_BUFFER_SIZE; Index ++) {
/* Aardvark as slave can only set 64 bytes for output */
              if (RecvBuffer[Index] != Index % 64) {
                      return XST FAILURE;
     return XST_SUCCESS;
```

lab8I2ConARM template.c

```
1//lab8I2ConARM templat.c
 3//This is a recommended template for Lab #8\
 4//lab8I2ConARM ???, where ??? is your name initial
 5//Summer 2021, HUST
 6//Lab #8 to read two tmp101 breakout boards from both PL and PS sides with ARM I2C
 modules
 7//Date: 1-14-2019
 8//separate I2C instance configuration and TMP101 configuration
 9//Revision to make the code more modular and portable
10
11 #include <stdio.h>
12 #include "xparameters.h"
13 #include <xiicps.h>
14
15 #define PS I2C DEVICE ID XPAR PS7 I2C 0 DEVICE ID
16 #define PS DATA RATE 100000 // 100KHz
17 #define PS TMP101 ADDRESS 0b1001001 //floating
18 #define PS TMP101 RESOLUTION 0b01100000 //12 bit resolution for TMP101
20 #define PL_I2C_DEVICE_ID XPAR_PS7_I2C 1 DEVICE ID
21 #define PL DATA RATE 200000 // 200KHz
22 #define PL TMP101 ADDRESS 0b1001000 //ground
23 #define PL TMP101 RESOLUTION 0b00100000 //10 bit resolution for TMP101
25 XIicPs i2c ps, i2c pl;
                       //device instances
27 #define DELAYLOOPCOUNT 80000000
28//function prototype
29 int ReadTemperature (XIicPs * I2Cinstance, float * temperature, int I2C address);
31 /*******************
32 * This function ConfigureTMP101() configures an I2C TMP101 instance.
33 *
34 * @param I2Cinstance is a pointer to an I2C instance.
35 * @param
           I2CAddress is the address of I2C TMP101 chip.
36 * @param
            TEMPresolution is .the resolution of TMP101 temperature as 0b0RR00000
37 *
38 * @return
39 * - XST SUCCESS if everything went well.
40 *
         - XST FAILURE if failed.
41 *
44 int ConfigureTMP101 (XIicPs *I2Cinstance, u8 I2CAddress, u8 TEMPresolution) {
45
     u8 SetPointertoZero=0b00000000;
     u8 SetResolution[]={0b00000001,0b00000000};
46
47
48
     SetResolution[1] = TEMPresolution;
49
50 //Set resolution
52 //set pointer back to 0x00 to point to the temperature value
53
54
     return XST SUCCESS;
55 } //end ConfigureTMP101()
```

lab8I2ConARM template.c

```
58 * This function ConfigureI2Cinstance() configures an I2C instance.
 59 *
 60 * @param
              I2Cinstance is a pointer to an I2C instance.
 61 * @param
              I2CdeviceID is the ID of I2C device defined in xparamenters.h.
 62 * @param
              I2C ClockRate is clock frequency of I2C TMP101 in Hz.
 63 *
 64 * @return
 65 * - XST SUCCESS if everything went well.
 66 *
          - XST FAILURE if failed.
 67 *
 69 int Configure I2Cinstance (XIicPs *I2Cinstance, int I2CdeviceID, int I2C ClockRate) {
 70
 71
      XIicPs Config *I2C config;
 72//Call lookup table to find I2C hardware module for I2CdeviceID
 73
          I2C config = XIicPs LookupConfig(I2CdeviceID);
 74
          if (NULL == I2C config) {
 75
              XST FAILURE;
 77//Initialize I2C instance. Return XST FAILTURE if failed.
 78
 79
 80//\text{Self} test. Return XST FAILTURE if failed
 81
 82
 83//Set I2C clock frequency. Return XST FAILTURE if failed
 86//Wait when I2Cdevice is busy until bus is idle to start another transfer
 87
 88
 89
          return XST SUCCESS;
 90
 91
 92 } // end ConfigureI2Cinstance()
 94 int main()
 95 {
 96
      float temp ps, temp pl;
 97
      unsigned int loopcount;
      int status=XST FAILURE;
 99
      printf("\r\n\n -- Start Lab #8 I2C for TMP101 --\r\n");
100
101 //configure I2C instance and tmp101 board on PS port
102
      ConfigureI2Cinstance();
       if(status == XST_FAILURE) printf("\r\n Failed to configure I2C instance on PS.");
103
104
      ConfigureTMP101();
105//configure I2C instance and tmp101 board on PL port
106
      ConfigureI2Cinstance();
      if(status == XST FAILURE) printf("\r\n Failed to configure I2C instance on PL.");
107
108
      ConfigureTMP101();
109
      while(1) {
110 //Read tmp101 board and calculate temperature value on PS port
111
      status=ReadTemperature();
112
      if(status == XST FAILURE) printf("\r\n Failed to read TMP101 from PS on bottom row
   of Connector JF.");
113
```

lab8I2ConARM template.c

```
114//Read tmp101 board and calculate temperature value on PL port
115
   status=ReadTemperature();
      if(status == XST FAILURE) printf("\r\n Failed to read TMP101 from PL on top row of
  Connector JB.");
117
118 //printing floating numbers is not supported by xil printf().
119//Use printf() from <stdio.h> to print floating points.
120 //Mixing Xil printf() with printf() may cause some printf() being dropped.
121 //Display temperature in floating point number with 4 digits after decimal point
         printf("\n\r");
122
123
124
125 //delay loop to pause for a while
126
         127
128 } //while(1)
129 while(1); // hold just in case
130 } //end main()
131
133 * This function ReadTemperature() reads temperature of an TMP101.
134 *
135 * @param
            I2Cinstance is a pointer to an I2C instance.
136 * @param temperature is the returned floaing point temperature value.
137 * @param
            I2C address is the address of I2C TMP101 chip.
138 *
139 * @return
140 * - XST SUCCESS if everything went well.
141 *
         - XST FAILURE if failed.
142 *
144 int ReadTemperature (XIicPs * I2Cinstance, float * temperature, int I2C address) {
      u8 temp[2]; //2 byte temperature
145
      u8 SetPointertoZero=0b00000000;
147//set pointer back to 0x00 to point to the temperature value
148
149
150 //Read temperature. Return XST FAILURE if failed
153 //Convert temperature to floating number
154
155
156
         return XST SUCCESS;
157 } //end of ReadTemperature()
158
```