Thank you for your recent purchase of the **vSeeBox V6 Plus**, the newest digital streaming hardware. vSeeBox V6 Plus is the newest 2025 model upgraded from the 2024 V3 Plus. Compared with the previous generation v3Plus, V6plus has huge upgrades in hardware and software, with faster speed and more powerful performance!
Featured a brand-new design look, all-new **backlit** remote, be the first to experience the all-new VseeBox V6 Plus, the ultimate Android TV Box built for next-generation streaming.

Note: You will need two AA batteries for the remote, as it does not come with them.

Unboxing, Physical, and Software Setup

What's included in the box?


- vSeeBox V6 Plus x 1
- Bluetooth Remote Control x 1
- User Manual x 1
- HDMI 2.0 Cable x 1
- Power Supply x 1

How do I connect the box to the TV?

1. When looking at the back of the box, connect the power adapter to the far right port on the back of the vSeeBox.
2. Connect the vSeeBox to your TV with the HDMI cable provided. If you already have an HDMI cable plugged into your TV you wish to use, you can use it as well.
3. ***Optional:*** If you are connecting your vSeeBox with an Ethernet cable for a direct internet connection, connect the vSeeBox to your router now.
4. At this point, your vSeeBox should be powering on, and you will see "Boot" on the box's display screen. Ensure the source on your TV matches whatever HDMI port you plugged the box into on your TV.


How do I proceed with the software setup?

1. After the box boots up for the first time, it will bring you to a screen to pair the remote control. Ensure you have put the batteries into the remote, hold both "**OK**" and "**VOL—"** buttons at the same time while pointing the remote in the direction of the box until the red light flashes on the remote indicator. The screen will tell you when to release the buttons and when the remote has been paired successfully.







2. Select the language, then press **OK** to proceed to the next step.




3. Adjust the screen ratio if needed by selecting **Zoom in screen** or **Zoom out screen**, otherwise press **Next**.



4. Select the time zone and then press the **OK** button.



5. Read the disclaimer message, then press the **OK** button.




6. If using Wi-Fi, you will now be prompted to select your **Wi-Fi** network. Select your Wi-Fi network from the list and input your Wi-Fi password; you should see a **Connection Successful** message.



7. After connecting the device to the internet, the box will begin downloading and installing the applications and the default configuration. This usually takes around five minutes, depending on your connection speed.




8. After the installation is complete, the box will show the main screen with all of the available applications.



Programming the vSeeBox Remote to the TV

1. To program the vSeeBox remote to your television to control the volume and power on/off, you will need the original remote control for the TV.
2. On the vSee remote, hold the blue/white **TV Control** power button in the top left corner for 5 seconds. The blue light on the remote will go from blinking to solid. Once it goes to solid, it is in pairing mode.



3. On the **vSeeBox** remote, press one of the four buttons in the top to program. (OK, TV IN, VOL -, VOL +). The blue light will begin blinking slowly, which means it is ready to pair with the button you just pressed.



4. Take the original TV remote and point the remote controls together so the eyes are facing one another. Then, press the button you are trying to program for the TV. For example, if in Step 3 you pressed **VOL -**, press **VOL—** on the TV remote as well, with the remotes facing each other. If successful, the blue light will flash three times.



5. Continue this process for the remaining buttons. **Note:** The “TV IN” button doesn’t need to be programmed if you aren’t switching sources on the TV.
6. After you have completed the programming of the TV remote, press the **OK** button on the **vSeeBox** remote to exit pairing mode.

   It is recommended to set the TV volume to the loudest you want it using the TV controls on the top left corner of the remote. After setting the volume as loud as you want it, you can use the **Vol + and -** buttons at the bottom of the remote, which control the audio of the box itself.

Powering the Device and TV On/Off

To power your vSeeBox on and off, simply press the **Red Power Button** on the top right corner of the remote.

To power on and off your TV after programming it with the steps above, you can use the **White Power Button** on the top left of the remote.



Streaming Apps on vSeeBox

Note: It is not recommended to use the streaming applications on the vSeeBox, such as YouTube, Netflix, Disney+, or Prime Video, as they are not stable.

The V6 Plus comes with **SIX** streaming applications, which are outlined below:


Heat Live


This is the application that will be used for all Live TV channels.

First Time Launch

When launching this app for the first time, you will receive a permission message; just select **Allow** and press **OK**.

Optional: Press the **Menu** button on the remote, then go to **Setting** and press **OK**. Turn off the **Make internet speed visible** option, then select **Change text size** → select **Large** or **Extra Large**, then click on **RESTART APP NOW.**







TV Guide Option 1

There are two different TV guide options. The first is available if you press the **EPG** button on the remote.

On the **EPG** guide, you will notice a list of categories on the left side. To get to the left side to select a category, **hold the left arrow button next to OK**.



You will notice a line down the guide; this is the current time.



You can use the up/down arrows to navigate through the guide one by one, or you can use the Channel Up/Down button to navigate by page.




To change the date of the guide, press the up button and switch the date with the left/right arrows.

Note: When you change the date, be sure to check the times at the top of the guide as they will default to 12 AM. To go back to the current time, just move to the right and find the line on the guide that indicates the current time.


TV Guide Option 2


For the second guide option, when you are on a channel, press the **OK** button.
This guide also allows you to switch categories and search for a specific channel. It also allows you to set favorite channels, which is in the next section.



Favorite List

Additionally, you can set a **Favorite Channel,** which will appear in the **Favorite List** on the left side. To set a favorite channel, find the channel you want to make a favorite in the second guide, highlight it, and press and hold the **OK** button. You will notice a **Heart** appears next to the channel. To remove a favorite, perform the same steps, and the **Heart** will disappear.





Voice Assistance

The last item I will touch on is the **Voice Assistance** button. This button is under the **Home** button. It has a blue, red, green, and yellow set of circles. When pressing this button for the first time, you will receive a permission request. Select **"While using the app**." You can push this button and speak a channel name into the remote, and the results will display as follows. This is the quickest way to find a channel without looking through the guide or knowing the number.





Live Ultra

This is another app that has live channels. In the unlikely event a channel is missing from **Heat Live**, you can use this channel to see if it's available. All of the above information for **Heat Live** also applies here.

Live Ultra+

New Split-screen Features are now available!

Multitasking just got easier! With the all-new **split-screen** feature, you can watch multiple channels at the same time — no more switching back and forth. Stay in the action, catch every moment, all on one screen.


Heat LIVE

This app offers live channels, sports, and pay-per-view events.


Heat VOD

This app is used to access movies and TV series.

After opening the app, select which you would like to view, **TV Series** or **Movies**. You can also view your **History** of previously watched items.



You can browse through the category list on the left or click the **Search** option and search for a movie or series by title.




Note: If you are searching for a TV Series or Movie, make sure you select the correct one from the home screen, as it won't show all results for both.

VOD Ultra

This is another app for streaming movies and TV series. The only difference is that this app classifies the shows by streaming Platform.

Select the category you wish to watch, either **Movie** or **TV Series**.



You will now see that the left side classifies the shows and movies by the streaming platform. You can also search for a show or movie if you couldn't locate it on **Heat VOD**.



Backup by Heat

This is a backup live TV channel if the main **Heat Live** isn't functioning. It works the same as the **Heat Live** app.

Troubleshooting

Please refer to pages 7 and 8 of the vSeeBox instruction manual that came with your device.