12 July 2022 12:36

1. Change the user permission for below folder to 755

```
cd /
sudo chmod 755 /usr/
```

2. Install pymssql using below commands

```
sudo apt-get update -y
sudo apt-get install -y freetds-dev
sudo apt install unixodbc-dev
pip3.8 install pymssql
```

- 3. pip3.8 install pyserial
- 4. If dev/ttlS0 port is not open for serial inward communication

5. Set /dev/ttySO file permission (follow next page)