- 1. REMOVE R29
- 2. ATTACH REGULATOR PCB TO MAIN PCB AS SHOWN USE DOW 748 RTV and UV Super GLUE
- 3. Solder 24 AWG Solid wire from R29 Via to OUT of REG PCB
- 4. Solder 24AWG BLACK wire from Pin2 of BATT conn to GND pin of REG PCB5. Solder 24AWG RED wire from Pin 1 of Batt conn to IN of REG PCB





