


PAUSE COUNTING BY PRESSING COUNT/RESET
(FIRST DIGIT WILL BLINK WHILE PAUSED)
RESUME COUNTING BY PRESSING COUNT/RESET AGAIN
PRESS SETUP TO ENTER FAST DIGIT SETTING
THEN PRESS COUNT/RESET TO INCREMENT
PRESS SETUP 2X TO ENTER COUNTING MODE SELECTION
THEN PRESS COUNT/RESET TO SELECT
RESET COUNT BY HOLDING COUNT/RESET UNTIL
ALL DIGITS ARE BLINKING
EXTERN PWR
3V
GND
16
12
4
0

2/6/2025 5:13 PM f=2.00 C:\Users\USER\Documents\GitHub\BeanCounter\hardware\BeanCounter_V10.brd