






Use 4 M3x8mm bolts with washers to fasten upper and lower parts of differential pivot.




Use 10 M3x16mm bolts and nuts (with washers) to fasten top and bottom parts of differential brace together.



Insert 2 M3 nut installation tools in center of differential beam side slots for future attachment of differential.

6 M3 nut installation tools, 12 M3x8mm bolts with washers.



2 M3 set screws to hold the links in place on the pivot shaft.



Bolt the differential onto the beam with 4 M3x8mm bolts with washers and the 2 previously installed M3 nut installation tools.



Bolt differential onto body box with 12 M3x8mm bolts with washers.



The Differential Ends should be about 20mm from the Rocker Body mounts. The distance will vary slightly, depending on the length of the turnbuckle used.