


Programmable Controller



Programming Manual (Structured Text)



• SAFETY PRECAUTIONS •

(Always read these precautions before use)

Before using the MELSEC-Q series or MELSEC-L series PLC, thoroughly read the manuals attached to the products and the relevant manuals introduced in the attached manuals. Also pay careful attention to safety and handle the products properly.

Please save the manuals attached to the products carefully to make them accessible when required, and always forward them to the end user.

• CONDITIONS OF USE FOR THE PRODUCT •

- (1) Mitsubishi programmable controller ("the PRODUCT") shall be used in conditions;
 - i) where any problem, fault or failure occurring in the PRODUCT, if any, shall not lead to any major or serious accident; and
 - ii) where the backup and fail-safe function are systematically or automatically provided outside of the PRODUCT for the case of any problem, fault or failure occurring in the PRODUCT.
- (2) The PRODUCT has been designed and manufactured for the purpose of being used in general industries.

MITSUBISHI SHALL HAVE NO RESPONSIBILITY OR LIABILITY (INCLUDING, BUT NOT LIMITED TO ANY AND ALL RESPONSIBILITY OR LIABILITY BASED ON CONTRACT, WARRANTY, TORT, PRODUCT LIABILITY) FOR ANY INJURY OR DEATH TO PERSONS OR LOSS OR DAMAGE TO PROPERTY CAUSED BY the PRODUCT THAT ARE OPERATED OR USED IN APPLICATION NOT INTENDED OR EXCLUDED BY INSTRUCTIONS, PRECAUTIONS, OR WARNING CONTAINED IN MITSUBISHI'S USER, INSTRUCTION AND/OR SAFETY MANUALS, TECHNICAL BULLETINS AND GUIDELINES FOR the PRODUCT.

("Prohibited Application")

Prohibited Applications include, but not limited to, the use of the PRODUCT in:

- Nuclear Power Plants and any other power plants operated by Power companies, and/or any other cases in which the public could be affected if any problem or fault occurs in the PRODUCT.
- Railway companies or Public service purposes, and/or any other cases in which establishment of a special quality assurance system is required by the Purchaser or End User.
- Aircraft or Aerospace, Medical applications, Train equipment, transport equipment such as Elevator and Escalator, Incineration and Fuel devices, Vehicles, Manned transportation, Equipment for Recreation and Amusement, and Safety devices, handling of Nuclear or Hazardous Materials or Chemicals, Mining and Drilling, and/or other applications where there is a significant risk of injury to the public or property.

Notwithstanding the above, restrictions Mitsubishi may in its sole discretion, authorize use of the PRODUCT in one or more of the Prohibited Applications, provided that the usage of the PRODUCT is limited only for the specific applications agreed to by Mitsubishi and provided further that no special quality assurance or fail-safe, redundant or other safety features which exceed the general specifications of the PRODUCTs are required. For details, please contact the Mitsubishi representative in your region.

REVISIONS

* The manual number is given on the bottom left of the back cover.

| Print Date | * Manual Number | Revision |
|-------------|------------------------|--|
| Feb., 2003 | SH (NA) 080366E-A | |
| Jul., 2003 | SH (NA) 080366E-B | Correction |
| | | Section 6.7.1, Section 6.7.2, Section 6.7.3, Section 6.9.1, Section 6.9.2, Section 6.9.3, Section 6.9.4, Section 6.9.5, Section 6.9.6, Chapter 7 |
| Jun., 2004 | SH (NA) 080366E-C | Additional models |
| | | Q12PRHCPU, Q25PRHCPU |
| | | Correction |
| | | Abbreviations and Generic Terms in This Manual |
| | | Section 2.1.1, Section 2.1.3, Chapter 5, Chapter 6, Section 6.1.8, |
| Feb., 2006 | SH (NA) 080366E-D | Section 6.1.14, Section 6.8.3, Chapter 7, WARRANTY Correction |
| 1 00., 2000 | OTT (147.1) 0000000L D | Section 6.1.14 |
| May, 2008 | SH (NA) 080366E-E | Correction |
| ,, | | Abbreviations and Generic Terms in This Manual, Section 2.1.1 |
| Oct., 2008 | SH (NA) 080366E-F | Additional models |
| | , , | Q00UJCPU, Q00UCPU, Q01UCPU, Q10UDHCPU, Q10UDEHCPU, |
| | | Q20UDHCPU, Q20UDEHCPU |
| | | Correction |
| | | Abbreviations and Generic Terms in This Manual, Section 2.1.1, |
| | | Section 3.2.1, Section 4.2.2 |
| Jan., 2009 | SH (NA) 080366E-G | Correction |
| | | Section 2.1.3, Chapter 5 |
| Jan., 2010 | SH (NA) 080366E-H | Additional models |
| | | L02CPU, L26CPU-BT |
| | | Addition |
| | | CONDITIONS OF USE FOR THE PRODUCT, Appendix 2 |
| | | Correction |
| | | SAFETY PRECAUTIONS, About Manuals, |
| | | Abbreviations and Generic Terms in This Manual, Section 1.2, Section 2.1.1, Section 2.1.3, Section 3.1, Section 3.3, Section 3.3.1, |
| | | Section 3.3.3, Section 4.2.1, Section 4.2.2, Chapter 5, |
| | | Section 5.16.1 to 5.16.4, Section 5.20.1, Section 5.20.2, Chapter 6, |
| | | Chapter 7,Appendix 1 |
| | | |
| | | |

* The manual number is given on the bottom left of the back cover.

| Print Date | * Manual Number | Revision |
|------------|-------------------|--|
| Oct., 2010 | SH (NA) 080366E-I | Correction |
| | | Section 3.2.3, Section 4.3.5, Section 5.16.1, Section 5.16.2 |
| Oct., 2014 | SH (NA) 080366E-J | Correction |
| | | About Manuals, How to Use This Manual, Section 4.3.3 |
| Feb., 2019 | SH (NA) 080366E-K | |
| | | Abbreviations and Generic Terms in This Manual, Section 5.10.6 |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |

Japanese Manual Version SH-080363-L

This manual confers no industrial property rights or any rights of any other kind, nor does it confer any patent licenses. Mitsubishi Electric Corporation cannot be held responsible for any problems involving industrial property rights which may occur as a result of using the contents noted in this manual.

INTRODUCTION

Thank you for choosing the Mitsubishi MELSOFT series Integrated FA software. Read this manual and make sure you understand the functions and performance of MELSEC series sequencer thoroughly in advance to ensure correct use.

CONTENTS

| SAFETY PRECAUTIONS CONDITIONS OF USE FOR THE PRODUCT REVISIONS INTRODUCTION CONTENTS About Manuals How to Use This Manual Abbreviations and Generic Terms in This Manual | A- 2 A- 3 A- 5 A- 5 A-13 A-14 |
|---|---|
| 1. OVERVIEW | 1- 1 to 1- 4 |
| 1.1 What Is the ST Language? 1.2 Features of ST Program in MELSEC-Q/L Series 1.3 ST Program Creating Procedure | 1- 3 |
| 2. SYSTEM CONFIGURATION | 2- 1 to 2- 3 |
| 2.1 System Configuration 2.1.1 Applicable CPUs | 2- 1 2- 1 |
| 3. HANDLING OF CHARACTERS AND NUMERIC VALUES IN ST PROGRAMS | 3- 1 to 3-16 |
| 3.1 Usable Characters 3.2 Data Handling | 3- 3 3- 3 3- 4 3- 5 3- 8 3- 8 3- 11 |
| 4. ST PROGRAM EXPRESSIONS | 4- 1 to 4-33 |
| 4.1 Assignment Statement | 4- 2 4- 2 |
| | |

| 4.3 Control Syntaxes | | 4- 6 |
|---|---------------------------------------|-------|
| 4.3.1 Control syntax list | | 4- 6 |
| 4.3.2 Conditional statements | | 4- 7 |
| 4.3.3 Repeat statement | | 4-15 |
| 4.3.4 Other control syntaxes | | 4-20 |
| 4.3.5 Precautions for use of control syntaxes | | 4-22 |
| 4.4 Call of Function Block | | |
| 4.5 Comment | | 4-32 |
| 5. MELSEC FUNCTIONS | 5- 1 to 5 | - 114 |
| How the functions are described | | |
| 5.1 Output | | |
| 5.1.1 Output to device | <u>–</u> | |
| 5.1.2 Low-speed timer | _ | |
| 5.1.3 High-speed timer | | |
| 5.1.4 Counter | - | |
| 5.1.5 Set of device | - | |
| 5.1.6 Reset of device | _ | |
| 5.1.7 Conversion of direct output into pulse | <u>–</u> | |
| 5.2 1-Bit Shift | | |
| 5.2.1 1-bit shift of device | _ | |
| 5.3 Termination | | |
| 5.3.1 Stop | _ | |
| 5.4 Comparison Operation | | |
| 5.4.1 Block data comparison (=) | | |
| 5.4.3 Block data comparison (>) | | |
| 5.4.4 Block data comparison (<=) | | |
| 5.4.5 Block data comparison (<) | | |
| 5.4.6 Block data comparison (>=) | | |
| 5.5 Arithmetic Operation | | |
| 5.5.1 Addition of BCD 4-digit data (2 devices) | | |
| 5.5.2 Addition of BCD 4-digit data (3 devices) | | |
| 5.5.3 Subtraction of BCD 4-digit data (2 devices) | — — | |
| 5.5.4 Subtraction of BCD 4-digit data (3 devices) | _ | |
| 5.5.5 Addition of BCD 8-digit data (2 devices) | — — — | |
| 5.5.6 Addition of BCD 8-digit data (3 devices) | - | |
| 5.5.7 Subtraction of BCD 8-digit data (2 devices) | | |
| 5.5.8 Subtraction of BCD 8-digit data (3 devices) | _ | |
| 5.5.9 Multiplication of BCD 4-digit data | | |
| 5.5.10 Division of BCD 4-digit data | _ | |
| 5.5.11 Multiplication of BCD 8-digit data | _ | |
| 5.5.12 Division of BCD 8-digit data | _ | |
| 5.5.13 Character string data connection (2 devices) | _ | |
| 5.5.14 Character string data connection (3 devices) | — — — — — — — — — — — — — — — — — — — | |
| 5.5.15 BIN block addition | BKPLUS_M | 5-20 |
| 5.5.16 BIN block subtraction | BKMINUS_M | 5-20 |
| | | |

| 5.5.17 Increment | INC_M | 5-21 |
|--|---------------------------------------|------|
| 5.5.18 Decrement | DEC_M | 5-21 |
| 5.5.19 32-bit BIN increment | DINC_M | 5-22 |
| 5.5.20 32-bit BIN decrement | DDEC_M | 5-22 |
| 5.6 Data Conversion | | 5-23 |
| 5.6.1 BIN → BCD conversion | BCD_M | 5-23 |
| 5.6.2 32-bit BIN → BCD conversion | DBCD_M | 5-23 |
| 5.6.3 BCD → BIN conversion | BIN_M | 5-24 |
| 5.6.4 32-bit BCD → BIN conversion | DBIN_M | 5-24 |
| 5.6.5 Floating-point → BIN conversion | INT_E_MD | 5-25 |
| 5.6.6 32-bit floating-point → BIN conversion | DINT_E_MD | 5-25 |
| 5.6.7 BIN → floating-point conversion | | |
| 5.6.8 32-bit BIN → floating-point conversion | _ | |
| 5.6.9 16-bit BIN → 32-bit BIN conversion | - | |
| 5.6.10 32-bit BIN → 16-bit BIN conversion | — | |
| 5.6.11 BIN → gray code conversion | - | |
| 5.6.12 32-bit BIN → gray code conversion | _ | |
| 5.6.13 Gray code → BIN conversion | — | |
| 5.6.14 32-bit gray code → BIN conversion | _ | |
| 5.6.15 2' complement of 16-bit BIN | - | |
| 5.6.16 2' complement of 32-bit BIN | | |
| 5.6.17 2' complement of floating-point | _ | |
| 5.6.18 Block BIN → BCD conversion | - | |
| 5.6.19 Block BCD → BIN conversion | — | |
| 5.7 Data Transfer | _ | |
| 5.7.1 16-bit data NOT transfer | | |
| 5.7.2 32-bit data NOT transfer | — | |
| 5.7.3 Block transfer | | |
| 5.7.4 Same data block transfer | — | |
| 5.7.5 16-bit data exchange | _ | |
| 5.7.6 32-bit data exchange | | |
| 5.7.7 Block data exchange | - | |
| 5.7.8 First/last byte exchange | — | |
| 5.8 Program Execution Control | - | |
| 5.8.1 Interrupt disable | | |
| 5.8.2 Interrupt enable | _ | |
| 5.9 I/O Refresh | – | |
| 5.9.1 I/O refresh | | |
| 5.10 Logical Operation Commands | — | |
| 5.10.1 Logical product (2 devices) | | |
| 5.10.2 Logical product (3 devices) | | |
| 5.10.3 32-bit data logical product (2 devices) | | |
| 5.10.4 32-bit data logical product (3 devices) | _ | |
| 5.10.5 Block data logical product | | |
| 5.10.6 Logical sum (2 devices) | - | |
| 5.10.7 Logical sum (3 devices) | - | |
| 5.10.8 32-bit data logical sum (2 devices) | — — — — — — — — — — — — — — — — — — — | |
| 5.10.9 32-bit data logical sum (3 devices) | _ | |
| 5. 1.5 52 5.t data 15g.5at 6ath (6 do 11005) | | 5 40 |

| 5.10.10 Block data logical sum | BKOR_M | 5-43 |
|---|--------------|------|
| 5.10.11 Exclusive OR (2 devices) | WXOR_M | 5-44 |
| 5.10.12 Exclusive OR (3 devices) | WXOR_3_M | 5-44 |
| 5.10.13 32-bit data exclusive OR (2 devices) | DXOR_M | 5-45 |
| 5.10.14 32-bit data exclusive OR (3 devices) | DXOR_3_M | 5-45 |
| 5.10.15 Block data exclusive OR | BKXOR_M | 5-46 |
| 5.10.16 NOT exclusive OR (2 devices) | WXNR_M | 5-46 |
| 5.10.17 NOT exclusive OR (3 devices) | WXNR_3_M | 5-47 |
| 5.10.18 32-bit data NOT exclusive OR (2 devices) | DXNR_M | 5-47 |
| 5.10.19 32-bit data NOT exclusive OR (3 devices) | DXNR_3_M | 5-48 |
| 5.10.20 Block data NOT exclusive OR | BKXNR_M | 5-48 |
| 5.11 Rotation | | 5-49 |
| 5.11.1 Right rotation (carry flag not included) | ROR_M | 5-49 |
| 5.11.2 Right rotation (carry flag included) | RCR_M | 5-49 |
| 5.11.3 Left rotation (carry flag not included) | ROL_M | 5-50 |
| 5.11.4 Left rotation (carry flag included) | RCL_M | 5-50 |
| 5.11.5 32-bit data right rotation (carry flag not included) | DROR_M | 5-51 |
| 5.11.6 32-bit data right rotation (carry flag included) | DRCR_M | 5-51 |
| 5.11.7 32-bit data left rotation (carry flag not included) | DROL_M | 5-52 |
| 5.11.8 32-bit data left rotation (carry flag included) | DRCL_M | 5-52 |
| 5.12 Shift | | 5-53 |
| 5.12.1 n-bit right shift | SFR_M | 5-53 |
| 5.12.2 n-bit left shift | SFL_M | 5-53 |
| 5.12.3 n-bit data 1-bit right shift | BSFR_M | 5-54 |
| 5.12.4 n-bit data 1-bit left shift | BSFL_M | 5-54 |
| 5.12.5 1-word right shift | DSFR_M | 5-55 |
| 5.12.6 1-word left shift | DSFL_M | 5-55 |
| 5.13 Bit Processing | | 5-56 |
| 5.13.1 Bit set of word device | BSET_M | 5-56 |
| 5.13.2 Bit reset of word device | BRST_M | 5-56 |
| 5.13.3 Bit test of word device | TEST_MD | 5-57 |
| 5.13.4 Bit test of 32-bit data | - | |
| 5.13.5 Bit device batch reset | BKRST_M | 5-58 |
| 5.14 Data Processing | | 5-59 |
| 5.14.1 Data search | SER_M | 5-59 |
| 5.14.2 32-bit data search | DSER_M | 5-59 |
| 5.14.3 Bit check | SUM_M | 5-60 |
| 5.14.4 32-bit data bit check | DSUM_M | 5-60 |
| 5.14.5 Decode | DECO_M | 5-61 |
| 5.14.6 Encode | - | |
| 5.14.7 7-segment decode | | |
| 5.14.8 4-bit disconnection of 16-bit data | DIS_M | 5-62 |
| 5.14.9 4-bit connection of 16-bit data | — | |
| 5.14.10 Bit disconnection of any data | - | |
| 5.14.11 Bit connection of any data | NUNI_M | 5-64 |
| 5.14.12 Byte unit data disconnection | - | |
| 5.14.13 Byte unit data connection | _ | |
| 5.14.14 Data maximum value retrieval | MAX_M | 5-65 |
| | | |

| 5.14.15 32-bit data maximum value retrieval | DMAX_M | 5-66 |
|--|-------------|------|
| 5.14.16 Data minimum value retrieval | MIN_M | 5-66 |
| 5.14.17 32-bit data minimum value retrieval | DMIN_M | 5-67 |
| 5.14.18 Data sort | SORT_M | 5-67 |
| 5.14.19 32-bit data sort | DSORT_M | 5-68 |
| 5.14.20 Total value calculation | WSUM_M | 5-68 |
| 5.14.21 32-bit total value calculation | DWSUM_M | 5-69 |
| 5.15 Structuring | | 5-70 |
| 5.15.1 Refresh | COM_M | 5-70 |
| 5.16 Buffer Memory Access | | 5-71 |
| 5.16.1 Intelligent function module 1-word data read | FROM_M | 5-71 |
| 5.16.2 Intelligent function module 2-word data read | DFRO_M | 5-71 |
| 5.16.3 Intelligent function module 1-word data write | TO_M | 5-72 |
| 5.16.4 Intelligent function module 2-word data write | DTO_M | 5-72 |
| 5.17 Character string processing | | 5-73 |
| 5.17.1 BIN → decimal ASCII conversion | BINDA_S_MD | 5-73 |
| 5.17.2 32-bit BIN → decimal ASCII conversion | DBINDA_S_MD | 5-73 |
| 5.17.3 BIN → hexadecimal ASCII conversion | BINHA_S_MD | 5-74 |
| 5.17.4 32-bit BIN → hexadecimal ASCII conversion | DBINHA_S_MD | 5-74 |
| 5.17.5 BCD 4-digit → decimal ASCII conversion | BCDDA_S_MD | 5-75 |
| 5.17.6 BCD 8-digit → decimal ASCII conversion | DBCDDA_S_MD | 5-75 |
| 5.17.7 Decimal ASCII → BIN conversion | DABIN_S_MD | 5-76 |
| 5.17.8 Decimal ASCII → 32-bit BIN conversion | DDABIN_S_MD | 5-76 |
| 5.17.9 Hexadecimal ASCII → BIN conversion | HABIN_S_MD | 5-77 |
| 5.17.10 Hexadecimal ASCII → 32-bit BIN conversion | DHABIN_S_MD | 5-77 |
| 5.17.11 Decimal ASCII → BCD 4-digit conversion | DABCD_S_MD | 5-78 |
| 5.17.12 Decimal ASCII → BCD 8-digit conversion | DDABCD_S_MD | 5-78 |
| 5.17.13 Device comment data read | COMRD_S_MD | 5-79 |
| 5.17.14 Character string length detection | LEN_S_MD | 5-79 |
| 5.17.15 BIN → character string conversion | STR_S_MD | 5-80 |
| 5.17.16 32-bit BIN → character string conversion | DSTR_S_MD | 5-80 |
| 5.17.17 Character string → BIN conversion | VAL_S_MD | 5-81 |
| 5.17.18 Character string → 32-bit BIN conversion | DVAL_S_MD | 5-81 |
| 5.17.19 Floating-point → character string conversion | ESTR_M | 5-82 |
| 5.17.20 Character string → floating-point conversion | EVAL_M | 5-82 |
| 5.17.21 BIN → ASCII conversion | ASC_S_MD | 5-83 |
| 5.17.22 ASCII → BIN conversion | HEX_S_MD | 5-83 |
| 5.17.23 Fetch from character string right side | RIGHT_M | 5-84 |
| 5.17.24 Fetch from character string left side | LEFT_M | 5-84 |
| 5.17.25 Any data fetch in character string | MIDR_M | 5-85 |
| 5.17.26 Any data replacement in character string | MIDW_M | 5-85 |
| 5.17.27 Character string search | INSTR_M | 5-86 |
| 5.17.28 Floating-point → BCD decomposition | EMOD_M | 5-86 |
| 5.17.29 BCD format data → floating-point | EREXP_M | 5-87 |
| 5.18 Special Functions | | 5-88 |
| 5.18.1 Floating-point SIN operation | SIN_E_MD | 5-88 |
| 5.18.2 Floating-point COS operation | COS_E_MD | 5-88 |
| 5.18.3 Floating-point TAN operation | TAN_E_MD | 5-89 |
| | | |

| 5.18.4 Floating-point SIN-1 operation | ASIN_E_MD | 5-89 |
|---|---------------|----------|
| 5.18.5 Floating-point COS-1 operation | ACOS_E_MD | 5-90 |
| 5.18.6 Floating-point TAN-1 operation | ATAN_E_MD | 5-90 |
| 5.18.7 Floating-point angle radian | RAD_E_MD | 5-91 |
| 5.18.8 Floating-point radian → angle conversion | DEG_E_MD | 5-91 |
| 5.18.9 Floating-point square root | SQR_E_MD | 5-92 |
| 5.18.10 Floating-point natural exponential operation | EXP_E_MD | 5-92 |
| 5.18.11 Floating-point natural logarithm operation | | |
| 5.18.12 Random number generation | | |
| 5.18.13 Sequence change | <u>—</u> | |
| 5.18.14 BCD 4-digit square root | - | |
| 5.18.15 BCD 8-digit square root | - | |
| 5.18.16 BCD type SIN operation | _ | |
| 5.18.17 BCD type COS operation | - | |
| 5.18.18 BCD type TAN operation | _ | |
| 5.18.19 BCD type SIN ⁻¹ operation | _ | |
| 5.18.20 BCD type COS ⁻¹ operation | _ | |
| 5.18.21 BCD type TAN ⁻¹ operation | - | |
| 5.19 Data Control | - | |
| 5.19.1 Upper/lower limit control | | |
| 5.19.2 32-bit data upper/lower limit control | - | |
| 5.19.3 Dead band control | _ | |
| 5.19.4 32-bit data dead band control | _ | |
| 5.19.5 Bit zone control | — | |
| 5.19.6 32-bit data bit zone control | - | |
| 5.19.7 File register block No. switching | - | |
| 5.19.8 Set of file register file | - | |
| 5.19.9 Set of comment file | - | |
| 5.20 Clock | — | |
| 5.20.1 Read of clock data | | |
| 5.20.2 Write of clock data | _ | |
| 5.20.3 Addition of clock data | — | |
| 5.20.4 Subtraction of clock data | — | |
| 5.20.4 Subtraction of clock data | _ | |
| 5.20.6 Clock data format conversion (second → hour, minute, second) | — | |
| 5.20.6 Clock data format conversion (second → nour, minute, second) | _ | |
| <u> </u> | | |
| 5.21.1 Program standby | - | |
| 5.21.2 Program output OFF standby | - | |
| 5.21.3 Program scan execution registration | - | |
| 5.21.4 Program low-speed execution registration | | |
| 5.22 Others | | |
| 6. IEC FUNCTIONS | 6- 1 | to 6- 77 |
| | | |
| How the functions are described | | |
| 6.1 1 Boolean type (BOOL) double precision integer type (DINT) conversion | | |
| Domest voe tovs a followe decision medelivoe ilani i conversio | | n- 5 |

| 6.1.2 Boolean type (BOOL) integer type (INT) conversion | BOOL_TO_INT (_E) | 6- 4 |
|--|-------------------|---------|
| 6.1.3 Boolean type (BOOL) character string type (STRING) conversion | BOOL_TO_STR (_E |) 6- 5 |
| 6.1.4 Double precision integer type (DINT) Boolean type (BOOL) conversion | DINT_TO_BOOL (_E | Ē).6- 6 |
| 6.1.5 Double precision integer type (DINT) integer type (INT) conversion | DINT_TO_INT (_E) | 6- 7 |
| 6.1.6 Double precision integer type (DINT) real number type | | |
| (REAL) conversion | DINT_TO_REAL (_E |)6- 8 |
| 6.1.7 Double precision integer type (DINT) character string type | | |
| (STRING) conversion | DINT_TO_STR (_E) | 6- 9 |
| 6.1.8 Integer type (INT) Boolean type (BOOL) conversion | INT_TO_BOOL (_E) | 6-10 |
| 6.1.9 Integer type (INT) double precision integer type (DINT) conversion . | INT_TO_DINT (_E) | 6-11 |
| 6.1.10 Integer type (INT) real number type (REAL) conversion | INT_TO_REAL (_E). | 6-12 |
| 6.1.11 Integer type (INT) character string type (STRING) conversion | INT_TO_STR (_E) | 6-13 |
| 6.1.12 Real number type (REAL) double precision integer type | | |
| (DINT) conversion | REAL_TO_DINT (_E | . 6-14 |
| 6.1.13 Real number type (REAL) integer type (INT) conversion | REAL_TO_INT (_E). | 6-15 |
| 6.1.14 Real number type (REAL) character string type | | |
| (STRING) conversion | REAL_TO_STR (_E) | 6-16 |
| 6.1.15 Character string type (STRING) Boolean type (BOOL) conversion | STR_TO_BOOL (_E |) 6-17 |
| 6.1.16 Character string type (STRING) double precision integer type | | |
| (DINT) conversion | STR_TO_DINT (_E) | 6-18 |
| 6.1.17 Character string type (STRING) integer type (INT) conversion | STR_TO_INT (_E) | 6-19 |
| 6.1.18 Character string type (STRING) real number type | | |
| (REAL) conversion | STR_TO_REAL (_E) | 6-20 |
| 6.2 Numerical Functions (General Functions) | | 6-21 |
| 6.2.1 Absolute value | ABS (_E) | 6-21 |
| 6.2.2 Square root | SQRT (_E) | 6-22 |
| 6.3 Numeric Functions (Logarithm Functions) | | 6-23 |
| 6.3.1 Natural logarithm | LN (_E) | 6-24 |
| 6.3.2 Natural exponent | EXP (_E) | 6-24 |
| 6.4 Numerical Functions (Trigonometric Functions) | | 6-25 |
| 6.4.1 Floating-point SIN operation | SIN (_E) | 6-25 |
| 6.4.2 Floating-point COS operation | COS (_E) | 6-26 |
| 6.4.3 Floating-point TAN operation | TAN (_E) | 6-27 |
| 6.4.4 Floating-point SIN ⁻¹ operation | ASIN (_E) | 6-28 |
| 6.4.5 Floating-point COS ⁻¹ operation | ACOS (_E) | 6-29 |
| 6.4.6 Floating-point TAN ⁻¹ operation | ATAN (_E) | 6-30 |
| 6.5 Arithmetic Operation Functions | | 6-31 |
| 6.5.1 Addition | ADD_E | 6-31 |
| 6.5.2 Multiplication | MUL_E | 6-32 |
| 6.5.3 Subtraction | SUB_E | 6-33 |
| 6.5.4 Division | DIV_E | 6-34 |
| 6.5.5 Modulus operation | MOD (_E) | 6-35 |
| 6.5.6 Natural exponential | EXPT (_E) | 6-36 |
| 6.5.7 Assignment | MOVE (_E) | 6-38 |
| 6.6 Bit Shift Functions | | 6-39 |
| 6.6.1 Bit left shift | SHL (_E) | 6-39 |
| 6.6.2 Bit right shift | SHR (_E) | 6-40 |
| 6.6.3 Right rotation | ROR (_E) | 6-41 |
| | | |

A - 11 A - 11

| 6.6.4 Left rotation | ROL (_E) | 6-42 |
|--|----------------|-------------|
| 6.7 Bit Type Boolean Functions | _ · | 6-43 |
| 6.7.1 Logical product | | |
| 6.7.2 Logical sum | | |
| 6.7.3 Exclusive logical sum | XOR E | 6-45 |
| 6.7.4 Logical NOT | - | |
| 6.8 Selection Functions | - ' | |
| 6.8.1 Binary selection | SEL (E) | 6-47 |
| 6.8.2 Maximum value | | |
| 6.8.3 Minimum value | MIN (E) | 6-51 |
| 6.8.4 Limiter | - ' | |
| 6.8.5 Multiplexer | - ' | |
| 6.9 Comparison Functions | - · | |
| 6.9.1 Greater than right member (>) | | |
| 6.9.2 Greater than or equal to right member (>=) | | |
| 6.9.3 Equal (=) | | |
| 6.9.4 Less than or equal to right member (<=) | — | |
| 6.9.5 Less than right member (<) | _ | |
| 6.9.6 Unequal (<>) | _ | |
| 6.10 Character String Functions | | 6-69 |
| 6.10.1 Character string length acquisition | LEN (_E) | 6-69 |
| 6.10.2 Acquisition from start position of character string | LEFT (_E) | 6-70 |
| 6.10.3 Acquisition from end of character string | RIGHT (_E) | 6-71 |
| 6.10.4 Acquisition from specified position of character string | MID (_E) | 6-72 |
| 6.10.5 Concatenation of character strings | CONCAT (_E) | 6-73 |
| 6.10.6 Insertion of character string into specified position | INSERT (_E) | 6-74 |
| 6.10.7 Deletion of character string from specified position | | |
| 6.10.8 Replacement of character string from specified position | REPLACE (_E) . | 6-76 |
| 6.10.9 Search for character string from specified position | FIND (_E) | 6-77 |
| | | |
| 7. ERROR LIST | | 1 to 7- 17 |
| | | |
| | | |
| APPENDICES | Арр- | 1to App- 4 |
| Appendix 1 Character Strings that cannot be Used as Labels and FB Names. | | Δnn- 1 |
| Appendix 1 Character Strings triat carmot be used as Labers and 1 B Names. Appendix 2 ST instruction table for GX Developer and GX Works2 | | |
| - Appendix 2 of mondourn date for on beveloper and on violing2 | | |
| INDEX | Index- 1 to | o Index- 10 |

About Manuals

The manuals related to this product are shown below. Refer to the following table when ordering required manuals.

Relevant manuals

| Manual Name | Manual Number (Model Code) | |
|--|-------------------------------|--|
| GX Developer Version 8 Operating Manual (Startup) Explains the system configuration, installation method and startup method of GX Developer. (Sold separately) | SH-080372E (13JU40) | |
| GX Developer Version 8 Operating Manual Explains the program creation method, printout method, monitoring method, debugging method, etc. | SH-080373E | |
| using GX Developer | (13JU41) | |
| (Sold separately) | | |
| GX Developer Version 8 Operating Manual (Function Block) | SH-080376E | |
| Explains the function block creation method, printout method, etc. using GX Developer. | (13JU44) | |
| (Sold separately) | | |
| GX Developer Version 8 Operating Manual (Structured Text) | CH 090367E | |
| Explains the structured text (ST) program creation method, printout method, etc. using GX Developer. | SH-080367E (13JU37) | |
| (Sold separately) | , | |
| Structured Text (ST) Programming Guide Book | | |
| Written for those who will create structured text (ST) programs for the first time. Explains the basic operation methods and functions through sample programs. | SH-080368E (13JF69) | |
| (Sold separately) | | |
| MELSEC-Q/L Programming Manual (Common Instruction) | | |
| Explains the methods of using the sequence instructions, basic instructions and application instructions. | SH-080809ENG (13JW10) | |
| (Sold separately) | (1007710) | |
| GX Works2 Beginner's Manual (Structured Project) | | |
| Explains the structured text (ST) programming methods using GX Works2. | SH-080788ENG (13JZ23) | |
| (Sold separately) | | |

REMARK

The Operating Manuals and Structured Text (ST) Programming Guide Book are included on the CD-ROM of the software package in a PDF file format. Manuals in printed form are sold separately for single purchase. Order a manual by quoting the manual number (model code) listed in the table above.

How to Use This Manual

This Manual ...

Use this manual to perform structured text (hereafter abbreviated to ST) programming with GX Developer. It is suitable for the users who have the knowledge and programming experience of PLC ladder programs and for the users who have the knowledge and programming experience of high-level languages such as the C language.

"CHAPTER 1 OVERVIEW" describes the overview of the ST language, the features of ST programming, and the ST program creation procedure.

"CHAPTER 2 SYSTEM CONFIGURATION" describes the applicable CPUs, ST program specifications, etc.

"CHAPTER 3 HANDLING OF CHARACTERS AND NUMERIC VALUES IN ST PROGRAMS" describes the types and representation methods of data used in ST programs.

"CHAPTER 4 ST PROGRAM EXPRESSIONS" describes the expressions of the operators, control syntaxes, etc. used in ST programs.

"CHAPTER 5 MELSEC FUNCTIONS" and "CHAPTER 6 IEC FUNCTIONS" describe the arguments, return values and description examples of the functions used in ST programs.

Operating Manual ...

The "GX Developer Operating Manual (ST)" consists of in-depth explanations of all menus and menu options used to perform ST programming. Refer to the manual when information on operation details is necessary.

When information on other than ST programming is necessary, refer to the "GX Developer Operating Manual" or "GX Developer Operating Manual (Startup)".

When you already have the knowledge of the ST language and want to start programming immediately ...

Proceed to "CHAPTER 5 MELSEC FUNCTIONS". It describes the necessary items for use of the functions in ST programs. When it is desired to know the data to be used in ST programs, refer to "CHAPTER 3 HANDLING OF CHARACTERS AND NUMERIC VALUES IN ST PROGRAMS". It describes the types and representation methods of the data used in ST programs. When it is desired to use control syntaxes in ST programs, refer to "CHAPTER 4 ST PROGRAM EXPRESSIONS". It describes the formats and description examples of the control syntaxes used in ST programs.

When using GX Works2...

Refer to "GX Works2 Beginner's Manual (Structured Project)". It describes the procedures for creating ST programs with GX Works2, checking the operation with a programmable controller CPU module, and others.

The following explains the symbols and information used in this manual.

| Symbol | Description | Example |
|--------|--|-----------|
| Point | Gives the section-related knowledge and necessary information. | Point |
| Remark | Gives the section-related knowledge and useful information. | REMARK |
| [] | Menu name of menu bar | [Project] |

Abbreviations and Generic Terms in This Manual

This manual uses the following terms.

| Generic Terms /Abbreviation | Description/Applicable Module |
|-----------------------------|---|
| GX Developer | A programming tool for setting, programming, debugging, and maintaining |
| GX Works2 | programmable controllers. |
| 00011 (0 1-) | Generic term for the Basic model QCPU, High Performance model QCPU, |
| QCPU (Q mode) | Process CPU, Redundant CPU, and Universal model QCPU. |
| ST | Abbreviation for structured text. |
| FB | Abbreviation for function block. |

1 OVERVIEW

1.1 What Is the ST Language?

The ST language is defined in the International Standard IEC61131-3 that stipulates the logic description system in open controllers.

The ST language supports operators, control syntaxes and functions to permit the following descriptions.

- Control syntaxes such as conditional statement-dependent selective branch and repeated statement-based repetition
- Expressions using operators (*, /, +, -, <, >, =, etc.)
- Call of user-defined function blocks (FB)
- Call of functions (MELSEC functions, IEC functions)
- Description of comments

The main features of the ST language are as described below.

(1) Free description in text format The ST language is described in text format of alphanumeric characters, comments and labels.

```
ST MAIN 9Row 105Step

(* A valve is closed when the limit switch of a tank turns on A valve is opened when turned off. *)

IF Limit_switch = TRUE THEN
Valve := FALSE; (* A valve is closed when a limit switch turns on *)

ELSE
Valve := TRUE; (* A valve is opened when a limit switch turns off *)

EMD_IF;
```

(2) Programming on the same level as those of the C and other high-level languages Like the high-level languages such as C, the ST language can describe control with control syntaxes such as conditional statement-dependent selective branches and repeated statement-based repetitions. Hence, easy-to-read programs can be written briefly.

```
_ | 🗆 | × |
ST MAIN 17Row 148Step
 (* Lines A, B, and C are controlled. *)
                                                                                                      •
CASE Line OF
    1: Start switch := TRUE;
                                (* Conveyer operation start *)
    2: Start_switch := FALSE;
                               (* Conveyer stop *)
    3: Start_switch := TRUE;
                                (* Warning of a conveyer stop *)
       Warning_lamp := TRUE:
END CASE:
IF Start_switch = TRUE THEN
                                (* It processes 100 times *)
    FOR Num_of_process := 0
        TO 100
        BY 1 DO
        Parts_A := Parts_A + 1;
    END_FOR;
END IF;
```

(3) Ease of describing operation processing

Capable of briefly describing easy-to-read operation processing that is difficult to describe in lists or ladders, the ST language has a high level of program readability and is suitable for the fields where complex arithmetic operations, comparison operations, etc. are performed.

```
CASE Line OF

1: Speed_A := Distance_B / Hour_C * 3600;

(* FB call *)

FB1(I_Test:=D0, O_Test:=D1, IO_Test:=D100);

2: MO := GT_E(XO, DO, D1, D2, D3, Result);

(* When the execution conditions XO turn on, *)

(* it judges whether the order of the value of D0 to D3 is right *)

Valve := FALSE;

RETURN;

END_CASE;
```

1.2 Features of ST Program in MELSEC-Q/L Series

ST programs are described in ST language.

Using GX Developer to perform ST programming enables efficient programming to be performed in excellent operation environment. The following provides the main features of ST programs in the MELSEC-Q/L series.

(1) Design efficiency improved by defining processing as parts

With often used processing defined as parts in the form of function blocks (FB) in ST language, they can be used in necessary areas of each program. This not only enhances the efficiency of program development but also reduces program mistakes, improving program quality.

For more information, refer to the "GX Developer Operating Manual (Function Block)" given in Relevant Manuals.

(2) Restoration of ST program read from PLC

In the MELSEC-Q/L series, the created ST program is written to the PLC and executed, and can be read from the PLC and then restored to enable editing in the ST language format.

- (3) Program change during system operation (online change)
 Part of a running program can be changed without the PLC CPU being stopped.
- (4) Connection with other language programs

Since the MELSEC-Q/L series also supports languages other than the ST, the language adequate for processing can be used to create efficient programs. Execution conditions can be set on a file basis in each program, and multiple program files can be written to a single PLC CPU.


Multiple languages support widespread application under optimum control.

(5) A wealth of functions group

The MELSEC functions compatible with various common instructions for the MELSEC-Q/L series and the IEC functions defined in IEC61131-3 are available for ST programs in the MELSEC-Q/L series.

1.3 ST Program Creating Procedure

The following flowchart indicates the general procedure of ST programming. In the following example, parts were created with the function block function and a main program was then created in ST language.



2 SYSTEM CONFIGURATION

2.1 System Configuration

This section explains the system configuration for use of ST programs.

2.1.1 Applicable CPUs

ST programs are applicable to the following CPU modules.

| Basic Model QCPU | High Performance Model QCPU | Universal model QCPU | Process CPU | Redundant CPU | LCPU |
|-----------------------------|--|---|--|------------------------|---------------------|
| Q00JCPU Q00CPU Q01CPU | Q02CPU Q02HCPU Q06HCPU Q12HCPU Q25HCPU | Q00UJCPU Q00UCPU Q01UCPU Q01UCPU Q03UDCPU Q03UDECPU Q04UDHCPU Q04UDHCPU Q06UDHCPU Q06UDHCPU Q10UDHCPU Q13UDHCPU Q13UDHCPU Q20UDHCPU Q20UDHCPU Q26UDHCPU Q26UDHCPU | Q02PHCPU Q06PHCPU Q12PHCPU Q25PHCPU | Q12PRHCPU Q25PRHCPU | L02CPU L26CPU-BT |

2.1.2 Programming tool for ST program

Use the following programming tool to create, edit and/or monitor ST programs.

| Software Package Name | Operating Environment |
|-------------------------------------|---|
| GX Developer Version 8.00A or later | Refer to the "GX Developer Version 8 Operating Manual |
| | (Startup)". |

2.1.3 ST program specifications

This section explains the ST specifications and applicable devices.

(1) Program size

The file size per program is 839680.



- Note the following when counting the number of characters in a file.
 - Carriage return (CR) and Line feed (LF) are handled as two characters.
 - A space is handled as one character.
 - A TAB code is handled as one character.

(2) Applicable devices

The device names that can be used in ST programs are as indicated below. The number of device points can be changed in parameter setting.

Refer to Section "3.3.3 Devices" for details of the device representation methods.

| Classification | Туре | Device | Representation |
|-----------------------------|--------------|-----------------------------|----------------|
| Internal user device | Bit | Input | Х |
| | | Output | Υ |
| | | Internal relay | M |
| | | Latch relay | L |
| | | Annunciator | F |
| | | Link relay | В |
| | | Link special relay | SB |
| | Word | Data register | D |
| | | Link register | W |
| | | Link special register | SW |
| Internal system device | Bit | Special relay | SM |
| | Word | Special register | SD |
| Link direct device | Bit | Link input | Jn\X |
| | | Link output | Jn\Y |
| | | Link relay | Jn\B |
| | | Link special relay | Jn\SB |
| | Word | Link register | Jn\W |
| | | Link special register | Jn\SW |
| Intelligent function module | Word | Intelligent function module | Un\G |
| device | | device | |
| Index register | Word | Index register | Z*1 |
| File register | Word | File register | R |
| | | | ZR |
| Constant | Bit/word/dou | Decimal constant | K |
| | ble word | Hexadecimal constant | Н |
| | Real number | Real number constant | E |
| | Character | Character string constant | "ABC", etc. |
| | string | | |
| Others | Bit | SFC block device | BL |
| | Bit | SFC transition device | BL\TR |
| | Bit | SFC step relay | BL\S |
| | Bit | Direct input | DX |
| | Bit | Direct output | DY |

^{*1:} Z0 and Z1 cannot be used.

For Universal model QCPU/LCPU, Z16 to Z19 cannot be used.

(3) Devices applicable to ST programs only

In ST programs, the contacts, coils and present values of the timers and counters are represented and used as individual devices.

The device representations and types of the contacts, coils and present values of the timers and counters are as indicated below.

| Classification | Туре | Device | Representation |
|----------------------|-----------------|-------------------------------|----------------|
| Internal user device | Bit | Timer contact | TS |
| | | Timer coil | TC |
| | | Retentive timer contact | STS |
| | | Retentive timer coil | STC |
| | Counter contact | | CS |
| | | Counter coil | CC |
| | Word | Timer present value | TN/T |
| | | Retentive timer present value | |
| | | Counter present value | CN/C |

Examples of use

(1) [ST program] [Equivalent list program]

M0: = TS0; LD T0 OUT M0

(2) [ST program] [Equivalent list program]

COUNTER_M(X0, CC20, 10); LD X0

OUT C20 K10



For details of compatible instructions, refer to the following manual:

• MELSEC-Q/L Programming Manual (Common Instruction)

3 HANDLING OF CHARACTERS AND NUMERIC VALUES IN ST PROGRAMS

3.1 Usable Characters

The ST language is a programming language described in text format. It can be described as in document editing using a general text editor, but the grammar and usable characters and symbols have been defined.

(1) Usable characters

The following characters can be used in ST programs.

| Character Type | Program statement | Comment | Character string | Label*1 | Character Examples |
|--|-------------------|---------|---------------------|---------|-----------------------|
| Alphanumeric characters | 0 | 0 | 0 | 0 | ABC, IF, D0 |
| Symbols +-*/=<>[]() .,_:;\$#"'{} | 0 | 0 | △*2 | × | (D0 * D1) |
| Space | 0 | 0 | 0 | × | |
| Line feed code | 0 | 0 | × | X | |
| TAB code | 0 | 0 | × | × | |

^{○:} Can be used. ×: Cannot be used. △: Part cannot be used.

^{*1:} For the characters that cannot be used in labels, refer to "Appendix 1 Character Strings that cannot be Used as Labels and FB Names".

^{*2:} A double quotation (") cannot be used in a character string. Doing so will result in a conversion error.

(2) Character types

The characters used in ST programs can be classified as indicated below.

| Classific | cation | Description | Example |
|---------------|-------------------|--|------------------------------|
| Label name | | Character string defined as desired by the user. It includes a function block name, array name, structure name, etc. | Switch_A |
| Constant | | Value written directly to a program. (Integer, real number, character string, etc.) | 123, "abc" |
| Comment | | Commentary statement that is not the processing target of control in a program. | (* Turns ON *) |
| | Data type name | Word that represents a data type. | BOOL, DWORD |
| Reserved | Control syntax | Word whose meaning has been defined grammatically for use as a control syntax. | IF, CASE, WHILE, RETURN |
| word | Device name | Data name for MELSEC PLC | X, Y, M, ZR |
| | Function name | MELSEC function/IEC function name already defined. | OUT_M REAL_TO_STR_E |
| Operator | | Character code whose meaning has been defined for an expression or assignment statement. | +-<>= |
| Delimiter | | Character code whose meaning has been defined to clarify a program structure. | ;() |
| Other symbols | | Code for putting a layout in order. | Space Line feed code, TAB |

3.2 Data Handling

In ST programs, the types of used data have been defined. Sections 3.2 and 3.3 indicate the data types and their representation methods in ST programs.

3.2.1 Data types

The following data types can be used in ST programs.

| Data Type | Definition | Range | Type in Ladder | Type in C Language |
|-----------|-------------------------------|---|------------------|-----------------------|
| BOOL | Boolean type | TRUE•FALSE,1•0*1 | Bit | bool |
| INT | Integer type | -32768 to 32767 | Word | signed short |
| DINT | Double precision integer type | -2147483648 to 2147483647 | Double word | signed long |
| REAL | Real number type | -3.402823 ⁺³⁸ to -1.175495 ⁻³⁸ , 0.0, +1.175495 ⁻³⁸ to +3.402823 ⁺³⁸ | Real number | float |
| STRING | Character string type | Up to 50 characters can be defined. | Character string | char |
| ARRAY | Array data type | Depends on the data type of the specified element. | Array | char[], etc. |
| STRUCT | Structured data type | Depends on the data type of the specified element. | Structure | struct |

^{*1:} K0, K1, H0 and H1 for specification of K and H cannot be used as the BOOL type.



Precautions when an operation result exceeds the data type range
 When an operation result exceeds the data type range, correct result cannot be obtained.

3.2.2 About ANY type

Use the ANY type when multiple data types are permitted for the argument, return value, etc. of a function. The ANY type is a data type that handles any data type and is available in different types indicated in the following table.

For example, when the argument of a function has been defined as ANY_NUM, any data type can be specified as an argument from the word type, double word type and real number type.

| [Description example] REAL EXPT(REAL In1, ANY_NUM In2); | (* Function definition of function EXPT *) |
|---|--|
| | e, double word type or real number |

- When a word type device is specified RealLabel := EXPT(E1. 0, D0);
- When a double word type label is specified RealLabel := EXPT(E1. 0, DWLabel);
- When a real number is specified
 RealLabel := EXPT(E1. 0, E1. 0);

The data types and device types corresponding to the ANY types are as indicated below.

| | Data Type | BOOL | INT | DINT | REAL | STRING |
|------------|----------------|------|------|----------------|----------------|------------------|
| ANY Type | Type in ladder | Bit | Word | Double word | Real number | Character string |
| ANY | L | 0 | 0 | 0 | 0 | 0 |
| ANY_SIMPLE | | 0 | 0 | 0 | 0 | 0 |
| ANY_BIT | | 0 | Δ | | _ | _ |
| ANY_NUM | | _ | 0 | 0 | 0 | _ |
| ANY_REAL | | _ | _ | _ | 0 | _ |
| ANY_INT | | _ | 0 | 0 | _ | _ |
| ANY16 | | | 0 | | | _ |
| ANY32 | | _ | | 0 | _ | _ |

- : Can be specified as corresponding type.
- : Cannot be specified.
- \triangle : Can be used for device, constant and digit specification, but cannot be used for label.
- ☐: Can be used for constant and digit specification.

3.2.3 Array and structure

In ST programs, arrays and structures can be used as data.

Arrays and structures are data having a structure that can be handled as one block in a program when their elements are defined with local or global labels before use.

(1) Array

An array is a data type that has been defined by combining multiple data of the same type.

For an array in an ST program, each element can be referred to individually by specifying its element number within [] after the variable (label) name defined for the array type.


The specification numbers of the array elements are counted from 0.

[Format]

Array name[specification number of array element]

[Image diagram]

When a word type array having four elements is set to have the array name of Unit price, the specification numbers of the array elements are 0, 1, 2, 3.




For a word type array, word data enters each array element.


[Description example]

Unit price [0] := 100; (* 100 is assigned to the first element of the array *)

(* 1200 is assigned to the second element of the array using device D1 *) D1 := 1;



(*Unit price [0] + Unit price [1] is assigned to the third element of the array *) Unit price [2] := Unit price [0] + Unit price [1];



Point

Precaution for use of the specification numbers of the array elements When an array has n elements, the specification numbers of the array elements are 0 to n-1. Hence, if n or more is specified, an error will occur at the time of conversion.

Example: When an array has four elements

Unit price [4]: = 100; \leftarrow Error occurs.

Precaution for use of arrays in the specification number of the array element
 Arrays can be used in the specification number of the array element. Up to five
 arrays can be nested. Using 17 or more arrays will result in a conversion error.

Example: When five arrays are nested

Unit price [Unit price [Unit price [Unit price [Unit price [D1]]]]] = 100;

- Precaution for setting the specification number of the array element Since there is a possibility that the data of the other devices may be corrupted, be careful so that the value specified as the array element number does not exceed the number of array elements.
- Precaution for setting the number of array elements
 Enter the number of elements on the global (local) variable setting screen. The number of elements that can be entered is 256.

(2) Structure

A structure is a data type defined by combining the data of any types. Each element can be referred to individually by describing the element name after the variable (label) name defined for the structure type, with a period (.) placed between them.

The element name is also called a member variable.

[Format]

Structure name.structure element name


[Image diagram]

When the setting is as follows

Structure name stocking,

Structure element:

One word type Structure element name Unit No
One real number type Structure element name unit price
One character string type Structure element name name of
article



[Description example]

(* 100 is assigned to structure element Unit No *) Stocking.Unit No := 100;

(* 98.2 is assigned to structure element Unit price *) Stocking.Unit price := E98.2;

(* "APPLE" is assigned to structure element Name of article *) Stocking.Name of article := "APPLE";



Precaution for use of the member variables of a structure
 The number of members that can be entered on the structure variable setting screen is 128.

3.3 Data Representation Methods

Constants, labels and devices can be used as data in ST programs.

| Item | Description | Representation Example |
|----------|--|---------------------------|
| Constant | Numeric value or character string data written directly to a program. It does not change during program execution. | 123, "ABC" |
| Label | Data whose type and name are defined by the user. | Switch_A |
| Device | Device used by the QCPU (Q mode)/LCPU. It is identified by the device name and device number. | X0, Y0, D100, J1\X0 |

3.3.1 Constants

Each constant is represented as described below in ST programs.

| Data Type | Numeric Notation | Representation Method | Example |
|-----------|------------------|---|-----------------|
| | | TRUE • FALSE 1•0 | M0 := TRUE; |
| | Binary | The used binary number is preceded by "2#". | M0 := 2#0; |
| | | | M0 := 2#1; |
| BOOL | Octal | The used octal number is preceded by "8#". | |
| | | | M0 := 8#1; |
| | Hexadecimal | The used hexadecimal number is preceded | M0 := 16#0; |
| | | by "16#". | M0 := 16#1; |
| | Binary | The used binary number is preceded by "2#". | D0 := 2#110; |
| | Octal | The used octal number is preceded by "8#". | D0 := 8#377; |
| | Decimal | The used decimal number is preceded by | D0 := 123; |
| INT | | "10#". | D0 := K123; |
| DINT | | (The numeric value may be preceded by "K".) | |
| | Hexadecimal | The used hexadecimal number is preceded | D0 := 16#FF; |
| | | by "16#". | D0 := HFF; |
| | | (The numeric value may be preceded by "H".) | |
| REAL | | The used real number is directly input. | ABC := 2.34; |
| KEAL | | (The numeric value may be preceded by "E".) | Rtest := E2.34; |
| STRING | | A character string is enclosed by !! (er !! !!) | Stest := 'ABC'; |
| STRING | | A character string is enclosed by ' ' (or " "). | Stest := "ABC"; |

For the range that can be specified for each constant, refer to Section 3.2.1 Data types. The following ranges apply to the areas that are not described in Section 3.2.1 Data types.

[K, H representation]

| Value Range | IEC Data Type | |
|-----------------------------|--------------------------------------|--|
| K-32768 to K32767 | INT, ANY16 | |
| K-2147483648 to K2147483647 | DINT, ANY32 | |
| K0 to K32767 | ANY_BIT (word)*1 | |
| K0 to K2147483647 | ANY_BIT (double word)*2 | |
| H0 to HFFFF | INT, ANY16, ANY_BIT (word)*1 | |
| H0 to HFFFFFFF | SINT, ANY32, ANY_BIT (double word)*2 | |

[K, H-less representation]

| Value Range | IEC Data Type | |
|--------------------------------------|-------------------------|--|
| 0 to 1 | BOOL | |
| -32768 to 32767 | INT | |
| -2147483648 to 2147483647 | DINT | |
| 0 to 4294967295 | ANY_BIT (double word)*2 | |
| 0 to 65535 | ANY_BIT (word)*1 | |
| -32768 to 65535 | ANY16 | |
| -2147483648 to 4294967295 | ANY32 | |
| 2#0 to 2#1 | BOOL | |
| 8#0 to 8#1 | | |
| 16#0 to 16#1 | | |
| 2#0 to 2#1111_1111_1111 | INT | |
| 8#0 to 8#177777 | ANY16 | |
| 16#0 to 16#FFFF | ANY_BIT (word)*1 | |
| 2#0 to | DINT | |
| 2#1111_1111_1111_1111_1111_1111_1111 | ANY_BIT (double word)*2 | |
| 8#0 to 8#3777777777 | ANY32 | |
| 16#0 to 16#FFFFFFF | | |

^{*1:} Indicates when handled as a word device.

<Example> D0 := NOT(K32767);

^{*2:} Indicates when handled as a double word device.

<Example> K8M0 := NOT(K2147483647);

Point

 Precaution for use of the H, 2#, 8# and 16#-specified numeric values in word label and word device operation expressions

When the value handled in operation is in the range H8000 to HFFFF, the operation result available by ST program conversion differs from the operation result available by the assignment of a value to a device in the PLC CPU.

Since whether the handled value is a word type or double word type cannot be judged in the operation result available by ST program conversion, it is operated as unsigned, but it is operated as signed in the PLC CPU.

<Example of use>

Data1 = -32768;

Data2 = 16#8000;

- ST Result := Data1 / Data2; → -32768 / 32768 = -1
- CPU Result := Data1 / Data2; → -32768 / -32768 = 1
- Precaution for use of "\$" and " ' " in character string type data "\$" is used as an escape sequence.

Two hexadecimal numbers following "\$" are recognized as the ASCII code, and the characters corresponding to the ASCII code are inserted into the character string.

A conversion error will occur when the two hexadecimal numbers following "\$" do not correspond to the ASCII code.

However, an error will not occur when the characters following "\$" are any of the following.

| Representation | Symbol/Printer Code Used in Character String |
|----------------|--|
| \$\$ | \$ |
| \$' | 1 |
| \$L or \$1 | Line feed |
| \$N or \$n | Change line |
| \$P or \$p | Page scrolling |
| \$R or \$r | Carriage return |
| \$T or \$t | Tab |

Example: Value := "\$'APPLE\$' \$\$100";

 Precaution for binary, octal, decimal, hexadecimal and real number representations

In binary, octal, decimal, hexadecimal or real number representation, "_ (underscore)" can be used for ease of identification. "_" is ignored as a numeric value

Example: 2#1101_1111 8#377_1 16#01FF_ABCD 22_323 1.0_1

(When K, H or E is specified, "_" cannot be used.)

3 - 10 3 - 10

3.3.2 Labels

In ST programs, labels can be used with data.

When labels are used in an ST program, label declaration must be made on the local variable setting screen or global variable setting screen before use.

(For the label and structure label declaration methods, refer to the "GX Developer Operating Manual".)

Label representation examples in ST programs are as follows.

Example: <u>Switch_A</u>:= FALSE; (* FALSE is assigned to Switch_A. *)

Example: IF INT_TO_BOOL(<u>Unit_No</u>) = FALSE THEN

<u>Line_No</u> := 2147483647;

END_IF;

(* IF INT_TO_BOOL (Unit_No) is FALSE *) (* 2147483647 is assigned to Unit_Number. *)

Example: <u>Limit_A</u> := E1.0; (* 1.0 is assigned to Limit_A *)

Example: Conveyor[4] := Unit_No; (* The value of Unit_No is assigned to *)

(* the fifth element of Conveyor. *)

Example: stPressure.Status := TRUE; (* TRUE is assigned to *)

(* element name Status of stPressure. *)

Example: stPressure.eLimit := E1.0; (* 1.0 is assigned to *)

(* element name eLimit of stPressure. *)

3 - 11 3 - 11

REFERENCE

Label declaration procedure

Make label declaration on the local variable setting screen or global variable setting screen.

The local variable setting screen can be opened by performing the following operation.

ightarrow Double-click Header icon ightarrow Local variable setting screen

The following example shows the label setting made on the local variable setting screen.

| | Au | Label | Constant | Device type | | |
|---|------|----------|----------|-------------|---|--|
| 1 | | Switch_A | | BOOL | T | |
| 2 | | Unit_No | | INT | • | |
| 3 | | Line_No | | DINT | T | |
| 4 | XXXX | Limit_A | | REAL | ¥ | |
| 5 | | Conveyer | | INT(20) | ¥ | |

When structure label is to be declared

1) Declare the structure element.

GX Developer start \rightarrow [Open project] \rightarrow Double-click the structure tab



"ADDRESS".→Structure variable setting screen


The following example shows the structure element label setting made on the structure variable setting screen.

| | Label | Device type | | |
|---|------------|-------------|--|--|
| 1 | Unit_No | INT 🔻 | | |
| 2 | Unit_Price | REAL 🔻 | | |

2) Declare the structure label.

Make structure label declaration on the local variable setting screen or global variable setting screen.

The local variable setting screen can be opened by performing the following operation.



→ Local variable setting screen

The following example shows the structure label setting made on the local variable setting screen.

| | Αu | Label | Constant | Device type |
|---|------|--------------|----------------|------------------|
| 1 | XXXX | StockingData | Setting detail | STRUCTURE(STOCK) |

3 - 12 3 - 12

Point

- Precaution for use of the pointer type, timer type, counter type and retentive timer type labels
 - The pointer type, timer type, counter type or retentive timer type label can be declared, but if it is used in an ST program as a label, a conversion error will occur and the label cannot be used.
- Precaution for use of the timer type, counter type and retentive timer type labels If the timer type, counter type or retentive timer type label is defined in the member variable of a structure, that member variable cannot be used on the ST edit screen. However, the other member variables of a structure that include the timer type, counter type and retentive timer type labels can be used.

3.3.3 Devices

(1) How to use devices

In an ST program, devices of QCPU (Q mode)/LCPU can be used by directly describing them without labels being used. Devices can be used in the left and right members of an expression and the argument, return value, etc. of a function.

```
[Description example] \underline{\text{M0}} := \text{TRUE}; \qquad (* \text{ M0 is turned ON. *}) \text{IF INT\_TO\_BOOL}(\underline{\text{D0}}) = \text{FALSE THEN} \quad (* \text{ If INT\_TO\_BOOL}(\underline{\text{D0}}) \text{ is FALSE *}) \underline{\text{W0}} := 1000; \qquad (* 1000 \text{ is assigned to W0. *}) \text{END\_IF};
```

REMARK

- When devices are to be specified ...
 Devices can be specified in both upper case and lower case.
- What devices are available?
 For available devices, refer to "2.1.3(2) Applicable devices" in this manual.

(2) Other using methods

The following three methods can be used as the device modification and specifying methods.

These can be used in the same usage as when devices are used in ladder programs. The following gives the description examples and explanations for use of devices in ST programs. (For details of each using method, refer to the "MELSEC-Q/L Programming Manual (Common Instruction)".)

- (a) Index modification
- (b) Bit specification
- (c) Digit specification

3 - 14 3 - 14


(a) Index modification

Index modification is indirect address specification using the index register. When the index register is used, the device number is (directly specified device number) + (index register contents).

[Description example]

(b) Bit specification

By specifying the bit No. of a word device, it can be used as a bit device.



[Description example]

D0.0 = TRUE; (* Bit 0 of D0 device is turned ON. *) W0.F = FALSE; (* Bit 15 of W0 device is turned OFF. *)

(c) Digit specification

By specifying the 4 bits, 8 bits, 12 bits, etc. of a bit device as a single digit, word data or double word data can be handled by the bit device.



[Description example]

K4X0 := D0; (* 16 bits are used from X0 device as integer type (INT) and D0 is assigned. *)

Wtest := K1X0; (* 4 bits are assigned to word type label

Wtest from X0 device. *)

Dwtest := K5X0; (* 20 bits are assigned to double word type

label Dwtest from X0 device. *)

3 - 15 3 - 15

REMARK

Data type when digit specification is used ...

When digit specification is used, the data types are as follows.

Example: When X0 is used

Integer type (INT): K1X0, K2X0, K3X0, K4X0

Double precision integer type (DINT): K5X0, K6X0, K7X0, K8X0



Precaution 1 for use of digit specification

A conversion error will occur if the data type differs between the right member and left member.

Example: D0 := K5X0;

Since K5X0 is a double word type and D0 is a word type, the above $\,$

program will result in an error.

Precaution 2 for use of digit specification

If the right member is greater than the left member, data will be transferred to the left member within the range of the applicable number of points.

(For the applicable number of points for digit specification, refer to the MELSEC-Q/L Programming Manual (Common Instructions).)

Example: K5X0 := 2#1011_1101_1111_0111_0011_0001;

K5X0 : Applicable number of points = 20 points

1101_1111_0111_0011_0001 (20 digits) is assigned to K5X0.

3 - 16 3 - 16

4 ST PROGRAM EXPRESSIONS

4.1 Assignment Statement

An assignment statement has a function to assign the result of an expression in the right member to a label or device in the left member.

In the assignment statement, the result of the expression in the right member must be equal to the data type in the left member. If they are different, a conversion error will occur.

[Description example]

· When actual device is used

D0 := 0;

When this expression is executed, a decimal number of 0 is assigned to D0.

· When label is used

When the character string type label of Stest is used

Stest : = "APPLE";

When this expression is executed, character string "APPLE" is assigned to Stest.



- Precaution for assigning a character string
 A character string of up to 32 characters can be assigned. A conversion error will occur if a character string of more than 32 characters is assigned.
- Precaution for use of a device in the left member of an assignment statement The TS, TC, STS, STC, CS, CC, BL, DX, BL\S, or BL\TR device cannot be used in the left member of an assignment statement. A conversion error will occur if any of the above devices is used in the left member.

4 - 1 4 - 1

4.2 Operators

This section gives a list of operators usable in ST programs and their examples of use.

4.2.1 Operator list

The following table lists the operators used in ST programs and indicates the priorities at the time of operation execution.

| Operator | Description | Priority |
|--------------|---|----------|
| () | Parenthesis expression | Highest |
| Function () | Function parameter list | ♠ |
| ** | Exponent (exponentiation) tei**shisuu | |
| NOT | Boolean complement (Bit inverted value) | |
| * | Multiplication | |
| / | Division | |
| MOD | Modulus operation | |
| + | Addition | |
| - | Subtraction | |
| <, >, <=, >= | Comparison | |
| = | Equality | |
| <> | Inequality | |
| AND, & | Logical product | |
| XOR | Exclusive logical add | |
| OR | Logical sum | Lowest |

When the priorities are the same, evaluation is made from the left-hand side to the right-hand side operators.

The following table lists the operators, applicable data types and operation result data types.

| Operator | Applicable Data Type | Operation Result Data Type |
|----------------------|-----------------------|----------------------------|
| *, /, +, - | ANY_NUM | ANY_NUM |
| <, >, <=, >=, =, <> | ANY_SIMPLE | BOOL |
| MOD | ANY_INT | ANY_INT |
| AND, &, XOR, OR, NOT | ANY_BIT ^{*1} | ANY_BIT*1 |
| ** | ANY_ REAL (base) | ANN/ DEAL |
| ** | ANY_NUM (exponent) | ANY_REAL |

^{*1:} Except the label and constant (negative range).

Point

- Precaution 1 for use of operator
 A conversion error will occur if the applicable data in the right member of an operator is not the same in data type as the applicable data in the left member.
- Precaution 2 for use of operator
 The number of used operators that can be described in a single expression is up to 1024. A conversion error will occur if 1025 or more operators are used.

REMARK

Explanation of ANY type ...
 For the explanation of the ANY type, refer to "3.2.2 About ANY type".

4.2.2 Examples of using the operators

The following gives the examples of using the operators in ST programs.

- (1) Operation of integer type (INT)
 - (a) When actual devices are used

[Example of use]

D0 := D1 * (D2 + K3) / K100;

<<Operation order>>

- 1) D2 + K3
- 2) (D2 + K3) * D1
- 3) (D2 + K3) * D1 / K100
- 4) The result of 3) is assigned to D0.

(b) When labels are used

 When word type labels Dtest1, Dtest2 are used [Example of use]

Dtest2 : = Dtest1 MOD (D2 + K3) * K100;

- <<Operation order>>
- 1) D2 + K3
- 2) Dtest1 MOD (D2 + K3)
- 3) Dtest1 MOD (D2 + K3) * K100
- 4) The result of 3) is assigned to Dtest2.
- When double word type labels Dwtest1, Dwtest2 are used [Example of use]

Dwtest2 : = Dwtest1 - Dwtest1 / K100;

- <<Operation order>>
- 1) Dwtest1 / K100
- 2) Dwtest1 Dwtest1 / K100
- 3) The result of 2) is assigned to Dwtest2.



Precautions when an operation result exceeds the data type range
 When an operation result exceeds the data type range, correct result cannot be obtained.

For data type range, refer to Section 3.2.1.

(2) Operation of Boolean type (BOOL)

(a) When actual devices are used

[Example of use]

M0 := X0 AND X1 AND (D1 = 100);

<<Operation order>>

1) Only when the result of X0 AND X1 is ON and D is 100, M0 turns ON.

(b) When labels are used

• When bit type labels Btest1, Btest2 are used

[Example of use]

Btest2 : = Btest2 OR Btest1;

<<Operation order>>

1) When Btest2 or Btest1 is ON, Btest2 turns ON.

4.3 Control Syntaxes

Conditional statements and repeat statements are available for ST programs to perform comparison and repetition.

Conditional statement: When a certain condition is satisfied, the selected statement is

executed.

Repeat statement: One or more statements are executed repeatedly according to

the state of a certain variable or condition.

4.3.1 Control syntax list

The following table lists the control syntaxes.

| O diki | IF conditional statement | | |
|-------------------------|----------------------------|--|--|
| Conditional statement | CASE conditional statement | | |
| | FOR DO syntax | | |
| Repeat statement | WHILE DO syntax | | |
| | REPEAT UNTIL syntax | | |
| Other control overtoves | RETURN syntax | | |
| Other control syntaxes | EXIT syntax | | |



Precaution for use of a hierarchy for a control syntax A hierarchy of up to 16 levels is enabled for a control syntax. A conversion error will not occur if 17 or more levels are used. However, since a deep hierarchy may make a program difficult to understand, it is recommended to program a hierarchy up to 4 or 5 levels at the deepest.

4.3.2 Conditional statements

(1) IF THEN conditional statement

[Format]

```
IF <Boolean expression> THEN


<Statement ... >

END_IF;
```

[Explanation]

The statement is executed when the Boolean expression (conditional expression) is TRUE. If the Boolean expression is FALSE, the statement is not executed.

Any Boolean expression can be used if it returns TRUE or FALSE as the result of Boolean operation of the condition of a single bit type variable or a complicated expression including many variables.



[Description example]

(a) When actual device is used in Boolean expression

```
IF X0 THEN (* If X0 is ON, 0 is assigned to D0. *)
D0:=0; (* If the X0 area is X0= TRUE, the meaning is *)
(* the same. *)
```

END_IF;

(b) When operator is used in Boolean expression

```
IF (D0*D1) <= 200 THEN (* If D0*D1 is less than or equal to 200 *)
D0:=0; (* 0 is assigned to D0. *)
END IF;
```

(c) When label is used in Boolean expression

2) When label w_Str is specified as character string type IF w Str = "ABC" THEN (* If w_Str is "ABC" *) D0 := 0;(* 0 is assigned to D0. *) END IF; 3) When label w_Str is specified as character string type IF w_Str = 'ABC' THEN (* If w_Str is 'ABC' *) D0 := 0: (* 0 is assigned to D0. *) END_IF; (d) When function block is used in Boolean expression When function block name w_FB is set to the local variable setting and word type label w_Out is set as the output variable of the function block After the function block is executed (For the method of using the function block, refer to the "GX Developer Version 8 Operating Manual".) IF $w_FB. w_Out = 100 THEN$ (* If w_Out is 100 D0 := 0;(* 0 is assigned to D0. *) END IF; (e) When function is used in Boolean expression IF INT TO BOOL (D0) = FALSE THEN D0 := 0: (* If INT_T0_BOOL (D0) is FALSE *) *) (* 0 is assigned to D0. END IF;


(2) IF ... ELSE conditional statement

[Format]

[Explanation]

Statement 1 is executed when the Boolean expression (conditional expression) is TRUE.

Statement 2 is executed if the value of the Boolean expression is FALSE.



[Description example]

(a) When actual device is used in Boolean expression

(b) When operator is used in Boolean expression

(c) When function is used in Boolean expression

```
IF INT_TO_BOOL (D0) = FALSE THEN

(* If INT_T0_BOOL(D0) is FALSE *)

D0 := 0; (* 0 is assigned to D0. *)

ELSE (* If INT_T0_BOOL(D0) is not FALSE *)

D0 := 1; (* 1 is assigned to D0. *)

END_IF;
```


(3) IF ... ELSIF conditional statement

[Format]

[Explanation]

Statement 1 is executed when Boolean expression (conditional expression) 1 is TRUE. Statement 2 is executed if the value of Boolean expression 1 is FALSE and the value of Boolean expression 2 is TRUE.

Statement 3 is executed if the value of Boolean expression 2 is FALSE and the value of Boolean expression 3 is TRUE.



4 - 10 4 - 10

```
[Description example]
(a) When actual devices are used in Boolean expressions
     IF D0 < 100 THEN
                                     (* If D0 is less than 100
                                                                            *)
           D1 := 0;
                                     (* 0 is assigned to D1.
                                                                            *)
     ELSIF D0 <= 200 THEN
                                     (* If D0 is less than or equal to 200
           D1 := 1;
                                     (* 1 is assigned to D1.
                                                                            *)
     ELSIF D0 <= 300 THEN
                                                                            *)
                                     (* If D0 is less than or equal to 300
           D1 := 2:
                                     (* 2 is assigned to D1.
                                                                            *)
     END_IF;
(b) When operators are used in Boolean expressions
     IF (D0*D1) < 100 THEN
                                                                            *)
                                     (* If D0*D1 is less than 100
                                     (* 0 is assigned to D1.
           D1 := 0:
     ELSIF (D0*D1) <= 200 THEN
                                     (* If D0*D1 is less than or equal to 200
                                                                            *)
                                                                            *)
           D1:=1:
                                     (* 1 is assigned to D1.
     ELSIF (D0*D1) <= 300 THEN
                                     (* If D0*D1 is less than or equal to 300
                                                                           *)
           D1 := 2;
                                     (* 2 is assigned to D1.
                                                                            *)
     END IF;
(c) When functions are used in Boolean expressions
     IF INT_TO_BOOL (D0) = TRUE THEN
                                                (* If INT_T0_BOOL (D0) is
                                                (* TRUE
                                                                            *)
                                                                            *)
           D1 := 0:
                                                (* 0 is assigned to D1.
     ELSIF INT_TO_BOOL (D0) = TRUE THEN (* If INT_T0_BOOL(D2) is
                                                                            *)
                                                (* TRUE
                                                                            *)
           D1 := 1;
                                                (* 1 is assigned to D1.
                                                                            *)
     END_IF;
```

4 - 11 4 - 11

(4) CASE conditional statement

[Format]

 Specifying method that can be used for <Integer selection *> in CASE conditional statement

One value, multiple values, or a value range can be specified for <Integer selection *> in the CASE conditional statement as indicated below. Example:

```
1: (* When the value of the integer expression is 1 *)
2, 3, 4: (* When the value of the integer expression is any of 2, 3 and 4 *)
5..10: (* When the value of the integer expression is any of 5 to 10 *)
```

When ".." is used to specify the range, make the value following ".." greater than the value preceding "..".

Also, multiple values and range specification can be combined to specify values.

1, 2..5, 9: (* When the value of the integer expression is any of 1, 2..5, and 9 *)

Data types that can be used in <integer expression> of CASE conditional statement


The data types that can be specified as the <integer expression> in the CASE conditional statement are the integer type (INT) and double precision integer type (DINT). The word devices and word type or double word type labels can be specified.

[Explanation]

The result of the expression in the CASE conditional statement is returned as an integer value. This conditional statement can be used when a selection statement is executed with a single integer value or the integer value of the result of a complicated expression, for example.

The statement having the integer selection that matches the value of the integer expression is executed first, and if there are no matches, the statement that follows ELSE is executed.

4 - 12 4 - 12



[Description example]

(a) When actual device is used in integer expression

CASE D0 OF

1:

2, 3:

4..6:

ELSE

END_CASE;

(b) When operation result is used in integer expression

CASE D0*D1 OF

1:

2, 3:

4..6:

ELSE

D1 := 3; (* If D0*D1 is other than the above, 3 is assigned to D1. *) END_CASE ;

4 - 13 4 - 13

(c) When function is used in integer expression

```
CASE DINT_TO_INT (dData) OF
                (* If DINT_TO_INT (dData) is 1
   1:
                                                                        *)
      D1 := 0; (* 0 is assigned to D1.
                                                                        *)
                (* If DINT_TO_INT (dData) is 2 or 3
                                                                         *)
   2, 3:
      D1 := 1; (* 1 is assigned to D1.
                                                                        *)
                (* If DINT_TO-INT(dData) is any of 4 to 6
                                                                        *)
      D1 : = 2; (* 2 is assigned to D1.
                                                                        *)
                                                                        *)
                (* If DINT_TO_INT (dData) is other than the above
      D1 : = 3; (* 3 is assigned to D1.
                                                                        *)
END CASE;
```

Point

Precaution for use of integer selection

When a CASE conditional statement has multiple values of the same integer selection, the statement on the upper line is executed with priority and the latter statement having the same integer selection is not executed. For example, when the D100 value is 3 in the following CASE conditional statement, statement 3 having integer selection 3 is executed and statement 4 having the same integer selection is not executed.

CASE D100 OF

1: < Statement 1 ...>

2: < Statement 2 ...>

3: < Statement 3 ...>

3, 4: < Statement 4 ...>

ELSE

< Statement 5 ...>

END_CASE;

To specify the <integer selection *>, only a decimal number without K specification can be used.

4 - 14 4 - 14

4.3.3 Repeat statement

(1) FOR...DO syntax

[Format]

FOR <Repeat variable initialization>
TO <Last value expression>
BY <Incremental expression> DO
< Statement ...>
END_FOR;

Repeat variable initialization: The data used as a repeat variable is initialized. Last value expression, incremental expression:

The initialized repeat variable is incremented or decremented according to the incremental expression, and repetitive processing is performed until the last value is reached.

 Data types that can be used in <Last value expression, incremental expression> of FOR syntax

Integer values and the integer values of operation expression results can be specified.

[Explanation]

The data used as a repeat variable is initialized. The initialized repeat variable is incremented or decremented according to the incremental expression, and one or more statements between DO and END_FOR are repeatedly executed until the value of repeat variable exceeds the last value expression. The repeat variable after the FOR...DO statement is completed retains the value at the time of completion.

4 - 15 4 - 15

Point

Precaution for use of repeat variable

The double precision integer type (DINT) and integer type (INT) can be used for a repeat variable, but structure elements and array elements cannot be used.

Also, match the type used for the repeat variable with the types of the <last


Precaution for use of incremental expression

value expression> and <incremental expression>.

The <incremental expression> can be omitted. When omitted, the <incremental expression> is executed as 1.

When "0" is assigned to the <incremental expression>, the FOR syntax and later may not be executed or an endless loop may occur.

Precaution for use of FOR ... DO syntax In the FOR ... DO syntax, the count processing of the repeat variable is performed after execution of <Statement ...> in the FOR syntax. An endless loop will occur if the count processing higher than the maximum value or lower than the minimum value of the data type of the repeat variable is executed.



[Description example]

(a) When actual device is used in repeat variable

```
FOR W1 := 0 (* W1 is initialized with 0. *)
TO 100 (* Processing is repeated until W1 reaches 100. *)
BY 1 D0 (* W1 is incremented by 1. *)
W3 := W3 + 1; (* During repeat processing, W3 is incremented by 1.*)
END_FOR;
```

4 - 16 4 - 16

(2) WHILE...DO syntax

[Format]


```
WHILE <Boolean expression> D0

<Statement ...>
END_WHILE;
```

[Explanation]

The WHILE ... DO syntax executes one or more statements while the Boolean expression (conditional expression) is TRUE.

The Boolean expression is judged before execution of the statement. If the Boolean expression is FALSE, the statement in DO ... END_WHILE is not executed. Since the <Boolean expression> in the WHILE syntax is only required to return whether the result is true or false, all expressions that can be specified in the <Boolean expression> in the IF conditional statement can be used.



[Description example]

(a) When actual device and operator are used in Boolean expression

```
WHILE W100 < (W2-100) D0 (* While W100<(W2-100) is true (* processing is repeated. *)</p>
W100 : = W100 + 1; (* During repeat processing, W100 is (* incremented by 1 *)
```

END_WHILE;

(b) When function is used in Boolean expression

```
WHILE BOOL_TO_DINT(M0) < BOOL_TO_DINT(M1) D0

D4 := D4 + 1; (* While BOOL_TO_DINT(M0) < *)

(* BOOL_TO_DINT(M1) is true *)

(* processing is repeated. *)

(* During repeat processing, D4 is *)

(* incremented by 1 *)
```

END_WHILE;

4 - 17 4 - 17

(3) REPEAT...UNTIL syntax

[Format]

```
REPEAT

<Statement ...>


UNTIL <Boolean expression>

END_REPEAT;
```

[Explanation]

The REPEAT ... UNTIL syntax executes one or more statements while the Boolean expression (conditional expression) is FALSE.

The Boolean expression is judged after execution of the statement. If the value is TRUE, the statement in REPEAT ... UNTIL is not executed. Since the <Boolean expression> in the REPEAT syntax is only required to return whether the result is true or false, all expressions that can be specified in the <Boolean expression> in the IF conditional statement can be used.



[Description example]

(a) When actual device is used in Boolean expression

REPEAT

```
D1 := D1 + 1; (* Until D1 becomes less than 100 *)
UNTIL D1 < 100 (* D1 is incremented by 1 *)
END_REPEAT;
```

(b) When operator is used in Boolean expression

```
REPEAT
```

4 - 18 4 - 18

(c) When function is used in Boolean expression

Point

- Precaution 1 for use of repeat statements
 When using a repeat statement, be careful not to result in endless loop processing.
- Precaution 2 for use of repeat statements
 If many repeat statements are used, it should be noted that the PLC scan time will increase remarkably.

4.3.4 Other control syntaxes

(1) RETURN syntax


[Format]

| | | - |
|---------|--|---|
| RETURN; | | |

[Explanation]

The RETURN syntax is used to terminate a program in a function block or an ST program.

When the RETURN syntax is used in a program, the processing after the RETURN syntax are all ignored, and a jump occurs from the place where RETURN is executed to the last line of the ST program or the program in the function block.



[Description example]

(a) When actual device is used in IF conditional statement Boolean expression IF X0 THEN (If X0 is ON, the statement in IF is executed. *) RETURN; (* The program after the RETURN line is ignored. *) END_IF;

(2) EXIT syntax


[Format]

| EXIT; | | |
|-------|--|--|

[Explanation]

The EXIT syntax can be used in the repeat statement of an ST program and terminates a repeat loop midway.

When the EXIT syntax is reached during execution of a repeat loop, the repeat loop processing after the EXIT syntax is not executed. The program is continued on the line that follows the one where the repeat loop processing has been terminated.



[Description example]

(a) When actual device is used in IF conditional Boolean expression

```
FOR D0: = 0 TO 10 D0 (* If the D0 value is less than or equal to 10,
                                                                         *)
                                                                          *)
                          (* repeat is executed.
   IF D1 > 10 THEN
                          (* Whether the D1 value is greater than 10
                                                                         *)
                          (* or not is checked.
                                                                         *)
      EXIT;
                          (* If the D1 value is greater than 10,
                                                                         *)
                          (* repeat processing
                          (* ends.
                                                                         *)
   END_IF;
END_FOR;
```

4 - 21 4 - 21

4.3.5 Precautions for use of control syntaxes

This section explains the number of used steps, operation processing time and instructions for use of the control syntaxes in an ST program.

(1) Number of used steps and operation processing time for use of control syntaxes

The number of used steps and operation processing time for use of the control syntaxes will be explained.

The operation processing time is calculated by addition of the processing times of the instructions. Use it as reference for program creation.

(a) IF conditional statements

IF conditional statement 1

Unit (µs)

| | | Number of Steps | Operation Processing Time (Q25H) | Operation Processing Time (Q00J) |
|--------------|----------------------------------|-----------------|-------------------------------------|-------------------------------------|
| ST program | IF X0 THEN D0 : = 100; END_IF; | 7 | 1.534 | 10.9 |
| List program | LD X0 MOV K100 D0 | 3 | 0.134 | 0.90 |

[Remarks]

In only the conditional statement area, the processing time is shorter than when ST is not used.

However, since the comparison target of the IF conditional statement in ST is the Boolean expression, complicated comparison can be made easily.

IF conditional statement 2

Unit (µs)

| | | Number of Steps | Operation Processing Time (Q25H) | Operation Processing Time (Q00J) |
|--------------|------------------------------------|-----------------|-------------------------------------|-------------------------------------|
| ST program | IF D0 = 0 THEN D0 : = 100; END_IF; | 9 | 1.6 | 11.5 |
| List program | LD = D0 K0 MOV K100 D0 | 5 | 0.20 | 1.50 |

[Remarks]

In only the conditional statement area, the processing time is shorter than when ST is not used.

However, since the comparison target of the IF conditional statement in ST is the Boolean expression, complicated comparison can be made easily.

(b) CASE conditional statement

Unit (µs)

| | | Number of Steps | Operation Processing Time (Q25H) | Operation Processing Time (Q00J) |
|--------------|---|-----------------|-------------------------------------|-------------------------------------|
| ST program | CASE D0 OF 1, 2: D0 : = 100; 310: D1 : = D1 + 1; END_CASE; | 29 | 5.004 | 36.1 |
| List program | LD= D0 K1 AND= D0 K2 MOV K100 D0 LD>= D0 K3 AND<= D0 K10 INC D1 | 16 | 0.64 | 4.6 |

[Remarks]

Since CJ, JMP, etc. need not be executed in a list unlike ST, only the times for the compared areas are measured.

The time has been calculated on the assumption that the compared areas are conducting.

(c) FOR...DO statement

Unit (µs)

| | | Number of Steps | Operation Processing Time (Q25H) | Operation Processing Time (Q00J) |
|--------------|--|-----------------|--|-------------------------------------|
| ST program | FOR D0 : = 0 T0 10 BY 1 D0 D1 : = D1 + 1; END_FOR; | | Initialization: 0.134 Repeat: 3.308 In this case, the repeated area operates 10 times. | Initialization: 0.9 Repeat: 24.0 |
| List program | FOR K10 LD SM400 INC D1 NEXT | 6 | 2.574 | 21.6 |

[Remarks]

The above operation processing time is taken by the number of repeat times.

In a list, only the number of repeat times can be specified. In ST, repeat and other operation processing can be performed by condition comparison.

(d) WHILE...DO statements

WHILE...DO statement 1

Unit (µs)

| | | Number of Steps | Operation Processing Time (Q25H) | Operation Processing Time (Q00J) |
|--------------|---|-----------------|---------------------------------------|-------------------------------------|
| ST program | WHILE X0 DO D0 : = 100; END_ WHILE; | | 3.034 Repeated until X0 becomes TRUE. | 21.9 |
| List program | As above | As above | As above | As above |

[Remarks]

If the statement is described in a list, the program is the same as the ST program conversion result. Therefore, the processing time is also the same as that of ST.

WHILE...DO statement 2

Unit (µs)

| | | Number of Steps | Operation Processing Time (Q25H) | Operation Processing Time (Q00J) |
|--------------|--|-----------------|-------------------------------------|-------------------------------------|
| ST program | WHILE D0= 100 DO D0 : = 100; END_ WHILE; | 15 | 3.1 | 22.5 |
| List program | As above | As above | As above | As above |

[Remarks]

If the statement is described in a list, the program is the same as the ST program conversion result. Therefore, the processing time is also the same as that of ST.

(e) REPEAT...UNTIL statements

REPEAT...UNTIL statement 1

Unit (µs)

| | | Number of Steps | Operation Processing Time (Q25H) | Operation Processing Time (Q00J) |
|--------------|--|-----------------|---|-------------------------------------|
| ST program | REPEAT D0:=100; UNTIL X0 END_ REPEAT; | | 1.534 Repeated until X0 becomes TRUE. | 10.9 |
| List program | As above | As above | As above | As above |

[Remarks]

If the statement is described in a list, the program is the same as the ST program conversion result. Therefore, the processing time is also the same as that of ST.

REPEAT...UNTIL statement 2

Unit (µs)

| | | Number of Steps | Operation Processing Time (Q25H) | Operation Processing Time (Q00J) |
|--------------|---|-----------------|--|-------------------------------------|
| ST program | REPEAT D0:=100; UNTIL D0=0 END_REPEAT; | | 1.6 Repeated until D0 becomes 0. | 11.5 |
| List program | As above | As above | As above | As above |

[Remarks]

If the statement is described in a list, the program is the same as the ST program conversion result. Therefore, the processing time is also the same as that of ST.

(f) EXIT statement

Unit (µs)

| | | Number of Steps | Operation Processing Time (Q25H) | Operation Processing Time (Q00J) | |
|--------------|----------|-----------------|----------------------------------|-------------------------------------|--|
| ST program | _ | 3 | 1.4 | 11 | |
| List program | As above | As above | As above | As above | |

[Remarks]

Using the JMP instruction, execution moves to the pointer immediately after repeat processing termination. If the statement is described in a list, the operation is the same as in the ST program. Therefore, the processing time is also the same as that of ST.

(g) RETURN statement

Unit (µs)

| | | Number of Steps | Operation Processing | Operation Processing |
|--------------|----------|-----------------|----------------------|----------------------|
| | | Number of Steps | Time (Q25H) | Time (Q00J) |
| ST program | _ | 3 | 1.4 | 11 |
| List program | As above | As above | As above | As above |

[Remarks]

Using the JMP instruction, execution moves to the pointer immediately after repeat processing termination. If the statement is described in a list, the operation is the same as in the ST program. Therefore, the processing time is also the same as that of ST.

(2) Precautions for use of bit devices

The following explains the precautions to be taken when a program is created using an IF/CASE conditional statement in an ST program.

Once the Boolean expression (conditional expression) is satisfied in the IF condition statement, when a bit device is turned ON in the IF condition statement, that bit device becomes always ON.

```
[ST program example 1]

IF M0 THEN

Y0 := TRUE;

END_IF;

The above program is equivalent to the following.

LD M0;

SET Y0:
```

To avoid the bit device being always ON, change the program as shown below.

```
[ST program example 2]

IF M0 THEN

Y0 := TRUE;

ELSE

Y0 := FALSE;

END_IF;

The above program is equivalent to the following.

(a) LD M0;

OUT Y0;

(b) Y0 := M0;
```

(c) OUT_M (M0, Y0);

However, when OUT_M() is used in the IF conditional statement, the condition is as in [ST program example 1].

The above precautions also apply to when the CASE conditional statement is used.

Once the integer expression (conditional expression) is satisfied in the CASE condition statement, when a bit device is turned ON in the CASE condition statement, that bit device becomes always ON.

(3) Precautions for use of timers and counters

The following explains the precautions to be taken when a program is created using an IF/CASE conditional statement in an ST program.

In the IF condition statement, the Boolean expression (conditional expression) differs from the execution condition of the timer/counter instruction.

```
Example: In the case of timer
[ST program example 1]
      IF M0 THEN
             TIMER M (M1, TC0, K10);
      END_IF;
      (* When M0 = ON and M1 = ON, counting starts.
                                                                           *)
      (* When M0 = ON and M1 = OFF, counting is cleared.
                                                                           *)
                                                                           *)
      (* When M0 = OFF and M1 = ON, counting is stopped. The counting
                                                                           *)
      (* value is not cleared.
       (* When M0 = OFF and M1 = OFF, counting is stopped. The counting
                                                                           *)
      (* value is not cleared.
                                                                           *)
Example: In the case of counter
[ST program example 2]
      IF M0 THEN
             COUNTER M (M1, CC0, K10);
      END IF;
      (* When M0 = ON and M1 = ON/OFF, counting is incremented by 1.
                                                                           *)
      (* When M0 = OFF and M1 = ON/OFF, counting is not executed.
                                                                           *)
      (* M0 = ON/OFF and counting incrementing by 1 are not synchronized. *)
```

The above occurs since the timer/counter-related statement is not executed if the IF condition statement is not satisfied.

When the AND condition of M0 and M1 is used to operate the timer/counter, do not use the control syntax but use only the MELSEC function.

[Changed ST program example]

```
When timer is used TIMER_M (M0 & M1, TC0, K10);
When counter is used COUNTER M (M0 & M1, CC0, K10);
```

Using the new program, the timer/counter can be operated under the AND condition of M0 and M1.

The above precautions also apply to when the CASE conditional statement is used.

In the CASE condition statement, the integer expression (conditional expression) differs from the execution condition of the timer/counter instruction.

4.4 Call of Function Block

In an ST program, a function blocks (FB) can be used.

This section explains the method of using a user-created FB in an ST program. (For the FB creating method, refer to the "GX Developer Version 8 Operating Manual (Function Block)".

(1) Call of function block

When a created FB is to be used in an ST program, an FB name must be defined first on the local variable setting screen. (Refer to REFERENCE).) The FB can be used by describing the defined FB name (FB call) in the ST program.

When calling the FB, describe all input variables and I/O variables. Also, always specify values for the input variables and I/O variables.

For an output variable, its description can be omitted if the result of the output variable is not needed.

[Description example]

When the following FB is created

FB data name : LINE1_FB
Input variable : I_Test
Output variable : O_Test
I/O variable : IO_Test
FB label name : FB1

The description example of a FB call is as given below.

The description of the output variable can be omitted.

(2) How to acquire the output result

By providing "." after the FB name to specify the output variable name, the output of the FB can be acquired.


[Description example]

Describe as given below when assigning the result of the output variable to D1.

REFERENCE

● To make label declaration for the input, I/O and output variables of FB ...

GX Developer start \rightarrow [Open project] \rightarrow Click the FB tab \rightarrow Add new FB




 \rightarrow FB label setting screen

The following example shows the FB input/output variable label setting made on the FB label setting screen.

| | Input/Output | | Label | Constant | Device type | |
|---|--------------|---|---------|----------|-------------|---|
| 1 | VAR_INPUT | • | I_TEST | | INT 🔻 | - |
| 2 | VAR_OUTPUT | • | O_TEST | | INT - | • |
| 3 | VAR_IN_OUT | • | IO_TEST | | INT | - |

● To make label declaration for the FB data name ...

Before an FB is called, the label declaration of the used FB must be made.



→ Local (or global) variable setting screen

| | Au | Label | Constant | Device type | |
|---|----|---------|----------------|--|---|
| 1 | | BLabel | | BOOL | - |
| 2 | | DwLabel | | DINT | - |
| 3 | | label2 | Setting detail | FB(FB1) | ₹ |
| 4 | | | | COUNTER | Ī |
| | | | | STOREDTIMER POINTER STRUCTURE FB FB(FB1) | - |
| | | | | → | |

Select FB in Device type.

The following example shows the FB label definition made on the local variable setting screen.

| 3 | label2 | Setting detail | FB(FB1) | • |
|---|--------|----------------|---------|---|

Point

Precaution for acquiring the FB output

Execute FB output acquirement after an FB call. If it is executed before an FB call, an error will occur.

Example: FB name: FB1

Input variable : I_Test
Output variable: O_Test

D1 : = FB1.O_Test; (* FB output acquirement *)
FB1(I_Test : = D0, O_Test : = D1); (* FB call *)

An error occurs since this program is written in order of FB output acquirement and FB call.

•

Precaution for use of I/O variables

If the result of an I/O variable is used like an output variable, an error will occur. Like an input variable, the value of an I/O variable must be specified at the time of an FB call.

Example: FB name: FB1

I/O variable : IO_TEST Output variable: O_Test

[Description example]

FB1(IO_Test : = D1);

D1 : FB1.IO_Test; \rightarrow An error occurs.

Precaution for making an FB call

In an ST program, the FB set on the local variable setting screen can be used only once. (If it is used more than once, an error will occur.) To use the same FB more than once, declare the FB by the number of times it will be used beforehand on the local variable setting screen.

Example: The following example shows that the FB label has been defined more than once on the local variable setting screen.

| | Au | Label | Constant | Device type |
|---|----|--------|----------------|------------------|
| 1 | | label | Setting detail | FB(FB1) ▼ |
| 2 | | label1 | Setting detail | FB(FB1) ▼ |
| 3 | | label2 | Setting detail | FB(FB1) ▼ |

In the program, the FB is used as indicated below.

label (I_Test := D0, IO_Test := D100); label1 (I_Test := D1, IO_Test := D150); label2 (I Test := D3, IO Test := D200);

4 - 31 4 - 31

4.5 Comment

In an ST program, comments can be input. An area enclosed by "(*" and "*)" is handled as a comment. If a comment is placed within a comment, an error will occur.

| MEMO | |
|------|--|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

4 - 33


5 MELSEC FUNCTIONS

How the functions are described

This manual describes the function definitions, arguments, return values and using examples of the MELSEC functions.

The MELSEC functions are created on the basis of the MELSEC common commands. For the applicable CPU types, basic operations, detailed functions and applicable devices of the functions and the errors that may occur during execution of the functions, refer to the "MELSEC-Q/L Programming Manual (Common Instruction)".

The reference section is the section described in "Corresponding MELSEC command".



- 1) Indicates the function of the function.
- 2) Indicates the data type of the function.
- Indicates the function name.
- 4) Indicates the data type of the argument. (The STRING type is represented STRING (number of characters). It is represented STRING(6) when the number of characters is 6. The ARRAY type is represented data type(number of elements). It is represented ANY16(3) when the array is of ANY16 type and has three elements.)
- 5) Indicates the argument name.
- 6) Indicates the list (argument name, IN/OUT, description) of arguments used with the function. (The STRING type is represented ARRAY [0..Number of elements-1] OF Data type. It is represented ARRAY [0..2] OF ANY16 when the array is of ANY16 type and has three elements.)
- 7) Indicates the list (return value name, description) of return values used with the function.
- 8) Indicates the example of using the function. (Indicates the example that uses the actual device/label.)
- 9) Indicates the QCPU (Q mode)/LCPU MELSEC command corresponding to the function.


2)

The following indicates the correspondences between the MELSEC command in the "MELSEC-Q/L Programming Manual (Common Instruction)" and the MELSEC function in this manual.

MELSEC-Q/L Programming Manual (Common Instruction) [MELSEC in struction]

6.1.6 BIN block data comparisons (BKCMP□, BKCMP□P)





- Si : Data to be compared or head number of the devices where the data to be compared is stored (BIN 16 bits)
- : Head number of the devices where the comparison data is stored (BIN 16 bits)
- ① : Head number of the devices where the comparison operation result will be stored (bits)
- $n\ \ :$ Number of comparison data blocks (BIN 16 bits)

| Setting | Internal | Devices | R, ZR | JŪ | i\iii | uiiikgiii | Zn | Constants | Other | |
|------------|----------|---------|---------|-----|-------|-----------|------|-----------|-------|----------|
| Data | Bit | Word | 11, 211 | Bit | Word | 0 | 2.11 | K, H | Othor | |
| S 1 | _ | | | | | _ | | 0 | | |
| \$2 | _ | | | | | _ | | _ | | _ |
| 0 | 0 | | | | | _ | | _ | | _ |
| n | 0 | | | | | 0 | | 0 | | |

[MELSEC function] in this manual

5.4.1 Block data comparison (=) BKCMP_EQ_M

n points of BIN 16-bit data (word unit), starting at the specified devices, are compared in terms of "=".

■ Function definition BOOL BKCMP_EQ_M (BOOL EN, ANY16 S1, ANY16 S2, ANY16 n, BOOL D);

9) 10) 11) 1:

5 - 2 5 - 2

- Applicable CPU types
 CPU types that can use the instructions are indicated.
- 2) Applicable devices
- The correspondences between the arguments of the MELSEC function and MELSEC command are as follows. (The arguments of the same argument names correspond to each other.)



Precaution for use of the arguments of the MELSEC and IEC functions When the argument is of ANY32 type, the data type that can be specified is the DIN type, and therefore, an actual device cannot be specified. Only the double word type label can be specified. However, digit specification is allowed.

Example: BSQR_MD(BOOL EN, ANY16 s, ANY32 d);

(* Function definition of BSQR_MD *)

BSQR_MD (X0, D0, <u>dData</u>); (* Program example In the MELSEC common command, an actual device can be described as indicated below.

BSQR(D0, W0);

However, it cannot be described in the MELSEC/IEC function. BSQR_MD(X0, D0, $\underline{W0}$); \leftarrow An error will occur.

When the argument is of REAL type, the data type that can be specified is the real number type label, or a real number value can be described directly.

An actual device cannot be specified.

Example: ESTR_M(BOOL EN, REAL s1, ANY16(3) s2, STRING d);

(* Function definition of ESTR M *)

*)

ESTR M(X0, rData, ArrayData, sData);

(* Program example

In the MELSEC common command, the actual device can be described as indicated below.

ESTR(R0, R10, D10);

However, it cannot be described in the MELSEC/IEC function. ESTR_M(X0, $\underline{R0}$, ArrayData, sData); \leftarrow An error will occur.

5 - 3 5 - 3

5.1 Output

5.1.1 Output to device OUT_M

The execution condition is output to the specified device.

■ Function definition BOOL OUT_M (BOOL EN, BOOL D);

| Argument Name | IN/OUT | Description |
|---------------|--------|----------------------------|
| EN | IN | Execution condition |
| D | OUT | Target to be turned ON/OFF |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

(* Execution condition X0 is output to the assigned device of bData. OUT_M (X0, bData);



Corresponding MELSEC command

OUT (Output)

5.1.2 Low-speed timer TIMER M

When the coil of the timer (low-speed timer, low-speed retentive timer) turns ON, the timer measures up to the set value, and when the timer times out (calculation value (set value), the contact is put in the following status. N/O contact: Conduction N/C contact: Non-conduction

■ Function definition

BOOL TIMER_M (BOOL EN, BOOL TCoil, ANY16 TValue);

| Argument Name | IN/OUT | Description |
|---------------|--------|--|
| - FN | 15.1 | Execution condition (Function is executed only |
| EN | EN IN | when the result is TRUE) |
| TCoil | IN | TS, TC device or STS, STC device (bit data) |
| TValue | IN | Timer set value (BIN 16-bit data) |

Remarks: When a constant is specified for the timer set value, only a decimal number can be specified.

The timer set value can be specified within the range 0 to 32767.

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, TC0 turns ON and the timer calculates *
- (* up to TValue, and when the timer times out (calculation value (set value),
- (* the contact is put in the following status. *)
- (* N/O contact: Conduction N/C contact: Non-conduction *)
 TIMER M (X0, TC0, TValue);



Corresponding MELSEC command

- OUT T (Low-speed timer)

For the usable data type, refer to "3.2.2 About ANY type".

*)

5 - 4 5 - 4

5.1.3 High-speed timer TIMER H M

When the coil of the timer (high-speed timer, high-speed retentive timer) turns ON, the timer calculates up to the set value, and when the timer times out (calculation value (set value), the contact is put in the following status.

N/O contact: Conduction N/C contact: Non-conduction

BOOL TIMER H M (BOOL EN, BOOL TCoil, ANY16 TValue); ■ Function definition

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | | Execution condition (Function is executed only when the result is TRUE) |
| TCoil | IN | TS, TC device or STS, STC device (bit data) |
| TValue | IN | Timer set value (BIN 16-bit data) |

Remarks: When a constant is specified for the timer set value, only a decimal number can be specified. The timer set value can be specified within the range 0 to 32767.

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, TC0 turns ON and the timer calculates*)
- (* up to TValue, and when the timer times out (calculation value(TValue), the
- (* contact is put in the following status.
- *) (* N/O contact: Conduction N/C contact: Non-conduction *) TIMER_H_M (X0, TC0, TValue);



Corresponding MELSEC command

OUTH T (High-speed timer)

5.1.4 Counter COUNTER M

The present value (count value) of the counter is incremented by 1, and when the counter counts up (present value = set value), the contact is put in the following status.

N/O contact: Conduction N/C contact: Non-conduction

■ Function definition BOOL COUNTER M (BOOL EN, BOOL CCoil, ANY16 CValue);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | INI | Execution condition (Function is executed only when the result is TRUE) |
| CCoil | IN | CS, CC device number (bit data) |
| CValue | IN | Counter set value (BIN 16-bit data) |

Remarks: When a constant is specified for the counter set value, only a decimal number can be specified.

The timer set value can be specified within the range 0 to 32767.

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* After execution condition X0 has turned ON, the present value (count value) is *)
- incremented by 1 when CC0 changes from OFF to ON, and when the counter *)
- counts up (present value = CValue), the contact is put in the following status.
- N/O contact: Conduction N/C contact: Non-conduction COUNTER M (X0, CC0, CValue);



Corresponding MELSEC command

- OUT C (Counter)

For the usable data type, refer to "3.2.2 About ANY type".

5 - 5 5 - 5

5.1.5 Set of device SET M

When the execution condition is satisfied, the specified device is operated as described below.

- Bit device: The coil/contact is turned ON.
- When bit of word device is specified: The specified bit is turned to 1.
- Function definition BOOL SET_M (BOOL EN, BOOL D);


| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | | Execution condition (Function is executed only when the result is TRUE) |
| D | OUT | Data to be set |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

(* When execution condition X0 turns ON, the assigned device of bData is

(* turned ON.



Corresponding MELSEC command

SET (Set of device)

5.1.6 Reset of device RST_M

When the execution condition is satisfied, the specified device is operated as described below.

- Bit device: The coil/contact is turned OFF.
- Timer, counter: 0 is assigned to the present value and the coil/contact is turned OFF.
- When bit of word device is specified: The specified bit is turned to 0.
- Word device other than timer and counter: 0 is assigned to the device data.
- Function definition BOOL RST M (BOOL EN, BOOL ANY SIMPLE D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | INI | Execution condition (Function is executed only when the result is TRUE) |
| D | OUT | Data to be reset |

Remarks: The DINT/REAL/STRING type cannot be used in argument "D".

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

(* When execution condition X0 turns ON, the assigned device of bData is

(* turned OFF.

RST_M (X0, bData);



Corresponding MELSEC command

- RST (Reset of device)

For the usable data type, refer to "3.2.2 About ANY type".

5 - 6

5.1.7 Conversion of direct output into pulse DELTA_M

When the execution condition is satisfied, the specified direct access output (DY) is output as a pulse.

■ Function definition BOOL DELTA_M (BOOL EN, BOOL D);

| Argument Name | IN/OUT | Description | | | |
|---------------|--------|---|--|--|--|
| EN | I INI | Execution condition (Function is executed only when the result is TRUE) | | | |
| D | OUT | Data to be output as pulse (DY device) | | | |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

• Example of use

(*When execution condition X0 turns ON, device DY0 is converted into pulse. *) DELTA_M (X0, DY0);



- Corresponding MELSEC command
 - DELTA (Conversion of direct output into pulse)

5-7

5.2 1-Bit Shift

5.2.1 1-bit shift of device SFT M

When the execution condition is satisfied, the specified device is operated as described below.

- In the case of bit device:
 - The ON/OFF status of the device number preceding the specified device number is shifted to the specified device number, and the preceding device number is turned OFF.
- In the case of word device bit specification:

The 1/0 status of the bit preceding the bit of the specified device is shifted to the specified bit, and the preceding device number is turned to 0.

■ Function definition BOOL SFT_M (BOOL EN, BOOL D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | I INI | Execution condition (Function is executed only when the result is TRUE) |
| D | OUT | Data to be shifted |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, ON/OFF of M10 is shifted to M11
- (* and M10 is turned OFF.
 SFT M (X0, M11);
- (* When execution condition X0 turns ON, ON/OFF of W100.1 is shifted to
- (* W100.2 and W100.1 is turned OFF. *)
 SFT_M (X0, W100.2);

*)



Corresponding MELSEC command

- SFT (Bit device shift)

5 - 8 5 - 8

5.3 Termination

5.3.1 Stop STOP_M

When the execution condition is satisfied, output Y is reset and the CPU operation is stopped. (This operation is the same as performed when the RUN/STOP DIP switch is moved to the STOP position.)

■ Function definition BOOL STOP_M (BOOL EN);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | INI | Execution condition (Function is executed only when the result is TRUE) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

*)

Example of use

(* When execution condition X0 turns ON, the CPU operation is stopped. STOP_M (X0);



- Corresponding MELSEC command
 - STOP (Sequence program stop)

5 - 9 5 - 9

5.4 Comparison Operation

5.4.1 Block data comparison (=) BKCMP EQ M

n points of BIN 16-bit data (word unit), starting at the specified devices, are compared in terms of "=".

■ Function definition BOOL BKCMP EQ M (BOOL EN, ANY16 S1, ANY16 S2, ANY16 n, BOOL D);

| Argument Name | IN/OUT | Description | | | |
|---------------|--------|---|------------|--|-----|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) | | | |
| S1 | IN | Compared data (BIN 16-bit data) | | | |
| S2 | IN | Comparison data (BIN 16-bit data) | | | |
| n | IN | Number of data to be compared (BIN 16-bit data) | | | |
| | OUT | Comparison | Comparison | When comparison condition is satisfied | ON |
| ט | OUT | result (bit) | result | When comparison condition is not satisfied | OFF |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the data of the number of points stored *)
- (* in D0, starting at D100, is compared with the data of the number of points stored *)
- (* in D0, starting at D200, in terms of "=", and the result stored into M0 and later. *)

 BKCMP EQ M (X0, D100, D200, D0, M0);



Corresponding MELSEC command

- BKCMP= (BIN block data comparison (=))

5.4.2 Block data comparison (<>) BKCMP NE M

n points of BIN 16-bit data (word unit), starting at the specified devices, are compared in terms of "<>".

■ Function definition BOOL BKCMP_NE_M (BOOL EN, ANY16 S1, ANY16 S2, ANY16 n, BOOL D);

| Argument Name | IN/OUT | Description | | | |
|---------------|--------|---|---|--|-----|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) | | | |
| S1 | IN | Compared data (BIN 16-bit data) | | | |
| S2 | IN | Comparison data (BIN 16-bit data) | | | |
| n | IN | Number of da | Number of data to be compared (BIN 16-bit data) | | |
| | 0.17 | Comparison | | When comparison condition is satisfied | ON |
| U | OUT | result (bit) | result | When comparison condition is not satisfied | OFF |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the data of the number of points stored in *)
- (* D0, starting at D100, is compared with the data of the number of points stored *
- (* D0, starting at D200, in terms of "<>", and the result is stored into M0 and later. *)
 BKCMP NE M (X0, D100, D200, D0 M0);



Corresponding MELSEC command

- BKCMP<> (BIN block data comparison (<>))

For the usable data type, refer to "3.2.2 About ANY type".

5 - 10 5 - 10

5.4.3 Block data comparison (>) BKCMP_GT_M

n points of BIN 16-bit data (word unit), starting at the specified devices, are compared in terms of ">".

■ Function definition BOOL BKCMP_GT_M (BOOL EN, ANY16 S1, ANY16 S2, ANY16 n, BOOL D);

| Argument Name | IN/OUT | Description | | | |
|---------------|---------|---------------------------------|----------------|--|-----|
| EN | IN | Execution cor result is TRUE | • | on is executed only wher | the |
| S1 | IN | Compared da | ta (BIN 16-bit | data) | |
| S2 | IN | Comparison of | lata (BIN 16-b | oit data) | |
| n | IN | Number of da | ta to be comp | pared (BIN 16-bit data) | |
| | O. I.T. | Comparison | Comparison | When comparison condition is satisfied | ON |
| ט | OUT | result (bit) | result | When comparison condition is not satisfied | OFF |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the data of the number of points stored *)
- (* in D0, starting at D100, is compared with the data of the number of points stored *)
- (* in D0, starting at D200, in terms of ">", and the result is stored into M0 and later. *)
 BKCMP GT M (X0, D100, D200, D0, M0);



Corresponding MELSEC command

- BKCMP> (BIN block data comparison (>))

5.4.4 Block data comparison (<=) BKCMP LE M

n points of BIN 16-bit data (word unit), starting at the specified devices, are compared in terms of "<=".

Function definition BOOL BKCMP_LE_M (BOOL EN, ANY16 S1, ANY16 S2, ANY16 n, BOOL D);

| Argument Name | IN/OUT | Description | | | |
|---------------|--------|---|----------------|--|-----|
| EN | IN | Execution con result is TRUE | • | on is executed only wher | the |
| S1 | IN | Compared da | ta (BIN 16-bit | data) | |
| S2 | IN | Comparison d | lata (BIN 16-b | oit data) | |
| n | IN | Number of data to be compared (BIN 16-bit data) | | | |
| | 0.17 | Comparison | | When comparison condition is satisfied | ON |
| ט | OUT | result (bit) | result | When comparison condition is not satisfied | OFF |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the data of the number of points stored *)
- (* in D0, starting at D100, is compared with the data of the number of points stored *)
- (* in D0, starting at D200, in terms of "<=", and the result is stored into M0 and later. *)

 BKCMP_LE_M (X0, D100, D200, D0, M0);



Corresponding MELSEC command

BKCMP<= (BIN block data comparison (<=))

For the usable data type, refer to "3.2.2 About ANY type".

5 - 11 5 - 11

5.4.5 Block data comparison (<) BKCMP_LT_M

n points of BIN 16-bit data (word unit), starting at the specified devices, are compared in terms of "<".

■ Function definition BOOL BKCMP_LT_M (BOOL EN, ANY16 S1, ANY16 S2, ANY16 n, BOOL D);

| Argument Name | IN/OUT | Description | | | |
|---------------|--------|---------------------------------|----------------|--|-----|
| EN | IN | Execution cor result is TRUE | • | on is executed only wher | the |
| S1 | IN | Compared da | ta (BIN 16-bit | data) | |
| S2 | IN | Comparison of | lata (BIN 16-b | oit data) | |
| n | IN | Number of da | ta to be comp | pared (BIN 16-bit data) | |
| | 0.17 | Comparison | Comparison | When comparison condition is satisfied | ON |
| ט | OUT | result (bit) | result | When comparison condition is not satisfied | OFF |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the data of the number of points stored *)
- (* in D0, starting at D100, is compared with the data of the number of points stored *)
- (* in D0, starting at D200, in terms of "<", and the result is stored into M0 and later. *)
 BKCMP LT M (X0, D100, D200, D0, M0);



Corresponding MELSEC command

- BKCMP< (BIN block data comparison (<))

5.4.6 Block data comparison (>=) BKCMP GE M

n points of BIN 16-bit data (word unit), starting at the specified devices, are compared in terms of ">=".

Function definition BOOL BKCMP_GE_M (BOOL EN, ANY16 S1, ANY16 S2, ANY16 n, BOOL D);

| Argument Name | IN/OUT | Description | | | |
|---------------|--------|---|----------------|--|-----|
| EN | IN | Execution con result is TRUE | • | on is executed only wher | the |
| S1 | IN | Compared da | ta (BIN 16-bit | data) | |
| S2 | IN | Comparison d | lata (BIN 16-b | oit data) | |
| n | IN | Number of data to be compared (BIN 16-bit data) | | | |
| | 0.1.17 | Comparison | | When comparison condition is satisfied | ON |
| D | OUT | result (bit) | result | When comparison condition is not satisfied | OFF |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the data of the number of points stored *)
- (* in D0, starting at D100, is compared with the data of the number of points stored *)
- (* in D0, starting at D200, in terms of ">=", and the result is stored into M0 and later. *) BKCMP GE M (X0, D100, D200, D0, M0);



Corresponding MELSEC command

- BKCMP>= (BIN block data comparison (>=))

For the usable data type, refer to "3.2.2 About ANY type".

5 - 12 5 - 12

5.5 Arithmetic Operation

5.5.1 Addition of BCD 4-digit data (2 devices) BPLUS_M

The specified two BCD 4-digit data are added.

■ Function definition BOOL BPLUS_M (BOOL EN, ANY16 S1, ANY16 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Addend data (BCD 4-digit data) |
| D | IN/OUT | Augend data, addition result (BCD 4-digit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the BCD 4-digit data stored in D0
- (* and D100 are added, and the addition result is stored into D100. *)
 BPLUS_M (X0, D0, D100);

*)

*)



Corresponding MELSEC command

- B+ (BCD 4-digit data addition)

5.5.2 Addition of BCD 4-digit data (3 devices) BPLUS 3 M

The specified two BCD 4-digit data are added.

■ Function definition BOOL BPLUS_3_M (BOOL EN, ANY16 S1, ANY16 S2, ANY16 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Augend data (BCD 4-digit data) |
| S2 | IN | Addend data (BCD 4-digit data) |
| D | OUT | Addition result (BCD 4-digit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the BCD 4-digit data stored in D1
- (* and D2 are added, and the addition result is stored into D100. *)
 BPLUS_3_M (X0, D1, D2, D100);



Corresponding MELSEC command

- B+ (BCD 4-digit data addition)

For the usable data type, refer to "3.2.2 About ANY type".

5 - 13 5 - 13

5.5.3 Subtraction of BCD 4-digit data (2 devices) BMINUS M

Subtraction is performed between the specified two BCD 4-digit data.

■ Function definition BOOL BMINUS_M (BOOL EN, ANY16 S1, ANY16 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | INI | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Subtrahend data (BCD 4-digit data) |
| D | IN/OUT | Minuend data, subtraction result (BCD 4-digit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, subtraction is performed between the *)
- (* BCD 4-digit data stored in D0 and D100, and the subtraction result is stored
- (* into D100. *)

BMINUS_M (X0, D0, D100);



- Corresponding MELSEC command
 - B- (BCD 4-digit data subtraction)

5.5.4 Subtraction of BCD 4-digit data (3 devices) BMINUS_3_M

Subtraction is performed between the specified two BCD 4-digit data.

■ Function definition BM

BMINUS_3_M (BOOL EN, ANY16 S1, ANY16 S2, ANY16 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | INI | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Minuend data (BCD 4-digit data) |
| S2 | IN | Subtrahend data (BCD 4-digit data) |
| D | OUT | Subtraction result (BCD 4-digit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, subtraction is performed between the
- (* BCD 4-digit data stored in D1 and D2, and the subtraction result is stored *)
- (* into D100. *)

BMINUS_3_M (X0, D1, D2, D100);



- Corresponding MELSEC command
 - B- (BCD 4-digit data subtraction)

For the usable data type, refer to "3.2.2 About ANY type".

5 - 14 5 - 14

5.5.5 Addition of BCD 8-digit data (2 devices) DBPLUS M

The specified two BCD 8-digit data are added.

■ Function definition BOOL DBPLUS_M (BOOL EN, ANY16 S1, ANY32 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | INI | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Addend data (BCD 8-digit data) |
| D | IN/OUT | Augend data, addition result (BCD 8-digit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the BCD 8-digit data stored in
- (* dwData1 and Result are added, and the addition result is stored into Result. *) DBPLUS_M (X0, dwData1, Result);



- Corresponding MELSEC command
 - DB+ (BCD 8-digit data addition)

5.5.6 Addition of BCD 8-digit data (3 devices) DBPLUS_3_M

The specified two BCD 8-digit data are added.

■ Function definition DBPLUS_3_M (BOOL EN, ANY32 S1, ANY32 S2, ANY32 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | INI | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Augend data (BCD 8-digit data) |
| S2 | IN | Addend data (BCD 8-digit data) |
| D | OUT | Addition result (BCD 8-digit data) |

| Return Value | Description | |
|--------------|---------------------|--|
| BOOL | Execution condition | |

Example of use

- (* When execution condition X0 turns ON, the BCD 8-digit data stored in
- (* dwData1 and dwData2 are added, and the addition result is stored into Result. *) DBPLUS_3_M (X0, dwData1, dwData2, Result);



Corresponding MELSEC command

- DB+ (BCD 8-digit data addition)

For the usable data type, refer to "3.2.2 About ANY type".

5 - 15 5 - 15

5.5.7 Subtraction of BCD 8-digit data (2 devices) DBMINUS M

Subtraction is performed between the specified two BCD 8-digit data.

■ Function definition BOOL DBMINUS_M (BOOL EN, ANY32 S1, ANY32 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Subtrahend data (BCD 8-digit data) |
| D | IN/OUT | Minuend data, subtraction result (BCD 8-digit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, subtraction is performed between the *)
- (* BCD 8-digit data stored in dwData1 and Result, and the subtraction result is
- (* stored into Result. *)

DBMINUS_M (X0, dwData1, Result);



Corresponding MELSEC command

- DB- (BCD 8-digit data subtraction)

5.5.8 Subtraction of BCD 8-digit data (3 devices) DBMINUS_3_M

Subtraction is performed between the specified two BCD 8-digit data.

■ Function definition BOOL DBMINUS 3 M (BOOL EN, ANY32 S1, ANY32 S2, ANY32 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | I INI | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Minuend data (BCD 8-digit data) |
| S2 | IN | Subtrahend data (BCD 8-digit data) |
| D | OUT | Subtraction result (BCD 8-digit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, subtraction is performed between the *)
- (* BCD 8-digit data stored in dwData1 and dwData2, and the subtraction result *)
- (* is stored into Result. *)

DBMINUS 3 M (X0, dwData1, dwData2, Result);



Corresponding MELSEC command

- DB- (BCD 8-digit data subtraction)

For the usable data type, refer to "3.2.2 About ANY type".

5 - 16 5 - 16

5.5.9 Multiplication of BCD 4-digit data BMULTI_M

The specified two BCD 4-digit data are multiplied.

■ Function definition BOOL BMULTI M (BOOL EN, ANY16 S1, ANY16 S2, ANY32 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Multiplicand data (BCD 4-digit data) |
| S2 | IN | Multiplier data (BCD 4-digit data) |
| D | OUT | Multiplication result (BCD 4-digit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

- Example of use
 - (* When execution condition X0 turns ON, the BCD 4-digit data stored in D1
 - (* and D2 are multiplied, and the multiplication result is stored into Result. *) BMULTI_M (X0, D1, D2, Result);



- Corresponding MELSEC command
 - B* (BCD 4-digit data multiplication)

5.5.10 Division of BCD 4-digit data BDIVID_M

Division is performed between the specified two BCD 4-digit data.

■ Function definition BOOL BDIVID_M (BOOL EN, ANY16 S1, ANY16 S2, ANY16(2) D);

| Argument Name | IN/OUT | Description | |
|---------------|--------|--|------------------------------|
| EN | IN | Execution condition (Function is exresult is TRUE) | ecuted only when the |
| S1 | IN | Dividend data (BCD 4-digit data) | |
| S2 | IN | Divisor data (BCD 4-digit data) | |
| D | OUT | Division result (ARRAY [01] OF ANY16) | D[0] Quotient D[1] Remainder |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

- Example of use
 - (* When execution condition X0 turns ON, division is performed between the
 - (* BCD 4-digit data stored in D1 and D2, and the division result is stored into
 - (* array ArrayResult. *)
 BDIVID_M (X0, D1, D2, ArrayResult);



Corresponding MELSEC command

- B/ (BCD 4-digit data division)

For the usable data type, refer to "3.2.2 About ANY type".

*)

*)

5 - 17 5 - 17

5.5.11 Multiplication of BCD 8-digit data DBMULTI M

The specified two BCD 8-digit data are multiplied.

■ Function definition

BOOL DBMULTI_M (BOOL EN, ANY32 S1, ANY32 S2, ANY16(4) D);

| Argument Name | IN/OUT | Description | 1 | |
|---------------|--------|---|----------------|----------------|
| EN | IN | Execution condition (Function is execution is TRUE) | xecuted | only when the |
| S1 | IN | Multiplicand data (BCD 8-digit data | a) | |
| S2 | IN | Multiplier data (BCD 8-digit data) | | |
| D | OUT | Multiplication result (ARRAY [03] OF ANY16) | D[0] D[1] D[2] | Lower 4 digits |
| | | | D[3] | Upper 4 digits |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the BCD 8-digit data stored in
- (* dwData1 and dwData2 are multiplied, and the multiplication result is stored *)
- (* into array ArrayResult.

DBMULTI_M (X0, dwData1, dwData2, ArrayResult);



Corresponding MELSEC command

- DB* (BCD 8-digit data multiplication)

5.5.12 Division of BCD 8-digit data DBDIVID M

Division is performed between the specified two BCD 8-digit data.

■ Function definition

BOOL DBDIVID_M (BOOL EN, ANY32 S1, ANY32 S2, ANY32(2) D);

| Argument Name | IN/OUT | Description | | |
|---------------|--------|---|--------|-----------------------|
| EN | IN | Execution condition (Function is ex result is TRUE) | ecuted | only when the |
| S1 | IN | Dividend data (BCD 8-digit data) | | |
| S2 | IN | Divisor data (BCD 8-digit data) | | |
| D | | Division result (ARRAY [01] OF ANY32) | | Quotient Remainder |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, division is performed between the
- (* BCD 8-digit data stored in dwData1 and dwData2, and the division result is
- *) (* stored into array ArrayResult. *) DBDIVID M (X0, dwData1, dwData2, ArrayResult);



Corresponding MELSEC command

- DB/ (BCD 8-digit data division)

For the usable data type, refer to "3.2.2 About ANY type".

5 - 18 5 - 18

5.5.13 Character string data connection (2 devices) STRING PLUS M

The specified character string data are connected.

■ Function definition BOOL STRING_PLUS_M (BOOL EN, STRING S1, STRING D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to connect (character string data) |
| D | IN/OUT | Data to be connected, connection result (character string data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, character string "ABC" is connected
- (* to the end of the character string stored in StrResult and the connected
- (* character strings are stored into StrResult. *)

*)

*)

STRING_PLUS_M (X0, "ABC" StrResult);



Corresponding MELSEC command

• \$+ (Character string connection)

5.5.14 Character string data connection (3 devices) STRING_PLUS_3_M

The specified character string data are connected.

■ Function definition BOOL STRING PLUS 3

BOOL STRING PLUS 3 M (BOOL EN, STRING S1, STRING S2, STRING D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be connected (character string data) |
| S2 | IN | Data to connect (character string data) |
| D | OUT | Connection result (character string data) |

| Return Valu | ıe | Description |
|-------------|---------------------|-------------|
| BOOL | Execution condition | |

Example of use

- (* When execution condition X0 turns ON, the character string stored in
- (* StrData2 is connected to the end of the character string stored in StrData1 *)
- (* and the connected character strings are stored into StrResult. *)
 STRING_PLUS_3_M (X0, StrData1, StrData2, StrResult);



Corresponding MELSEC command

- \$+ (Character string connection)

For the usable data type, refer to "3.2.2 About ANY type".

5 - 19 5 - 19

5.5.15 BIN block addition BKPLUS M

n points of BIN 16-bit data, starting at the specified devices, are added.

■ Function definition BOOL BKPLUS M (BOOL EN, ANY16 S1, ANY16 S2, ANY16 n, ANY16 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Augend data (BIN 16-bit data) |
| S2 | IN | Addend data (BIN 16-bit data) |
| n | IN | Number of addition data (BIN 16-bit data) |
| D | OUT | Addition result (BIN 16-bit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the data of the number of points
- (* stored in D0, starting at D100, and the data of the number of points stored in *)
- (* D0, starting at D200, are added, and the result is stored into D1000 and later. *) BKPLUS M (X0, D100, D200, D0, D1000);



Corresponding MELSEC command

BK+ (Block data addition)

5.5.16 BIN block subtraction BKMINUS_M

Subtraction is performed between n points of BIN 16-bit data, starting at the specified devices.

■ Function definition BOOL BKMINUS M (BOOL EN, ANY16 S1, ANY16 S2, ANY16 n, ANY16 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Minuend data (BIN 16-bit data) |
| S2 | IN | Subtrahend data (BIN 16-bit data) |
| n | IN | Number of subtraction data (BIN 16-bit data) |
| D | OUT | Subtraction result (BIN 16-bit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, subtraction is performed between
- (* the data of the number of points stored in D0, starting at D100, and the data
- (* of the number of points stored in D0, starting at D200, and the result is



Corresponding MELSEC command

- BK- (Block data subtraction)

For the usable data type, refer to "3.2.2 About ANY type".

5 - 20 5 - 20

5.5.17 Increment INC_M

The specified BIN 16-bit data is incremented (by 1).

■ Function definition BOOL INC_M (BOOL EN, ANY16 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | INI | Execution condition (Function is executed only when the result is TRUE) |
| D | IN/OUT | Increment data, incrementing result (BIN 16-bit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

(* When execution condition X0 turns ON, the data stored in D0 is incremented by 1. *) INC_M (X0, D0);



- Corresponding MELSEC command
 - INC (BIN 16-bit increment)

5.5.18 Decrement DEC_M

The specified BIN 16-bit data is decremented (by 1).

■ Function definition BOOL DEC_M (BOOL EN, ANY16 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | I INI | Execution condition (Function is executed only when the result is TRUE) |
| D | IN/OUT | Decrement data, decrementing result (BIN 16-bit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

(* When execution condition X0 turns ON, the data stored in D0 is decremented by 1. *) DEC_M (X0, D0);



- Corresponding MELSEC command
 - DEC (BIN 16-bit decrement)

For the usable data type, refer to "3.2.2 About ANY type".

5 - 21 5 - 21

5.5.19 32-bit BIN increment DINC_M

The specified BIN 32-bit data is incremented (by 1).

■ Function definition BOOL DINC_M (BOOL EN, ANY32 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | INI | Execution condition (Function is executed only when the result is TRUE) |
| D | IN/OUT | Increment data, incrementing result (BIN 32-bit data) |

| Return Valu | ıe | Description |
|-------------|---------------------|-------------|
| BOOL | Execution condition | |

Example of use

- (* When execution condition X0 turns ON, the data stored in dwData1 is
- (* incremented by 1. *)
 DINC_M (X0, dwData1);



- Corresponding MELSEC command
 - DINC (BIN 32-bit increment)

5.5.20 32-bit BIN decrement DDEC_M

The specified BIN 32-bit data is decremented (by 1).

■ Function definition BOOL DDEC M (BOOL EN, ANY32 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | INI | Execution condition (Function is executed only when the result is TRUE) |
| D | IN/OUT | Decrement data, decrementing result (BIN 32-bit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

- Example of use
 - (* When execution condition X0 turns ON, the data stored in dwData1 is
 - (* decremented by 1. *)
 DDEC_M (X0, dwData1);



- Corresponding MELSEC command
 - DDEC (BIN 32-bit decrement)

For the usable data type, refer to "3.2.2 About ANY type".

5 - 22 5 - 22

5.6 Data Conversion

5.6.1 BIN→BCD conversion BCD M

The specified BIN 16-bit data (0 to 9999) is converted into BCD 4-digit data.

■ Function definition BOOL BCD_M (BOOL EN, ANY16 S1, ANY16 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | INI | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be converted (BIN 16-bit data) |
| D | OUT | Conversion result (BCD 4-digit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the BIN data stored in D0 is



Corresponding MELSEC command

BCD (Conversion from BIN data to 4-digit BCD data)

5.6.2 32-bit BIN→BCD conversion DBCD M

The specified BIN 32-bit data (0 to 99999999) is converted into BCD 8-digit data.

■ Function definition BOOL DBCD_M (BOOL EN, ANY32 S1, ANY32 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be converted (BIN 32-bit data) |
| D | OUT | Conversion result (BCD 8-digit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the BIN data stored in dwData1 is
- (* converted into BCD, and the result is stored into Result. *) DBCD_M (X0, dwData1, Result);



Corresponding MELSEC command

- DBCD (Conversion from BIN data to 8-digit BCD data)

For the usable data type, refer to "3.2.2 About ANY type".

*)

5 - 23 5 - 23

5.6.3 BCD→BIN conversion BIN_M

The specified BCD 4-digit data (0 to 9999) is converted into BIN 16-bit data.

■ Function definition BOOL BIN _M (BOOL EN, ANY16 S1, ANY16 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be converted (BCD 4-digit data) |
| D | OUT | Conversion result (BIN 16-bit data) |

| Return | Value | Description |
|--------|-------|---------------------|
| ВО | OL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the BCD data stored in D0 is
- (* converted into BIN, and the result is stored into D100. *) BIN_M (X0, D0, D100);



Corresponding MELSEC command

- BIN (Conversion from BCD 4-digit data to BIN data)

5.6.4 32-bit BCD→BIN conversion DBIN_M

The specified BCD 8-digit data (0 to 99999999) is converted into BIN 32-bit data.

■ Function definition DBIN M (BOOL EN, ANY32 S1, ANY32 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be converted (BCD 8-digit data) |
| D | OUT | Conversion result (BIN 32-bit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the BCD data stored in dwData1 is
- (* converted into BIN, and the result is stored into Result. *)
 DBIN_M (X0, dwData1, Result);



Corresponding MELSEC command

- DBIN (Conversion from BCD 8-digit data to BIN data)

For the usable data type, refer to "3.2.2 About ANY type".

*)

5 - 24 5 - 24

5.6.5 Floating-point → BIN conversion INT_E_MD

The specified real number data is converted into BIN 16-bit data.

■ Function definition BOOL INT_E_MD (BOOL EN, REAL S1, ANY16 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | I INI | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be converted (real number data) |
| D | OUT | Conversion result (BIN 16-bit data) |

Remarks: The real number data specified in argument "S1" can be specified within the range -32768 to 32767.

The data after conversion is the value obtained by rounding off the real number in the first decimal place.

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the real number data in RealData1 is *)
- (* converted into BIN 16-bit data, and the result is stored into D0. *)
 INT E MD (X0, RealData1, D0);



Corresponding MELSEC command

• INT (Conversion from floating decimal point data to BIN16-bit data (Single precision))

5.6.6 32-bit floating-point → BIN conversion DINT E MD

The specified real number data is converted into BIN 32-bit data.

■ Function definition BOOL DINT E MD (BOOL EN, REAL S1, ANY32 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | INI | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be converted (real number data) |
| D | OUT | Conversion result (BIN 32-bit data) |

Remarks: The real number data specified in argument "S1" can be specified within the range -2147483648 to 2147483647.

The data after conversion is the value obtained by rounding off the real number in the first decimal place.

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, real number data E2.6 is converted
- (* into BIN 32-bit data, and the result is stored into Result. *)
 DINT_E_MD (X0, E2.6, Result);



Corresponding MELSEC command

DINT (Conversion from floating decimal point data to BIN32-bit data (Single precision))

For the usable data type, refer to "3.2.2 About ANY type".

5 - 25

5 - 25

5.6.7 BIN→floating-point conversion FLT_M

The specified BIN 16-bit data is converted into real number data.

■ Function definition BOOL FLT_M (BOOL EN, ANY16 S1, REAL D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be converted (BIN 16-bit data) |
| D | OUT | Conversion result (real number data) |

| Return | Value | Description |
|--------|-------|---------------------|
| ВО | OL | Execution condition |

Example of use

(*When execution condition X0 turns ON, the BIN 16-bit data in D100 is

(* converted into real number data, and the result is stored into Result. FLT M (X0, D100, Result);



Corresponding MELSEC command

- FLT (Conversion from BIN 16-bit data to floating decimal point (Single precision))

5.6.8 32-bit BIN→floating-point conversion DFLT_M

The specified BIN 32-bit data is converted into real number data.

■ Function definition BOOL DFLT M (BOOL EN, ANY32 S1, REAL D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be converted (BIN 32-bit data) |
| D | OUT | Conversion result (real number data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the BIN 32-bit data in dwData1 is *)
- (* converted into real number data, and the result is stored into Result. *)

 DFLT_M (X0, dwData1, RealResult);



Corresponding MELSEC command

- DFLT (Conversion from BIN 32-bit data to floating decimal point (Single precision))

For the usable data type, refer to "3.2.2 About ANY type".

*)

5 - 26 5 - 26

5.6.9 16-bit BIN→32-bit BIN conversion DBL_M

The specified BIN 16-bit data is converted into signed BIN 32-bit data.

■ Function definition BOOL DBL_M (BOOL EN, ANY16 S1, ANY32 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be converted (BIN 16-bit data) |
| D | OUT | Conversion result (BIN 32-bit data) |

| Return | Value | Description |
|--------|-------|---------------------|
| ВО | OL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the BIN 16-bit data in D0 is
- (* converted into signed BIN 32-bit data, and the result is stored into Result. *)
 DBL M (X0, D0, Result);



- Corresponding MELSEC command
 - DBL (Conversion from BIN 16-bit to BIN 32-bit data)

5.6.10 32-bit BIN→16-bit BIN conversion WORD M

The specified BIN 32-bit data is converted into signed BIN 16-bit data.

■ Function definition BOOL WORD M (BOOL EN, ANY32 S1, ANY16 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be converted (BIN 32-bit data) |
| D | OUT | Conversion result (BIN 16-bit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

- Example of use
 - (* When execution condition X0 turns ON, the BIN 32-bit data stored in dwData1 *)
 - (* is converted into signed BIN 16-bit data, and the result is stored into D0. *)
 WORD_M (X0, dwData1, D0);



- Corresponding MELSEC command
 - WORD (Conversion from BIN 32-bit to BIN 16-bit data)

For the usable data type, refer to "3.2.2 About ANY type".

5 - 27 5 - 27

5.6.11 BIN→gray code conversion GRY_M

The specified BIN 16-bit data is converted into gray code 16-bit data.

■ Function definition BOOL GRY_M (BOOL EN, ANY16 S1, ANY16 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | INI | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be converted (BIN 16-bit data) |
| D | OUT | Conversion result (gray code 16-bit data) |

| Return | Value | Description |
|--------|-------|---------------------|
| ВО | OL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the BIN 16-bit data in D0 is
- (* converted into gray code 16-bit data, and the result is stored into D100. *) GRY_M (X0, D0, D100);



- Corresponding MELSEC command
 - GRY (Conversion from BIN 16-bit data to Gray code)

5.6.12 32-bit BIN→gray code conversion DGRY_M

The specified BIN 32-bit data is converted into gray code 32-bit data.

■ Function definition BOOL DGRY_M (BOOL EN, ANY32 S1, ANY32 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be converted (BIN 32-bit data) |
| D | OUT | Conversion result (gray code 32-bit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the BIN 32-bit data in dwData1 is
- (* converted into gray code 32-bit data, and the result is stored into Result. *)
 DGRY M (X0, dwData1 Result);



Corresponding MELSEC command

- DGRY (Conversion from BIN 32-bit data to Gray code)

For the usable data type, refer to "3.2.2 About ANY type".

*)

5 - 28 5 - 28

5.6.13 Gray code→BIN conversion GBIN M

The specified gray code 16-bit data is converted into BIN 16-bit data.

■ Function definition BOOL GBIN_M (BOOL EN, ANY16 S1, ANY16 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be converted (gray code 16-bit data) |
| D | OUT | Conversion result (BIN 16-bit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the gray code 16-bit data in D100 is
- (* converted into BIN 16-bit data, and the result is stored into D200. *)

 GBIN_M (X0, D100, D200);



- Corresponding MELSEC command
 - GBIN (Conversion of Gray code to BIN 16-bit data)

5.6.14 32-bit gray code→BIN conversion DGBIN_M

The specified gray code 32-bit data is converted into BIN 32-bit data.

■ Function definition BOOL DGBIN_M (BOOL EN, ANY32 S1, ANY32 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | INI | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be converted (gray code 32-bit data) |
| D | OUT | Conversion result (BIN 32-bit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the gray code 32-bit data in dwData1 *
- (* is converted into BIN 32-bit data, and the result is stored into Result. *)
 DGBIN M (X0, dwData1, Result);



- Corresponding MELSEC command
 - DGBIN (Conversion of Gray code to BIN 32-bit data)

For the usable data type, refer to "3.2.2 About ANY type".

*)

5 - 29 5 - 29

5.6.15 2' complement of 16-bit BIN NEG_M

The sign of the specified BIN 16-bit data is inverted. (2's complement)

■ Function definition BOOL NEG_M (BOOL EN, ANY16 D);

| Argument Name | IN/OUT | Description |
|---------------|---------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| D | IN/OUT | Data whose sign will be inverted, sign inversion result |
| D | IIV/OUT | (BIN 16-bit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the sign of the BIN 16-bit data in D0



- Corresponding MELSEC command
 - NEG (Complement of 2 of BIN 16-bit data (sign reversal))

5.6.16 2' complement of 32-bit BIN DNEG_M

The sign of the specified BIN 32-bit data is inverted. (2's complement)

■ Function definition BOOL DNEG M (BOOL EN, ANY32 D);

| Argument Name | IN/OUT | Description |
|---------------|----------|---|
| EN | I INI | Execution condition (Function is executed only when the result is TRUE) |
| D | INI/OLIT | Data whose sign will be inverted, sign inversion result (BIN 32-bit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the sign of the BIN 32-bit data in
- (* Result is inverted, and the result is stored into Result. *)
 DNEG_M (X0, Result);



- Corresponding MELSEC command
 - DNEG (Complement of 2 of BIN 32-bit data (sign reversal))

For the usable data type, refer to "3.2.2 About ANY type".

5 - 30 5 - 30

5.6.17 2' complement of floating-point ENEG_M

The sign of the specified real number data is inverted. (2's complement)

■ Function definition BOOL ENEG_M (BOOL EN, REAL D);

| Argument Name | IN/OUT | Description |
|---------------|--------|--|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| D | IN/OUT | Data whose sign will be inverted, sign inversion result (real number data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the sign of the real number data in
- (* Result is inverted, and the result is stored into Result. *)
 ENEG_M (X0, Result);

*)



- Corresponding MELSEC command
 - ENEG (Floating-point sign inversion (Single precision))

5.6.18 Block BIN→BCD conversion BKBCD M

n points of BIN 16-bit data (0 to 9999), starting at the specified device, is converted into BCD 4-digit data.

■ Function definition BOOL BKBCD_M (BOOL EN, ANY16 S1, ANY16 n, ANY16 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be converted (BIN 16-bit data) |
| n | IN | Number of converted data |
| D | OUT | Conversion result (BCD 4-digit data) |

| Return Value | Description | |
|--------------|---------------------|--|
| BOOL | Execution condition | |

Example of use

- (* When execution condition X0 turns ON, the BIN 16-bit data of the number
- (* of points stored in W0, starting at D0, is converted into BCD, and the result is *)
- (* stored into D100 and later. *)
 BKBCD_M (X0, D0, W0, D100);



Corresponding MELSEC command

- BKBCD (Conversion from block BIN 16-bit data to BCD 4-digit data)

For the usable data type, refer to "3.2.2 About ANY type".

5 - 31 5 - 31

5.6.19 Block BCD→BIN conversion BKBIN M

n points of BCD 4-digit data (0 to 9999), starting at the specified device, is converted into BIN 16-bit data.

■ Function definition BOOL BKBIN_M (BOOL EN, ANY16 S1, ANY16 n, ANY16 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | INI | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be converted (BCD 4-digit data) |
| n | IN | Number of converted data |
| D | OUT | Conversion result (BIN 16-bit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the BCD data of the number of points *)
- (* stored in W0, starting at D0, is converted into BIN, and the result is stored into *)
- (* D100 and later. *)

BKBIN M (X0, D0, W0, D100);



Corresponding MELSEC command

- BKBIN (Conversion from block BCD 4-digit data to block BIN 16-bit data)

For the usable data type, refer to "3.2.2 About ANY type".

5 - 32 5 - 32

5.7 Data Transfer

5.7.1 16-bit data NOT transfer CML M

The specified BIN 16-bit data are inverted bit by bit.

■ Function definition BOOL CML_M (BOOL EN, ANY16 S1, ANY16 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| FN | INI | Execution condition (Function is executed only when the |
| EIN | IN | result is TRUE) |
| S1 | IN | Data whose bits will be inverted (BIN 16-bit data) |
| D | OUT | Inversion result transfer destination (BIN 16-bit data) |

| Return Value | Description | |
|--------------|---------------------|--|
| BOOL | Execution condition | |

- Example of use
 - (* When execution condition X0 turns ON, the data of M0 to M7 are inverted,
 - (* and the result is transferred to D0. *)

 CML_M (X0, K2M0, D0);



- Corresponding MELSEC command
 - CML (16-bit NOT transfer)

5.7.2 32-bit data NOT transfer DCML M

The specified BIN 32-bit data are inverted bit by bit.

■ Function definition BOOL DCML_M (BOOL EN, ANY32 S1, ANY32 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | l IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data whose bits will be inverted (BIN 32-bit data) |
| D | OUT | Inversion result transfer destination (BIN 32-bit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

- Example of use
 - (* When execution condition X0 turns ON, the data in dwData1 are inverted *)
 - (* bit by bit, and the result is transferred to Result. *)
 DCML_M (X0, dwData1, Result);



- Corresponding MELSEC command
 - DCML (32-bit NOT transfer)

For the usable data type, refer to "3.2.2 About ANY type".

5 - 33 5 - 33

5.7.3 Block transfer BMOV M

n points of BIN 16-bit data, starting at the specified device, are batch-transferred.

■ Function definition BOOL BMOV M (BOOL EN, ANY16 S1, ANY16 n, ANY16 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when |
| EIN | IIN | the result is TRUE) |
| S1 | IN | Data to be transferred (BIN 16-bit data) |
| n | IN | Number of data to be transferred (BIN 16-bit data) |
| D | OUT | Transfer destination (BIN 16-bit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the 16-bit data of the number of
- (* points stored in W0, starting at the device specified in D0, are transferred to *)
- (* the number of points stored in W0, starting at D100. *)
 BMOV_M (X0, D0, W0, D100);



- Corresponding MELSEC command
 - BMOV (Block 16-bit transfer)

5.7.4 Same data block transfer FMOV M

The 16-bit data of the specified device are transferred to the number of points, starting at the specified device.

■ Function definition

BOOL FMOV_M (BOOL EN, ANY16 S1, ANY16 n, ANY16 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | l IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be transferred (BIN 16-bit data) |
| n | IN | Number of data to be transferred (BIN 16-bit data) |
| D | OUT | Transfer destination (BIN 16-bit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the 16-bit data of D0 are transferred *)
- (* to the number of points stored in W0, starting at D100. *) FMOV_M (X0, D0, W0, D100);



Corresponding MELSEC command

- FMOV (Block 16-bit data transfer)

For the usable data type, refer to "3.2.2 About ANY type".

5 - 34 5 - 34

5.7.5 16-bit data exchange XCH_M

The specified two BIN 16-bit data are exchanged.


■ Function definition BOOL XCH M (BOOL EN, ANY16 D1, ANY16 D2);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the |
| LIN | IIN | result is TRUE) |
| S1 | IN/OUT | Data to be exchanged, exchange result (BIN 16-bit data) |
| D2 | IN/OUT | Data to be exchanged, exchange result (BIN 16-bit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the 16-bit data in D100 and D200
- (* are exchanged. *)





- Corresponding MELSEC command
 - XCH (16-bit data exchange)

5.7.6 32-bit data exchange DXCH_M

The specified two BIN 32-bit data are exchanged.

■ Function definition

BOOL DXCH_M (BOOL EN, ANY32 D1, ANY32 D2);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| D1 | IN/OUT | Data to be exchanged, exchange result (BIN 32-bit data) |
| D2 | IN/OUT | Data to be exchanged, exchange result (BIN 32-bit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the 32-bit data in dwData1 and
- (* dwData2 are exchanged. *)

DXCH_M (X0, dwData1, dwData2);



- Corresponding MELSEC command
 - DXCH (32-bit data exchange)

For the usable data type, refer to "3.2.2 About ANY type".

*)

5 - 35

5.7.7 Block data exchange BXCH_M

n points of BIN 16-bit data, starting at the specified devices, are exchanged.

■ Function definition BOOL BXCH_M (BOOL EN, ANY16 n, ANY16 D1, ANY16 D2);

| Argument Name | IN/OUT | Description |
|---------------|---------|---|
| EN | l IN | Execution condition (Function is executed only when the result is TRUE) |
| n | IN | Number of data to be exchanged (BIN 16-bit data) |
| D1 | IN/ OUT | Data to be exchanged, exchange result (BIN 16-bit data) |
| D2 | IN/ OUT | Data to be exchanged, exchange result (BIN 16-bit data) |

| I | Return Value | Description |
|---|--------------|---------------------|
| | BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, 3 points of 16-bit data, starting at *)
- (* D100, and 3 points of 16-bit data, starting at D200, are exchanged. *) BXCH_M (X0, K3, D100, D200);



- Corresponding MELSEC command
 - BXCH (Block 16-bit data exchange)

5.7.8 First/last byte exchange SWAP MD

The first 8 bits and last 8 bits of the specified device are exchanged.

■ Function definition BOOL SWAP_MD (BOOL EN, ANY16 D);

| Argument Name | IN/OUT | Description |
|---------------|---------|---|
| ГМ | INI | Execution condition (Function is executed only when |
| EN | IN | the result is TRUE) |
| D | IN/OUT | Data to be exchanged, exchange result (BIN 16-bit |
| Ь | 119/001 | data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the first 8 bits and last 8 bits of D0 *)
- (* are exchanged. *)
 SWAP_MD (X0, D0);



- Corresponding MELSEC command
 - SWAP (First/last byte exchange)

For the usable data type, refer to "3.2.2 About ANY type".

5 - 36 5 - 36

5.8 Program Execution Control

5.8.1 Interrupt disable DI_M

If the interrupt factor of an interrupt program occurs, the execution of the interrupt program is disabled until EI_M is executed.

■ Function definition BOOL DI_M (BOOL EN);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| | | Execution condition |
| EN | IN | (Only value TRUE indicating that the result is always |
| | | valid or normally ON device SM400 can be specified.) |

| Return Value | Description | |
|--------------|-----------------------------------|--|
| BOOL | Execution condition (always TRUE) | |

- Example of use
 - (* The execution of the interrupt program is disabled until until EI_M is executed. *) DI_M (TRUE);



- Corresponding MELSEC command
 - DI (Interrupt disable)

5.8.2 Interrupt enable EI M

The interrupt disable status during DI_M execution is reset, and the execution of the interrupt program of the interrupt pointer number enabled by IMASK is enabled.

■ Function definition BOOL EI_M (BOOL EN);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| | | Execution condition |
| EN | IN | (Only value TRUE indicating that the result is always |
| | | valid or normally ON device SM400 can be specified.) |

| Return Value | Description | | |
|--------------|-----------------------------------|--|--|
| BOOL | Execution condition (always TRUE) | | |

- Example of use
 - (* The interrupt disable status during DI_M execution is reset. EI_M (TRUE);

Corresponding



- Corresponding MELSEC command
 - EI (Interrupt enable)

5 - 37 5 - 37

5.9 I/O Refresh

5.9.1 I/O refresh RFS_M

n points of I/O devices, starting at the specified device, are refreshed.

■ Function definition BOOL RFS_M (BOOL EN, BOOL S1, ANY16 n);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| r.N. | IN | Execution condition (Function is executed only when |
| EN | IIN | the result is TRUE) |
| S1 | IN | Devices to be refreshed (bit data) |
| n | IN | Number of data to be refreshed (BIN 16-bit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

(* When execution condition X0 turns ON, 32 points of devices, starting at

*) *)

(* X100, are refreshed. RFS_M (M0, X100, H20);

*)



Corresponding MELSEC command

- RFS (I/O refresh)

For the usable data type, refer to "3.2.2 About ANY type".

5 - 38

5.10 Logical Operation Commands

5.10.1 Logical product (2 devices) WAND M

The specified two BIN 16-bit data are ANDed bit by bit.

■ Function definition BOOL WAND M (BOOL EN, ANY16 S1, ANY16 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the |
| | | result is TRUE) |
| S1 | IN | Data to AND (BIN 16-bit data) |
| D | IN/OUT | Data to be ANDed, operation result (BIN 16-bit data) |

Remarks: For bit devices, the bits greater than in the digit specification are processed as "0 (zero)".

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

- Example of use
 - (* When execution condition X0 turns ON, the 16-bit data in D0 and D10 are
 - (* ANDed bit by bit, and the result is stored into D10.

 WAND_M (X0, D0, D10);



- Corresponding MELSEC command
 - WAND (16-bit data logical product)

5.10.2 Logical product (3 devices) WAND 3 M

The specified two BIN 16-bit data are ANDed bit by bit.

■ Function definition BOOL WAND 3 M (BOOL E

BOOL WAND_3_M (BOOL EN, ANY16 S1, ANY16 S2, ANY16 D1);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | l IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be ANDed (BIN 16-bit data) |
| S2 | IN | Data to AND (BIN 16-bit data) |
| D1 | OUT | Operation result (BIN 16-bit data) |

Remarks: For bit devices, the bits greater than in the digit specification are processed as "0 (zero)".

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

- Example of use
 - (* When execution condition X0 turns ON, the 16-bit data in D0 and D10 are
 - (* ANDed bit by bit, and the result is stored into D100.

 WAND_3_M (X0, D0, D10, D100);



Corresponding MELSEC command

- WAND (16-bit data logical product)

For the usable data type, refer to "3.2.2 About ANY type".

5 - 39 5 - 39

5.10.3 32-bit data logical product (2 devices) DAND M

The specified two BIN 32-bit data are ANDed bit by bit.

■ Function definition BOOL DAND_M (BOOL EN, ANY32 S1, ANY32 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|--|
| EN | INI | Execution condition (Function is executed only when |
| EN | IN | the result is TRUE) |
| S1 | IN | Data to AND (BIN 32-bit data) |
| D | IN/OUT | Data to be ANDed, operation result (BIN 32-bit data) |

Remarks: For bit devices, the bits greater than in the digit specification are processed as "0 (zero)".

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the 24-bit data in dwData1 and
- (* X30 to X47 are ANDed, and the result is stored into dwData1. *)
 DAND_M (X0, K6X30, dwData1);



- Corresponding MELSEC command
 - DAND (32-bit data logical product)

5.10.4 32-bit data logical product (3 devices) DAND_3_M

The specified two BIN 32-bit data are ANDed bit by bit.

■ Function definition BOOL DAND_3_M (BOOL EN, ANY32 S1, ANY32 S2, ANY32 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | l IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | | Data to be ANDed (BIN 32-bit data) |
| S2 | IN | Data to AND (BIN 32-bit data) |
| D | OUT | Operation result (BIN 32-bit data) |

Remarks: For bit devices, the bits greater than in the digit specification are processed as "0 (zero)".

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the 32-bit data in dwData1 and
- (* dwData2 are ANDed, and the result is stored into Result. *)

 DAND 3 M (X0, dwData1, dwData2, Result);



Corresponding MELSEC command

DAND (32-bit data logical product)

For the usable data type, refer to "3.2.2 About ANY type".

5 - 40 5 - 40

5.10.5 Block data logical product BKAND_M

n points of 16-bit data, starting at the specified two devices, are ANDed bit by bit.


■ Function definition BOOL BKAND M (BOOL EN, ANY16 S1, ANY16 S2, ANY16 n, ANY16 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be ANDed, operation result (BIN 16-bit data) |
| S2 | IN | Data to AND (BIN 16-bit data) |
| n | IN | Number of data to be processed (BIN 16-bit data) |
| D | OUT | Operation result (BIN 16-bit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the data of the number of points
- (* stored in D0, starting at D100, and the data of the number of points stored
- (* in D0, starting at D200, are ANDed, and the result is stored into D1000
- (* and later.





- Corresponding MELSEC command
 - BKAND (Block logical product)

5.10.6 Logical sum (2 devices) WOR M

The specified two BIN 16-bit data are ORed bit by bit.

■ Function definition BOOL WOR_M (BOOL EN, ANY16 S1, ANY16 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN. | INI | Execution condition (Function is executed only when |
| EN | IN | the result is TRUE)) |
| S1 | IN | Data to OR (BIN 16-bit data) |
| D | IN/OUT | Data to be ORed, operation result (BIN 16-bit data) |

Remarks: For bit devices, the bits greater than in the digit specification are processed as "0 (zero)".

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the data in D10 and D20 are ORed, *)
- (* and the result is stored into D20.

 WOR_M (X0, D10, D20);



Corresponding MELSEC command

WOR (16-bit data logical sum)

For the usable data type, refer to "3.2.2 About ANY type".

*) *)

*)

5 - 41 5 - 41

5.10.7 Logical sum (3 devices) WOR_3_M

The specified two BIN 16-bit data are ORed bit by bit.

■ Function definition BOOL WOR 3 M (BOOL EN, ANY16 S1, ANY16 S2, ANY16 D1);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | l IN | Execution condition (Function is executed only when |
| | | the result is TRUE) |
| S1 | IN | Data to be ORed (BIN 16-bit data) |
| S2 | IN | Data to OR (BIN 16-bit data) |
| D1 | OUT | Operation result (BIN 16-bit data) |

Remarks: For bit devices, the bits greater than in the digit specification are processed as "0 (zero)".

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the data in X10 to X1B and the data *)
- (* in D0 are ORed, and the result is output to Y10 Y1B. *)
 WOR_3_M (M0, K3X10, D0, K3Y10);



Corresponding MELSEC command

- WOR (16-bit data logical sum)

5.10.8 32-bit data logical sum (2 devices) DOR_M

The specified two BIN 32-bit data are ORed bit by bit.

■ Function definition BOOL DOR_M (BOOL EN, ANY32 S1, ANY32 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | INI | Execution condition (Function is executed only when |
| EN | IN | the result is TRUE) |
| S1 | IN | Data to OR (BIN 32-bit data) |
| D | IN/OUT | Data to be ORed, operation result (BIN 32-bit data) |

Remarks: For bit devices, the bits greater than in the digit specification are processed as "0 (zero)".

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the data in dwData1 and Result are *)
- (* ORed, and the result is output to Result. *)
 DOR _M (X0, dwData1, Result);



Corresponding MELSEC command

- DOR (32-bit data logical sum)

For the usable data type, refer to "3.2.2 About ANY type".

5 - 42 5 - 42

5.10.9 32-bit data logical sum (3 devices) DOR_3_M

The specified two BIN 32-bit data are ORed bit by bit.

■ Function definition BOOL DOR 3 M (BOOL EN, ANY32 S1, ANY32 S2, ANY32 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be ORed (BIN 32-bit data) |
| S2 | IN | Data to OR (BIN 32-bit data) |
| D | OUT | Operation result (BIN 32-bit data) |

Remarks: For bit devices, the bits greater than in the digit specification are processed as "0 (zero)".

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the 32-bit data in dwData1 and the
- (* 32-bit data in X20 to X3F are ORed, and the result is output to Result. *) DOR_3_M (X0, dwData1, K8X20, Result);



Corresponding MELSEC command

- DOR (32-bit data logical sum)

5.10.10 Block data logical sum BKOR M

n points of 16-bit data, starting at the specified two devices, are ORed bit by bit.

■ Function definition

BOOL BKOR M (BOOL EN, ANY16 S1, ANY16 S2, ANY16 n, ANY16 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | INI | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be ORed (BIN 16-bit data) |
| S2 | IN | Data to OR (BIN 16-bit data) |
| n | IN | Number of data to be processed (BIN 16-bit data) |
| D | OUT | Operation result (BIN 16-bit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the data of the number of points
- (* stored in D0, starting at D10, and the data of the number of points stored in *)
- (* D0, starting at D20, are ORed, and the result is stored into D100 and later. *) BKOR_M (X0, D10, D20, D0, D100);



Corresponding MELSEC command

- BKOR (Block logical sum)

For the usable data type, refer to "3.2.2 About ANY type".

5 - 43 5 - 43

5.10.11 Exclusive OR (2 devices) WXOR_M

The specified two BIN 16-bit data are EXCLUSIVE ORed bit by bit.

■ Function definition BOOL WXOR_M (BOOL EN, ANY16 S1, ANY16 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | I INI | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to EXCLUSIVE OR (BIN 16-bit data) |
| D | IN/OUT | Data to be EXCLUSIVE ORed, operation result (BIN 16-bit data) |

Remarks: For bit devices, the bits greater than in the digit specification are processed as "0 (zero)".

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the 16-bit data in D10 and D20 are *
- (* EXCLUSIVE ORed, and the result is stored into D20.
 WXOR_M (X0, D10, D20);



- Corresponding MELSEC command
 - WXOR (16-bit data exclusive OR)

5.10.12 Exclusive OR (3 devices) WXOR_3_M

The specified two BIN 16-bit data are EXCLUSIVE ORed bit by bit.

■ Function definition

BOOL WXOR_3_M (BOOL EN, ANY16 S1, ANY16 S2, ANY16 D1);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | I INI | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be EXCLUSIVE ORed (BIN 16-bit data) |
| S2 | IN | Data to EXCLUSIVE OR (BIN 16-bit data) |
| D | OUT | Operation result (BIN 16-bit data) |

Remarks: For bit devices, the bits greater than in the digit specification are processed as "0 (zero)".

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the 16-bit data in D10 and D20 are *
- (* EXCLUSIVE ORed, and the result is stored into D100.
 WXOR_3_M (X0, D10, D20, D100);



- Corresponding MELSEC command
 - WXOR (16-bit data exclusive OR)

For the usable data type, refer to "3.2.2 About ANY type".

5 - 44 5 - 44

5.10.13 32-bit data exclusive OR (2 devices) DXOR_M

The specified two BIN 32-bit data are EXCLUSIVE ORed bit by bit.

■ Function definition BOOL DXOR_M (BOOL EN, ANY32 S1, ANY32 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to EXCLUSIVE OR (BIN 32-bit data) |
| D | IN/OUT | Data to be EXCLUSIVE ORed, operation result (BIN 32-bit data) |

Remarks: For bit devices, the bits greater than in the digit specification are processed as "0 (zero)".

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the 32-bit data in dwData1 and
- (* Result are EXCLUSIVE ORed, and the result is stored into Result.

 DXOR M (X0, dwData1, Result);



- Corresponding MELSEC command
 - DXOR (32-bit data exclusive OR)

5.10.14 32-bit data exclusive OR (3 devices) DXOR_3_M

The specified two BIN 32-bit data are EXCLUSIVE ORed bit by bit.

■ Function definition BOOL DXC

BOOL DXOR_3_M (BOOL EN, ANY32 S1, ANY32 S2, ANY32 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | I INI | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be EXCLUSIVE ORed (BIN 32-bit data) |
| S2 | IN | Data to EXCLUSIVE OR (BIN 32-bit data) |
| D | OUT | Operation result (BIN 32-bit data) |

Remarks: For bit devices, the bits greater than in the digit specification are processed as "0 (zero)".

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the 32-bit data in dwData1 and
- (* dwData2 are EXCLUSIVE ORed, and the result is stored into Result.

 DXOR_3_M (X0, dwData1, dwData2, Result);



- Corresponding MELSEC command
 - DXOR (32-bit data exclusive OR)

For the usable data type, refer to "3.2.2 About ANY type".

*)

*)

5 - 45 5 - 45

5.10.15 Block data exclusive OR BKXOR M

n points of 16-bit data, starting at the specified two devices, are EXCLUSIVE ORed bit by bit.

BOOL BKXOR M (BOOL EN, ANY16 S1, ANY16 S2, ANY16 n, ANY16 D); ■ Function definition

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | INI | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be EXCLUSIVE ORed, operation result (BIN 16-bit data) |
| S2 | IN | Data to EXCLUSIVE OR (BIN 16-bit data) |
| n | IN | Number of data to be processed (BIN 16-bit data) |
| D | OUT | Operation result (BIN 16-bit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the data of the number of points
- (* stored in D0, starting at D10, and the data of the number of points stored *)
- (* in D0, starting at D20, are EXCLUSIVE ORed, and the result is stored into
- (* D100 and later.

BKXOR M (X0, D10, D20, D0, D100);



Corresponding MELSEC command

- BKXOR (Block exclusive OR)

5.10.16 NOT exclusive OR (2 devices) WXNR M

The specified two BIN 16-bit data are NOT EXCLUSIVE ORed bit by bit.

■ Function definition BOOL WXNR M (BOOL EN, ANY32 S1, ANY32 S2, ANY32 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | I INI | Execution condition (Function is executed only when the result is TRUE) |
| S1 | | Data to NOT EXCLUSIVE OR (BIN 16-bit data) |
| D | IN/OUT | Data to be NOT EXCLUSIVE ORed, operation result (BIN 16-bit data) |

Remarks: For bit devices, the bits greater than in the digit specification are processed as "0 (zero)".

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the 16-bit data in X20 to X2F and
- (* the 16-bit data in D10 are NOT EXCLUSIVE ORed, and the result is stored
- *) (* into D10.

WXNR M (X0, K4X20, D10);



Corresponding MELSEC command

WXNR (16-bit data NOT exclusive OR)

For the usable data type, refer to "3.2.2 About ANY type".

5 - 46 5 - 46

5.10.17 NOT exclusive OR (3 devices) WXNR_3_M

The specified two BIN 16-bit data are NOT EXCLUSIVE ORed bit by bit.

■ Function definition BOOL WXNR_3_M (BOOL EN, ANY16 S1, ANY16 S2, ANY16 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be NOT EXCLUSIVE ORed (BIN 16-bit data) |
| S2 | IN | Data to NOT EXCLUSIVE OR (BIN 16-bit data) |
| D | OUT | Operation result (BIN 16-bit data) |

Remarks: The same device can be specified in arguments "S1" and "D", and in "S2" and "D".

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

(* When execution condition X0 turns ON, the 16-bit data in X20 to X2F and

*)

*) *)

*)

- (* the 16-bit data in D0 are NOT EXCLUSIVE ORed, and the result is stored
- (* into D100.

WXNR_3_M (X0, K4X20, D0, D100);



Corresponding MELSEC command

WXNR (16-bit data NOT exclusive OR)

5.10.18 32-bit data NOT exclusive OR (2 devices) DXNR M

The specified two BIN 32-bit data are NOT EXCLUSIVE ORed bit by bit.

■ Function definition BOOL DXNR_M (BOOL EN, ANY32 S1, ANY32 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to NOT EXCLUSIVE OR (BIN 32-bit data) |
| D | IN/OUT | Data to be NOT EXCLUSIVE ORed, operation result (BIN 32-bit data) |

Remarks: For bit devices, the bits greater than in the digit specification are processed as "0 (zero)".

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the 32-bit data in dwData1 and the
- (* 32-bit data in Result are NOT EXCLUSIVE ORed, and the result is stored
- (* into Result. *)

DXNR M (X0, dwData1, Result);



Corresponding MELSEC command

DXNR (32-bit data NOT exclusive OR)

For the usable data type, refer to "3.2.2 About ANY type".

5 - 47 5 - 47

5.10.19 32-bit data NOT exclusive OR (3 devices) DXNR 3 M

The specified two BIN 32-bit data are NOT EXCLUSIVE ORed bit by bit.

■ Function definition BOOL DXNR_3_M (BOOL EN, ANY32 S1, ANY32 S2, ANY32 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | I INI | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be NOT EXCLUSIVE ORed (BIN 32-bit data) |
| S2 | IN | Data to NOT EXCLUSIVE OR (BIN 32-bit data) |
| D | OUT | Operation result (BIN 32-bit data) |

Remarks: For bit devices, the bits greater than in the digit specification are processed as "0 (zero)".

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the 32-bit data in dwData1 and the *)
- (* 32-bit data in dwData2 are NOT EXCLUSIVE ORed, and the result is stored *)
- (* into Result.

DXNR_3_M (X0, dwData1, dwData2, Result);



Corresponding MELSEC command

DXNR (32-bit data NOT exclusive OR)

5.10.20 Block data NOT exclusive OR BKXNR M

n points of 16-bit data, starting at the specified two devices, are NOT EXCLUSIVE ORed bit by bit.

■ Function definition BOOL BKXNR_M (BOOL EN, ANY16 S1, ANY16 S2, ANY16 n, ANY16 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | I INI | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be NOT EXCLUSIVE ORed (BIN 16-bit data) |
| S2 | IN | Data to NOT EXCLUSIVE OR (BIN 16-bit data) |
| n | IN | Number of data to be processed (BIN 16-bit data) |
| D | OUT | Operation result (BIN 16-bit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the data of the number of points
- (* stored in D0, starting at D100, and the data of the number of points stored
- (* in D0, starting at W100, are NOT EXCLUSIVE ORed, and the result is
- (* stored into D200 and later.

BKXNR M (X0, D100, W100, D0, D200);



Corresponding MELSEC command

- BKXNR (Block NOT exclusive OR)

For the usable data type, refer to "3.2.2 About ANY type".

*)

5 - 48 5 - 48

5.11 Rotation

5.11.1 Right rotation (carry flag not included) ROR M

The specified BIN 16-bit data are rotated n bits to the right, without the carry flag being included.

■ Function definition BOOL ROR_M (BOOL EN, ANY16 n, ANY16 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | I INI | Execution condition (Function is executed only when the result is TRUE) |
| n | IN | Number of rotations (0 to 15) (BIN 16-bit data) |
| D | IN/OUT | Data to be rotated, rotation result (BIN 16-bit data) |

Remarks: When a bit device is specified in "D", the data in the specified number of digits are rotated.

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

- Example of use
 - (* When execution condition X0 turns ON, the data in D0 are rotated 3 bits to
 - (* the right, without the carry flag being included. ROR M (X0, K3, D0);



- Corresponding MELSEC command
 - ROR (Right rotation of 16-bit data)

5.11.2 Right rotation (carry flag included) RCR_M

The specified BIN 16-bit data are rotated n bits to the right, with the carry flag being included.

■ Function definition BOOL RCR_M (BOOL EN, ANY16 n, ANY16 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | l INI | Execution condition (Function is executed only when the result is TRUE) |
| n | IN | Number of rotations (0 to 15) (BIN 16-bit data) |
| D | IN/OUT | Data to be rotated, rotation result (BIN 16-bit data) |

Remarks: When a bit device is specified in "D", the data in the specified number of digits are rotated.

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

- Example of use
 - (* When execution condition X0 turns ON, the data in D0 are rotated 3 bits to *
 - (* the right, with the carry flag being included. *)

 RCR_M (X0, K3, D0);



- Corresponding MELSEC command
 - RCR (Right rotation of 16-bit data)

For the usable data type, refer to "3.2.2 About ANY type".

5 - 49 5 - 49

5.11.3 Left rotation (carry flag not included) ROL_M

The specified BIN 16-bit data are rotated n bits to the left, without the carry flag being included.

■ Function definition BOOL ROL M (BOOL EN, ANY16 n, ANY16 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| n | IN | Number of rotations (0 to 15) (BIN 16-bit data) |
| D | IN/OUT | Data to be rotated, rotation result (BIN 16-bit data) |

Remarks: When a bit device is specified in "D", the data in the specified number of digits are rotated.

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the data in D0 are rotated 3 bits to
- (* the left, without the carry flag being included.

 **
 ROL_M (X0, K3, D0);



- Corresponding MELSEC command
 - ROL (Left rotation of 16-bit data)

5.11.4 Left rotation (carry flag included) RCL_M

The specified BIN 16-bit data are rotated n bits to the left, with the carry flag being included.

■ Function definition BOOL RCL M (BOOL EN, ANY16 n, ANY16 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | I INI | Execution condition (Function is executed only when the result is TRUE) |
| n | IN | Number of rotations (0 to 15) (BIN 16-bit data) |
| D | IN/OUT | Data to be rotated, rotation result (BIN 16-bit data) |

Remarks: When a bit device is specified in "D", the data in the specified number of digits are rotated.

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

- Example of use
 - (* When execution condition X0 turns ON, the data in D0 are rotated 3 bits to
 - (* the left, with the carry flag being included. *)
 RCL M (X0, K3, D0);



- Corresponding MELSEC command
 - RCL (Left rotation of 16-bit data)

For the usable data type, refer to "3.2.2 About ANY type".

5 - 50 5 - 50

5.11.5 32-bit data right rotation (carry flag not included) DROR M

The specified BIN 32-bit data are rotated n bits to the right, without the carry flag being included.

■ Function definition BOOL DROR_M (BOOL EN, ANY16 n, ANY32 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| n | IN | Number of rotations (0 to 31) (BIN 16-bit data) |
| D | IN/OUT | Data to be rotated, rotation result (BIN 32-bit data) |

Remarks: When a bit device is specified in "D", the data in the specified number of digits are rotated.

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the 32-bit data in dwData1 are
- (* rotated to the right by the number of bits stored in D0, without the carry flag
- (* being included. * DROR_M (X0, D0, dwData1);



Corresponding MELSEC command

- DROR (Right rotation of 32-bit data)

5.11.6 32-bit data right rotation (carry flag included) DRCR_M

The specified BIN 32-bit data are rotated n bits to the right, with the carry flag being included.

■ Function definition BOOL DRCR M (BOOL EN, ANY16 n, ANY32 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | I INI | Execution condition (Function is executed only when the result is TRUE) |
| n | IN | Number of rotations (0 to 31) (BIN 16-bit data) |
| D | IN/OUT | Data to be rotated, rotation result (BIN 32-bit data) |

Remarks: When a bit device is specified in "D", the data in the specified number of digits are rotated.

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the 32-bit data in dwData1 are
- (* rotated to the right by the number of bits stored in D0, with the carry flag
- (* being included. *)
 DRCR M (X0, D0, dwData1);



Corresponding MELSEC command

- DRCR (Right rotation of 32-bit data)

For the usable data type, refer to "3.2.2 About ANY type".

5 - 51 5 - 51

5.11.7 32-bit data left rotation (carry flag not included) DROL_M

The specified BIN 32-bit data are rotated n bits to the left, without the carry flag being included.

■ Function definition BOOL DROL M (BOOL EN, ANY16 n, ANY32 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| n | IN | Number of rotations (0 to 31) (BIN 16-bit data) |
| D | IN/OUT | Data to be rotated, rotation result (BIN 32-bit data) |

Remarks: When a bit device is specified in "D", the data in the specified number of digits are rotated.

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the 32-bit data in dwData1 are
- (* rotated 4 bits to the left, without the carry flag being included. DROL_M (X0, K4, dwData1);



- Corresponding MELSEC command
 - DROL (Left rotation of 32-bit data)

5.11.8 32-bit data left rotation (carry flag included) DRCL_M

The specified BIN 32-bit data are rotated n bits to the left, with the carry flag being included.

■ Function definition BOOL DRCL_M (BOOL EN, ANY16 n, ANY32 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| n | IN | Number of rotations (0 to 31) (BIN 16-bit data) |
| D | IN/OUT | Data to be rotated, rotation result (BIN 32-bit data) |

Remarks: When a bit device is specified in "D", the data in the specified number of digits are rotated.

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the 32-bit data in dwData1 are
- (* rotated 4 bits to the left, with the carry flag being included. *)
 DRCL M (X0, K4, dwData1);



- Corresponding MELSEC command
 - DRCL (Left rotation of 32-bit data)

For the usable data type, refer to "3.2.2 About ANY type".

5 - 52 5 - 52

5.12 Shift

5.12.1 n-bit right shift SFR_M

The specified BIN 16-bit data are shifted n bits to the right.

■ Function definition BOOL SFR_M (BOOL EN, ANY16 n, ANY16 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| n | IN | Number of shifts (0 to 15) (BIN 16-bit data) |
| D | IN/OUT | Data to be shifted, shift result (BIN 16-bit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

- Example of use
 - (* When execution condition X0 turns ON, the data in D100 are shifted 4 bits
 - (* to the right. SFR_M (X0, K4, D100);



- Corresponding MELSEC command
 - SFR (n-bit right shift of 16-bit data)

5.12.2 n-bit left shift SFL_M

The specified BIN 16-bit data are shifted n bits to the left.

■ Function definition BOOL SFL_M (BOOL EN, ANY16 n, ANY16 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | I INI | Execution condition (Function is executed only when the result is TRUE) |
| n | IN | Number of shifts (0 to 15) (BIN 16-bit data) |
| D | IN/OUT | Data to be shifted, shift result (BIN 16-bit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

- Example of use
 - (* When execution condition X0 turns ON, the data in D100 are shifted 4 bits *
 - (* to the left.

SFL_M (X0, K4, D100);



- Corresponding MELSEC command
 - SFL (n-bit left shift of 16-bit data)

For the usable data type, refer to "3.2.2 About ANY type".

*)

5 - 53 5 - 53

5.12.3 n-bit data 1-bit right shift BSFR M

n points of bit data, starting at the specified device, are shifted one bit to the right.

■ Function definition BOOL BSFR_M (BOOL EN, ANY16 n, ANY16 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| n | IN | Number of devices to be shifted (BIN 16-bit data) |
| D | IN/OUT | Data to be shifted, shift result (bit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the data in M100 to M104 are
- (* shifted 1 bit to the right.

 BSFR_M (X0, K5, M100);



- Corresponding MELSEC command
 - BSFR (1-bit right shift of n-bit data)

5.12.4 n-bit data 1-bit left shift BSFL_M

n points of bit data, starting at the specified device, are shifted one bit to the left.

■ Function definition BOOL BSFL_M (BOOL EN, ANY16 n, BOOL D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | I INI | Execution condition (Function is executed only when the result is TRUE) |
| n | IN | Number of devices to be shifted (BIN 16-bit data) |
| D | IN/OUT | Data to be shifted, shift result (bit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the data in M100 to M104 are
- (* shifted 1 bit to the left.

BSFL_M (X0, K5, M100);



- Corresponding MELSEC command
 - BSFL (1-bit left shift of n-bit data)

For the usable data type, refer to "3.2.2 About ANY type".

5 - 54 5 - 54

5.12.5 1-word right shift DSFR M

n points of 16-bit data, starting at the specified device, are shifted one word to the right.

■ Function definition BOOL DSFR_M (BOOL EN, ANY16 n, ANY16 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| n | IN | Number of devices to be shifted (BIN 16-bit data) |
| D | IN/OUT | Data to be shifted, shift result (BIN 16-bit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the data in D100 to D106 are
- (* shifted 1 word to the right.

 DSFR_M (X0, K7, D100);



Corresponding MELSEC command

DSFR (1-word right shift of n-word data)

5.12.6 1-word left shift DSFL M

n points of 16-bit data, starting at the specified device, are shifted one word to the left.

■ Function definition BOOL DSFL_M (BOOL EN, ANY16 n, ANY16 D);

| the result is TRUE) | Argument Name | gument Name IN/OUT | Description |
|--|---------------|--------------------|---|
| | EN | EN IN | Execution condition (Function is executed only when the result is TRUE) |
| n IN Number of devices to be shifted (BIN 16-bit data) | n | n IN | Number of devices to be shifted (BIN 16-bit data) |
| D OUT Data to be shifted, shift result (BIN 16-bit data) | D | D OUT | Data to be shifted, shift result (BIN 16-bit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the data in D100 to D106 are
- (* shifted 1 word to the left.

 DSFL_M (X0, K7, D100);



Corresponding MELSEC command

- DSFL (1-word left shift of n-word data)

For the usable data type, refer to "3.2.2 About ANY type".

5 - 55

5.13 Bit Processing

5.13.1 Bit set of word device BSET_M

Bit n of the specified word device is set.

■ Function definition BOOL_BSET_M (BOOL EN, ANY16 n, ANY16 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| n | IN | Bit number to be set (BIN 16-bit data) |
| D | IN/OUT | Data to be set, bit set result (BIN 16-bit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

(* When execution condition X0 turns ON, bit 8 of D100 is set. BSET_M (X0, K8, D100);



- Corresponding MELSEC command
 - BSET (Bit set of word device)

5.13.2 Bit reset of word device BRST_M

Bit n of the specified word device is reset.

■ Function definition BOOL_BRST_M (BOOL EN, ANY16 n, ANY16 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | l IN | Execution condition (Function is executed only when the result is TRUE) |
| n | IN | Bit number to be reset (BIN 16-bit data) |
| D | IN/OUT | Data to be reset, bit reset result (BIN 16-bit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

(* When execution condition X0 turns ON, bit 8 of D100 is reset. BRST_M (X0, K8, D100);



- Corresponding MELSEC command
 - BRST (Bit reset of word device)

For the usable data type, refer to "3.2.2 About ANY type".

5 - 56 5 - 56

5.13.3 Bit test of word device TEST MD

The bit status in the specified position of the specified word device is written to the specified bit device.

■ Function definition

BOOL TEST_MD (BOOL EN, ANY16 S1, ANY 16 S2, BOOL D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be extracted (BIN 16-bit data) |
| S2 | IN | Position of bit to be extracted (BIN 16-bit data) |
| D | OUT | Extracted data (bit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

(* When execution condition X0 turns ON, M0 is turned ON/OFF

*) *)

(* according to the status of bit 10 of D100.





- Corresponding MELSEC command
 - TEST (Bit set)

5.13.4 Bit test of 32-bit data DTEST MD

The bit in the specified position of the specified BIN 32-bit data is written to the specified bit device.

■ Function definition

BOOL DTEST_MD (BOOL EN, ANY32 S1, ANY16 S2, BOOL D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | l IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be extracted (BIN 32-bit data) |
| S2 | IN | Position of bit to be extracted (BIN 16-bit data) |
| D | OUT | Extracted data (bit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

(* When execution condition X0 turns ON, bit 10 in dData is fetched and

*)

(* written to M0.

*)

DTEST_MD (X0, dData, K10, M0);



Corresponding MELSEC command

- DTEST (Bit set)

For the usable data type, refer to "3.2.2 About ANY type".

5 - 57 5 - 57

5.13.5 Bit device batch reset BKRST M

n points, starting at the specified bit device, are reset.

■ Function definition BOOL BKRST_M (BOOL EN, BOOL S1, ANY16 n);

| _ | • | · · · · · · · · · · · · · · · · · · · |
|---------------|--------|---|
| Argument Name | IN/OUT | Description |
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Head of data to be reset (bit data) |
| n | IN | Number of bits to be reset (BIN 16-bit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

(* When execution condition X0 turns ON, the number of points stored in D100, *)

(* starting at M10, are reset. *)
BKRST_M (X0, M10, D100);



- Corresponding MELSEC command
 - BKRST (Batch reset of bit devices)

For the usable data type, refer to "3.2.2 About ANY type".

5 - 58 5 - 58

5.14 Data Processing

5.14.1 Data search SER M

n points of data, starting at the specified BIN 16-bit data, are searched for the specified BIN 16-bit data.

■ Function definition BOOL SER_M (BOOL EN, ANY16 S1, ANY16 S2, ANY16 n, ANY16(2) D);

| Argument Name | IN/OUT | Descr | iption |
|---------------|--------|---|--|
| EN | IN | Execution condition (Function result is TRUE) | n is executed only when the |
| S1 | IN | Data to be searched for (BIN | 16-bit data) |
| S2 | IN | Data to be searched (BIN 16 | -bit data) |
| n | IN | Number of data to be search | ed (BIN 16-bit data) |
| D | OUT | Search result (ARRAY [01] OF ANY16) | D[0] Match position D[1] Number of matches |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, D300 points of data, starting at D200, *
- (* are searched for D100.
- (* The number of data that matched the search target is stored into D[1], and the
- (* relative value indicating the number of points from D200 is stored into D[0]. * SER M (X0, D100, D200, D300, D);



Corresponding MELSEC command

- SER (16-bit data search)

5.14.2 32-bit data search DSER M

2n points of data, starting at the specified BIN 32-bit data, are searched for the specified BIN 32-bit data.

■ Function definition BOOL SER M (BOOL EN, ANY16 S1, ANY16 S2, ANY16 n, ANY16(2) D);

| Argument Name | IN/OUT | Desci | ription |
|---------------|--------|--|--|
| EN | IN | Execution condition (Functio result is TRUE) | n is executed only when the |
| S1 | IN | Data to be searched for (BIN | l 32-bit data) |
| S2 | IN | Data to be searched (BIN 32 | ?-bit data) |
| n | IN | Number of data to be search | ned (BIN 16-bit data) |
| D | OUT | Search result (ARRAY [01] OF ANY16) | D[0] Match position D[1] Number of matches |

| I | Return Value | Description |
|---|--------------|---------------------|
| | BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the number of points stored in D100,
- (* starting at dData2, are searched on a 32-bit basis for dData1 and dData1+1.
- (* The number of data that matched the search target is stored into
- (* ArrayResult[1], and the relative value indicating the number of points from
- (* dData2 is stored into ArrayResult[0].

DSER_M (X0, dData1, dData2, D100, ArrayResult);



Corresponding MELSEC command

- DSER (32-bit data search)

For the usable data type, refer to "3.2.2 About ANY type".

5 - 59 5 - 59

5.14.3 Bit check SUM M

The number of bits having 1 in the specified BIN 16-bit data is counted.

■ Function definition

BOOL SUM_M (BOOL EN, ANY16 S1, ANY16 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | l IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be counted (BIN 16-bit data) |
| D | OUT | Count result (BIN 16-bit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the number of bits having 1 in dData
- (* is stored into Result. *)

SUM_M (X0, iData, Result);



- Corresponding MELSEC command
 - SUM (16-bit data bit check)

5.14.4 32-bit data bit check DSUM_M

The number of bits having 1 in the specified BIN 32-bit data is counted.

■ Function definition BOOL

BOOL DSUM_M (BOOL EN);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be counted (BIN 32-bit data) |
| D | OUT | Count result (BIN 16-bit data) |

| ı | Return Value | Description |
|---|--------------|---------------------|
| ı | BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the number of bits having 1
- (* in iData is stored into Result. *)
 DSUM_M (X0, dData, Result);



Corresponding MELSEC command

- DSUM (32-bit data bit check)

For the usable data type, refer to "3.2.2 About ANY type".

5 - 60 5 - 60

5.14.5 Decode DECO M

The lower n bits of the specified data are decoded.

■ Function definition BOOL DECO_M (BOOL EN, ANY_SIMPLE S1, ANY16 n, ANY_SIMPLE D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be decoded |
| n | IN | Valid bit length (1 to 8) *0: No processing (BIN 16-bit data) |
| D | OUT | Decode result |

Remarks: The DINT, REAL and STRING types cannot be used in arguments S1" and "D".

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the lower Bit Size bits of D100 are
- (* decoded, and the decode result is stored into 2^{BitSize} bits, starting at Result. *)
 DECO M (X0, D100, BitSize, Result)



Corresponding MELSEC command

- DECO (8 → 256 bits decode)

For the usable data type, refer to "3.2.2 About ANY type".

5.14.6 Encode ENCO M

2ⁿ bits of data, starting at the specified data, are encoded.

■ Function definition BOOL ENCO M (BOOL EN, ANY SIMPLE S1, ANY16 n, ANY16 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be encoded |
| n | IN | Valid bit length (1 to 8) *0: No processing (BIN 16-bit data) |
| D | OUT | Encode result |

Remarks: The DINT, REAL and STRING types cannot be used in argument S1".

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, 2^{BitSize} bits, starting at D100, are
- (* encoded, and the result is stored into Result.

 ENCO (X0, D100, BitSize, Result);



Corresponding MELSEC command

- ENCO (256 → 8 bits decode)

For the usable data type, refer to "3.2.2 About ANY type".

5 - 61 5 - 61

5.14.7 7-segment decode SEG_M

The lower 4 bits (0 to F) of the specified data are decoded into 7-segment display data.

■ Function definition

BOOL SEG M (BOOL EN, ANY16 S1, ANY16 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be decoded |
| D | OUT | Decode result (BIN 16-bit data) |

| I | Return Value | Description |
|---|--------------|---------------------|
| | BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the lower 4 bits of D100 are decoded '
- (* into 7-segment display data, and the result is stored into Result. *)
 SEG M (X0, D100, Result);



Corresponding MELSEC command

- SEG (7-segment decode)

5.14.8 4-bit disconnection of 16-bit data DIS_M

The data in the lower n digits of the specified BIN 16-bit data are disconnected and stored into the lower 4 bits of n points, starting at the specified device.

■ Function definition

BOOL DIS_M (BOOL EN, ANY16 S1, ANY16 n, ANY16 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|--|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be disconnected (BIN 16-bit data) |
| n | IN | Number of disconnected data (1 to 4) *0: No processing (BIN 16-bit data) |
| D | OUT | Disconnection result (BIN 16-bit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the data in the lower D200 digits
- (* (1 digit = 4 bits) of D100 are stored into the lower 4 bits of D200 points,
- (* starting at Result. *)

DIS_M (X0, D100, D200, Result);



Corresponding MELSEC command

DIS (4-bit disconnection of 16-bit data)

For the usable data type, refer to "3.2.2 About ANY type".

5 - 62 5 - 62

5.14.9 4-bit connection of 16-bit data UNI M

The lower 4 bits of n points of BIN 16-bit data, starting at the specified device, are connected to the specified device.

■ Function definition

BOOL UNI_M (BOOL EN, ANY16 S1, ANY16 n, ANY16 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be connected (BIN 16-bit data) |
| n | IN | Number of connected data (1 to 4) *0: No processing (BIN 16-bit data) |
| D | OUT | Connection result (BIN 16-bit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the lower 4 bits of 3 points of 16-bit
- (* data, starting at D100 are connected to Result. *)
 UNI_M (X0, D100, K3, Result);



Corresponding MELSEC command

- UNI (4-bit connection of 16-bit data)

5.14.10 Bit disconnection of any data NDIS_M

The bits of the data stored in and after the specified device are disconnected in units of the specified bits.

■ Function definition

BOOL NDIS M (BOOL EN, ANY16 S1, ANY16 S2, ANY16 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|--|
| EN | I IIVI | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be disconnected (BIN 16-bit data) |
| S2 | IN | Disconnection unit (number of bits to be disconnected) (BIN 16-bit data) |
| D | OUT | Disconnection result (BIN 16-bit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the bits of the data stored in and
- (* after iData1 are disconnected in units of iData2 bits, and the result is stored
- (* into Result and later. *)

NDIS_M (X0, iData1, iData2, Result);



Corresponding MELSEC command

- NDIS (Disconnection of any bit data)

For the usable data type, refer to "3.2.2 About ANY type".___

*)

5 - 63 5 - 63

5.14.11 Bit connection of any data NUNI_M

The bits of the data stored in and after the specified device are connected in units of the specified bits.

■ Function definition

BOOL NUNI_M (BOOL EN, ANY16 S1, ANY16 S2, ANY16 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | l IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be connected (BIN 16-bit data) |
| S2 | IN | Connection unit (number of bits to be connected) (BIN 16-bit data) |
| D | OUT | Connection result (BIN 16-bit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the bits of the data stored in and after *)
- (* iData1 are connected in units of iData2 bits, and the result is stored into
- (* Result and later. *)
 NUNI_M (X0, iData1, iData2, Result);



Corresponding MELSEC command

NUNI (Connection of any bit data)

5.14.12 Byte unit data disconnection WTOB MD

The BIN 16-bit data stored in and after the specified device are disconnected into n bytes.

■ Function definition

BOOL WTOB MD (BOOL EN, ANY16 S1, ANY16 n, ANY16 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | l IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be disconnected in byte units (BIN 16-bit data) |
| n | IN | Number of resultant byte data (BIN 16-bit data) |
| D | OUT | Disconnection result (BIN 16-bit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the 16-bit data stored in and after
- (* iData1 is disconnected in iData2 bytes, and the result is stored into Result
- (* and later.

WTOB_MD (X0, iData1, iData2, Result);



Corresponding MELSEC command

WTOB (Disconnection into byte unit data)

For the usable data type, refer to "3.2.2 About ANY type".

*) *)

5 - 64 5 - 64

5.14.13 Byte unit data connection BTOW MD

The lower 8 bits of n points of BIN 16-bit data in and after the specified device are connected in word units.

■ Function definition BOOL BTOW_MD (BOOL EN, ANY16 S1, ANY16 n, ANY16 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be connected in byte units (BIN 16-bit data) |
| n | IN | Number of byte data to be connected (BIN 16-bit data) |
| D | OUT | Connection result (BIN 16-bit data) |

| Return Va | alue | | Desci | ription | |
|-----------|------|---------------------|-------|---------|--|
| BOOL | - | Execution condition | | | |

Example of use

- (* When execution condition X0 turns ON, the lower 8 bits of iData2 words of
- (* 16-bit data in and after iData1 are connected in word units, and the result is *)



Corresponding MELSEC command

- BTOW (Connection of byte unit data)

5.14.14 Data maximum value retrieval MAX_M

The maximum value is retrieved from n points of BIN 16-bit data, starting at the specified device.

■ Function definition BOOL MAX_M (BOOL EN, ANY16 S1, ANY16 n, ANY16 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | l IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Head of data to be retrieved (BIN 16-bit data) |
| n | IN | Number of data to be retrieved (BIN 16-bit data) |
| D | OUT | Maximum value retrieval result (BIN 16-bit data) |

Remarks: When a constant is specified for the timer set value, only a decimal number can be specified.

The timer set value can be specified within the range 0 to 32767.

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the maximum value is retrieved
- (* from iData2 points of 16-bit BIN data in and after iData1, and the result is
- (* stored into Result. *

MAX_M (X0, iData1, iData2, Result)



Corresponding MELSEC command

MAX (16-bit data maximum value retrieval)

For the usable data type, refer to "3.2.2 About ANY type".

5 - 65 5 - 65

5.14.15 32-bit data maximum value retrieval DMAX M

The maximum value is retrieved from n points of BIN 32-bit data, starting at the specified device.

■ Function definition BOOL DMAX_M (BOOL EN, ANY32 S1, ANY16 n, ANY32 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Head of data to be retrieved (BIN 32-bit data) |
| n | IN | Number of data to be retrieved (BIN 16-bit data) |
| D | OUT | Maximum value retrieval result (BIN 32-bit data) |

| I | Return Value | Description |
|---|--------------|---------------------|
| | BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the maximum value is retrieved
- (* from iData points of 32-bit BIN data in and after dData, and the result *)
- (* is stored into Result. *)

DMAX_M (X0, dData, iData, Result);



Corresponding MELSEC command

DMAX (32-bit data maximum value retrieval)

5.14.16 Data minimum value retrieval MIN M

The minimum value is retrieved from n points of BIN 16-bit data, starting at the specified device.

■ Function definition BOOL MIN M (BOOL EN, ANY16 S1, ANY16 n, ANY16 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Head of data to be retrieved (BIN 16-bit data) |
| n | IN | Number of data to be retrieved (BIN 16-bit data) |
| D | OUT | Minimum value retrieval result (BIN 16-bit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the minimum value is retrieved from
- (* iData2 points of 16-bit BIN data in and after iData1, and the result is stored *)
- (* into Result. Execution condition X0 is output to the assigned device of bData. *) MIN_M (X0, iData1, iData2, Result);



Corresponding MELSEC command

MIN (16-bit data minimum value retrieval)

For the usable data type, refer to "3.2.2 About ANY type".

*)

5 - 66 5 - 66

5.14.17 32-bit data minimum value retrieval DMIN_M

The minimum value is retrieved from n points of BIN 32-bit data, starting at the specified device.

■ Function definition BOOL DMIN_M (BOOL EN, ANY32 S1, ANY16 n, ANY32 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Head of data to be retrieved (BIN 32-bit data) |
| n | IN | Number of data to be retrieved (BIN 16-bit data) |
| D | OUT | Minimum value retrieval result (BIN 32-bit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the minimum value is retrieved from
- (* iData points of 32-bit BIN data in and after dData, and the result is stored
- (* into Result and Result+1. *)

*)

DMIN_M (X0, dData, iData, Result);



Corresponding MELSEC command

- DMIN (32-bit data minimum value retrieval)

5.14.18 Data sort SORT M

n points of BIN 16-bit data, starting at the specified device, are sorted in ascending or descending order.

■ Function definition BOOL SORT_M (BOOL EN, ANY16 S1, ANY16 n, ANY16 S2, BOOL D1, ANY16 D2);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Head of data to be sorted (BIN 16-bit data) |
| n | IN | Number of data to be sorted (BIN 16-bit data) |
| S2 | IN | Number of data to be compared at one execution (BIN 16-bit data) |
| D1 | OUT | Bit device to be turned ON at sort completion (bit data) |
| D2 | OUT | System used device (BIN 16-bit data) |

Remarks: Specify the sort order by turning ON/OFF SM703. When SM703 is OFF:

Ascending order, when SM703 is ON: Descending order

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, iData2 points of BIN 16-bit data,
- (* starting at iData1, are sorted in ascending or descending order. *)
- SORT_M (X0, iData1, iData2, iData3, bData, iData4);



Corresponding MELSEC command

SORT (16-bit data sort)

For the usable data type, refer to "3.2.2 About ANY type".

5 - 67 5 - 67

5.14.19 32-bit data sort DSORT M

n points of BIN 32-bit data, starting at the specified device, are sorted in ascending or descending order.

■ Function definition BOOL DSORT_M (BOOL EN, ANY32 S1, ANY16 n, ANY16 S2, BOOL D1, ANY16 D2);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Head of data to be sorted (BIN 32-bit data) |
| n | IN | Number of data to be sorted (BIN 16-bit data) |
| S2 | IN | Number of data to be compared at one execution (BIN 16-bit data) |
| D1 | OUT | Bit device to be turned ON at sort completion (bit data) |
| D2 | OUT | System used device (BIN 16-bit data) |

Remarks: Specify the sort order by turning ON/OFF SM703. When SM703 is OFF:

Ascending order, when SM703 is ON: Descending order

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, iData1 points of BIN 32-bit data,
- (* starting at dData, are sorted in ascending or descending order. *)
 DSORT M (X0, dData, iData1, iData2, bData, iData3);



Corresponding MELSEC command

- DSORT (32-bit data sort)

5.14.20 Total value calculation WSUM M

n points of BIN 16-bit data, starting at the specified device, are all added.

■ Function definition BOOL WSUM_M (BOOL EN, ANY16 S1, ANY16 n, ANY32 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data from which total value will be calculated (BIN 16-bit data) |
| n | IN | Number of data (BIN 16-bit data) |
| D | OUT | Total value storage destination (BIN 32-bit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, iData2 points of 16-bit BIN data,
- (* starting at iData1, are all added, and the result is stored into Result. WSUM_M (X0, iData1, iData2, Result);



Corresponding MELSEC command

- WSUM (16-bit total value calculation)

For the usable data type, refer to "3.2.2 About ANY type".

*)

5 - 68 5 - 68

5.14.21 32-bit total value calculation DWSUM_M

n points of BIN 32-bit data, starting at the specified device, are all added.

■ Function definition

BOOL DWSUM_M (BOOL EN, ANY32 S1, ANY16 n, ANY16(4) D);

| Argument Name | IN/OUT | Description | on | |
|---------------|--------|---|---------------------|--|
| EN | IN | Execution condition (Function is result is TRUE) | execute | ed only when the |
| S1 | IN | Data from which total value will b | e calcu | lated (BIN 32-bit |
| n | IN | Number of data (BIN 16-bit data) |) | |
| D | OUT | Total value storage destination (ARRAY [03] OF ANY16) | D[0] D[1] D[2] D[3] | Upper 4 digits to Lower 4 digits |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, iData points of 32-bit BIN data,
- (* starting at dData, are all added, and the result is stored into Result. *)
 DWSUM_M (X0, dData, iData, Result);



Corresponding MELSEC command

DWSUM (32-bit total value calculation)

For the usable data type, refer to "3.2.2 About ANY type".

5 - 69 5 - 69

5.15 Structuring

5.15.1 Refresh COM_M

The I/O refresh and general data processing of the intelligent function module are performed.

■ Function definition BOOL COM_M (BOOL EN);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| | | Execution condition |
| EN | IN | (Only value TRUE indicating that the result is always |
| | | valid or normally ON device SM400 can be specified.) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When SM755 is OFF: I/O refresh and general data processing of intelligent
- (* function module, when SM755 is ON: Only general data processing is
- *) *) (* performed.

*)

COM_M (TRUE);



- Corresponding MELSEC command
 - COM (Refresh command)

5 - 70 5 - 70

5.16 Buffer Memory Access

5.16.1 Intelligent function module 1-word data read FROM M

The specified points of data are read from the specified address and later of the buffer memory in the specified intelligent function module or special function module.

■ Function definition

BOOL FROM M (BOOL EN. ANY16 n1. ANY16 n2. ANY16 n3. ANY16 D):

| Argument Name | IN/OUT | Description |
|---------------|--------|--|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| n1 | IN | Head input number of specified intelligent function module/special function module (BIN 16-bit data) |
| n2 | IN | Head address of data to be read (BIN 16-bit data) |
| n3 | IN | Number of data to be read (BIN 16-bit data) |
| D | OUT | Read data (BIN 16-bit data) |

^{*1:} Specified with the upper three digits when the head I/O number is expressed in 4 hexadecimal digits.

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, 1 word of data are read to D0 from
- (* address 10 and later of the buffer memory in the intelligent function module
- *) (* mounted at I/O numbers 040 to 05F. FROM_M (X0, H4, K10, K1, D0);



Corresponding MELSEC command

- FROM (Reading 1-word data from the intelligent function module)

5.16.2 Intelligent function module 2-word data read DFRO M

The specified points ×2 of data are read from the specified address and later of the buffer memory in the specified intelligent function module or special function module.

■ Function definition

BOOL DFRO M (BOOL EN, ANY16 n1, ANY16 n2, ANY16 n3, ANY32 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|--|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| n1 | IN | Head input number of specified intelligent function module/special function module (BIN 16-bit data) |
| n2 | IN | Head address of data to be read (BIN 16-bit data) |
| n3 | IN | Number of data to be read (BIN 16-bit data) |
| D | OUT | Read data (BIN 32-bit data) |

^{*1:} Specified with the upper three digits when the head I/O number is expressed in 4 hexadecimal digits.

| Return Value | Description | |
|--------------|---------------------|--|
| BOOL | Execution condition | |

Example of use

- (* When execution condition X0 turns ON, 2 words of data are read to DwResult
- (* from addresses 602, 603 and later of the buffer memory in the intelligent
- (* function module mounted at I/O numbers 040 to 05F. *) DFRO M (X0, H4, K602, K1, DwResult);



Corresponding MELSEC command

- DFRO (Reading 2-word data from the intelligent function module)

For the usable data type, refer to "3.2.2 About ANY type".

5 - 71 5 - 71

5.16.3 Intelligent function module 1-word data write TO_M

n3 points of data, starting at the specified device, are written to the specified address and later of the buffer memory in the specified intelligent function module or special function module.

■ Function definition BOOL TO M (BOOL EN, ANY16 S1, ANY16 n1, ANY16 n2, ANY16 n3);

| Argument Name | IN/OUT | Description |
|---------------|--------|--|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be written (BIN 16-bit data) |
| n1 | IN | Head input number of specified intelligent function module/special function module (BIN 16-bit data) |
| n2 | IN | Head address where data will be written (BIN 16-bit data) |
| n3 | IN | Number of data to be written (BIN 16-bit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, 3 is written to address 0 of the buffer
- (* memory in the intelligent function module mounted at I/O numbers 040 to 05F. *) TO M (X0, K3, H4, K0, K1);



Corresponding MELSEC command

- TO (Writing 1-word data to intelligent function module)

5.16.4 Intelligent function module 2-word data write DTO_M

n3×2 points of data, starting at the specified device, are written to the specified address and later of the buffer memory in the specified intelligent function module or special function module.

■ Function definition BOOL DTO M (BOOL EN, ANY32 S1, ANY16 n1, ANY16 n2, ANY16 n3);

| Argument Name | IN/OUT | Description |
|---------------|--------|--|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be written (BIN 32-bit data) |
| n1 | IN | Head input number of specified intelligent function module/special function module (BIN 16-bit data) |
| n2 | IN | Head address where (3×2) points of data will be written (BIN 16-bit data) |
| n3 | IN | Number of data to be written (BIN 16-bit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, 0 is written to addresses 41, 42
- (* of the buffer memory in the intelligent function module mounted at I/O
- (* numbers 040 to 05F.

DTO_M (X0, K0, H4, K41, K1);



Corresponding MELSEC command

- DTO (Writing 2-word data to intelligent function module)

For the usable data type, refer to "3.2.2 About ANY type".

5 - 72 5 - 72

5.17 Character string processing

5.17.1 BIN→decimal ASCII conversion BINDA S MD

The numeric value in each digit of the specified BIN 16-bit data represented in decimal is converted into ASCII code data.

■ Function definition BOOL BINDA S MD (BOOL EN, ANY16 S1, STRING(8) D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be converted (BIN 16-bit data) |
| D | OUT | Conversion result (decimal ASCII code data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

- Example of use
 - (* When execution condition X0 turns ON, the numeric value in each digit of the
 - (* BIN data stored in iData and represented in decimal is converted into ASCII
 - *) (* code, and the result is stored into sData. *) BINDA S MD (X0, iData, sData);



- Corresponding MELSEC command
 - BINDA (BIN 16-bit to decimal ASCII conversion)

5.17.2 32-bit BIN→decimal ASCII conversion DBINDA S MD

The numeric value in each digit of the specified BIN 32-bit data represented in decimal is converted into ASCII code data.

■ Function definition BOOL DBINDA S MD (BOOL EN, ANY32 S1, STRING(12) D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | l IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be converted (BIN 32-bit data) |
| D | OUT | Conversion result (decimal ASCII code data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the numeric value in each digit of
- (* the BIN data stored in dData and represented in decimal is converted into
- *) (* ASCII code, and the result is stored into sData. *) DBINDA S MD (X0, dData, sData);



Corresponding MELSEC command

DBINDA (BIN 32-bit → decimal ASCII conversion)

For the usable data type, refer to "3.2.2 About ANY type".

5 - 73 5 - 73

5.17.3 BIN→hexadecimal ASCII conversion BINHA_S_MD

The numeric value in each digit of the specified BIN 16-bit data represented in hexadecimal is converted into ASCII code data.

■ Function definition

BOOL BINHA_S_MD (BOOL EN, ANY 16S1, STRING(6) D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | l IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be converted (BIN 16-bit data) |
| D | OUT | Conversion result (hexadecimal ASCII code data) |

| Return Value | Description | |
|--------------|---------------------|--|
| BOOL | Execution condition | |

Example of use

- (* When execution condition X0 turns ON, the numeric value in each digit of
- (* the BIN data stored in iData and represented in hexadecimal is converted *)
- (* into ASCII code, and the result is stored into sData. *)
 BINHA_S_MD (X0, iData, sData);



- Corresponding MELSEC command
 - BINHA (BIN 16-bit → hexadecimal ASCII conversion);

5.17.4 32-bit BIN→hexadecimal ASCII conversion DBINHA S MD

The numeric value in each digit of the specified BIN 32-bit data represented in hexadecimal is converted into ASCII code data.

■ Function definition

BOOL DBINHA_S_MD (BOOL EN, ANY32 S1, STRINGS (10) D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be converted (BIN 32-bit data) |
| D | OUT | Conversion result (hexadecimal ASCII code data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the numeric value in each digit of
- (* the BIN data stored in dData and represented in hexadecimal is converted
- (* into ASCII code, and the result is stored into sData. *)
 DBINHA_S_MD (X0, dData, sData);



Corresponding MELSEC command

DBINHA (BIN 32-bit → hexadecimal ASCII conversion)

For the usable data type, refer to "3.2.2 About ANY type".

*)

*)

5 - 74 5 - 74

5.17.5 BCD 4-digit → decimal ASCII conversion BCDDA S MD

The numeric value in each digit of the specified BCD 4-digit data is converted into ASCII code.

■ Function definition

BOOL BCDDA_S_MD (BOOL EN, ANY16 S1, STRING(6) D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be converted (BCD 4-digit data) |
| D | OUT | Conversion result (decimal ASCII code data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the numeric value in each digit of
- (* the BCD data stored in iData and represented in decimal is converted into
- (* ASCII code, and the result is stored into sData. *) BCDDA_S_MD (X0, iData, sData);

*)

*)



Corresponding MELSEC command

BCDDA (BCD 4-digit → decimal ASCII conversion)

5.17.6 BCD 8-digit → decimal ASCII conversion DBCDDA S MD

The numeric value in each digit of the specified BCD 8-digit data is converted into ASCII code.

■ Function definition BOOL DBCDDA S MD (BOOL EN, ANY32 S1, STRING (10) D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be converted (BCD 8-digit data) |
| D | OUT | Conversion result (decimal ASCII code data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the numeric value in each digit of
- (* the BCD data stored in dData and represented in decimal is converted into
- *) (* ASCII code, and the result is stored into sData. *) DBCDDA_S_MD (X0, dData, sData);



Corresponding MELSEC command

DBCDDA (BCD 8-digit → decimal ASCII conversion)

For the usable data type, refer to "3.2.2 About ANY type".

5 - 75 5 - 75

5.17.7 Decimal ASCII→BIN conversion DABIN_S_MD

The specified decimal ASCII code data is converted into BIN 16-bit data.

■ Function definition

BOOL DABIN_S_MD (BOOL EN, STRING (6) S1, ANY16 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | l IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | | Data to be converted (decimal ASCII code data) |
| D | OUT | Conversion result (BIN 16-bit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the decimal ASCII data stored
- (* in sData is converted into BIN 16-bit data, and the result is stored into iData. *) DABIN_S_MD (X0, sData, iData);

*)

*)



- Corresponding MELSEC command
 - DABIN (Decimal ASCII → BIN 16-bit conversion)

5.17.8 Decimal ASCII→32-bit BIN conversion DDABIN_S_MD

The specified decimal ASCII code data is converted into BIN 32-bit data.

■ Function definition BOOL DDABIN

BOOL DDABIN_S_MD (BOOL EN, STRING (11) S1, ANY32 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | l IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be converted (decimal ASCII code data) |
| D | OUT | Conversion result (BIN 32-bit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the decimal ASCII data stored in
- (* sData is converted into BIN 32-bit data, and the result is stored into dData. *) DDABIN_S_MD (X0, sData, dData);



- Corresponding MELSEC command
 - DDABIN (Decimal ASCII → BIN 32-bit conversion)

For the usable data type, refer to "3.2.2 About ANY type".

5 - 76 5 - 76

5.17.9 Hexadecimal ASCII→BIN conversion HABIN_S_MD

The specified hexadecimal ASCII code data is converted into BIN 16-bit data.

■ Function definition BOOL HABIN_S_MD (BOOL EN, STRING(4) S1, ANY16 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| FN | INI | Execution condition (Function is executed only when the |
| EIN | | result is TRUE) |
| S1 | IN | Data to be converted (hexadecimal ASCII code data) |
| D | OUT | Conversion result (BIN 16-bit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the hexadecimal ASCII data stored *)
- (* in sData is converted into BIN 16-bit data, and the result is stored into iData. *) HABIN_S_MD (X0, sData, iData);



- Corresponding MELSEC command
 - HABIN (Hexadecimal ASCII → BIN 16-bit conversion)

5.17.10 Hexadecimal ASCII→32-bit BIN conversion DHABIN_S_MD

The specified hexadecimal ASCII code data is converted into BIN 32-bit data.

■ Function definition BOC

BOOL DHABIN_S_MD (BOOL EN, STRING (8) S1, ANY32 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the |
| | | result is TRUE) |
| S1 | IN | Data to be converted (hexadecimal ASCII code data) |
| D | OUT | Conversion result (BIN 32-bit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the hexadecimal ASCII data stored in *)
- (* sData is converted into BIN 32-bit data, and the result is stored into dData. *) DHABIN_S_MD (X0, sData, dData);



- Corresponding MELSEC command
 - DHABIN (Hexadecimal ASCII → BIN 32-bit conversion)

For the usable data type, refer to "3.2.2 About ANY type".

5 - 77 5 - 77

5.17.11 Decimal ASCII→BCD 4-digit conversion DABCD_S_MD

The specified decimal ASCII code data is converted into BCD 4-digit data.

■ Function definition

BOOL DABCD_S_MD (BOOL EN, STRING(4) S1, ANY16 D);

| Argument Name | IN/OUT | Description |
|---------------|--|---|
| ΓN | INI | Execution condition (Function is executed only when the |
| EN | IN | result is TRUE) |
| S1 | IN | Data to be converted (decimal ASCII code data) |
| D | D OUT Conversion result (BCD 4-digit data) | |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the decimal ASCII data stored in
- (* sData is converted into BCD 4-digit data, and the result is stored into iData. *) DABCD_S_MD (X0, sData, iData);

*)

*)



- Corresponding MELSEC command
 - DABCD (Decimal ASCII → BCD 4-digit conversion)

5.17.12 Decimal ASCII→BCD 8-digit conversion DDABCD_S_MD

The specified decimal ASCII code data is converted into BCD 8-digit data.

■ Function definition

BOOL DDABCD_S_MD (BOOL EN, STRING(8) S1, ANY32 D);

| Argument Name | IN/OUT | Description |
|---------------|--|---|
| EN | l IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be converted (decimal ASCII code data) |
| D | OUT Conversion result (BCD 8-digit data) | |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the decimal ASCII data stored in
- (* sData is converted into BCD 8-digit data, and the result is stored into dData. *) DDABCD_S_MD (X0, sData, dData);



- Corresponding MELSEC command
 - DDABCD (Decimal ASCII → BCD 8-digit conversion)

For the usable data type, refer to "3.2.2 About ANY type".

5 - 78 5 - 78

5.17.13 Device comment data read COMRD S MD

The comment of the specified device is read as ASCII code data.

■ Function definition

BOOL COMRD_S_MD (BOOL EN, ANY_SIMPLE S1, STRING (32) D);

| Argument Name | IN/OUT | Description | |
|---------------|--------|---|--|
| EN | l IN | Execution condition (Function is executed only when the result is TRUE) | |
| S1 | IN | Data from which comment will be read | |
| D | OUT | Comment read result (ASCII code data) | |

Remarks: The DINT, REAL and STRING types cannot be used in argument "S1".

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

(* When execution condition X0 turns ON, the comment set in D100 is read,

(* and stored into sData in ASCII code. *)

COMRD_S_MD (X0, D100, sData);

*)



Corresponding MELSEC command

COMRD (Device comment data read)

5.17.14 Character string length detection LEN_S_MD

The length of the specified character string is obtained.

■ Function definition BOOL LEN S MD (BOOL EN, STRING S1, ANY16 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data whose character string length will be detected (character string data) |
| D | OUT | Detection result (BIN 16-bit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

(* When execution condition X0 turns ON, the length of the character string

(* specified in sData is detected, and stored into iData. *)
LEN_S_MD (X0, sData, iData);



Corresponding MELSEC command

LEN (Character string length detection)

For the usable data type, refer to "3.2.2 About ANY type".

5 - 79 5 - 79

5.17.15 BIN→character string conversion STR_S_MD

The specified BIN 16-bit data is converted into a character string with a decimal point added in the specified position.

■ Function definition

BOOL STR_S_MD (BOOL EN, ANY32 S1, ANY16 S2, STRING(9) D);

| Argument Name | IN/OUT | Description | | |
|---------------|--------|--|------------|--|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) | | |
| S1 | IN | Number of digits of numeric value to be converted (BIN 32-bit data) | S1 S1+1 | Total number of digits (2 to 8 digits) Number of fraction part digits (0 to 5 digits) |
| S2 | IN | Data to be converted (BIN 16-bit data) | | |
| D | OUT | Conversion result (character string data) | | |

Remarks: The digits of a bit device cannot be specified in "S1".

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the BIN 16-bit data specified in
- (* iData is converted into a character string with a decimal point added in the
- (* position specified in dData, and the result is stored into sData.

 * STR S MD (X0, dData, iData, sData);



Corresponding MELSEC command

STR (BIN 16-bit → character string conversion)

5.17.16 32-bit BIN→character string conversion DSTR_S_MD

The specified BIN 32-bit data is converted into a character string with a decimal point added in the specified position.

■ Function definition

BOOL DSTR S MD (BOOL EN, ANY32 S1, ANY32 S2 STRING(14) D);

| Argument Name | IN/OUT | Description | |
|---------------|--------|---|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) | |
| S1 | IN | Number of digits of numeric value to be converted (BIN 32-bit data) | Total number of digits (2 to 8 digits) 11+1 Number of fraction part digits (0 to 5 digits) |
| S2 | IN | Data to be converted (BIN 32-bit data) | |
| D | OUT | Conversion result (character string data) | |

Remarks: The digits of a bit device cannot be specified in "S1".

| Ĺ | Return Value | Description |
|---|--------------|---------------------|
| I | BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the BIN 32-bit data specified in
- (* dData1 is converted into a character string with a decimal point added in
- (* the position specified in dData2, and the result is stored into sData. *)
 DSTR S MD (X0, dData1, dData2, sData);

 *)



Corresponding MELSEC command

DSTR (BIN 32-bit → character string conversion)

For the usable data type, refer to "3.2.2 About ANY type".

5 - 80 5 - 80

5.17.17 Character string→BIN conversion VAL_S_MD

The specified character string is converted into BIN 16-bit data, and its number of digits and BIN 16-bit data are obtained.

■ Function definition

BOOL VAL_S_MD (BOOL EN, STRING (8) S1, ANY32 D1, ANY16 D2);

| Argument Name | IN/OUT | Description | |
|------------------|--------|---|--|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) | |
| S1 | | Data to be converted (character string data) Remarks: The number of characters in the fraction part of the character | |
| D1 | OUT | Conversion result (number of digits) (BIN 32-bit data) | |
| D2 | OUT | Conversion result (BIN 16-bit data) | |

Remarks: The digits of a bit device cannot be specified in "D1".

| | , |
|--------------|---------------------|
| Return Value | Description |
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the character string specified in
- (* sData is converted into BIN 16-bit data, the number of digits is stored
- (* into dData, and the BIN data is stored into iData.

VAL S MD (X0, sData, dData, iData);



Corresponding MELSEC command

VAL (Character string → BIN 16-bit conversion)

5.17.18 Character string→32-bit BIN conversion DVAL_S_MD

The specified character string is converted into BIN 32-bit data, and its number of digits and BIN 32-bit data are obtained.

■ Function definition

BOOL DVAL S MD (BOOL EN, STRING(13) S1, ANY32 D1, ANY32 D2);

| Argument Name | IN/OUT | Description | |
|------------------|--------|---|--|
| EN | IN | Execution condition (Function is executed only when the result is FRUE) | |
| S1 | IN | Data to be converted (character string data) Remarks: The number of characters in the fraction part of the character string specified in S1 is 0 to 5 characters. Note that the character string should be specified within the (total number of digits - 3) or less. | |
| D1 | OUT | Conversion result (number of digits) (BIN 32-bit data) | |
| D2 | OUT | Conversion result (BIN 32-bit data) | |

Remarks: The digits of a bit device cannot be specified in "D1".

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the character string specified
- (* in sData is converted into BIN 32-bit data, the number of digits is stored into
- (* dData1, and the BIN data is stored into dData2.

DVAL_S_MD (X0, sData, dData1, dData2);



Corresponding MELSEC command

DVAL (Character string → BIN 32-bit conversion)

For the usable data type, refer to "3.2.2 About ANY type".

5 - 81 5 - 81

5.17.19 Floating-point → character string conversion ESTR_M

The specified real number data is converted into a character string according to the specified display instruction.

■ Function definition

BOOL ESTR_M (BOOL EN, REAL S1, ANY16 (3) S2, STRING (24) D);

| Argument Name | IN/OUT | Description | |
|---------------|--------|---|--|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) | |
| S1 | IN | Data to be converted (real number data) | |
| S2 | IN | Data to be converted (real number data) Display specification of numeric value to be converted S2 [0] Display format (0: decimal point format, 1: exponent format) S2 [1] Total number of digits (2 to 24 digits) When the number of fraction part digits is "0" Number of digits (max.: 24) ≥ 2 When the number of fraction part digits is other than "0" Number of digits (max.: 24) ≥ (number of fraction part digits + 3) S2 [2] Number of fraction part digits (0 to 7 digits) | |
| D | OUT | Conversion result (character string data) | |

| Return Value | Description | |
|--------------|---------------------|--|
| BOOL | Execution condition | |

Example of use

- (* When execution condition X0 turns ON, the real number data specified in
- (* rData is converted into a character string according to the display instruction
- (* specified in ArrayData, and the result is stored into sData.

 ESTR M (X0, rData, ArrayData, sData,);



Corresponding MELSEC command

ESTR (Floating-point data → character string conversion)

5.17.20 Character string→floating-point conversion EVAL_M

The specified character string is converted into real number data.

■ Function definition

BOOL EVAL M (BOOL EN. STRING (24) S1, REAL D);

| Argument Name | IN/OUT | Description | |
|---------------|--------|---|--|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) | |
| S1 | IN | Data to be converted (character string data) | |
| D | OUT | Conversion result (real number data) | |

| Ret | urn Value | Description | |
|-----|-----------|---------------------|--|
| | BOOL | Execution condition | |

Example of use

- (* When execution condition X0 turns ON, the character string specified in
- (* sData is converted into real number data, and the result is stored into rData. EVAL M (X0, sData, rData);



Corresponding MELSEC command

EVAL (Character string data _ floating-point conversion)

For the usable data type, refer to "3.2.2 About ANY type".

5 - 82 5 - 82

5.17.21 BIN→ASCII conversion ASC S MD

The specified BIN 16-bit data is converted into the hexadecimal ASCII data of the specified number of characters.

■ Function definition BOOL ASC S MD (BOOL EN, ANY16 S1, ANY16 n, STRING D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be converted (BIN 16-bit data) |
| n | IN | Number of characters to be stored (BIN 16-bit data) |
| D | OUT | Conversion result (ASCII data) |

| | Return Value | Description |
|---|--------------|---------------------|
| Ī | BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the BIN 16-bit data specified in
- (* iData1 is converted into hexadecimal ASCII, and the result is stored into the
- (* range of the number of characters specified in iData2, starting at the device *)

*)

*) *)

(* number specified in sData. *)

ASC S MD (X0, iData1, iData2, sData);



Corresponding MELSEC command

ASC (BIN 16-bit data → ASCII conversion)

5.17.22 ASCII→BIN conversion HEX_S_MD

The hexadecimal ASCII data stored in the specified number of characters is converted into BIN 16-bit data.

■ Function definition

BOOL HEX S MD (BOOL EN, STRING S1, ANY16n, ANY16 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be converted (hexadecimal ASCII data) |
| n | IN | Number of characters to be converted (BIN 16-bit data) |
| D | OUT | Conversion result (BIN 16-bit data) |

| Return Value | Description | |
|--------------|---------------------|--|
| BOOL | Execution condition | |

Example of use

- (* When execution condition X0 turns ON, the hexadecimal ASCII data stored
- (* in the number of characters specified in iData1, starting at the device number *)
- (* specified in sData, is converted into a BIN value, and the result is stored into
- (* iData2.

HEX_S_MD (X0, sData, iData1, iData2);



Corresponding MELSEC command

HEX (ASCII → BIN 16-bit conversion)

For the usable data type, refer to "3.2.2 About ANY type".

5 - 83 5 - 83

5.17.23 Fetch from character string right side RIGHT M

n characters of data, starting at the right of the specified character string data (end of the character string), are

■ Function definition

BOOL RIGHT M (BOOL EN, STRING S1, ANY16 n, STRING D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be acquired (character string data) |
| n | IN | Number of characters to be acquired (BIN 16-bit data) |
| D | OUT | Acquisition result (n characters of character string data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, iData characters of data, starting at
- (* the right of the character string specified in sData (end of the character string), *)
- (* are stored into Result. RIGHT M (X0, sData, iData, Result);



Corresponding MELSEC command

RIGHT (Fetch from right side of character string)

5.17.24 Fetch from character string left side LEFT M

n characters of data, starting at the left of the specified character string data (head of the character string), are acquired.

■ Function definition

BOOL LEFT_M (BOOL EN, STRING S1, ANY16 n, STRING D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be acquired (character string data) |
| n | IN | Number of characters to be acquired (BIN 16-bit data) |
| D | OUT | Acquisition result (n characters of character string data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, iData characters of data, starting at
- (* the left of the character string specified in sData (head of the character string),
- (* are stored into Result.
 - LEFT_M (X0, sData, iData, Result);



Corresponding MELSEC command

LEFT (Fetch from left side of character string)

For the usable data type, refer to "3.2.2 About ANY type".

5 - 84 5 - 84

5.17.25 Any data fetch in character string MIDR M

S2[1] characters of data, starting at S2[0] of the specified character data, are acquired.

■ Function definition BOOL MIDR_M (BOOL EN, STRING S1, ANY16(2) S2, STRING D);

| Argument Name | IN/OUT | Description | | |
|---------------|--------|---|-----------|--|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) | | |
| S1 | IN | Data to be acquired (character string data) | | |
| S2 | INI | Position of first character and storage destination of characters to be acquired (ARRAY [01] OF ANY16) | | Position of first character Number of acquired characters |
| D | OUT | Acquisition result (character | string da | ta) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the data of the number of
- (* characters specified in StrArray [1] from the position specified in StrArray [0],
- (* starting at the left of the character specified in sData (head of the character
- (* starting), are stored into Result.

 MIDR M (X0, sData, StrArray, Result);



Corresponding MELSEC command

- MIDR (Any data fetch in character string)

5.17.26 Any data replacement in character string MIDW M

The data of the number of characters specified in S2[1] are stored into the position, starting at S2[0], of the specified character string data.

■ Function definition

BOOL MIDW M (BOOL EN, STRING S1, ANY16(S) S2, STRING D);

| Argument Name | IN/OUT | Description | | |
|---------------|--------|---|--------|--|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) | | |
| S1 | | Data to be acquired (character | | |
| S2 | | Position of first character and storage destination of | S2 [0] | Position of first character of replacement destination |
| 32 | IIN | characters to be acquired (ARRAY [01] OF ANY16) | S2 [1] | Number of acquired characters |
| D | IN/OUT | Data to be replaced, replacement result (character string data) | | |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the data of the number of characters
- (* specified in StrArray [1], starting at the left of the character specified in sData
- (* (head of the character string), are stored into the position specified in StrArray *
- * [0], starting at the left of the character string data stored in sData2.

 MIDW M (X0, sData1, StrArray, sData2);



Corresponding MELSEC command

MIDW (Any data replacement in character string)

For the usable data type, refer to "3.2.2 About ANY type".

5 - 85 5 - 85

5.17.27 Character string search INSTR M

A searched for the specified character string data is performed, starting at the "n"th character from the left of the specified character string data.

■ Function definition BOOL INSTR M (BOOL EN, STRING S1, STRING S2, ANY16 n, ANY16 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be searched for (character string data) |
| S2 | IN | Data to be searched (character string data) |
| n | IN | Search start position (at the "n"th character from left) (BIN 16-bit data) |
| D | OUT | Search result (character position from head of character string data specified in S2) (BIN 16-bit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- When execution condition X0 turns ON, a search for the character string
- * specified in sData1 is performed, starting at the iData character from the left of
- the character string specified in sData2 (head of the character string), and the
- search result is stored into Result.

INSTR M (X0, sData1, sData2, iData, Result);



Corresponding MELSEC command

INSTR (Character string search)

5.17.28 Floating-point → BCD decomposition EMOD M

The specified real number data is decomposed into the BCD type floating-point format based on the specified fraction part digits.

■ Function definition

BOOL EMOD M (BOOL EN, REAL S1, ANY16 S2, ANY16(5) D);

| Argument Name | IN/OUT | Description | | |
|---------------|--------|---|--|--|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) | | |
| S1 | IN | Data to be decomposed (real number data) | | |
| S2 | | Fraction part digit data (BIN 16-bit data) | | |
| D | OUT | BCD-decomposed data storage destination (ARRAY[04] OF ANY16) | D[0] Sign (positive: 0, negative: 1) D[1] BCD 7 digits D[3] Exponent part sign (positive: 0, negative: 1) D[4] BCD exponent | |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- When execution condition X0 turns ON, the real number data specified in
- rData is decomposed into the BCD type floating-point format based on the
- fraction part digits specified in iData, and the result is stored into Result. EMOD M (X0, rData, iData, Result);



Corresponding MELSEC command

EMOD (Floating-point data → BCD decomposition);

For the usable data type, refer to "3.2.2 About ANY type".

5 - 86 5 - 86

5.17.29 BCD format data→floating-point EREXP_M

The specified BCD type floating-point format data is converted into real number data based on the specified fraction part digits.

■ Function definition

BOOL EREXP_M (BOOL EN, ANY16 S1, ANY16 S2, REAL D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be converted (BCD type floating-point format data) |
| S2 | IN | Fraction part digit data (BIN 16-bit data) |
| D | OUT | Conversion result (real number data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the BCD type floating-point format
- (* data specified in iData1 is converted into real number data based on the *)
- (* fraction part digits specified in iData2, and the result is stored into Result.
- (* real number data based on the fraction part digits specified in iData2, and *)
- (* the result is stored into Result.

EREXP_M (X0, iData1, iData2, Result);



Corresponding MELSEC command

- EREXP (BCD format data → floating-point)

For the usable data type, refer to "3.2.2 About ANY type".

*)

*)

*)

5 - 87 5 - 87

5.18 Special Functions

5.18.1 Floating-point SIN operation SIN E MD

The SIN (sine) value of the specified angle is operated.

■ Function definition BOOL SIN E MD (BOOL EN, REAL S1, REAL D);

| Argument Name | IN/OUT | Description |
|---------------|--------|--|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Angle data to be SIN (sine) operated (real number data) Remarks: Set the specified angle in radian unit (angle $\times \pi/180$). |
| D | OUT | Operation result (SIN value) (real number data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the SIN value of the angle specified
- *) (* in rData is calculated, and the result is stored into Result. *) SIN_E_MD (X0, rData, Result);



Corresponding MELSEC command

SIN (SIN operation on floating-point data (Single precision))

5.18.2 Floating-point COS operation COS E MD

The COS (cosine) value of the specified angle is operated.

■ Function definition BOOL COS_E_MD (BOOL EN, REAL S1, REAL D);

| Argument Name | IN/OUT | Description |
|---------------|--------|--|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Angle data to be COS (cosine) operated (real number data) Remarks: Set the specified angle in radian unit (angle $\times \pi/180$). |
| D | OUT | Operation result (COS value) (real number data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the COS value of the angle
- (* specified in rData is calculated, and the result is stored into Result. COS_E_MD (X0, rData, Result)



Corresponding MELSEC command

- COS (COS operation on floating-point data (Single precision))

5-88 5-88

5.18.3 Floating-point TAN operation TAN_E_MD

The TAN (tangent) value of the specified angle is operated.

■ Function definition BOOL TAN E

BOOL TAN_E_MD (BOOL EN, REAL S1, REAL D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Angle data to be TAN (tangent) operated (real number data) Remarks: Set the specified angle in radian unit (angle \times π /180). |
| D | OUT | Operation result (TAN value) (real number data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the TAN value of the angle specified *
- (* in rData is calculated, and the result is stored into Result. *)
 TAN_E_MD (X0, rData, Result);



Corresponding MELSEC command

- TAN (TAN operation on floating-point data (Single precision))

5.18.4 Floating-point SIN⁻¹ operation ASIN_E_MD

The SIN-1 (arcsine) operation of the specified SIN value is performed.

■ Function definition BOOL ASIN_E_MD (BOOL EN, REAL S1, REAL D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be operated, SIN value (-1.0 to 1.0) (real number data) |
| D | OUT | Operation result (angle data in radian unit) (real number data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the angle is operated from the SIN
- (* value specified in rData, and the result is stored into Result.
 *)
 ASIN_E_MD (X0, rData, Result);

*)



Corresponding MELSEC command

ASIN (SIN⁻¹ operation on floating-point data (Single precision))

5- 89 5- 89

5.18.5 Floating-point COS-1 operation ACOS_E_MD

The COS-1 (arccosine) operation of the specified COS value is performed.

■ Function definition

BOOL ACOS_E_MD (BOOL EN, REAL S1, REAL D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be operated, COS value (-1.0 to 1.0) (real number data) |
| D | OUT | Operation result (angle data in radian unit) (real number data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the angle is operated from the COS
- (* value specified in rData, and the result is stored into Result.
 *)

 ACOS E MD (X0, rData, Result);



Corresponding MELSEC command

- ACOS (COS⁻¹ operation on floating-point data (Single precision))

5.18.6 Floating-point TAN-1 operation ATAN_E_MD

The TAN-1 (arctangent) operation of the specified TAN value is performed.

■ Function definition BOOL ATAN_E_MD (BOOL EN, REAL S1, REAL D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be operated, TAN value (real number data) |
| D | OUT | Operation result (angle data in radian unit) (real number data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the angle is operated from the TAN



Corresponding MELSEC command

ATAN (TAN⁻¹ operation on floating-point data (Single precision))

5-90

5.18.7 Floating-point angle → radian RAD_E_MD

The unit of magnitude of the specified angle is converted from the degree unit to the radian unit.

■ Function definition

BOOL RAD_E_MD (BOOL EN, REAL S1, REAL D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be converted, angle data in degree unit (real number data) |
| D | OUT | Conversion result (radian unit) (real number data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the angle data of degree unit specified *)
- (* in rData is converted into the radian unit, and the result is stored into Result. * RAD_E_MD (X0, rData, Result);



Corresponding MELSEC command

- RAD (Conversion from floating-point angle to radian (Single precision))

5.18.8 Floating-point radian → angle conversion DEG_E_MD

The unit of magnitude of the specified angle is converted from the radian unit to the degree unit.

■ Function definition

BOOL DEG_E_MD (BOOL EN, REAL S1, REAL D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | l IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be converted, radian value data (real number data) |
| D | OUT | Conversion result (degree unit) (real number data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the unit of magnitude of the angle is *)
- (* converted from the radian unit to the degree unit, and the result is stored into Result. *) DEG_E_MD (X0, rData, Result);



Corresponding MELSEC command

- DEG (Conversion from floating-point radian to angle (Single precision))

5- 91 5- 91

5.18.9 Floating-point square root SQR_E_MD

The square root of the specified value is operated.

■ Function definition

BOOL SQR_E_MD (BOOL EN, REAL S1, REAL D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be operated (only positive value can be specified) (real number data) |
| D | OUT | Operation result (real number data) |

Remarks: The value to be specified in "S1" is a positive number only.

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the square root of the value specified *)
- (* in rData is operated, and the result is stored into Result. *) SQR_E_MD (X0, rData, Result);



Corresponding MELSEC command

- SQR (Square root operation for floating-point data (Single precision))

5.18.10 Floating-point natural exponential operation EXP_E_MD

The base e natural exponent of the specified value is operated.

■ Function definition BOOL EXP_E_MD (BOOL EN, REAL S1, REAL D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | l IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Exponent part data to be operated (real number data) |
| D | OUT | Operation result (es1) (real number data) |

Remarks: Operation is performed on the assumption that the base (e) is "2.71828".

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, natural exponential operation
- (* performed using rData as an exponent is, and the result is stored into Result. *) EXP_E_MD (X0, rData, Result);



Corresponding MELSEC command

- EXP (Exponent operation on floating-point data (Single precision))

5- 92 5- 92

5.18.11 Floating-point natural logarithm operation LOG E MD

The base e logarithm (natural logarithm) of the specified value is operated.

■ Function definition BOOL LOG_E_MD (BOOL EN, REAL S1, REAL D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | l IN | Data to be operated (only positive value can be specified) (real number data) |
| D | OUT | Operation result (log _e S1) (real number data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

- Example of use
 - (* When execution condition X0 turns ON, the base e logarithm (natural logarithm) *)
 - (* of the value specified in rData is operated, and the result is stored into Result. *) LOG_E_MD (X0, rData, Result);



- Corresponding MELSEC command
 - LOG (Natural logarithm operation on floating-point data (Single precision))

5.18.12 Random number generation RND_M

Random numbers of 0 to 32767 are generated.

■ Function definition BOOL RND_M (BOOL EN, ANY16 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN IN | Execution condition (Function is executed only when the result is TRUE) |
| D | OUT | Random number generation result (BIN 16-bit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

- Example of use
 - (* When execution condition X0 turns ON, random numbers of 0 to 32767 are *)
 - (* generated and stored into Result. *)
 RND_M (X0, Result);



- Corresponding MELSEC command
 - RND (Random number generation)

For the usable data type, refer to "3.2.2 About ANY type".

5- 93 5- 93

5.18.13 Sequence change SRND M

The random number sequence is changed according to the specified 16-bit BIN data.

■ Function definition

BOOL SRND_M (BOOL EN, ANY16 S1);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Random number sequence change result (BIN 16-bit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the random number sequence is changed *)
- (* according to the 16-bit BIN data stored in the device specified in iData. *) SRND_M (X0, iData);



- Corresponding MELSEC command
 - SRND (Series updates)

5.18.14 BCD 4-digit square root BSQR MD

The square root of the specified BCD 4-digit data is operated.

■ Function definition BOOL BSQR MD (BOOL EN, ANY16 S1, ANY32 D);

| Argument Name | IN/OUT | Description | |
|---------------|--------|---|--|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) | |
| S1 | IN | BCD 4-digit data to be operated (BIN 16-bit data) | |
| D | OUT | Operation result (BIN 32-bit data) | |

Remarks: The digits of a bit device cannot be specified in "D".

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the square root of the value specified *)
- (* in iData is operated, and the result is stored into Result. *)
 BSQR_MD (X0, iData, dData);



- Corresponding MELSEC command
 - BSQR (BCD 4-digit square root)

For the usable data type, refer to "3.2.2 About ANY type".

5- 94 5- 94

5.18.15 BCD 8-digit square root BDSQR_MD

The square root of the specified BCD 8-digit data is operated.

■ Function definition BO

BOOL BDSQR_MD (BOOL EN, ANY32 S1, ANY32 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | l IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | BCD 8-digit data to be operated (BIN 32-bit data) |
| D | OUT | Operation result (BIN 32-bit data) |

Remarks: The digits of a bit device cannot be specified in "D".

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the square root of the value specified in
- (* dData is operated, and the result is stored into Result. BDSQR_MD (X0, dData, Result);



- Corresponding MELSEC command
 - BDSQR (BCD 8-digit square root)

5.18.16 BCD type SIN operation BSIN_MD

The BCD 4-digit data of the specified angle is SIN (sine) operated.

■ Function definition BOOL BSIN

BOOL BSIN_MD (BOOL EN, ANY16 S1, ANY16(3) D);

| Argument Name | IN/OUT | | Description |
|---------------|--------|-------------------------------------|--|
| EN | IN | Execution condition result is TRUE) | n (Function is executed only when the |
| S1 | IN | Data to be operate | d (BCD 4-digit data) |
| D | OUT | • | D [0] Sign (positive: 0, negative: 1) D [1] Integer part (BCD 4-digit data) D [2] Fraction part (BCD 4-digit data) |

| Return Value | Description | |
|--------------|---------------------|--|
| BOOL | Execution condition | |

Example of use

- (* When execution condition X0 turns ON, the SIN value of the angle specified in iData is *)
- (* operated, the sign of the operation result is stored into ArrayData [0], the integer part of *)
- (* the operation result into ArrayData [1], and the fraction part into ArrayData [2]. *) BSIN_MD (X0, iData, ArrayData);



- Corresponding MELSEC command
 - BSIN (BCD type SIN operation)

For the usable data type, refer to "3.2.2 About ANY type".

*)

*)

5- 95

5.18.17 BCD type COS operation BCOS_MD

The BCD 4-digit data of the specified angle is COS (cosine) operated.

■ Function definition BOOL BCOS_MD (BOOL EN, ANY16 S1, ANY16(3) D);

| Argument Name | IN/OUT | | De | scription |
|---------------|--------|--|---------|---|
| EN | IN | Execution condition result is TRUE) | n (Func | tion is executed only when the |
| S1 | IN | Data to be operated (BCD 4-digit data) | | |
| D | OUT | Operation result (ARRAY [02] OF | | Sign (positive: 0, negative: 1) Integer part (BCD 4-digit data) |
| | | ANY16) | D [2] | Fraction part (BCD 4-digit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the COS value of the angle specified in iData is *)
- (* operated, the sign of the operation result is stored into ArrayData [0], the integer part of *)
- (* the operation result into ArrayData [1], and the fraction part into ArrayData [2]. *) BCOS_MD (X0, iData, ArrayData);



- Corresponding MELSEC command
 - BCOS (BCD type COS operation)

5.18.18 BCD type TAN operation BTAN_MD

The BCD 4-digit data of the specified angle is TAN (tangent) operated.

■ Function definition BOOL BTAN MD (BOOL EN, ANY16 S1, ANY16(3) D);

| Argument Name | IN/OUT | | Description |
|---------------|--------|-------------------------------------|---|
| EN | IN | Execution condition result is TRUE) | n (Function is executed only when the |
| S1 | IN | Data to be operate | ed (BCD 4-digit data) |
| D | OUT | • | D [0] Sign (positive: 0, negative: 1) D [1] Integer part (BCD 4-digit data) |
| D | 001 | ANY16) | D [2] Fraction part (BCD 4-digit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the TAN value of the angle specified in iData is *)
- (* operated, the sign of the operation result is stored into ArrayData [0], the integer part of *)
- (* the operation result into ArrayData [1], and the fraction part into ArrayData [2].
 *)
 BTAN_MD (X0, iData, ArrayData);



- Corresponding MELSEC command
 - BTAN (BCD type TAN operation)

For the usable data type, refer to "3.2.2 About ANY type".

5- 96 5- 96

5.18.19 BCD type SIN⁻¹ operation BASIN_MD

The SIN-1 (arcsine) value of the specified BCD value is operated.

■ Function definition BOOL BASIN_MD (BOOL EN, ANY16(3) S1, ANY16 D);

| Argument Name | IN/OUT | Description | |
|---------------|--------|--|--|
| EN | IN | Execution condition result is TRUE) | n (Function is executed only when the |
| S1 | IN | Operation result (ARRAY [02] OF ANY16) | S [0] Sign (positive: 0, negative: 1) S [1] Integer part (BCD 4-digit data) S [2] Fraction part (BCD 4-digit data) |
| D | OUT | Operation result (hea | ad number of device) (BCD 4-digit data |

| I | Return Value | Description |
|---|--------------|---------------------|
| | BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the SIN-1 value of the value specified in
- (* BasinArrayData is operated, and the result is stored into Result. *)
 BASIN_MD (X0, BasinArrayData, Result);

*)



- Corresponding MELSEC command
 - BASIN (BCD type SIN-1 operation)

5.18.20 BCD type COS⁻¹ operation BACOS_MD

The COS-1 (arccosine) value of the specified BCD value is operated.

■ Function definition

BOOL BACOS_MD (BOOL EN, ANY16(3) S1, ANY16 D);

| Argument Name | IN/OUT | | De | escription |
|---------------|--------|-------------------------------------|--------|------------------------------------|
| EN | IN | Execution condition result is TRUE) | (Fund | ction is executed only when the |
| | | Data to be COS-1 | S [0] | Sign (positive: 0, negative: 1) |
| S1 | IN | (arccosine) operated | S [1] | Integer part (BCD 4-digit data) |
| 31 | IIV | (ARRAY [02] OF ANY16) | S [2] | Fraction part (BCD 4-digit data) |
| D | OUT | Operation result (hea | ad num | nber of device) (BCD 4-digit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the COS-1 value of the value specified *)
- (* in BacosArrayData is operated, and the result is stored into Result. *)
 BACOS_MD (X0, BacosArrayData, Result);



- Corresponding MELSEC command
 - BACOS (BCD type COS-1 operation)

For the usable data type, refer to "3.2.2 About ANY type".

5- 97 5- 97

5.18.21 BCD type TAN-1 operation BATAN MD

The TAN-1 (arctangent) value of the specified BCD value is operated.

■ Function definition

BOOL BATAN_MD (BOOL EN, ANY16(3) S1, ANY16 D);

| | , | · · · · | ,. | |
|---------------|--------|-------------------------------------|--------|----------------------------------|
| Argument Name | IN/OUT | | De | escription |
| EN | IN | Execution condition result is TRUE) | (Fund | ction is executed only when the |
| | | Head number of | S [0] | Sign (positive: 0, negative: 1) |
| | | device that stores | S [1] | Integer part (BCD 4-digit data) |
| S1 | IN | data to be operated | | |
| | | (ARRAY [02] OF | S [2] | Fraction part (BCD 4-digit data) |
| | | ANY16) | | |
| D | OUT | Operation result (BC | D 4-di | git data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the TAN-1 value of the value specified in *)
- (* BatanArrayData is operated, and the result is stored into Result. *)
 BATAN_MD (X0, BatanArrayData, Result);



- Corresponding MELSEC command
 - BATAN (BCD type TAN-1 operation)

For the usable data type, refer to "3.2.2 About ANY type".

5-98

5.19 Data Control

5.19.1 Upper/lower limit control LIMIT MD

The output value is controlled depending on whether the specified BIN 16-bit data is within the upper/lower limit value range or not.

■ Function definition

BOOL LIMIT_MD (BOOL EN, ANY16 S1, ANY16 S2, ANY16 S3, ANY16 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Lower limit value (BIN 16-bit data) |
| S2 | IN | Upper limit value (BIN 16-bit data) |
| S3 | IN | Input value (BIN 16-bit data) |
| D | OUT | Output value (BIN 16-bit data) |

Remarks: The output value is controlled as described below.

When S1 (lower limit value) > S3 (input value)

When S2 (upper limit value) < S3 (input value)

......S2 (upper limit value) → D (output value)

When S1 (lower limit value) \leq S3 (input value) \leq S2 (upper limit value)

......S3 (input value) → D (output value)

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the output value is stored into Result *)
- (* depending on whether or not the input value specified in iData3 is within the *)
- (* per/lower limit value range specified in iData1 and iData 2. *)
 LIMIT_MD (X0, iData1, iData2, iData3, Result);



Corresponding MELSEC command

- LIMIT (16-bit upper/lower limit control)

For the usable data type, refer to "3.2.2 About ANY type".

5- 99 5- 99

5.19.2 32-bit data upper/lower limit control DLIMIT_MD

The output value is controlled depending on whether the specified BIN 32-bit data is within the upper/lower limit value range or not.

■ Function definition

BOOL DLIMIT_MD (BOOL EN, ANY32 S1, ANY32 S2, ANY32 S3, ANY32 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | l IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Lower limit value (BIN 32-bit data) |
| S2 | IN | Upper limit value (BIN 32-bit data) |
| S3 | IN | Input value (BIN 32-bit data) |
| D | OUT | Output value (BIN 32-bit data) |

Remarks: The output value is controlled as described below.

When S1 (lower limit value) > S3 (input value)

......S1 (lower limit value) → D (output value)

When S2 (upper limit value) < S3 (input value)

......S2 (upper limit value) \rightarrow D (output value)

When S1 (lower limit value) \leq S3 (input value) \leq S2 (upper limit value)

......S3 (input value) → D (output value)

| Re | eturn Value | Description |
|----|-------------|---------------------|
| | BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the output value is stored into Result *)
- (* depending on whether or not the input value specified in dData3 is within the
- (* upper/lower limit value range specified in dData1 and dData 2. *)

 DLIMIT_MD (X0, dData1, dData2, dData3, Result);



- Corresponding MELSEC command
 - DLIMIT (32-bit upper/lower limit control)

For the usable data type, refer to "3.2.2 About ANY type".

5- 100 5- 100

5.19.3 Dead band control BAND_MD

The output value is controlled depending on whether the specified BIN 16-bit data is within the upper/lower limit range of the specified dead band or not.

■ Function definition BOOL BAND_MD (BOOL EN, ANY16 S1, ANY16 S2, ANY16 S3, ANY16 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Lower limit value data of dead band (BIN 16-bit data) |
| S2 | IN | Upper limit value data of dead band (BIN 16-bit data) |
| S3 | IN | Input value (BIN 16-bit data) |
| D | OUT | Output value (BIN 16-bit data) |

Remarks: The output value is controlled as described below.

When S1 (lower limit value) > S3 (input value)

When S2 (upper limit value) < S3 (input value)

......S3 (input value) - S2 (upper limit value) -> D (output value)

When S1 (lower limit value) \leq S3 (input value) \leq S2 (upper limit value)

......0 → D (output value)

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the output value is stored into Result *)
- (* depending on whether or not the input value specified in iData3 is within the
- (* upper/lower limit range of the dead band specified in iData1 and iData2. *)
 BAND MD (X0, iData1, iData2, iData3, Result);



- Corresponding MELSEC command
 - BAND (16-bit dead band control)

For the usable data type, refer to "3.2.2 About ANY type".

*)

5- 101 5- 101

5.19.4 32-bit data dead band control DBAND_MD

The output value is controlled depending on whether the specified BIN 32-bit data is within the upper/lower limit range of the specified dead band or not.

■ Function definition BOOL DBAND_MD (BOOL EN, ANY32 S1, ANY32 S2, ANY32 S3, ANY32 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Lower limit value data of dead band (BIN 32-bit data) |
| S2 | IN | Upper limit value data of dead band (BIN 32-bit data) |
| S3 | IN | Input value (BIN 32-bit data) |
| D | OUT | Output value (BIN 32-bit data) |

Remarks: The output value is controlled as described below.

When S1 (lower limit value) > S3 (input value)

When S2 (upper limit value) < S3 (input value)

......S3 (input value) - S2 (upper limit value) → D (output value)

When S1 (lower limit value) \leq S3 (input value) \leq S2 (upper limit value)

...... $0 \rightarrow D$ (output value)

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the output value is stored into Result *)
- (* depending on whether or not the input value specified in iData3 is within the
- *) (* upper/lower limit range of the dead band specified in iData1 and iData2. *) DBAND MD (X0, dData1, dData2, dData3, Result);



- Corresponding MELSEC command
 - DBAND (32-bit dead band control)

For the usable data type, refer to "3.2.2 About ANY type".

5- 102 5-102

5.19.5 Bit zone control ZONE MD

The output value is zone-controlled with a bias value added to the specified BIN 16-bit data.

■ Function definition

BOOL ZONE MD (BOOL EN, ANY16 S1, ANY16 S2, ANY16 S3, ANY16 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Negative bias value added to input value (BIN 16-bit data) |
| S2 | IN | Positive bias value added to input value (BIN 16-bit data) |
| S3 | IN | Input value (BIN 16-bit data) |
| D | OUT | Output value (BIN 16-bit data) |

Remarks: The output value is controlled as described below.

When S3 (input value) < 0

......S3 (input value) + S1 (negative bias value) \rightarrow D (output value)

When S3 (input value) = 0 $0 \rightarrow D$ (output value)

When S3 (input value) > 0

...... S3 (input value) + S1 (positive bias value) → D (output value)

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the bias value specified in iData1 or *
- (* iData2 is added to the input value specified in iData3, and the result is stored *)
- (* into Result. *)

ZONE_MD (X0, iData1, iData2, iData3, Result);



Corresponding MELSEC command

ZONE (16-bit zone control)

For the usable data type, refer to "3.2.2 About ANY type".

5- 103 5- 103

5.19.6 32-bit data bit zone control DZONE_MD

The output value is zone-controlled with a bias value added to the specified BIN 32-bit data.

■ Function definition

BOOL DZONE MD (BOOL EN, ANY32 S1, ANY32 S2, ANY32 S3, ANY32 D);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Negative bias value added to input value (BIN 32-bit data) |
| S2 | IN | Positive bias value added to input value (BIN 32-bit data) |
| S3 | IN | Input value (BIN 32-bit data) |
| D | OUT | Output value (BIN 32-bit data) |

Remarks: The output value is controlled as described below.

When S3 (input value) < 0

......S3 (input value) + S1 (negative bias value) \rightarrow D (output value)

When S3 (input value) = 0 $0 \rightarrow D$ (output value)

When S3 (input value) > 0

...... S3 (input value) + S1 (positive bias value) → D (output value)

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the bias value specified in iData1 or *
- (* iData2 is added to the input value specified in iData3, and the result is stored *)
- (* into Result. *)

DZONE_MD (X0, dData1, dData2, dData3, Result);



Corresponding MELSEC command

- DZONE (32-bit zone control)

For the usable data type, refer to "3.2.2 About ANY type".

5- 104 5- 104

5.19.7 File register block No. switching RSET MD

The block No. of the file registers used in a program is changed into the specified block No.

■ Function definition

BOOL RSET_MD (BOOL EN, ANY16 S1);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | New block No. data (BIN 16-bit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the block No. of the file registers used *)
- (* in the program is changed into the block No. stored in the device specified in iData. *) RSET_MD (X0, iData);



Corresponding MELSEC command

RSET (File register block No. switching)

5.19.8 Set of file register file QDRSET_M

The file name of the file registers used in a program is changed into the specified file name.

■ Function definition BOOL QDRSET_M (BOOL EN, STRING S1);

| Argument Name | IN/OUT | Description |
|---------------|--------|--|
| EN | IN | Execution condition (Function is executed only when the |
| □N | | result is TRUE) |
| S1 | IN | "Drive No.: File name" of target file registers (character |
| 31 | | string data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the file name of the file registers of
- *) (* drive No. 1 is changed into "ABS.QDR". *) QDRSET_M (X0, "1: ABC");



Corresponding MELSEC command

QDRSET (Set of file register file)

For the usable data type, refer to "3.2.2 About ANY type".

5-105 5-105

5.19.9 Set of comment file QCDSET_M

The file name of the comment file used in a program is changed into the specified file name.

■ Function definition BOOL QDRSET

BOOL QDRSET_M (BOOL EN, STRING S1);

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | l IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | "Drive No.: File name" of target comment file (character string data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

(* When execution condition X0 turns ON, the file name of the comment file of the drive No. 3 is changed into "DEF.QCD".

QCDSET_M (X0, "3: DEF");



- Corresponding MELSEC command
 - QCDSET (Set of comment file)

5- 106 5- 106

5.20 Clock

5.20.1 Read of clock data DATERD_MD

The "year, month, day, hour, minute, second, day of week" is read from the clock element of the QCPU/LCPU. They are stored into the specified destination as BIN values.

■ Function definition

BOOL DATERD_MD (BOOL EN, ANY16(7) S);

| Argument Name | IN/OUT | | Description |
|---------------|--------|---|-----------------------------------|
| EN | IN | Execution condition (Furesult is TRUE) | unction is executed only when the |
| D | OUT | Read clock data (ARRAY [06] OF ANY16) | D [0] Year (1980 to 2079) |
| | | | D [1] Month (1 to 12) |
| | | | D [2] Day (1 to 31) |
| | | | D [3] Hour (0 to 23) |
| | | | D [4] Minute (0 to 59) |
| | | | D [5] Second (0 to 59) |
| | | | D [6] Day of week (0 to 6) |

| Return Value | Description | |
|--------------|---------------------|--|
| BOOL | Execution condition | |

Example of use

- (* When execution condition X0 turns ON, the "year, month, day, hour, minute,
- (* second, day of week" are read from the clock element of the QCPU/LCPU,
 - *) *)
- (* and stored into the device specified in TimeData as BIN values. DATERD_MD (X0, TimeData);



- Corresponding MELSEC command
 - DATERD (Read of clock data)

For the usable data type, refer to "3.2.2 About ANY type".

*)

5-107 5-107

5.20.2 Write of clock data DATEWR_MD

The clock data "year, month, day, hour, minute, second, day of week" are written to the clock element of the QCPU/LCPU.

■ Function definition BOOL DATEWR_MD (BOOL EN, ANY16(7) S);

| Argument Name | IN/OUT | | Description | on |
|---------------|--------------------------|--|----------------|------------------------|
| EN | IN | Execution condition (Furesult is TRUE) | ınction is | executed only when the |
| | | | S [0] | Year (1980 to 2079) |
| | | | S [1] | Month (1 to 12) |
| | Clock data to be written | S [2] | Day (1 to 31) | |
| S | | S [3] | Hour (0 to 23) | |
| | | (ARRAY [06] OF ANY16) | S [4] | Minute (0 to 59) |
| | | OI ANTIO) | S [5] | Second (0 to 59) |
| | | | S [6] | Day of week (0 to 6) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the clock data stored in TimeData are *)
- (* written to the clock element of the QCPU/LCPU. *)
 DATEWR_MD (X0, TimeData);



- Corresponding MELSEC command
 - DATEWR (Write of clock data)

For the usable data type, refer to "3.2.2 About ANY type".

5- 108 5- 108

5.20.3 Addition of clock data DATEPLUS_M

The specified time data is added to the specified time-of-day data.

■ Function definition

BOOL DATEPLUS_M (BOOL EN, ANY16(3) S1, ANY16(3) S2, ANY16(3) D);

| Argument Name | IN/OUT |] | Description | on |
|---------------|--------|--|-------------|------------------------|
| EN | IN | Execution condition (Furesult is TRUE) | nction is | executed only when the |
| | | Time-of-day data to | S1 [0] | Hour (0 to 23) |
| S1 | IN | which data will be added | S1 [1] | Minute (0 to 59) |
| | | (ARRAY [02] OF ANY16) | S1 [2] | Second (0 to 59) |
| | | Time data that will be | S2 [0] | Hour (0 to 23) |
| S2 | IN | added to data (ARRAY | S2 [1] | Minute (0 to 59) |
| | | [02] OF ANY16) | S2 [2] | Second (0 to 59) |
| | | Addition result time-of- | D [0] | Hour (0 to 23) |
| D | OUT | day data (ARRAY | D [1] | Minute (0 to 59) |
| | | [02] OF ANY16) | D [2] | Second (0 to 59) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the time data specified in TimeData2 *)
- (* is added to the time-of-day data specified in TimeData1, and the addition *)
- (* result is stored into Result. *)

DATEPLUS_M (X0, TimeData1, TimeData2, Result);



- Corresponding MELSEC command
 - DATE+ (Addition of clock data)

For the usable data type, refer to "3.2.2 About ANY type".

5- 109 5- 109

The specified time data is subtracted from the specified time-of-day data.

■ Function definition

BOOL DATEMINUS_M (BOOL EN, ANY16(3) S1, ANY16(3) S2, ANY16(3) D);

| Argument Name | IN/OUT |] | Descripti | on |
|---------------|--------|--|------------------|---------------------------------|
| EN | IN | Execution condition (Furesult is TRUE) | nction is | executed only when the |
| S1 | IN | Time-of-day data from which data will be | S1 [0] S1 [1] | Hour (0 to 23) Minute (0 to 59) |
| 31 | IIV | subtracted (ARRAY [02] OF ANY16) | S1 [2] | Second (0 to 59) |
| | | Time data that will be | S2 [0] | Hour (0 to 23) |
| S2 | IN | subtracted from data | S2 [1] | Minute (0 to 59) |
| 02 | IIV | (ARRAY [02] OF ANY16) | S2 [2] | Second (0 to 59) |
| | | Subtraction result | D [0] | Hour (0 to 23) |
| D | OUT | time-of-day data | D [1] | Minute (0 to 59) |
| D | 001 | (ARRAY [02] OF ANY16) | D [2] | Second (0 to 59) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the time data specified in TimeData2 *)
- (* is subtracted from the time-of-day data specified in TimeData1, and the
- (* subtraction result is stored into Result. *)

DATEMINUS_M (X0, TimeData1, TimeData2, Result);



- Corresponding MELSEC command
 - DATE- (Subtraction of clock data)

For the usable data type, refer to "3.2.2 About ANY type".

*)

5- 110 5- 110

5.20.5 Clock data format conversion (hour, minute, second → second) SECOND_M

The specified time data is converted into second.

■ Function definition BOOL SECOND_M (BOOL EN, ANY16(3) S, ANY32 D);

| Argument Name | IN/OUT | Description | | |
|---------------|--------|--|----------------------|---------------|
| EN | IN | Execution condition (Furesult is TRUE) | nction is executed o | only when the |
| | | Clock data to be | S [0] Hour (0 to | • |
| S | IN | converted (ARRAY | S [1] Minute (0 t | to 59) |
| | | [02] OF ANY16) | S [2] Second (0 | to 59) |
| D | OUT | Conversion result clock | data (second) (BIN | 32-bit data) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

- Example of use
 - (* When execution condition X0 turns ON, the time data specified in TimeData
 - (* is converted into second, and the result is stored into Result. *)
 SECOND_M (X0, TimeData, Result);



- Corresponding MELSEC command
 - SECOND (Clock data format conversion)

5.20.6 Clock data format conversion (second→hour, minute, second) HOUR_M

The specified data in second is converted into hour, minute, second.

■ Function definition BOOL HOUR_M (BOOL EN, ANY32 S1, ANY16(3) D);

| Argument Name | IN/OUT | | Description |
|---------------|--------|--|-----------------------------------|
| EN | IN | Execution condition (Furesult is TRUE) | unction is executed only when the |
| S1 | IN | Clock data to be conve | rted (second) (BIN 32-bit data) |
| | | Conversion result | D [0] Hour (0 to 23) |
| D | OUT | clock data (ARRAY | D [1] Minute (0 to 59) |
| | | [02] OF ANY16) | D [2] Second (0 to 59) |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

- Example of use
 - (* When execution condition X0 turns ON, the data in second specified in dData *)
 - (* is converted into hour, day, second, and the result is stored into Result. HOUR_M (X0, dData, TimeData);



- Corresponding MELSEC command
 - HOUR (Clock data format conversion)

For the usable data type, refer to "3.2.2 About ANY type".

5- 111 5- 111

5.21 Program Control

5.21.1 Program standby PSTOP M

The program of the specified file name is put in a standby status.

■ Function definition BOOL PSTOP_M (BOOL EN, STRING S1);

| Argument Name | IN/OUT | Description |
|---------------|--------|--|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | File name of program to be put in standby status (character string data) |

Remarks: Only the program stored in the program memory (drive No.: 0) can be placed in a standby status.

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the program whose file name is
- (* "ABC" is placed in a standby status. *)
 PSTOP_M (X0, "ABC");



Corresponding MELSEC command

PSTOP (Program standby command)

5.21.2 Program output OFF standby POFF M

The program of the specified file name is brought into non-execution and put in a standby status.

■ Function definition BOOL POFF M (BOOL EN, STRING S1);

| Argument Name | IN/OUT | Description | | | |
|---------------|--------|---|--|--|--|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) | | | |
| S1 | I IN | File name of program to be brought into non-execution and put in a standby status (character string data) | | | |

Remarks: Only the program stored in the program memory (drive No.: 0) can be brought into non-execution and placed in a standby status.

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the program whose file name is
- (* "ABC" is brought into non-execution and placed in a standby status. *) POFF M (X0, sData);

*)



Corresponding MELSEC command

POFF (Program output OFF standby command)

5- 112 5- 112

5.21.3 Program scan execution registration PSCAN M

The program of the specified file name is put in a scan execution status.

■ Function definition BOOL PSCAN_M (BOOL EN, STRING S1);

| Argument Name | IN/OUT | Description | | | |
|---------------|--------|---|--|--|--|
| EN | l IN | Execution condition (Function is executed only when the result is TRUE) | | | |
| S1 | l IN | File name of program to be put in scan execution status (character string data) | | | |

Remarks: Only the program stored in the program memory (drive No.: 0) can be placed in a scan execution status.

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

(* When execution condition X0 turns ON, the program whose file name is

(* "ABC" is placed in a scan execution status. *)
PSCAN_M (X0, sData);



Corresponding MELSEC command

PSCAN (Program scan execution registration command)

5.21.4 Program low-speed execution registration PLOW_M

The program of the specified file name is put in a low-speed execution status.

■ Function definition BOOL PLOW_M (BOOL EN, STRING S1);

| Argument Name | IN/OUT | Description | | | |
|---------------|--------|--|--|--|--|
| EN | l IN | Execution condition (Function is executed only when the result is TRUE) | | | |
| S1 | l IN | File name of program to be put in low-speed execution status (character string data) | | | |

Remarks: Only the program stored in the program memory (drive No.: 0) can be placed in a low-speed execution status.

| Return Value | Description | | | |
|--------------|---------------------|--|--|--|
| BOOL | Execution condition | | | |

Example of use

(* When execution condition X0 turns ON, the program whose file name is

(* "ABC" is placed in a low-speed execution status. *) PLOW_M (X0, "ABC");



Corresponding MELSEC command

- PLOW (Program low-speed execution registration instruction)

5- 113 5- 113

5.22 Others

5.22.1 WDT reset WDT_M

The watchdog timer is reset in a sequence program.

■ Function definition BOOL WDT _M (BOOL EN);

| Argument Name IN/OUT | | Description | | | |
|----------------------|------|---|--|--|--|
| EN | l IN | Execution condition (Function is executed only when the result is TRUE) | | | |

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

(* When execution condition X0 turns ON, the watchdog timer is reset in the *)

(* sequence program. *) WDT_M (X0);



- Corresponding MELSEC command
 - WDT (Watchdog timer reset)

5- 114 5- 114

6 IEC FUNCTIONS

How the functions are described

This manual describes the function definitions, arguments, return values and using examples of the IEC functions.

The IEC functions are created by combining the MELSEC common instructions. For the applicable devices of the IEC functions, the errors that may occur during execution of the functions, and the applicable CPU types, refer to the "MELSEC-Q/L

Programming Manual (Common Instruction)". The reference section is the section described in "Used Instructions" in the "© Example of use" table field.

6.1.6 Double precision integer type (DINT) \rightarrow real number type (REAL) conversion

DINT_TO_REAL_E

■ Function definition


● Argument → 6)

| Argument Name | IN/OUT | Description |
|---------------|--------|--|
| S1 IN | | Data to be converted (BIN 32-bit data) |

● Return ∨alue—→ 7)

| Return Value | Description | |
|--------------|--------------------------------------|--|
| REAL | Conversion result (real number data) | |

■ Example of use → 8)



- 1) Indicates the function of the function.
- 2) Indicates the data type of the function.
- 3) Indicates the function name.
- 4) Indicates the data type of the argument. (The STRING type is represented STRING (number of characters). It is represented STRING(6) when the number of characters is 6.)
- 5) Indicates the argument name.
- 6) Indicates the list (argument name, IN/OUT, description) of arguments used with the function.
- 7) Indicates the list (return value name, description) of return values used with the function.
- 8) Indicates the example of using the function. (Indicates the example that uses the actual device/label.)
- 9) This example is the one that uses a REAL type (real number type) label.
- 10) This example is the one that uses a DINT type (double word type) label.
- 11) Indicates the QCPU (Q mode)/L MELSEC common instruction corresponding to the function.

6


The following indicates the correspondences between the MELSEC instruction in the "MELSEC-Q/L Programming Manual (Common Instruction)" and the IEC function in this manual.

MELSEC-Q/L Programming Manual (Common Instruction) [MELSEC instruction]

6.3.3 Conversion from BIN 16 and 32-bit data to floating decimal →1) point (Single precision) (FLT(P),DFLT(P))



Basic model QCPU: The upper five digits of the serial No. are "04122" or larger.



- Integer data to be converted to 32-bit floating decimal point data or head number of the devices where the integer data is stored (BIN 16/32 bits)
- Head number of the devices where the converted 32-bit floating decimal point data will be stored (real number)

| Setting | Internal | Devices | R, ZR | Jill | \!!! | u:::\g::i | Zn | Constants | Other | — > 3\ |
|---------|----------|---------|---------|------|------|-----------|-----|-----------|-------|------------------|
| Data | Bit | Word | 11, 211 | Bit | Word | 0 (G | 211 | K, H | Other | 3) |
| s | 0 | | | 0 | | 0 | С |) | _ | |
| 0 | | | | _ | | 0 | O, | *1 | | |

*1:Available only in multiple Universal model QCPU and LCPU

[IEC function] in this manual

Example of use

| Argument Type | ST Program | Co | nversion Result | Used Instruction |
|---------------|-------------------------|------|-----------------|------------------|
| DINT | r_data1 := | LD | SM400 | LD,DFLT |
| | DINT_TO_REAL(di_data1); | DFLT | di_data1 | |
| | | | r_data1 | 4) |

- 1) MELSEC instruction reference destination
- Applicable CPU typesCPU types that can use the instructions are indicated.
- 3) Applicable devices
- 4) MELSEC common instructions to be referred to

6.1 Type Conversion Functions

6.1.1 Boolean type (BOOL)→double precision integer type (DINT) conversion BOOL_TO_DINT BOOL TO DINT E

The specified Boolean type (BOOL) data is converted into double precision integer type (DINT) data.

■ Function definition

DINT BOOL_TO_DINT(BOOL S1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|---------------------------------|
| S1 | IN | Data to be converted (bit data) |

Return value

| Return Value | Description |
|--------------|-------------------------------------|
| DINT | Conversion result (BIN 32-bit data) |

Remarks: The data to be converted (bit data) is stored into the least significant bit of the return value.

Example of use

| Argument Type | ST Program | Conversion Result | | Used Instruction |
|---------------|------------------------|-------------------|----------|------------------|
| BOOL | di_data1 := | LD | b_data1 | LD, DMOV, LDI |
| | BOOL_TO_DINT(b_data1); | DMOV | K1 | |
| | | | di_data1 | |
| | | LDI | b_data1 | |
| | | DMOV | K0 | |
| | | | di_data1 | |

■ Function definition

BOOL BOOL_TO_DINT_E(BOOL EN, BOOL S1, DINT D1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be converted (bit data) |
| D1 | OUT | Conversion result (BIN 32-bit data) |

Return value

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the Boolean type data in bData is
- (* converted into double precision integer type (DINT) data, and the result is
- (* stored into Result. *)

*) *)

M0 := BOOL_TO _DINT_E (X0, bData, Result);

6.1.2 Boolean type (BOOL)→integer type (INT) conversion

BOOL_TO_INT BOOL_TO_INT_E

Boolean type (BOOL) data is converted into integer type (INT) data.

■ Function definition

INT BOOL_TO_INT (BOOL S1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|---------------------------------|
| S1 | IN | Data to be converted (bit data) |

Return value

| Return Value | Description |
|--------------|-------------------------------------|
| INT | Conversion result (BIN 16-bit data) |

Remarks: The data to be converted (bit data) is stored into the least significant bit of the return value.

Example of use

| Argument Type | ST Program | Conversion Result | | | Used Instruction |
|---------------|----------------------|-------------------|------|-----|------------------|
| INT | D50 := | LD | M100 | | LD, MOV, LDI |
| | BOOL_TO_INT(M100); | MOV | K1 | D50 | |
| | | LDI | M100 | | |
| | | MOV | K0 | D50 | |

■ Function definition

BOOL BOOL_TO_INT_E(BOOL EN, BOOL S1, INT D1);

Argument

| Argument Name | IN/OUT | Description | |
|---------------|--------|---|--|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) | |
| S1 | IN | Data to be converted (bit data) | |
| D1 | OUT | Conversion result (BIN 16-bit data) | |

Return value

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

(* When execution condition X0 turns ON, the Boolean type (BOOL) in bData is *)

*)

(* converted into the integer type (INT), and the result is stored into Result.

M0 := BOOL_TO _INT_E (X0, bData, Result);

6.1.3 Boolean type (BOOL)→character string type (STRING) conversion BOOL_TO_STR BOOL_TO_STR_E

Boolean type (BOOL) data is converted into character string type (STRING) data.

■ Function definition

STRING(2) BOOL_TO_STR (BOOL S1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|---------------------------------|
| S1 | IN | Data to be converted (bit data) |

Return value

| Return Value | Description |
|--------------|---|
| STRING (2) | Conversion result (character string data) |

Remarks: When the data to be converted (bit data) is 0, the return value is "0". When the data to be converted (bit data) is 1, the return value is "1".

Example of use

| Argument Type | ST Program | Con | version Re | sult | Used Instruction |
|---------------|-----------------------|-----|------------|--------|------------------|
| BOOL | s_ary1 := | LD | b_data1 | | LD, MOV, LDI |
| | BOOL_TO_STR(b_data1); | MOV | K49 | s_ary1 | |
| | | LDI | b_data1 | | |
| | | MOV | K48 | s_ary1 | |

■ Function definition

BOOL BOOL_TO_STR_E(BOOL EN, BOOL S1, STRING(2) D1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be converted (bit data) |
| D1 | OUT | Conversion result (character string data) |

Return value

| Return Value | Description | |
|--------------|---------------------|--|
| BOOL | Execution condition | |

Example of use

- (* When execution condition X0 turns ON, the Boolean type (BOOL) data in *)
- (* bData is converted into the character string type, and the result is stored into *)
- (* Result. *)

M0 := BOOL_TO _STR _E (X0, bData, Result);

6.1.4 Double precision integer type (DINT)→Boolean type (BOOL) conversion DINT_TO_BOOL

DINT_TO_BOOL DINT_TO_BOOL_E

*)

Double precision integer type (DINT) data is converted into Boolean type (BOOL) data.

■ Function definition

BOOL DINT_TO_BOOL (DINT S1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|--|
| S1 | IN | Data to be converted (BIN 32-bit data) |

Return value

| I | Return Value | Description | | |
|---|--------------|------------------------------|--|--|
| | BOOL | Conversion result (bit data) | | |

Remarks: When the data to be converted (BIN 32-bit data) is 0, the return value is "0". When the data to be converted (BIN 32-bit data) is other than 0, the return value is "1".

Example of use

| Argument Type | ST Program | Con | version Result | Used Instruction |
|---------------|-------------------------|-------|----------------|------------------|
| DINT | M100 := | LDD<> | di_data1 K0 | LDD<>, OUT |
| | DINT TO BOOL(di data1); | OUT | M100 | |

■ Function definition

BOOL DINT_TO_BOOL _E(BOOL EN, DINT S1, BOOL D1);

Argument

| Argument Name | IN/OUT | Description | |
|---------------|--------|--|--|
| EN | IN | Execution condition (Function is executed only when the result is TRUI | |
| S1 | IN | Data to be converted (BIN 32-bit data) | |
| D1 | OUT | Conversion result (bit data) | |

Return value

| Return Value | Description | |
|--------------|---------------------|--|
| BOOL | Execution condition | |

Example of use

- (* When execution condition X0 turns ON, the double precision integer type
- (* (DINT) data in dData is converted into the Boolean type (BOOL), and the *)
- (* result is stored into Result. *)

M0 := DINT_TO _BOOL_E (X0, dData, Result);

6.1.5 Double precision integer type (DINT) \rightarrow integer type (INT) conversion

DINT_TO_INT DINT_TO_INT_E

Double precision integer type (DINT) data is converted into integer type (INT) data.

■ Function definition

INT DINT_TO_INT (DINT S1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|--|
| S1 | IN | Data to be converted (BIN 32-bit data) |

Return value

| Return Value | Description | |
|--------------|-------------------------------------|--|
| INT | Conversion result (BIN 16-bit data) | |

Remarks: The lower 16 bits of the data to be converted (BIN 32-bit data) is stored in the return value.

The upper 16 bits are discarded.

Example of use

| Argument Type | ST Program | Con | version Result | Used Instruction |
|---------------|------------------------|-----|----------------|------------------|
| DINT | i_data1 := | LD | SM400 | LD,MOV |
| | DINT_TO_INT(di_data1); | MOV | di_data1 | |
| | | | i_data1 | |

■ Function definition

BOOL DINT_TO_INT_E(BOOL EN, DINT S1, INT D1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be converted (BIN 32-bit data) |
| D1 | OUT | Conversion result (BIN 16-bit data) |

Return value

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the double precision integer type *)
- (* (DINT) data in dData is converted into integer type (INT) data, and the result *)
- (* is stored into Result. *)

M0 := DINT_TO _INT_E (X0, dData, Result);

6.1.6 Double precision integer type (DINT)→real number type (REAL) conversion

DINT_TO_REAL_E

*)

Double precision integer type (DINT) data is converted into real number type (REAL) data.

■ Function definition

REAL DINT_TO_REAL (DINT S1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|--|
| S1 | IN | Data to be converted (BIN 32-bit data) |

Return value

| Return Value | Description | |
|--------------|--------------------------------------|--|
| REAL | Conversion result (real number data) | |

Example of use

| Argument Type | ST Program Conversion Result | | Used Instruction | |
|---------------|------------------------------|------|------------------|---------|
| DINT | r_data1 := | LD | SM400 | LD,DFLT |
| | DINT_TO_REAL(di_data1); | DFLT | di_data1 | |
| | | | r_data1 | |

■ Function definition

BOOL DINT_TO_REAL_E(BOOL EN, DINT S1, REAL D1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be converted (BIN 32-bit data) |
| D1 | OUT | Conversion result (real number data) |

Return value

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the double precision integer type
- (* (DINT) data in dData is converted into real number type (REAL) data, and the *)
- (* result is stored into Result. *)

M0 := DINT_TO _REAL_E (X0, dData, Result);

6.1.7 Double precision integer type (DINT)→character string type (STRING) conversion DINT_TO_STR DINT_TO_STR_E

Double precision integer type (DINT) data is converted into character string type (STRING) data.

■ Function definition

STRING(12) DINT_TO_STR (DINT S1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|--|
| S1 | IN | Data to be converted (BIN 32-bit data) |

Return value

| Return Value | Description |
|--------------|---|
| STRING (12) | Conversion result (character string data) |

Remarks: This function cannot be used with the Basic model QCPU.

Example of use

| Argument Type | ST Program | Conv | ersion Result | Used Instruction |
|---------------|----------------------|--------|---------------|------------------|
| DINT | s_ary1 := | LD | SM400 | LD,DBINDA |
| | DINT_TO_STR(K65535); | DBINDA | K65535 | |
| | | | s_ary1 | |

■ Function definition

BOOL DINT_TO_STR _E(BOOL EN, DINT S1, STRING(12) D1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be converted (BIN 32-bit data) |
| D1 | OUT | Conversion result (character string data) |

Return value

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

(* When execution condition X0 turns ON, the double precision integer type

(* (DINT) data in dData is converted into character string type data, and the

(* result is stored into Result. *)

*)

*)

M0 := DINT_TO_STR_E(X0, dData, Result);

6.1.8 Integer type (INT)→Boolean type (BOOL) conversion

INT_TO_BOOL_E

Integer type (INT) data is converted into Boolean type (BOOL) data.

■ Function definition

BOOL INT_TO_BOOL (INT S1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|--|
| S1 | IN | Data to be converted (BIN 16-bit data) |

Return value

| I | Return Value | Description |
|---|--------------|------------------------------|
| | BOOL | Conversion result (bit data) |

Remarks: When the data to be converted (BIN 16-bit data) is 0, the return value is "0". When the data to be converted (BIN 16-bit data) is other than 0, the return value is "1".

Example of use

| Argument Type | ST Program | Conversion Result | | Used Instruction |
|---------------|------------------------------------|-------------------|-----------|------------------|
| INT | b_data1 := INT_TO_BOOL(i_data1); | LD<> | i_data K0 | LD<>, OUT |
| | | OUT | b_data1 | |

■ Function definition

BOOL INT_TO_BOOL _E(BOOL EN, INT S1, BOOL D1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be converted (BIN 16-bit data) |
| D1 | OUT | Conversion result (bit data) |

Return value

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

(* When execution condition X0 turns ON, the integer type (INT) data in iData is *)

(* converted into Boolean type (BOOL) data, and the result is stored into Result. *) $M0 := INT_TO_BOOL_E(\ X0, \ iData, \ Result \) \ ;$

6.1.9 Integer type (INT)→double precision integer type (DINT) conversion

INT_TO_DINT INT_TO_DINT_E

*)

Integer type (INT) data is converted into double precision integer type (DINT) data.

■ Function definition

DINT INT_TO_DINT (INT S1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|--|
| S1 | IN | Data to be converted (BIN 16-bit data) |

Return value

| Return Value | Description |
|--------------|-------------------------------------|
| DINT | Conversion result (BIN 32-bit data) |

Example of use

| Argument Type | ST Program | Cor | nversion Result | Used Instruction |
|---------------|----------------------|-----|-----------------|------------------|
| INT | di_data1 := | LD | SM400 | LD,DBL |
| | INT_TO_DINT(D500); | DBL | D500 | |
| | | | di_data1 | |

■ Function definition

BOOL INT_TO_DINT _E(BOOL EN, INT S1, DINT D1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be converted (BIN 16-bit data) |
| D1 | OUT | Conversion result (BIN 32-bit data) |

Return value

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

```
(* When execution condition X0 turns ON, the integer type (INT) data in iData is *)
```

(* converted into double precision integer type (DINT) data, and the result is

(* stored into Result. *)

M0 := INT_TO_DINT_E(X0, iData, Result);

6 - 11 6 - 11

6.1.10 Integer type (INT)→real number type (REAL) conversion

INT_TO_REAL INT_TO_REAL_E

Integer type (INT) data is converted into real number type (REAL) data.

■ Function definition

REAL INT_TO_REAL (INT S1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|--|
| S1 | IN | Data to be converted (BIN 16-bit data) |

Return value

| Return Value | Description |
|--------------|--------------------------------------|
| REAL | Conversion result (real number data) |

Example of use

| Argument Type | ST Program | Conversion Result | | Used Instruction |
|---------------|--------------------|-------------------|------------|------------------|
| INT | w_Real1:= | LD | SM400 | LD,FLT |
| | INT_TO_REAL(D0); | FLT | D0 w_Real1 | |

■ Function definition

BOOL INT_TO_REAL_E(BOOL EN, INT S1, REAL D1);

Argument

| Argument Name | IN/OUT | Description | |
|---------------|--------|---|--|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) | |
| S1 | IN | Data to be converted (BIN 16-bit data) | |
| D1 | OUT | Conversion result (real number data) | |

Return value

| Return Valu | е | Description |
|-------------|---------------------|-------------|
| BOOL | Execution condition | |

Example of use

- (* When execution condition X0 turns ON, the integer type (INT) data in iData is *)
- (* converted into real number type (REAL) data, and the result is stored into *)
- (* Result. *)

M0 := INT_TO_REAL_E(X0, iData, Result);

6.1.11 Integer type (INT)→character string type (STRING) conversion

INT_TO_STR INT_TO_STR_E

Integer type (INT) data is converted into character string type (STRING) data.

■ Function definition

STRING(8) INT_TO_STR (INT S1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|--|
| S1 | IN | Data to be converted (BIN 16-bit data) |

Return value

| Return Value | Description | |
|--------------|---|--|
| STRING (8) | Conversion result (character string data) | |

Remarks: This function cannot be used with the Basic model QCPU.

Example of use

| Argument Type | ST Program | Con | version Result | Used Instruction |
|---------------|-----------------------------|-------|----------------|------------------|
| INT | w_Str1 := INT_TO_STR(D0); | LD | SM400 | LD,BINDA |
| | | BINDA | D0 w_Str1 | |

■ Function definition

BOOL INT_TO_STR_E(BOOL EN, INT S1, STRING(8) D1);

Argument

| Argument Name | IN/OUT | Description | |
|---------------|--------|---|--|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) | |
| S1 | IN | ata to be converted (BIN 16-bit data) | |
| D1 | OUT | Conversion result (character string data) | |

Return value

| Return Value | Description | |
|--------------|---------------------|--|
| BOOL | Execution condition | |

Example of use

(* When execution condition X0 turns ON, the integer type (INT) data in iData is *)

(* converted into character string type data, and the result is stored into Result. *) $M0 := INT_TO_STR_E(\ X0,\ iData,\ Result\)\ ;$

6.1.12 Real number type (REAL) \rightarrow double precision integer type (DINT) conversion REAL_TO_DINT_E

The specified real number type (REAL) data is converted into double precision integer type (DINT) data.

■ Function definition

DINT REAL_TO_DINT(REAL S1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| S1 | IN | Data to be converted (real number data) |

Return value

| Return Value | Description | |
|--------------|-------------------------------------|--|
| DINT | Conversion result (BIN 32-bit data) | |

Example of use

| Argument Type | ST Program | Conversion Result | | Used Instruction |
|---------------|------------------------|-------------------|----------|------------------|
| REAL | w_DWord1:= | LD | SM400 | LD,DINT |
| | REAL_TO_DINT(w_Real1); | DINT | w_Real1 | |
| | | | w_DWord1 | |

■ Function definition

BOOL REAL_TO_DINT_E(BOOL EN, REAL S1, DINT D1);

Argument

| - 1 | | | |
|-----|---------------|--------|---|
| | Argument Name | IN/OUT | Description |
| | EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| | S1 | IN | Data to be converted (real number data) |
| | D1 | OUT | Conversion result (BIN 32-bit data) |

Return value

| Return Value | Description | |
|--------------|---------------------|--|
| BOOL | Execution condition | |

Example of use

- (* When execution condition X0 turns ON, the real number type (REAL) data in *)
- (* rData is converted into double precision integer type (DINT) data, and the *)
- (* result is stored into Result. *)

M0 := REAL_TO_DINT_E(X0, rData, Result);

6.1.13 Real number type (REAL)→integer type (INT) conversion

REAL_TO_INT_E

Real number type (REAL) data is converted into integer type (INT) data.

■ Function definition

INT REAL_TO_INT (REAL S1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| S1 | IN | Data to be converted (real number data) |

Return value

| Return Value | Description |
|--------------|-------------------------------------|
| INT | Conversion result (BIN 16-bit data) |

Example of use

| Argument Type | ST Program | | Conversion Result | Used Instruction |
|---------------|-----------------------|-----|-------------------|------------------|
| REAL | w_Word1:= | LD | SM400 | LD,INT |
| | REAL_TO_INT(w_Real1); | INT | w_Real1 | |
| | | | w_Word1 | |

■ Function definition

BOOL REAL_TO_INT_E(BOOL EN, REAL S1, INT D1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be converted (real number data) |
| D1 | OUT | Conversion result (BIN 16-bit data) |

Return value

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the real number type (REAL) data in *)
- (* rData is converted into integer type (INT) data, and the result is stored into *)
- (* Result. *)

M0 := REAL_TO_INT_E(X0, rData, Result);

6.1.14 Real number type (REAL)→character string type (STRING) conversion

REAL_TO_STR REAL_TO_STR_E

Real number type (REAL) data is converted into character string type data.

■ Function definition

STRING(14) REAL_TO_STR (REAL S1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| S1 | IN | Data to be converted (real number data) |

Return value

| Return Value | Description |
|--------------|---|
| STRING (14) | Conversion result (character string data) |

Note: The display format of the ESTR instruction is the Exponent format, the total number of digits is 13, and the number of fraction part digits is 5.

Example of use

| Argument Type | ST Program | Co | nversion Result | Used Instruction |
|---------------|---------------------------------|------|-----------------|------------------|
| REAL | w_Str1:= REAL_TO_STR(w_Real1); | LD | SM400 | LD,MOV,ESTR |
| | | MOV | K1 D10237 | |
| | | MOV | K13 D10238 | |
| | | MOV | K5 D10239 | |
| | | ESTR | w_Real1 D10237 | |
| | | | w_Str1 | |

■ Function definition

BOOL REAL_TO_STR _E(BOOL EN, REAL S1, STRING(14) D1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be converted (real number data) |
| D1 | OUT | Conversion result (character string data) |

Return value

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the real number type (REAL) data in *)
- (* rData is converted into character string type data, and the result is stored into *)
- (* Result. *)

M0 := REAL_TO_STR_E(X0, rData, Result);

6.1.15 Character string type (STRING)→Boolean type (BOOL) conversion

STR_TO_BOOL_E

Character string type (STRING) data is converted into Boolean type (BOOL) data.

■ Function definition

BOOL STR_TO_BOOL (STRING(2) S1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|--|
| S1 | IN | Data to be converted (character string data) |

Return value

| Return Value | Description |
|--------------|------------------------------|
| BOOL | Conversion result (bit data) |

Remarks: When the data to be converted (character string data) is 0, the return value is "0". When the data to be converted (character string data) is other than 0, the return value is "1".

Example of use

| Argument Type | ST Program | Conversion Result | | Used Instruction |
|---------------|----------------------|-------------------|------------|------------------|
| STRING | w_Bit1:= | LD<> | w_Str1 K48 | LD<>,OUT |
| | STR_TO_BOOL(w_Str1); | OUT | w_Bit1 | |

■ Function definition

BOOL STR_TO_BOOL_E(BOOL EN, STRING(2) S1, BOOL D1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be converted (character string data) |
| D1 | OUT | Conversion result (bit data) |

Return value

| Return Value | Description | | |
|--------------|---------------------|--|--|
| BOOL | Execution condition | | |

Example of use

(* When execution condition X0 turns ON, the character string type data in

(* sData is converted into Boolean type data, and the result is stored into Result. *)

M0 := STR_TO_BOOL_E(X0, sData, Result) ;

6.1.16 Character string type (STRING)→double precision integer type (DINT) conversion STR_TO_DINT STR TO DINT E

Character string type (STRING) data is converted into double precision integer type (DINT) data.

■ Function definition

DINT STR_TO_DINT (STRING(12) S1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|--|
| S1 | IN | Data to be converted (character string data) |

Return value

| Return Value | Description |
|--------------|-------------------------------------|
| DINT | Conversion result (BIN 32-bit data) |

Remarks: This function cannot be used with the Basic model QCPU.

Example of use

| Argument Type | ST Program | Conv | ersion Result | Used Instruction |
|---------------|---------------------|--------|---------------|------------------|
| STRING | w_DWord1:= | LD | SM400 | LD,DDABIN |
| | STR_TO_DINT("123"); | DDABIN | "123" | |
| | | | w_DWord1 | |

■ Function definition

BOOL STR_TO_DINT _E(BOOL EN, STRING(12) S1, DINT D1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be converted (character string data) |
| D1 | OUT | Conversion result (BIN 32-bit data) |

Return value

| Return Value | Description | | |
|--------------|---------------------|--|--|
| BOOL | Execution condition | | |

Example of use

(* When execution condition X0 turns ON, the character string type data in *)

(* sData is converted into double precision integer type (DINT) data, and the *)

(* result is stored into Result. *)

M0 := STR TO DINT E(X0, sData, Result);

6 - 18 6 - 18

6.1.17 Character string type (STRING)→integer type (INT) conversion

STR_TO_INT STR_TO_INT_E

Character string type (STRING) data is converted into integer type (INT) data.

■ Function definition

INT STR_TO_INT (STRING(6) S1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|--|
| S1 | IN | Data to be converted (character string data) |

Return value

| Return Value | Description |
|--------------|-------------------------------------|
| INT | Conversion result (BIN 16-bit data) |

Remarks: This function cannot be used with the Basic model QCPU.

Example of use

| Argument Type | ST Program | Conv | version Result | Used Instruction |
|---------------|---------------------|-------|----------------|------------------|
| STRING | w_Word1:= | LD | SM400 | LD,DABIN |
| | STR_TO_INT(w_Str1); | DABIN | w_Str1 w_Word1 | |

■ Function definition

BOOL STR_TO_INT _E(BOOL EN, STRING(6) S1, INT D1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be converted (character string data) |
| D1 | OUT | Conversion result (BIN 16-bit data) |

Return value

| Return Value | Description | |
|--------------|---------------------|--|
| BOOL | Execution condition | |

Example of use

- (* When execution condition X0 turns ON, the character string type data in *)
- (* sData is converted into integer type (INT) data, and the result is stored into *)
- (* Result. *)

M0 := STR_TO_INT_E(X0, sData, Result);

6.1.18 Character string type (STRING)→real number type (REAL) conversion

STR_TO_REAL_E

Character string type (STRING) data is converted into real number type (REAL) data.

■ Function definition

REAL STR_TO_REAL (STRING(24) S1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|--|
| S1 | IN | Data to be converted (character string data) |

Return value

| Return Value | Description | |
|--------------|--------------------------------------|--|
| REAL | Conversion result (real number data) | |

Remarks:

Example of use

| Argument Type | ST Program | Conv | version Result | Used Instruction |
|---------------|----------------------|------|----------------|------------------|
| STRING | w_Real1:= | LD | SM400 | LD,EVAL |
| | STR_TO_REAL(w_Str1); | EVAL | w_Str1 w_Real1 | |

■ Function definition

BOOL STR_TO_REAL_E(BOOL EN, STRING(24) S1, REAL D1);

Argument

| Argument Name | IN/OUT | Description | |
|--|---|--|--|
| EN | EN IN Execution condition (Function is executed only when the result is | | |
| S1 IN Data to be converted (character string data) | | Data to be converted (character string data) | |
| D1 | OUT | Conversion result (real number data) | |

Return value

| Return Value | Description | |
|--------------|---------------------|--|
| BOOL | Execution condition | |

Example of use

(* When execution condition X0 turns ON, the character string type data in *)

(* sData is converted into real number type (REAL) data, and the result is stored *)

(* into Result. *)

M0 := STR_TO_REAL_E(X0, sData, Result);

6.2 Numerical Functions (General Functions)

6.2.1 Absolute value ABS

ABS E

The absolute value of the specified data is operated.

■ Function definition

ANY_NUM ABS (ANY_NUM S1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| S1 | IN | Data whose absolute value will be found |

Return value

| Return Value | Description | |
|--------------|---------------------------------|--|
| ANY_NUM | Absolute value operation result | |

Example of use

| Argument Type | ST Program | Con | version Re | sult | Used Instruction |
|---------------|------------------------------|------|------------|------|---------------------|
| REAL | r_data1 := ABS(r_data2); | LD | SM400 | | LD,EMOV, LDE<, E* |
| | | EMOV | r_data2 | | |
| | | | r_data1 | | |
| | | LDE< | r_data2 | E0 | |
| | | E* | E-1 | | |
| | | | r_data2 | | |
| | | | r_data1 | | |
| INT | D0 := ABS(D1); | LD | SM400 | | LD,MOV, LD<, NEG |
| | | MOV | D1 | D0 | |
| | | LD< | D1 | K0 | |
| | | NEG | D0 | | |
| DINT | di_data1 := ABS(di_data2); | LD | SM400 | | LD,DMOV, LDD<, DCML |
| | | DMOV | di_data2 | | D+ |
| | | | di_data1 | | |
| | | LDD< | di_data2 | K0 | |
| | | DCML | di_data2 | | |
| | | | di_data1 | | |
| | | D+ | K1 | | |
| | | | di_data1 | | |

■ Function definition

BOOL ABS_E(BOOL EN, ANY_NUM S1, ANY_NUM D1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data whose absolute value will be found |
| D1 | OUT | Absolute value operation result |

Return value

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

(* When execution condition X0 turns ON, the absolute value of the data stored *) (* in iData is found, and the result is stored into Result. *)

M0 := ABS E(X0, iData, Result);

For the usable data type, refer to "3.2.2 About ANY type".

6 - 21 6 - 21

6.2.2 Square root SQRT SQRT_E

The square root of the specified data is operated.

■ Function definition

REAL SQRT (REAL S1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|--------------------------------------|
| S1 | IN | Data whose square root will be found |

Return value

| Return Value | Description |
|--------------|---|
| REAL | Square root operation result (real number data) |

Remarks:

Example of use

| Argument Type | ST Program | Cor | version Result | Used Instruction |
|---------------|-----------------------------|-----|----------------|------------------|
| REAL | r_data1 := SQRT(r_data2); | LD | SM400 | LD,SQR |
| | | SQR | r_data2 | |
| | | | r_data1 | |

■ Function definition

BOOL SQRT_E(BOOL EN, REAL S1, REAL D1);

Argument

| Argument Name | IN/OUT | Description | |
|---------------|--------|---|--|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) | |
| S1 | IN | Data whose square root will be found (real number data) | |
| D1 | OUT | Square root operation result (real number data) | |

Return value

| | Return Value | Description | | | |
|---|--------------|---------------------|--|--|--|
| I | BOOL | Execution condition | | | |

Example of use

```
(* When execution condition X0 turns ON, the square root of the data stored in *)
(* rData is found, and the result is stored into Result. *)
M0 := SQRT_E( X0, rData, Result );
```

6.3 Numeric Functions (Logarithm Functions)

6.3.1 Natural logarithm

LN LN E

The natural logarithm of the specified data is operated.

■ Function definition

REAL LN(REAL S1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| S1 | IN | Data whose natural logarithm will be found (real number data) |

Return value

| Return Value | Description |
|--------------|---|
| REAL | Natural logarithm operation result (real number data) |

Remarks:

Example of use

| Argument Type | ST Program | Со | nversion Result | Used Instruction |
|---------------|---------------------------|-----|-----------------|------------------|
| REAL | r_data1 := LN(1.23456); | LD | SM400 | LD,LOG |
| | | LOG | E1.23456 | |
| | | | r_data1 | |

■ Function definition

BOOL LN_E(BOOL EN, REAL S1, REAL D1);

Argument

| Argument Name | IN/OUT | Description | |
|---------------|--------|--|--|
| EN | IN | Execution condition (Function is executed only when the result is TRUE | |
| S1 | IN | Data whose natural logarithm will be found (real number data) | |
| D1 | OUT | Natural logarithm operation result (real number data) | |

Return value

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

(* When execution condition X0 turns ON, the natural logarithm of the data

*)

*)

(* stored in rData is found, and the result is stored into Result.

M0 := LN_E(X0, rData, Result);

6.3.2 Natural exponent

EXP EXP_E

The natural exponent of the specified data is operated.

■ Function definition

REAL EXP(REAL S1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|--|
| S1 | IN | Data whose natural exponent will be found (real number data) |

Return value

| Return Value | Description |
|--------------|--|
| REAL | Natural exponent operation result (real number data) |

Remarks:

Example of use

| Argument Type | ST Program | Con | version Result | Used Instruction |
|---------------|----------------------------|-----|----------------|------------------|
| REAL | r_data1 := EXP(r_data2); | LD | SM400 | LD,EXP |
| | | EXP | r_data2 | |
| | | | r_data1 | |

■ Function definition

BOOL EXP_E(BOOL EN, REAL S1, REAL D1);

Argument

| Argument Name | IN/OUT | Description | |
|---------------|--------|---|--|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) | |
| S1 | IN | ata whose natural exponent will be found (real number data) | |
| D1 | OUT | Natural exponent operation result (real number data) | |

Return value

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

M0 := EXP_E(X0, rData, Result);

6.4 Numerical Functions (Trigonometric Functions)

6.4.1 Floating-point SIN operation

SIN SIN_E

The SIN (sine) value of the specified angle is operated.

■ Function definition

REAL SIN(REAL S1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| S1 | IN | Angle data to be SIN (sine) operated (real number data) |

Remarks: Set the specified angle in radian unit (angle \times π / 180).

Return value

| Return Value | Description | |
|--------------|---|--|
| REAL | SIN operation result (real number data) | |

Example of use

| Argument Type | ST Program | C | onversion Result | Used Instruction |
|---------------|----------------------------|-----|------------------|------------------|
| REAL | r_data1 := SIN(1.23456); | LD | SM400 | LD,SIN |
| | | SIN | E1.23456 | |
| | | | r_data1 | |

■ Function definition

BOOL SIN_E(BOOL EN, REAL S1, REAL D1);

Argument

| Argument Name | IN/OUT | Description | |
|---------------|--------|--|--|
| EN | IN | xecution condition (Function is executed only when the result is TRUE) | |
| S1 | IN | Angle data to be SIN (sine) operated (real number data) | |
| | | Remarks: Set the specified angle in radian (unit angle $	imes \pi$ / 180). | |
| D1 | OUT | SIN operation result (real number data) | |

Return value

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

(* When execution condition X0 turns ON, the SIN value of the angle data

*)

(* stored in rData is calculated, and the result is stored into Result.

M0 := SIN_E(X0, rData, Result);

6.4.2 Floating-point COS operation

COS E

The COS (cosine) value of the specified angle is operated.

■ Function definition

REAL COS(REAL S1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| S1 | IN | Angle data to be COS (cosine) operated (real number data) |

Remarks: Set the specified angle in radian unit (angle \times π / 180).

Return value

| Return Value | Description |
|--------------|---|
| REAL | COS operation result (real number data) |

Example of use

| Argument Type | ST Program | Со | nversion Result | Used Instruction |
|---------------|----------------------------|-----|-----------------|------------------|
| REAL | w_Real1 := COS(w_Real2); | LD | SM400 | LD,COS |
| | | cos | w_Real2 | |
| | | | w Real1 | |

■ Function definition

BOOL COS_E(BOOL EN, REAL S1, REAL D1);

Argument

| Argument Name | IN/OUT | Description | |
|---------------|--------|--|--|
| EN | IN | execution condition (Function is executed only when the result is TRUE) | |
| S1 | IN | Angle data to be COS (cosine) operated (real number data) | |
| | | Remarks: Set the specified angle in radian unit (angle $	imes \pi$ / 180). | |
| D1 | OUT | COS operation result (real number data) | |

Remarks: Set the specified angle in radian unit (angle \times π / 180).

Return value

| Return Value | Description | |
|--------------|---------------------|--|
| BOOL | Execution condition | |

Example of use

(* When execution condition X0 turns ON, the COS value of the angle data

*)

*)

(* stored in rData is calculated, and the result is stored into Result.

M0 := COS_E(X0, rData, Result);

6.4.3 Floating-point TAN operation TAN TAN E

The TAN (tangent) value of the specified angle is operated.

■ Function definition

REAL TAN(REAL S1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|--|
| S1 | IN | Angle data to be TAN (tangent) operated (real number data) |

Remarks: Set the specified angle in radian unit (angle \times π / 180).

Return value

| Return Value | Description |
|--------------|---|
| REAL | TAN operation result (real number data) |

Example of use

| Argument Type | ST Program | Co | onversion Result | Used Instruction |
|---------------|----------------------------|-----|------------------|------------------|
| REAL | w_Real1 := TAN(w_Real2); | LD | SM400 | LD,TAN |
| | | TAN | w_Real2 | |
| | | | w Real1 | |

■ Function definition

BOOL TAN_E(BOOL EN, REAL S1, REAL D1);

Argument

| Argument Name | IN/OUT | Description | |
|---------------|--------|---|--|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) | |
| S1 | IN | Angle data to be TAN (tangent) operated (real number data) | |
| | | Remarks: Set the specified angle in radian unit (angle \times π / 180). | |
| D1 | OUT | TAN operation result (real number data) | |

Return value

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

(* When execution condition X0 turns ON, the TAN value of the angle data

*)

*)

(* stored in rData is calculated, and the result is stored into Result.

M0 := TAN_E(X0, rData, Result);

6.4.4 Floating-point SIN⁻¹ operation ASIN ASIN E

The SIN⁻¹ (arcsine) of the specified SIN value is operated.

■ Function definition

REAL ASIN(REAL S1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| S1 | IN | SIN value to be SIN ⁻¹ (arcsine) operated (-1.0 to 1.0) (real number data) |

Return value

| Return Value | Description |
|--------------|---|
| REAL | SIN ⁻¹ operation result (real number data) |

Remarks: This function cannot be used with the Basic model QCPU.

The operation result is the angle data in radian unit.

Example of use

| Argument Type | ST Program | Со | nversion Result | Used Instruction |
|---------------|-----------------------------|------|-----------------|------------------|
| REAL | w_Real1 := ASIN(w_Real2); | LD | SM400 | LD,ASIN |
| | | ASIN | w_Real2 | |
| | | | w_Real1 | |

■ Function definition

BOOL ASIN_E(BOOL EN, REAL S1, REAL D1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | SIN value to be SIN ⁻¹ (arcsine) operated (-1.0 to 1.0) (real number data) |
| D1 | OUT | SIN ⁻¹ operation result (real number data) |

Remarks: The operation result is the angle data in radian unit.

Return value

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

(* When execution condition X0 turns ON, the angle is operated from the SIN *)

*)

(* value stored in rData, and the result is stored into Result.

M0 := ASIN_E(X0, rData, Result);

6.4.5 Floating-point COS⁻¹ operation ACOS ACOS E

The COS⁻¹ (arccosine) of the specified COS value is operated.

■ Function definition

REAL ACOS(REAL S1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| S1 | IN | COS value to be COS ⁻¹ (arccosine) operated (-1.0 to 1.0) (real number |
| | | data) |

Return value

| Return Value | Description |
|--------------|---|
| REAL | COS ⁻¹ operation result (real number data) |

Remarks: This function cannot be used with the Basic model QCPU.

The operation result is the angle data in radian unit.

Example of use

| Argument Type | ST Program | Con | version Result | Used Instruction |
|---------------|-----------------------------|------|----------------|------------------|
| REAL | w_Real1 := ACOS(w_Real2); | LD | SM400 | LD,ACOS |
| | | ACOS | w_Real2 | |
| | | | w_Real1 | |

■ Function definition

BOOL ACOS_E(BOOL EN, REAL S1, REAL D1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | COS value to be COS ⁻¹ (arccosine) operated (-1.0 to 1.0) (real number |
| | | data) |
| D1 | OUT | COS ⁻¹ operation result (real number data) |

Remarks: The operation result is the angle data in radian unit.

Return value

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

(* When execution condition X0 turns ON, the angle is operated from the COS *

*)

(* value stored in rData, and the result is stored into Result.

M0 := ACOS_E(X0, rData, Result);

6.4.6 Floating-point TAN⁻¹ operation ATAN ATAN E

The TAN⁻¹ (arctangent) of the specified TAN value is operated.

■ Function definition

REAL ATAN(REAL S1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|--|
| S1 | IN | TAN value to be TAN ⁻¹ (arctangent) operated (real number data) |

Return value

| Return Value | Description |
|--------------|---|
| REAL | TAN ⁻¹ operation result (real number data) |

Remarks: This function cannot be used with the Basic model QCPU.

The operation result is the angle data in radian unit.

Example of use

| Argument Type | ment Type ST Program Conversion Result | | Used Instruction | |
|---------------|--|------|------------------|---------|
| REAL | w_Real1 := ATAN(w_Real2); | LD | SM400 | LD,ATAN |
| | | ATAN | w_Real2 | |
| | | | w_Real1 | |

■ Function definition

BOOL ATAN_E(BOOL EN, REAL S1, REAL D1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|--|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | TAN value to be TAN ⁻¹ (arctangent) operated (real number data) |
| D1 | OUT | TAN ⁻¹ operation result (real number data) |

Remarks: The operation result is the angle data in radian unit.

Return value

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

(* When execution condition X0 turns ON, the angle is operated from the TAN *)
(* value stored in rData, and the result is stored into Result. *)
M0 := ATAN_E(X0, rData, Result) ;

6.5 Arithmetic Operation Functions

6.5.1 Addition ADD_E

The specified multiple data are added.

■ Function definition

BOOL ADD_E(BOOL EN, ANY_NUM S1, ANY_NUM S2,...,ANY_NUM Sn, ANY_NUM D1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 to Sn | IN | Data to be added |
| D1 | OUT | Addition operation result |

Return value

| Return Value | Description | | |
|--------------|--------------------------------|--|--|
| BOOL | Execution condition (bit data) | | |

Example of use

| Argument Type | ST Program | Con | version Re | sult | Used Instruction |
|---------------|------------------------------|-----|------------|------|------------------|
| REAL | b_result := ADD_E(b_select, | LD | b_select | | LD, E+, OUT |
| | r_data1, r_data2, r_data3); | E+ | r_data1 | | |
| | | | r_data2 | | |
| | | | r_data3 | | |
| | | LD | b_select | | |
| | | OUT | b_result | | |
| INT | b_result := ADD_E(b_select, | LD | b_select | | LD, +, OUT |
| | D10, D20, D30, D40); | + | D10 | D20 | |
| | | | D40 | | |
| | | + | D30 | D40 | |
| | | LD | b_select | | |
| | | OUT | b_result | | |
| DINT | b_result := ADD_E(b_select, | LD | b_select | | LD,D+,OUT |
| | di_data1, | D+ | di_data1 | | |
| | di_data2, di_data3); | | di_data2 | | |
| | | | di_data3 | | |
| | | LD | b_select | | |
| | | OUT | b_result | | |

For the usable data type, refer to "3.2.2 About ANY type".

6 - 31 6 - 31

6.5.2 Multiplication MUL_E

The specified multiple data are multiplied.

■ Function definition BOOL MUL_E(BOOL EN, ANY_NUM S1, ANY_NUM S2,....,ANY_NUM Sn,

ANY_NUM D1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 to Sn | IN | Data to be multiplied |
| D1 | OUT | Multiplication operation result |

Return value

| Return Value | Description | | |
|--------------|--------------------------------|--|--|
| BOOL | Execution condition (bit data) | | |

Example of use

| Argument Type | ST Program | Con | version Resu | ult | Used Instruction |
|---------------|------------------------------|------|--------------|-----|------------------|
| REAL | b_result := MUL_E(b_select, | LD | b_select | | LD, E*, OUT |
| | r_data1, r_data2, r_data3); | E* | r_data1 | | |
| | | | r_data2 | | |
| | | | r_data3 | | |
| | | LD | b_select | | |
| | | OUT | b_result | | |
| INT | b_result := MUL_E(b_select, | LD | b_select | | LD, *, MOV, OUT |
| | D10, D20, D30, D40); | * | | D20 | |
| | | | D10238 | | |
| | | * | | D30 | |
| | | | D10236 | | |
| | | MOV | D10236 | D40 | |
| | | LD | b_select | | |
| | | OUT | b_result | | |
| DINT | b_result := MUL_E(b_select, | LD | b_select | | LD, D*, DMOV, |
| | di_data1, | D* | di_data1 | | OUT |
| | di_data2, di_data3); | | di_data2 | | |
| | | | D10236 | | |
| | | DMOV | D10236 | | |
| | | | di_data3 | | |
| | | LD | b_select | | |
| | | OUT | b_result | | |

For the usable data type, refer to "3.2.2 About ANY type".

6.5.3 Subtraction SUB_E

Subtraction is performed between the specified data.

■ Function definition

BOOL SUB_E(BOOL EN, ANY_NUM S1, ANY_NUM S2, ANY_NUM D1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Minuend data |
| S2 | IN | Subtrahend data |
| D1 | OUT | Subtraction operation result |

Return value

| Return Value | Description |
|--------------|--------------------------------|
| BOOL | Execution condition (bit data) |

Example of use

| Argument Type | ST Program | Con | version Result | Used Instruction |
|---------------|------------------------------|-----|----------------|------------------|
| REAL | b_result := SUB_E(b_select, | LD | b_select | LD, E-, OUT |
| | r_data1, r_data2, r_data3); | E- | r_data1 | |
| | | | r_data2 | |
| | | | r_data3 | |
| | | LD | b_select | |
| | | OUT | b_result | |
| INT | b_result := SUB_E(b_select, | LD | b_select | LD, -, OUT |
| | 32767, D100, i_data1); | - | K32767 D100 | |
| | | | i_data1 | |
| | | LD | b_select | |
| | | OUT | b_result | |
| DINT | b_result := SUB_E(b_select, | LD | b_select | LD, D-, OUT |
| | di_data1, | D- | di_data1 | |
| | di_data2, di_data3); | | di_data2 | |
| | | | di_data3 | |
| | | LD | b_select | |
| | | OUT | b_result | |

For the usable data type, refer to "3.2.2 About ANY type".

6.5.4 Division DIV_E

Division is performed between the specified data.

■ Function definition BOOL DIV_E(BOOL EN, ANY_NUM S1, ANY_NUM S2, ANY_NUM D1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Dividend data |
| S2 | IN | Divisor data |
| D1 | OUT | Division operation result |

Return value

| Return Value | Description |
|--------------|--------------------------------|
| BOOL | Execution condition (bit data) |

Example of use

| Argument Type | ST Program | Con | version Resi | ult | Used Instruction |
|---------------|------------------------------|------|--------------|-----|------------------|
| REAL | b_result := DIV_E(b_select, | LD | b_select | | LD, E/, OUT |
| | r_data1, r_data2, r_data3); | E/ | r_data1 | | |
| | | | r_data2 | | |
| | | | r_data3 | | |
| | | LD | b_select | | |
| | | OUT | b_result | | |
| INT | b_result := DIV_E(b_select, | LD | b_select | | LD, /, MOV, OUT |
| | D10, D20, D30); | / | D10 [| D20 | |
| | | | D10238 | | |
| | | MOV | D10238 I | D30 | |
| | | LD | b_select | | |
| | | OUT | b_result | | |
| DINT | b_result := DIV_E(b_select, | LD | b_select | | LD, D/, DMOV, |
| | di_data1, | D/ | di_data1 | | OUT |
| | di_data2, di_data3); | | di_data2 | | |
| | | | D10236 | | |
| | | DMOV | D10236 | | |
| | | | di_data3 | | |
| | | LD | b_select | | |
| | | OUT | b_result | | |

For the usable data type, refer to "3.2.2 About ANY type".

6.5.5 Modulus operation MOD MOD_E

Division is performed between the specified data, and its remainder is operated.

■ Function definition BOOL MOD_E(BOOL EN, ANY_INT S1, ANY_INT S2, ANY_INT D1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Dividend data |
| S2 | IN | Divisor data |
| D1 | OUT | Modulus operation result |

Return value

| Return Value | Description | | |
|--------------|--------------------------------|--|--|
| BOOL | Execution condition (bit data) | | |

Example of use

| Argument Type | ST Program | Conv | ersion Re | sult | Used Instruction |
|---------------|---------------------------------|------|-----------|------|------------------|
| INT | B100 := | LD | M1 | | LD, /, MOV, OUT |
| | MOD_E(M1, D10, D20, | / | D10 | D20 | |
| | D30); | | D10238 | | |
| | | MOV | D10239 | D30 | |
| | | LD | M1 | | |
| | | OUT | B100 | | |
| DINT | b_result := MOD_E(b_select, | LD | b_select | | LD, D/, DMOV, |
| | di_data1, di_data2, di_data3); | D/ | di_data1 | | OUT |
| | | | di_data2 | | |
| | | | D10236 | | |
| | | DMOV | D10238 | | |
| | | | di_data3 | | |
| | | LD | b_select | | |
| | | OUT | b_result | | |

^{*} MOD can be used as an operator only.

For the usable data type, refer to "3.2.2 About ANY type".

6.5.6 Natural exponential EXPT EXPT_E

Natural exponential is operated from the specified data used as a base and data used as an exponent.

■ Function definition

REAL EXPT (REAL S1, ANY_NUM S2);

Argument

| ĺ | Argument Name | IN/OUT | Description |
|---|---------------|--------|-----------------------|
| | S1 | IN | Data used as base |
| I | S2 | IN | Data used as exponent |

Return value

| Return Value | Description | |
|--------------|-------------------------------------|--|
| REAL | Operation result (real number data) | |

Example of use

| Argument Type | ST Program | Con | version Result | Used Instruction |
|---------------|---------------------------|------|----------------|-------------------|
| REAL | r_data1 := EXPT(r_data2, | LD | SM400 | LD, LOG, E*, EXP |
| | r_data3); | LOG | r_data2 | |
| | | | r_data1 | |
| | | E* | r_data1 | |
| | | | r_data3 | |
| | | | r_data1 | |
| | | EXP | r_data1 | |
| | | | r_data1 | |
| INT | r_data1 := EXPT(1.123, | LD | SM400 | LD, LOG, FLT, E*, |
| | k32767); | LOG | E1.123 | EXP |
| | | | r_data1 | |
| | | FLT | K32767 | |
| | | | D10238 | |
| | | E* | r_data1 | |
| | | | D10238 | |
| | | | r_data1 | |
| | | EXP | r_data1 | |
| | | | r_data1 | |
| DINT | r_data1 := EXPT(r_data2, | LD | SM400 | LD,LOG, DFLT, E*, |
| | di_data1); | LOG | r_data2 | EXP |
| | | | r_data1 | |
| | | DFLT | di_data1 | |
| | | | D10238 | |
| | | E* | r_data1 | |
| | | | D10238 | |
| | | EVD | r_data1 | |
| | | EXP | r_data1 | |
| | | | r_data1 | |

■ Function definition

BOOL EXPT_E(BOOL EN, REAL S1, ANY_NUM S2, REAL D1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data used as base |
| S2 | IN | Data used as exponent |
| D1 | OUT | Operation result |

Remarks: The operation result is the angle data in radian unit.

Return value

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

(* When execution condition X0 turns ON, the data stored in rData is natural *) *) (* exponential-operated with the data stored in iData, and the result is stored *) (* into Result.

M0 := EXPT_E(X0, rData, iData, Result);

For the usable data type, refer to "3.2.2 About ANY type".

6 - 37 6 - 37

6.5.7 Assignment MOVE MOVE_E

The specified data is assigned to the specified storage destination.

■ Function definition

ANY MOVE (ANY S1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|---------------------|
| S1 | IN | Data to be assigned |

Return value

| Return Value | Description |
|--------------|------------------------|
| ANY | Assignment result data |

Example of use

| Argument Type | ST Program | Con | version Result | Used Instruction |
|---------------|-----------------------------------|------------------------------------|--|--|
| REAL | W_Real1:= MOVE(W_Real2); | LD EMOV | SM400 w_Real2 w_Real1 | LD,EMOV |
| INT | D1 :=MOVE(D0); | LD MOV | SM400 D0 D1 | LD,MOV |
| DINT | w_DWord1:= MOVE(2147483647); | LD DMOV | SM400 K2147483647 w_DWord1 | LD,DMOV |
| BOOL | w_Bit1:= MOVE(w_Bit2); | LD MPS AND SET MRD ANI RST MPP OUT | SM400 w_Bit2 w_Bit1 w_Bit2 w_Bit1 M8191 | LD,MPS,AND,SET,MRD, ANI,RST,MPP,OUT |
| STRING | w_Str1 := MOVE("ABCDEFG"); | LD \$MOV | SM400 "ABCDEFG" w_Str1 | LD,\$MOV |

■ Function definition

BOOL MOVE_E(BOOL EN, ANY S1, ANY D1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be assigned |
| D1 | OUT | Assignment result data |

Return value

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

(* When execution condition X0 turns ON, the data stored in iData is stored into *) (* Result. *)

M0 := MOVE_E(X0, iData, Result);

For the usable data type, refer to "3.2.2 About ANY type".

6.6 Bit Shift Functions

6.6.1 Bit left shift SHL SHL E

The specified data is shifted n bits to the left.

■ Function definition

ANY_BIT SHL (ANY_BIT S1, ANY_BIT n);

Argument

| Argument Name | IN/OUT | Description | |
|---------------|--------|---|--|
| S1 | IN | Data to be shifted | |
| n | IN | Number of bits to be shifted | |
| | | Remarks: Only a constant can be specified as the number of bits to be | |
| | | shifted. | |

Return value

| ı | Return Value | Description |
|---|--------------|---|
| ı | ANY_BIT | Shifted data |
| | | Remarks: n bits of data from the least significant bit are 0. |

Remarks:

Example of use

| Argument Type | ST Program | Conv | ersion Result | Used Instruction |
|---------------|--------------------|------|---------------|------------------|
| INT | D0 := SHL(D1,1); | LD | SM400 | LD,MOV,SFL |
| | | MOV | D1 D0 | |
| | | SFL | D0 K1 | |

■ Function definition

BOOL SHL_E(BOOL EN, ANY_BIT S1, ANY_BIT n, ANY_BIT D1);

Argument

| Argument Name | IN/OUT | Description | |
|---------------|--------|---|--|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) | |
| S1 | IN | Data to be shifted | |
| n | IN | Number of bits to be shifted | |
| | | Remarks: Only a constant can be specified as the number of bits to be | |
| | | shifted. | |
| D1 | OUT | Shifted data | |
| | | Remarks: n bits of data from the least significant bit are 0. | |

Return value

| Return Value | Description | | |
|--------------|---------------------|--|--|
| BOOL | Execution condition | | |

Example of use

(* When execution condition X0 turns ON, the data stored in D0 is shifted 2 bits *)
(* to the left, and the result is stored into Result.

M0:=SHL_E(X0, D0, 2, D100);

For the usable data type, refer to "3.2.2 About ANY type".

6.6.2 Bit right shift SHR SHR E

The specified data is shifted n bits to the right.

■ Function definition

ANY_BIT SHR (ANY_BIT S1, ANY_BIT n);

Argument

| Argument Name | IN/OUT | Description | |
|---------------|--------|---|--|
| S1 | IN | Data to be shifted | |
| n | | Number of bits to be shifted | |
| | IN | Remarks: Only a constant can be specified as the number of bits to be | |
| | | shifted. | |

Return value

| Return Value | Description | | |
|--------------|--|--|--|
| ANY_BIT | Shifted data | | |
| | Remarks: n bits of data from the most significant bit are 0. | | |

Remarks:

Example of use

| | Argument Type | ST Program | Conversion Result | | Used Instruction |
|---|---------------|--------------------|-------------------|-------|------------------|
| ı | INT | D0 := SHR(D1,1); | LD | SM400 | LD,MOV,SFR |
| | | | MOV | D1 D0 | |
| | | | SFR | D0 K1 | |

■ Function definition

BOOL SHR_E(BOOL EN, ANY_BIT S1, ANY_BIT n, ANY_BIT D1);

Argument

| Argument Name | IN/OUT | Description | |
|---------------|--------|--|--|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) | |
| S1 | IN | Data to be shifted | |
| n | IN | Number of bits to be shifted | |
| | | Remarks: Only a constant can be specified as the number of bits to be shifted. | |
| D1 | OUT | Shifted data | |
| | | Remarks: n bits of data from the most significant bit are 0. | |

Return value

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

(* When execution condition X0 turns ON, the data stored in D0 is shifted 2 bits *) (* to the right, and the result is stored into Result.

M0:=SHR_E(X0, D0, 2, D100);

For the usable data type, refer to "3.2.2 About ANY type".

6.6.3 Right rotation

Data is rotated n bits to the right in a circle.

■ Function definition

ANY_BIT ROR (ANY_BIT S1, ANY_BIT n);

Argument

ROR ROR E

| Argument Name | IN/OUT | Description | | |
|---------------|--------|---|--|--|
| S1 | IN | Data to be rotated | | |
| n | IN | Number of bits to be rotated | | |
| | | Remarks: Only a constant can be specified as the number of bits to be | | |
| | | rotated. | | |

Return value

| Return Value | Description |
|--------------|----------------------|
| ANY_BIT | Rotation result data |

Remarks:

Example of use

| Argument Type | ST Program | Conversion Result | | Used Instruction |
|---------------|--------------------|-------------------|-------|------------------|
| INT | D0 := ROR(D1,1); | LD | SM400 | LD,MOV,ROR |
| | | MOV | D1 D0 | |
| | | ROR | D0 K1 | |

■ Function definition

BOOL ROR_E(BOOL EN, ANY_BIT S1, ANY_BIT n, ANY_BIT D1);

Argument

| Argument Name | IN/OUT | Description | |
|---------------|--------|---|--|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) | |
| S1 | IN | Data to be rotated | |
| n | IN | Number of bits to be rotated | |
| | | Remarks: Only a constant can be specified as the number of bits to be | |
| | | rotated. | |
| D1 | OUT | Rotation result data | |

Return value

| Return Value | Description | | |
|--------------|---------------------|--|--|
| BOOL | Execution condition | | |

Example of use

(* When execution condition X0 turns ON, the data stored in D0 is rotated 1 bit (* to the right, and the result is stored into D100. *)

M0:=ROR_E(X0, D0, 1, D100);

For the usable data type, refer to "3.2.2 About ANY type".

6 - 41 6 - 41

6.6.4 Left rotation

ROL E

Data is rotated n bits to the left in a circle.

■ Function definition

ANY_BIT ROL (ANY_BIT S1, ANY_BIT n);

Argument

| Argument Name | IN/OUT | Description | | |
|---------------|--------|---|--|--|
| S1 | IN | Data to be rotated | | |
| n | IN | Number of bits to be rotated | | |
| | | Remarks: Only a constant can be specified as the number of bits to be | | |
| | | rotated. | | |

Return value

| Return Value | Description |
|--------------|----------------------|
| ANY_BIT | Rotation result data |

Remarks:

Example of use

| Argument Type | ST Program | Conversion Result | | Used Instruction |
|---------------|--------------------|-------------------|-------|------------------|
| INT | D0 := ROL(D1,1); | LD | SM400 | LD,MOV,ROL |
| | | MOV | D1 D0 | |
| | | ROL | D0 K1 | |

■ Function definition

BOOL ROL_E(BOOL EN, ANY_BIT S1, ANY_BIT n, ANY_BIT D1);

Argument

| Argument Name | IN/OUT | Description | |
|---------------|--------|---|--|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) | |
| S1 | IN | Data to be rotated | |
| n | IN | Number of bits to be rotated | |
| | | temarks: Only a constant can be specified as the number of bits to be | |
| | | rotated. | |
| D1 | OUT | Rotation result data | |

Return value

| Return Value | Description | | |
|--------------|---------------------|--|--|
| BOOL | Execution condition | | |

Example of use

(* When execution condition X0 turns ON, the data stored in D0 is rotated 1 bit *)
(* to the left, and the result is stored into D100.

M0:=ROL_E(X0, D0, 1, D100);

For the usable data type, refer to "3.2.2 About ANY type".

6.7 Bit Type Boolean Functions

6.7.1 Logical product AND_E

The logical product of the specified multiple data is operated.

■ Function definition BOOL AND_E(BOOL EN, ANY_BIT S1, ANY_BIT S2,...., ANY_BIT Sn, ANY_BIT D1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 to Sn | IN | Data to be ANDed |
| D1 | OUT | AND operation result |

Return value

| Return Value | Description | |
|--------------|---------------------|--|
| BOOL | execution condition | |

Example of use

| Argument Type | ST Program | Con | version Re | sult | Used Instruction | |
|---------------|------------------------------|----------------------------|------------|---------|------------------|---------|
| BOOL | b_result := AND_E(b_select, | LD | b_data1 | | LD,AND,OUT,SET, | |
| | | b_data1, b_data2, b_data3, | AND | b_data2 | | ANI,RST |
| | b_data4); | AND | b_data3 | | | |
| | | OUT | M8191 | | | |
| | | LD | b_select | | | |
| | | AND | M8191 | | | |
| | | SET | b_data4 | | | |
| | | LD | b_select | | | |
| | | ANI | M8191 | | | |
| | | RST | b_data4 | | | |
| | | LD | b_select | | | |
| | | OUT | b_result | | | |
| Word device | b_result := AND_E(b_select, | LD | b_select | | LD, WAND, OUT | |
| | d0, d1, d2, d3); | WAND | D0 | D1 | | |
| | | | D10239 | | | |
| | | WAND | D10239 | D2 | | |
| | | | D3 | | | |
| | | LD | b_select | | | |
| | | OUT | b_result | | | |

For the usable data type, refer to "3.2.2 About ANY type".

6.7.2 Logical sum OR_E

The logical sum of the specified multiple data is operated.

■ Function definition

BOOL OR_E(BOOL EN, ANY_BIT S1, ANY_BIT S2,...., ANY_BIT Sn, ANY_BIT D1); ● Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 to Sn | IN | Data to be ORed |
| D1 | OUT | OR operation result |

Return value

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Remarks:

Example of use

| Argument Type | ST Program | Con | version Result | Used Instruction |
|---------------|---|----------|--------------------|-------------------------------|
| BOOL | b_result := OR_E(TRUE, b_data1, b_data2, b_data3); | LD OR | b_data1 b_data2 | LD,OR,OUT,AND,SET, ANI,RST |
| | | OUT | M8191 | , - |
| | | LD | SM400 | |
| | | AND | M8191 | |
| | | SET | b_data3 | |
| | | LD | SM400 | |
| | | ANI | M8191 | |
| | | RST | b_data3 | |
| | | LD | SM400 | |
| | | OUT | b_result | |
| Word device | B1 := | LD | SM400 | LD, WOR, OUT |
| | OR_E(TRUE, D0, D1, D2); | WOR | D0 D1 D2 | |
| | | LD | SM400 | |
| | | OUT | B1 | |

For the usable data type, refer to "3.2.2 About ANY type".

6.7.3 Exclusive logical sum XOR_E

The exclusive logical sum of the specified multiple data is operated.

■ Function definition

BOOL XOR_E(BOOL EN, ANY_BIT S1, ANY_BIT S2,...., ANY_BIT Sn, ANY_BIT D1); \bullet Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 to Sn | IN | Data to be EXCLUSIVE ORed |
| D1 | OUT | EXCLUSIVE OR operation result |

Return value

| Return Value | Description | | |
|--------------|---------------------|--|--|
| BOOL | Execution condition | | |

Remarks:

Example of use

| Argument Type | ST Program | Con | version Re | sult | Used Instruction |
|---------------|------------------------------|------|------------|------|---------------------|
| BOOL | b_result := XOR_E(b_select, | LD | b_data1 | | LD,ANI,LDI,AND,ORB, |
| | b_data1, b_data2, b_data3); | ANI | b_data2 | | OUT,SET,RST |
| | | LDI | b_data1 | | |
| | | AND | b_data2 | | |
| | | ORB | | | |
| | | OUT | M8191 | | |
| | | LD | b_select | | |
| | | AND | M8191 | | |
| | | SET | b_data3 | | |
| | | LD | b_select | | |
| | | ANI | M8191 | | |
| | | RST | b_data3 | | |
| | | LD | b_select | | |
| | | OUT | b_result | | |
| Word device | b_result := XOR_E(TRUE, | LD | SM400 | | LD,WXOR, OUT |
| | d0z2, d1z3, d2z4); | WXOR | D0Z2 | D1Z3 | |
| | | | D2Z4 | | |
| | | LD | SM400 | | |
| | | OUT | b_result | | |

For the usable data type, refer to "3.2.2 About ANY type".

6.7.4 Logical NOT NOT_E

The logical NOT of the specified data is operated.

■ Function definition

ANY_BIT NOT(ANY_BIT S1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|---------------------------------|
| S1 | IN | Data to be logical NOT operated |

Return value

| Return Value | Description |
|--------------|------------------------------|
| ANY BIT | Logical NOT operation result |

Remarks:

Example of use

| Argument Type | ST Program | Co | nversion Result | Used Instruction |
|---------------|-----------------------------|-----|-----------------|------------------|
| BOOL | b_result := NOT(b_data1); | LDI | b_data1 | LDI, OUT |
| | | OUT | b_result | |
| Word device | d0z2 := NOT(d1z3); | LD | SM400 | LD, CML |
| | | CML | D1Z3 D0Z2 | |

■ Function definition

BOOL NOT_E(BOOL EN, ANY_BIT S1, ANY_BIT D1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be logical NOT operated |
| D1 | OUT | Logical NOT operation result |

Return value

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

(* When execution condition X0 turns ON, the logical NOT of the data stored in *)
(* D0 is found, and the result is stored into D100.

M0:=NOT_E(X0, D0, D100);

For the usable data type, refer to "3.2.2 About ANY type".

6.8 Selection Functions

6.8.1 Binary selection SEL SEL E

One data is selected from among the specified two data according to the selection condition.

■ Function definition

ANY SEL(BOOL S1, ANY S2, ANY S3);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|--------------------------------------|
| S1 IN | | Selection condition |
| S2 IN | | Data to be selected when S1 is FALSE |
| S3 | IN | Data to be selected when S1 is TRUE |

Return value

| Return Value | Description | | |
|--------------|------------------------------------|--|--|
| | Selection result | | |
| | When S1 is FALSE Return value = S2 | | |
| | When S1 is TRUE Return value = S3 | | |

Example of use

| Argument Type | ST Program | Conversion Result | | Used Instruction |
|---------------|--|-------------------|--------------------------------|-------------------------|
| REAL | r_data1 := SEL(b_select, r_data2, r_data3); | LDI EMOV | b_select r_data2 r_data1 | LDI, EMOV, LD, |
| | | LD | b select | |
| | | EMOV | r_data3 | |
| | | | r_data1 | |
| INT | D1 := | LDI | X1 | LDI, MOV, LD |
| | SEL(X1, D2, D3); | MOV | D2 D1 | |
| | | LD | X1 | |
| | | MOV | D3 D1 | |
| DINT | K8X100 := | LDI | X1 | LDI, DMOV, LD |
| | SEL(X1, K8X10, | DMOV | K8X10 K8X100 | |
| | K2147483647); | LD | X1 | |
| | | DMOV | K2147483647 | |
| | | | K8X100 | |
| BOOL | b_result := SEL(b_select, | LDI | b_select | LDI, MPS,AND, SET, MPP, |
| | b_data1, b_data2); | MPS | | ANI, RST,LD |
| | | AND | b_data1 | |
| | | SET MPP | b_result | |
| | | ANI | h data1 | |
| | | RST | b_data1 b_result | |
| | | LD | b_select | |
| | | MPS | b_36/66t | |
| | | AND | b_data2 | |
| | | SET | b result | |
| | | MPP | _ | |
| | | ANI | b_data2 | |
| | | RST | b_result | |
| STRING | s_result := SEL(b_select, | LDI | b_select | LDI, \$MOV,LD |
| | s_ary1, s_ary2); | \$MOV | s_ary1 | |
| | | | s_result | |
| | | LD | b_select | |
| | | \$MOV | s_ary2 | |
| | | | s_result | |

■ Function definition

BOOL SEL_E(BOOL EN, BOOL S1, ANY S2, ANY S3, ANY D1);

Argument

| Argument Name | IN/OUT | Description | |
|---------------|--------|---|--|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) | |
| S1 | IN | Selection condition | |
| S2 | IN | Data to be selected when S1 is FALSE | |
| S3 | IN | Data to be selected when S1 is TRUE | |
| D1 | OUT | Selection result | |
| | | When S1 is FALSE Return value = S2 | |
| | | When S1 is TRUE Return value = S3 | |

Return value

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the data stored in iData1 is stored
- (* into Result if the bit data in bData is FALSE, or the data stored in iData2 is
- (* stored into Result if the bit data in bData is TRUE. *)

M0 := SEL_E(X0, bData, iData1, iData2, Result);

For the usable data type, refer to "3.2.2 About ANY type".

*)

*)

6.8.2 Maximum value MAX MAX_E

The specified data are searched for the maximum value.

■ Function definition

$\underline{\mathsf{ANY_SIMPLE}} \ \mathsf{MAX} (\ \mathsf{ANY_SIMPLE}\ \mathsf{S1},\ \mathsf{ANY_SIMPLE}\ \mathsf{S2}, \dots,\ \mathsf{ANY_SIMPLE}\ \mathsf{Sn}\);$

Argument

| Argum | ent Name | IN/OUT | Description |
|-------|----------|--------|--------------------|
| S1 | to Sn | IN | Search target data |

Return value

| Return Value | Description |
|--------------|---------------|
| ANY SIMPLE | Search result |

Example of use

| Argument Type | ST Program | Con | version Result | Used Instruction |
|---------------|------------------------------|-------|----------------|------------------|
| REAL | w_Real4 := | LD | SM400 | LD,EMOV,LDE< |
| | MAX(w_Real1,w_Real2,w_R | EMOV | w_Real1 | |
| | eal3); | | w_Real4 | |
| | | LDE< | w_Real4 | |
| | | | w_Real2 | |
| | | EMOV | w_Real2 | |
| | | | w_Real4 | |
| | | LDE< | w_Real4 | |
| | | | w_Real3 | |
| | | EMOV | w_Real3 | |
| | | | w_Real4 | |
| INT | D0 := MAX(D1,D2,D3); | LD | SM400 | LD,MOV,LD< |
| | | MOV | D1 D0 | |
| | | LD< | D0 D2 | |
| | | MOV | D2 D0 | |
| | | LD< | D0 D3 | |
| | | MOV | D3 D0 | |
| DINT | w_DWord4 := MAX(- | LD | SM400 | LD,DMOV |
| | 2147483648,0,2147483647); | DMOV | K2147483647 | |
| | | | w_DWord4 | |
| BOOL | w_Bit4 := | LD | w_Bit1 | LD,OR,OUT |
| | MAX(w_Bit1,w_Bit2,w_Bit3); | OR | w_Bit2 | |
| | | OR | w_Bit3 | |
| | | OUT | w_Bit4 | |
| STRING | w_Str4 := | LD | SM400 | LD,\$MOV,LD\$< |
| | MAX("ABC","DEF","GHI"); | \$MOV | "ABC" w_Str4 | |
| | | LD\$< | w_Str4 "DEF" | |
| | | \$MOV | "DEF" w_Str4 | |
| | | LD\$< | w_Str4 "GHI" | |
| | | \$MOV | "GHI" w_Str4 | |

■ Function definition

BOOL MAX_E(BOOL EN, ANY_SIMPLE S1, ANY_SIMPLE S2,...., ANY_SIMPLE Sn, ANY_SIMPLE D1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 to Sn | IN | Search target data |
| D1 | OUT | Search result |

Return value

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the data stored in iData1, iData2 and $\,$ *)
- (* iData3 are searched for the maximum value, and the result is stored into *)
- (* Result. *)

M0 := MAX_E(X0, iData1, iData2, iData3, Result);

For the usable data type, refer to "3.2.2 About ANY type".

6.8.3 Minimum value MIN MIN_E

The specified data are searched for the minimum value.

■ Function definition

Argument

| Argum | ent Name | IN/OUT | Description |
|-------|----------|--------|--------------------|
| S1 | to Sn | IN | Search target data |

Return value

| Return Val | ue | Description |
|------------|------------------|-------------|
| ANY SIMP | LE Search result | |

Example of use

| Argument Type | ST Program | Con | version Result | Used Instruction |
|---------------|-------------------------|-------|----------------|------------------|
| REAL | Real4:= | LD | SM400 | LD,EMOV,LDE> |
| | MIN(Real1,Real2,Real3); | EMOV | Real1 Real4 | |
| | | LDE> | Real4 Real2 | |
| | | EMOV | Real2 Real4 | |
| | | LDE> | Real4 Real3 | |
| | | EMOV | Real3 Real4 | |
| INT | Int4:= | LD | SM400 | LD,MOV,LD> |
| | MIN(Int1,Int2,Int3); | MOV | Int1 Int4 | |
| | | LD> | Int4 Int2 | |
| | | MOV | Int2 Int4 | |
| | | LD> | Int4 Int3 | |
| | | MOV | Int3 Int4 | |
| DINT | Dint4:= | LD | SM400 | LD,DMOV,LDD> |
| | MIN(Dint1,Dint2,Dint3); | DMOV | Dint1 Dint4 | |
| | | LDD> | Dint4 Dint2 | |
| | | DMOV | Dint2 Dint4 | |
| | | LDD> | Dint4 Dint3 | |
| | | DMOV | Dint3 Dint4 | |
| BOOL | bBit4:= | LD | bBit1 | LD,AND,OUT |
| | MIN(bBit1,bBit2,bBit3); | AND | bBit2 | |
| | | AND | bBit3 | |
| | | OUT | bBit4 | |
| STRING | Str4:= | LD | SM400 | LD,\$MOV,LD\$> |
| | MIN(Str1,Str2,Str3); | \$MOV | Str1 Str4 | |
| | | LD\$> | Str4 Str2 | |
| | | \$MOV | Str2 Str4 | |
| | | LD\$> | Str4 Str3 | |
| | | \$MOV | Str3 Str4 | |

■ Function definition

BOOL MIN_E (BOOL EN, ANY_SIMPLE S1, ANY_SIMPLE S2, ANY_SIMPLE S2,...., ANY_SIMPLE Sn, ANY_SIMPLE D1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 to Sn | IN | Search target data |
| D1 | OUT | Search result |

Return value

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

```
(* BOOL MIN_E(BOOL EN, ANY_SIMPLE S1, ANY_SIMPLE S2,...., *)
(* ANY_SIMPLE Sn, ANY_SIMPLE D1 ); *)
M0 := MIN_E( X0, iData1, iData2, iData3, Result ) ;
```

For the usable data type, refer to "3.2.2 About ANY type".

6.8.4 Limiter LIMIT LIMIT_E

The output value is controlled depending on whether the specified data is within the upper/lower limit value (minimum/maximum output limit value) range or not.

■ Function definition

ANY_SIMPLE LIMIT(ANY_SIMPLE MIN, ANY_SIMPLE S1, ANY_SIMPLE MAX); \blacksquare Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|----------------------------|
| MIN | IN | Minimum output limit value |
| S1 | IN | Input value |
| MAX | IN | Maximum output limit value |

Return value

| Return Value | Description |
|--------------|---|
| ANY_SIMPLE | Output value |
| | When MIN (lower limit value) > S1 (input value) |
| | Return value = MIN (lower limit value) |
| | When MAX (upper limit value) < S1 (input value) |
| | Return value = MAX (upper limit value) |
| | When MIN (lower limit value) ≦ S1 (input value) ≦ MAX (upper limit value) |
| | Return value = S1 (input value) |

Example of use

| Argument Type | ST Program | Conv | ersion Re | sult | Used Instruction |
|---------------|-----------------------------|---------------------|-----------|-------|-----------------------|
| REAL | Real4:= | LDE>= Real2 Real1 I | | al1 | LDE>=,ANDE<=,EMOV, |
| | LIMIT(Real1,Real2,Real3); | ANDE<= | Real2 Re | al3 | LDE<,LDE> |
| | | EMOV | Real2 Re | al4 | |
| | | LDE< | Real2 Re | al1 | |
| | | EMOV | Real1 Re | al4 | |
| | | LDE> | Real2 Re | al3 | |
| | | EMOV | Real3 Re | al4 | |
| INT | Int4:= | LD | SM400 | | LD,LIMIT |
| | LIMIT(Int1,Int2,Int3); | LIMIT | Int1 | Int3 | |
| | | | Int2 | Int4 | |
| DINT | Dint4:= | LD | SM400 | | LD,DLIMIT |
| | LIMIT(Dint1,Dint2,Dint3); | DLIMIT | Dint1 | Dint3 | |
| | | | Dint2 | Dint4 | |
| BOOL | bBit4:= | LD | bBit2 | | LD,OR,AND,OUT |
| | LIMIT(bBit1,bBit2,bBit3); | OR | bBit1 | | |
| | | AND | bBit3 | | |
| | | OUT | bBit4 | | |
| STRING | Str4:= | LD\$>= | Str2 Str1 | | LD\$>=,AND\$<=,\$MOV, |
| | LIMIT(Str1,Str2,Str3); | AND\$<= | Str2 Str3 | | LD\$<,LD\$> |
| | | \$MOV | Str2 Str4 | | |
| | | LD\$< | Str2 Str1 | | |
| | | \$MOV | Str1 Str4 | | |
| | | LD\$> | Str2 Str3 | | |
| | | \$MOV | Str3 Str4 | | |

■ Function definition

BOOL LIMIT_E(BOOL EN, ANY_SIMPLE MIN, ANY_SIMPLE S1, ANY_SIMPLE MAX, ANY_SIMPLE D1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| MIN | IN | Minimum output limit value |
| S1 | IN | Input value |
| MAX | IN | Maximum output limit value |
| D1 | OUT | Output value |
| | | When MIN (lower limit value) > S1 (input value) |
| | | |
| | | When MAX (upper limit value) < S1 (input value) |
| | | D1 = MAX (upper limit value) |
| | | When MIN (lower limit value) \leq S1 (input value) \leq MAX (upper limit value) |
| | | |

Return value

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

(* When execution condition X0 turns ON, the iData1 value is stored into Result *)
(* if the iData2 data is less than the iData1 data or minimum value, the iData3 *)
(* value is stored if the iData2 data is greater than the iData3 data or maximum *)
(* value, or the iData2 value is stored otherwise. *)

M0 := LIMIT_E(X0, iData1, iData2, iData3, Result);

For the usable data type, refer to "3.2.2 About ANY type".

6.8.5 Multiplexer MUX MUX_E

One data is selected from among the specified data according to the specified selection condition.

■ Function definition

ANY MUX (INT n, ANY S1, ANY S2,...,ANY Sn);

Argument

| Argument Name | IN/OUT | Description | |
|---------------|--------|-----------------------|--|
| n | IN | Selection condition | |
| S1 to Sn | IN | Selection target data | |

Return value

| Return Value | Description | | | |
|--------------|-------------------------------|--|--|--|
| ANY | Selection result | | | |
| | When n = 1, return value = S1 | | | |
| | When n = 2, return value = S2 | | | |
| | : : | | | |
| | When n = n, return value = Sn | | | |

Example of use

| Argument Type | ST Program | Con | version Result | Used Instruction |
|---------------|-------------------------------|-------------|------------------------|------------------|
| REAL | Real4 := | LD= | Int1 K1 | LD=,EMOV |
| | MUX(Int1, Real1,Real2, | EMOV | Real1 Real4 | |
| | Real3); | LD= | Int1 K2 | |
| | | EMOV LD= | Real2 Real4 Int1 K3 | |
| | | EMOV | Real3 Real4 | |
| INT | Int4:= | LD= | wCon1 K1 | LD=,MOV |
| IINT | MUX(wCon1 , Int1 , Int2, | MOV | Int1 Int4 | LD-,IVIOV |
| | Int3); | LD= | wCon1 K2 | |
| | , into), | MOV | Int2 Int4 | |
| | | LD= | wCon1 K3 | |
| | | MOV | Int3 Int4 | |
| DINT | Dint4:= | LD= | D0 K1 | LD=,DMOV |
| | MUX(D0, Dint1, Dint2, Dint3); | DMOV | Dint1 Dint4 | |
| | | LD= | D0 K2 | |
| | | DMOV | Dint2 Dint4 | |
| | | LD= | D0 K3 | |
| | | DMOV | Dint3 Dint4 | |
| BOOL | bBit4:= | LD= | K3 K1 | LD=,MPS,AND,SET, |
| | MUX(3,bBit1,bBit2,bBit3); | MPS | | MPP,ANI,RST |
| | | AND | bBit1 | |
| | | SET | bBit4 | |
| | | MPP | PD:14 | |
| | | ANI RST | bBit1 bBit4 | |
| | | LD= | K3 K2 | |
| | | MPS | NJ NZ | |
| | | AND | bBit2 | |
| | | SET | bBit4 | |
| | | MPP | | |
| | | ANI | bBit2 | |
| | | RST | bBit4 | |
| | | LD= | K3 K3 | |
| | | MPS | | |
| | | AND | bBit3 | |
| | | SET | bBit4 | |
| | | MPP | | |
| | | ANI | bBit3 | |
| | | RST | bBit4 | |

■ Function definition

BOOL MUX_E(BOOL EN, INT n, ANY S1, ANY S2,...,ANY Sn, ANY D1);

Argument

| Argument Name | IN/OUT | Description | |
|---------------|--------|---|--|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) | |
| n | IN | Selection condition | |
| S1 to Sn | IN | Selection target data | |
| D1 | OUT | Selection result | |
| | | When n = 1, D1 = S1 | |
| | | When n = 2, D1 = S2 | |
| | | : : | |
| | | When n = n, D1 = Sn | |

Return value

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, one of the data stored in iData2,
- (* iData3, iData4 and iData5 is stored into Result, after judgment made from the *)
- (* data in iData1.

M0 := MUX_E(X0, iData1, iData2, iData3, iData4, iData5, Result);

For the usable data type, refer to "3.2.2 About ANY type".

*)

6.9 Comparison Functions

6.9.1 Greater than right member (>) GT_E

In all the specified data, whether the relationship of > (greater than) is satisfied or not is acquired.

■ Function definition BOOL GT_E(BOOL EN, ANY_SIMPLE S1, ANY_SIMPLE S2,...., ANY_SIMPLE Sn, BOOL D1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 to Sn | IN | Comparison target data |
| D1 | OUT | Comparison result |

Return value

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

| Argument Type | ST Program | Con | version Result | Used Instruction |
|---------------|------------------------------|-------|----------------|------------------|
| REAL | GT_E(M0 , Real1, Real2, | LDE> | Real1 Real2 | LDE>, ANDE>,OUT, |
| | Real3, bBit1); | ANDE> | Real2 Real3 | LD,AND,SET,ANI, |
| | | OUT | M8191 | RST |
| | | LD | MO | |
| | | AND | M8191 | |
| | | SET | bBit1 | |
| | | LD | MO | |
| | | ANI | M8191 | |
| | | RST | bBit1 | |
| INT | GT_E(M0 , Int1, Int2, Int3, | LD> | Int1 Int2 | LD>,AND>,OUT,LD, |
| | bBit1); | AND> | Int2 Int3 | AND,SET,ANI,RST |
| | | OUT | M8191 | |
| | | LD | MO | |
| | | AND | M8191 | |
| | | SET | bBit1 | |
| | | LD | MO | |
| | | ANI | M8191 | |
| | | RST | bBit1 | |
| DINT | GT_E(M0 , Dint1, Dint2 , | LDD> | Dint1 Dint2 | LDD>, ANDD>,OUT |
| | Dint3, bBit1); | ANDD> | Dint2 Dint3 | LD, AND,SET,ANI, |
| | | OUT | M8191 | RST |
| | | LD | M0 | |
| | | AND | M8191 | |
| | | SET | bBit1 | |
| | | LD | MO | |
| | | ANI | M8191 | |
| | | RST | bBit1 | |

| Argument Type | ST Program | Con | version Result | Used Instruction |
|---------------|-------------------------------|--------|----------------|--------------------|
| BOOL | GT_E(M0 , M100, M101, | LD | M100 | LD,ANI,ANB,OUT, |
| | M102, M103, bBit1); | ANI | M101 | AND,SET,RST |
| | | LD | M101 | |
| | | ANI | M102 | |
| | | ANB | | |
| | | LD | M102 | |
| | | ANI | M103 | |
| | | ANB | | |
| | | OUT | M8191 | |
| | | LD | M0 | |
| | | AND | M8191 | |
| | | SET | bBit1 | |
| | | LD | M0 | |
| | | ANI | M8191 | |
| | | RST | bBit1 | |
| STRING | GT_E(M0 , Str1, Str2 , Str3, | LD\$> | Str1 Str2 | LD\$>, AND\$>, OUT |
| | bBit1); | AND\$> | Str2 Str3 | LD, AND, SET, ANI |
| | | OUT | M8191 | RST |
| | | LD | MO | |
| | | AND | M8191 | |
| | | SET | bBit1 | |
| | | LD | MO | |
| | | ANI | M8191 | |
| | | RST | bBit1 | |

For the usable data type, refer to "3.2.2 About ANY type".

6.9.2 Greater than or equal to right member (>=) GE_E

In all the specified data, whether the relationship of \geq (greater than or equal to) is satisfied or not is acquired.

■ Function definition BOOL GE_E(BOOL EN, ANY_SIMPLE S1, ANY_SIMPLE S2,...., ANY_SIMPLE Sn, BOOL D1);

Argument

| Argument Name | IN/OUT | Description | |
|---------------|--------|---|--|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) | |
| S1 to Sn | IN | Comparison target data | |
| D1 | OUT | Comparison result | |

Remarks: D1 = (S1 \ge S2) & (S2 \ge S3) & & (Sn -1 \ge Sn)

Return value

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

| Argument Type | ST Program | Conv | ersion Result | Used Instruction |
|---------------|------------------------------|--------|---------------|------------------|
| REAL | GE_E(M0 , Real1, Real2, | LDE>= | Real1 Real2 | LDE>=, ANDE>=, |
| | Real3, bBit1); | ANDE>= | Real2 Real3 | OUT,LD,AND,SET, |
| | | OUT | M8191 | ANI,RST |
| | | LD | M0 | |
| | | AND | M8191 | |
| | | SET | bBit1 | |
| | | LD | M0 | |
| | | ANI | M8191 | |
| | | RST | bBit1 | |
| INT | GE_E(M0 , Int1, Int2, Int3, | LD>= | Int1 Int2 | LD>=, AND>=,OUT |
| | bBit1); | AND>= | Int2 Int3 | LD,AND,SET,ANI, |
| | | OUT | M8191 | RST |
| | | LD | M0 | |
| | | AND | M8191 | |
| | | SET | bBit1 | |
| | | LD | MO | |
| | | ANI | M8191 | |
| | | RST | bBit1 | |
| DINT | GE_E(M0 , Dint1, Dint2 , | LDD>= | Dint1 Dint2 | LDD>=, ANDD>=, |
| | Dint3, bBit1); | ANDD>= | Dint2 Dint3 | OUT,LD,AND,SET |
| | | OUT | M8191 | ANI,RST |
| | | LD | M0 | |
| | | AND | M8191 | |
| | | SET | bBit1 | |
| | | LD | MO | |
| | | ANI | M8191 | |
| | | RST | bBit1 | |

| Argument Type | ST Program | Conv | version Result | Used Instruction |
|---------------|------------------------|------------|----------------|------------------|
| BOOL | GE_E(M0 , M100, M101, | LD | M100 | LD,ORI,ANB,OUT |
| | M102, M103, bBit1); | ORI | M101 | AND,SET,ANI,RST |
| | | LD | M101 | |
| | | ORI | M102 | |
| | | ANB | | |
| | | LD | M102 | |
| | | ORI | M103 | |
| | | ANB | | |
| | | OUT | M8191 | |
| | | LD | MO | |
| | | AND | M8191 | |
| | | SET | bBit1 | |
| | | LD | M0 | |
| | | ANI | M8191 | |
| | | RST | bBit1 | |
| STRING | | LD\$>= | Str1 Str2 | LD\$>=, AND\$>=, |
| | bBit1); | AND\$>= | Str2 Str3 | OUT,LD,AND,SET, |
| | | OUT | M8191 | LD,ANI,RST |
| | | LD | M0 | |
| | | AND | M8191 | |
| | | SET | bBit1 | |
| | | LD | MO | |
| | | ANI RST | M8191 bBit1 | |

For the usable data type, refer to "3.2.2 About ANY type".

6.9.3 Equal (=) EQ_E

In all the specified data, whether the relationship of = (equal) is satisfied or not is acquired.

■ Function definition BOOL EQ_E(BOOL EN, ANY_SIMPLE S1, ANY_SIMPLE S2,...., ANY_SIMPLE Sn, BOOL D1);

Argument

| - 1 | | | | |
|-----|---------------|--------|---|--|
| | Argument Name | IN/OUT | Description | |
| | EN | IN | Execution condition (Function is executed only when the result is TRUE) | |
| | S1 to Sn | IN | Comparison target data | |
| | D1 | OUT | Comparison result | |

Remarks: D1 = (S1 = S2) & (S2 = S3) & & (Sn -1 = Sn)

Return value

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

| Argument Type | ST Program | Cor | version Result | Used Instruction |
|---------------|--|-----------|----------------------|-----------------------|
| REAL | b_result := EQ_E(b_select, r_data1, r_data2, r_data3, | LDE= | r_data1 r_data2 | LDE=, ANDE=,OUT |
| | uata1,1_uata2,1_uata3, b_data1); | ANDE= | r_data2 r_data3 | LD,AND,SET,ANI, |
| | | OUT | M8191 | RST |
| | | LD | b_select | |
| | | AND | M8191 | |
| | | SET | b_data1 | |
| | | LD | b_select | |
| | | ANI | M8191 | |
| | | RST | b_data1 | |
| | | LD | b_select | |
| INT | B100 := | OUT | b_result | |
| 1 | EQ_E(M20, D10, D20, D30, | LD= | D10 D20 | LD=, AND=, OUT |
| | M200); | AND= | D20 D30 | LD,AND,SET,ANI RST |
| | | OUT | M8191 | |
| | | LD | M20 | |
| | | AND | M8191 | |
| | | SET | M200 | |
| | | LD | M20 | |
| | | ANI | M8191 | |
| | | RST | M200 | |
| | | LD OUT | M20 B100 | |
| DINT | b_result := EQ_E(b_select, di_data1, di_data2, di_data3, | LDD= | di_data1 di_data2 | LDD=, ANDD=,OUT, |
| | b_data1); | ANDD= | di_data2 di_data3 | |
| | | OUT | M8191 | RST |
| | | LD | b_select | |
| | | AND | M8191 | |
| | | SET | b_data1 | |
| | | LD | b_select | |
| | | ANI | M8191 | |
| | | RST | b_data1 | |
| | | LD OUT | b_select b_result | |

6 - 61 6 - 61

| Argument Type | ST Program | Con | version Result | Used Instruction |
|---------------|--|-----------|----------------------|-------------------|
| BOOL | b_result := EQ_E(b_select, | LD | X10 | LD,AND,LDI,ANI, |
| | X10, X11, X12, M20); | AND | X11 | ORB,ANB,SET,RST |
| | | LDI | X10 | |
| | | ANI | X11 | |
| | | ORB | | |
| | | LD | X11 | |
| | | AND | X12 | |
| | | LDI | X11 | |
| | | ANI | X12 | |
| | | ORB | | |
| | | ANB | | |
| | | OUT | M8191 | |
| | | LD | b_select | |
| | | AND | M8191 | |
| | | SET | M20 | |
| | | LD | b_select | |
| | | ANI | M8191 | |
| | | RST | M20 | |
| | | LD OUT | b_select b_result | |
| STRING | b_result := EQ_E(b_select, s_ary1, s_ary2, b_data1); | LD\$= | s_ary1 s_ary2 | LD\$=,OUT,LD,AND, |
| | S_ary 1, S_ary 2, D_uata 1), | OUT | M8191 | SET,ANI,RST |
| | | LD | b_select | |
| | | AND | M8191 | |
| | | SET | b_data1 | |
| | | LD | b_select | |
| | | ANI | M8191 | |
| | | RST | b_data1 | |
| | | LD OUT | b_select b_result | |

For the usable data type, refer to "3.2.2 About ANY type".

6.9.4 Less than or equal to right member (<=) LE_E

In all the specified data, whether the relationship of \leq (less than or equal to) is satisfied or not is acquired.

■ Function definition BOOL LE_E(BOOL EN, ANY_SIMPLE S1, ANY_SIMPLE S2,...., ANY_SIMPLE Sn, BOOL D1);

Argument

| Argument Name | IN/OUT | Description | |
|---------------|--------|---|--|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) | |
| S1 to Sn | IN | Comparison target data | |
| D1 | OUT | Comparison result | |

Remarks: D1 = (S1 \leq S2) & (S2 \leq S3) & & (Sn -1 \leq Sn)

Return value

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

| Argument Type | ST Program | Conv | version Result | Used Instruction |
|---------------|-----------------------------------|--------|-----------------|------------------|
| REAL | b_result := LE_E(b_select, | LDE<= | r_data1 r_data2 | LDE<=, ANDE<=, |
| | r_data1, r_data2, r_data3, | ANDE<= | r_data2 r_data3 | OUT,LD,AND,SET, |
| | b_data1); | OUT | M8191 | ANI,RST |
| | | LD | b_select | |
| | | AND | M8191 | |
| | | SET | b_data1 | |
| | | LD | b_select | |
| | | ANI | M8191 | |
| | | RST | b_data1 | |
| | | LD | b_select | |
| | | OUT | b_result | |
| INT | B100 := | LD<= | D10 D20 | LD<=, AND<=,OUT |
| | LE_E(M20, D10, D20, D30, M200); | AND<= | D20 D30 | LD,AND,SET,ANI, |
| | IVI200), | OUT | M8191 | RST |
| | | LD | M20 | |
| | | AND | M8191 | |
| | | SET | M200 | |
| | | LD | M20 | |
| | | ANI | M8191 | |
| | | RST | M200 | |
| | | LD | M20 | |
| | | OUT | B100 | |

| Argument Type | ST Program | Con | version Result | Used Instruction |
|---------------|---|--------|-------------------|-----------------------------------|
| DINT | b_result := LE_E(b_select, | LDD<= | di_data1 di_data2 | LDD<=, ANDD<=, |
| | di_data1, di_data2, di_data3, | ANDD<= | di_data2 di_data3 | OUT,LD,AND,SET, |
| | b_data1); | OUT | M8191 | ANI,RST |
| | | LD | b_select | |
| | | AND | M8191 | |
| | | SET | b_data1 | |
| | | LD | b_select | |
| | | ANI | M8191 | |
| | | RST | b_data1 | |
| | | LD | b_select | |
| | | OUT | b_result | |
| BOOL | b_result := LE_E(b_select, | LDI | X10 | LDI,OR,ANB,OUT, |
| | X10, X11, X12, M20); | OR | X11 | AND,SET,ANI,RST |
| | | LDI | X11 | |
| | | OR | X12 | |
| | | ANB | | |
| | | OUT | M8191 | |
| | | LD | b_select | |
| | | AND | M8191 | |
| | | SET | M20 | |
| | | LD | b_select | |
| | | ANI | M8191 | |
| | | RST | M20 | |
| | | LD | b_select | |
| STRING | b requite = LE E/b coloct | OUT | b_result | |
| STRING | b_result := LE_E(b_select, s_ary1, s_ary2, b_data1); | LD\$<= | s_ary1 s_ary2 | LD\$<=,OUT,LD, AND,SET,ANI,RST |
| | 0_ary 1, 0_ary 2, 0_aata 1 /, | OUT | M8191 | AND,SET,ANI,RST |
| | | LD | b_select | |
| | | AND | M8191 | |
| | | SET | b_data1 | |
| | | LD | b_select | |
| | | ANI | M8191 | |
| | | RST | b_data1 | |
| | | LD | b_select | |
| | | OUT | b_result | |

For the usable data type, refer to "3.2.2 About ANY type".

6.9.5 Less than right member (<) LT_E

In all the specified data, whether the relationship of < (less than) is satisfied or not is acquired.

■ Function definition BOOL LT_E(BOOL EN, ANY_SIMPLE S1, ANY_SIMPLE S2,...., ANY_SIMPLE Sn, BOOL D1);

Argument

| Argument Name | IN/OUT | Description | |
|---------------|--------|---|--|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) | |
| S1 to Sn | IN | Comparison target data | |
| D1 | OUT | Comparison result | |

Return value

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

| Argument Type | ST Program | Con | version Result | Used Instruction |
|---------------|-----------------------------------|-------|-----------------|------------------|
| REAL | b_result := LT_E(b_select, | LDE< | r_data1 r_data2 | LDE<, ANDE<,OUT, |
| | r_data1, r_data2, r_data3, | ANDE< | r_data2 r_data3 | LD,AND,SET,ANI, |
| | b_data1); | OUT | M8191 | RST |
| | | LD | b_select | |
| | | AND | M8191 | |
| | | SET | b_data1 | |
| | | LD | b_select | |
| | | ANI | M8191 | |
| | | RST | b_data1 | |
| | | LD | b_select | |
| | | OUT | b_result | |
| INT | B100 := | LD< | D10 D20 | LD<, AND<,OUT, |
| | LT_E(M20, D10, D20, D30, M200); | AND< | D20 D30 | LD,SET,ANI,RST |
| | IVI200), | OUT | M8191 | |
| | | LD | M20 | |
| | | AND | M8191 | |
| | | SET | M200 | |
| | | LD | M20 | |
| | | ANI | M8191 | |
| | | RST | M200 | |
| | | LD | M20 | |
| | | OUT | B100 | |

| Argument Type | ST Program | Cor | nversion Result | Used Instruction |
|---------------|-------------------------------|-------|-------------------|-------------------|
| DINT | b_result := LT_E(b_select, | LDD< | di_data1 di_data2 | LDD<, ANDD<,OUT, |
| | di_data1, di_data2, di_data3, | ANDD< | di_data2 di_data3 | LD,AND,SET,ANI, |
| | b_data1); | OUT | M8191 | RST |
| | | LD | b_select | |
| | | AND | M8191 | |
| | | SET | b_data1 | |
| | | LD | b_select | |
| | | ANI | M8191 | |
| | | RST | b_data1 | |
| | | LD | b_select | |
| | | OUT | b_result | |
| BOOL | b_result := LT_E(b_select, | LDI | X10 | LDI,AND,ANB,OUT, |
| | X10, X11, X12, M20); | AND | X11 | LD,SET,ANI,RST |
| | | LDI | X11 | |
| | | AND | X12 | |
| | | ANB | | |
| | | OUT | M8191 | |
| | | LD | b_select | |
| | | AND | M8191 | |
| | | SET | M20 | |
| | | LD | b_select | |
| | | ANI | M8191 | |
| | | RST | M20 | |
| | | LD | b_select | |
| | | OUT | b_result | |
| STRING | b_result := LT_E(b_select, | LD\$< | s_ary1 s_ary2 | LD\$<,OUT,LD,AND, |
| | s_ary1, s_ary2, b_data1); | OUT | M8191 | SET,ANI,RST |
| | | LD | b_select | |
| | | AND | M8191 | |
| | | SET | b_data1 | |
| | | LD | b_select | |
| | | ANI | M8191 | |
| | | RST | b_data1 | |
| | | LD | b_select | |
| | | OUT | b_result | |

For the usable data type, refer to "3.2.2 About ANY type".

6.9.6 Unequal (<>) NE_E

In all the specified data, whether the relationship of ≠ (unequal) is satisfied or not is acquired.

■ Function definition

${\tt BOOL\ NE_E(BOOL\ EN,\ ANY_SIMPLE\ S1,\ ANY_SIMPLE\ S2,\ BOOL\ D1\);}$

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Comparison target data |
| S2 | IN | Comparison target data |
| D1 | OUT | Comparison result |

Remarks: D1 = $(S1 \neq S2)$

Return value

| | Return Value | Description |
|---|--------------|---------------------|
| ſ | BOOL | Execution condition |

Example of use

| Argument Type | ST Program | Coi | nversion Result | Used Instruction |
|---------------|--------------------------------|-------|-----------------|-------------------|
| REAL | b_result := NE_E(b_select, | LDE<> | r_data1 r_data2 | LDE<>,OUT,LD, |
| | r_data1, r_data2, b_data1); | OUT | M8191 | AND,SET,ANI,RST |
| | | LD | b_select | |
| | | AND | M8191 | |
| | | SET | b_data1 | |
| | | LD | b_select | |
| | | ANI | M8191 | |
| | | RST | b_data1 | |
| | | LD | b_select | |
| | | OUT | b_result | |
| INT | B100 := | LD<> | D10 D20 | LD<>,OUT,LD,AND, |
| | NE_E(M20, D10, D20, M200); | OUT | M8191 | SET,ANI,RST |
| | 101200), | LD | M20 | |
| | | AND | M8191 | |
| | | SET | M200 | |
| | | LD | M20 | |
| | | ANI | M8191 | |
| | | RST | M200 | |
| | | LD | M20 | |
| 511.7 | | OUT | B100 | |
| DINT | b_result := NE_E(b_select, | | | LDD<>,OUT,LD,AND, |
| | di_data1, di_data2, b_data1); | OUT | M8191 | SET,ANI,RST |
| | | LD | b_select | |
| | | AND | M8191 | |
| | | SET | b_data1 | |
| | | LD | b_select | |
| | | ANI | M8191 | |
| | | RST | b_data1 | |
| | | LD | b_select | |
| | | OUT | b_result | |

For the usable data type, refer to "3.2.2 About ANY type".

6.10 Character String Functions

6.10.1 Character string length acquisition

LEN LEN E

The character string length of the specified character string data is acquired.

■ Function definition

INT LEN (STRING S1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| S1 | IN | Data whose character string length will be acquired (character string |
| | | data) |

Return value

| Return Value | Description |
|--------------|--|
| INT | Character string length result (BIN 16-bit data) |

Remarks: This function cannot be used with the Basic model QCPU.

Example of use

| Argument Type | ST Program | Conversion Result | | Used Instruction |
|---------------|---------------------------|-------------------|----------------|------------------|
| STRING | i_data1 := LEN(s_ary1); | LD | SM400 | LD,LEN |
| | | LEN | s_ary1 i_data1 | |

■ Function definition

BOOL LEN_E(BOOL EN, STRING S1, INT D1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data whose character string length will be acquired (character string |
| | | data) |
| D1 | OUT | Character string length result (BIN 16-bit data) |

Return value

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

```
(* When execution condition X0 turns ON, the length of the character string (* stored in sData1 is acquired and stored into Result.
```

*)

M0 := LEN_E(X0, sData, Result);

6.10.2 Acquisition from start position of character string LEFT LEFT E

The specified n characters of character string is acquired, starting at the left of the specified character string (head of the character string).

■ Function definition

STRING LEFT (STRING S1, INT n);

Argument

| Argument Name | IN/OUT | Description | |
|---------------|--------|---|--|
| S1 | IN | Data to be acquired (character string data) | |
| n | IN | Number of characters to be acquired (BIN 16-bit data) | |

Return value

| Return Value | Description | | |
|--------------|--|--|--|
| STRING | Acquisition result (character string data) | | |

Remarks: This function cannot be used with the Basic model QCPU.

Secure the area of n+1 characters as the data area that will store the acquired character string data.

Example of use

| Argument Type | ST Program | | Conversion Result | Used Instruction |
|---------------|-------------------------------------|------|-----------------------|------------------|
| STRING | s_ary1 := LEFT (s_ary2, i_data1); | LD | SM400 | LD,LEFT |
| | | LEFT | s_ary2 s_ary1 i_data1 | |

■ Function definition

BOOL LEFT _E(BOOL EN, STRING S1, INT n, STRING D1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be acquired (character string data) |
| n | IN | Number of characters to be acquired (BIN 16-bit data) |
| D1 | OUT | Acquisition result (character string data) |

Return value

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the character string of the number of *)
- (* characters specified in iData is acquired, starting at the left of the character *)
- (* string data stored in sData, and stored into Result. *)

M0 := LEFT_E(X0, sData, iData, Result);

6.10.3 Acquisition from end of character string RIGHT RIGHT E

The specified n characters of character string is acquired, starting at the right of the specified character string (end of the character string).

■ Function definition

STRING RIGHT (STRING S1, INT n);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| S1 | IN | Data to be acquired (character string data) |
| n | IN | Number of characters to be acquired (BIN 16-bit data) |

Return value

| Return Value | Description |
|--------------|--|
| STRING | Acquisition result (character string data) |

Remarks: This function cannot be used with the Basic model QCPU.

Secure the area of n+1 characters as the data area that will store the acquired character string data.

Example of use

| I | Argument Type | ST Program | Conversion Result | | Used Instruction |
|---|---------------|--------------------------|-------------------|---------|------------------|
| I | STRING | s_ary1 := RIGHT(s_ary2, | LD | SM400 | LD,RIGHT |
| ı | | i_data1); | RIGHT | s_ary2 | |
| ı | | | | s_ary1 | |
| | | | | i_data1 | |

■ Function definition

BOOL RIGHT _E(BOOL EN, STRING S1, INT n, STRING D1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be acquired (character string data) |
| n | IN | Number of characters to be acquired (BIN 16-bit data) |
| D1 | OUT | Acquisition result (character string data) |

Return value

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

(* When execution condition X0 turns ON, the character string of the number of $\,$ *)

(* characters specified in iData is acquired, starting at the right of the character *

(* string stored in sData, and stored into Result. *)

M0 := RIGHT_E(X0, sData, iData, Result);

6 - 71 6 - 71

6.10.4 Acquisition from specified position of character string MID MID E

The specified n characters of character string data is acquired, starting at the specified position from the left of the specified character string (head of the character string).

■ Function definition

STRING MID(STRING S1, INT n, INT POS);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|--|
| S1 | IN | Data to be acquired (character string data) |
| n | IN | Number of characters to be acquired (BIN 16-bit data) |
| POS | IN | Head position of data to be acquired (BIN 16-bit data) |

Return value

| Return Value | Description |
|--------------|--|
| STRING | Acquisition result (character string data) |

Remarks: This function cannot be used with the Basic model QCPU.

Secure the area of n+1 characters as the data area that will store the acquired character string data.

Example of use

| Argument Type | ST Program | Conversion Result | | Used Instruction |
|---------------|-----------------------|-------------------|---------------|------------------|
| STRING | s_ary1 := | LD | SM400 | LD,MOV,MIDR |
| | MID(s_ary2, i_data1, | MOV | i_data1 | |
| | i_data2); | | D10239 | |
| | | MOV | i_data2 | |
| | | | D10238 | |
| | | MIDR | s_ary2 s_ary1 | |
| | | | D10238 | |

■ Function definition

BOOL MID E(BOOL EN, STRING S1, INT n, INT POS, STRING D1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be acquired (character string data) |
| n | IN | Number of characters to be acquired (BIN 16-bit data) |
| POS | IN | Head position of data to be acquired (BIN 16-bit data) |
| D1 | OUT | Acquisition result (character string data) |

Return value

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the specified number of characters
- (* stored in iData1 are acquired, starting at the iData2 position from the head of *)
- (* the character string stored in sData, and stored into Result. *)

M0 := MID E(X0, sData, iData1, iData2, Result);

6.10.5 Concatenation of character strings

CONCAT_E

All the specified character strings are concatenated.

■ Function definition

STRING CONCAT(STRING S1, STRING S2,...,STRING Sn);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| S1 to Sn | IN | Data to be concatenated (character string data) |

Return value

| Return Value | Description |
|--------------|--|
| STRING | Concatenation result (character string data) |

Remarks: This function cannot be used with the Basic model QCPU.

Secure the area of the number of concatenated characters + 1 character as the data area that will store the concatenated character string data.

Example of use

| Argument Type | ST Program | Conversion Result | | Used Instruction |
|---------------|-------------------------|-------------------|----------|------------------|
| STRING | s_result := | LD | SM400 | LD,\$MOV,\$+ |
| | CONCAT(s_ary1, s_ary2, | \$MOV | s_ary1 | |
| | s_ary3); | | s_result | |
| | | \$+ | s_ary2 | |
| | | | s_result | |
| | | \$+ | s_ary3 | |
| | | | s_result | |

■ Function definition

BOOL_ CONCAT_E(BOOL EN, STRING S1, STRING S2,....,STRING Sn, STRING D1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 to Sn | IN | Data to be concatenated (character string data) |
| D1 | OUT | Concatenation result (character string data) |

Return value

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

(* When execution condition X0 turns ON, the character string data stored in

(* sData1 and sData2 are concatenated, and the result is stored into Result. *)
M0 := CONCAT_E(X0, sData1, sData2, Result) ;

6.10.6 Insertion of character string into specified position INSERT INSERT E

The character string data is inserted into the specified position and later of the specified character string data.

■ Function definition STRING INSERT(STRING S1, STRING S2, INT POS);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| S1 | IN | Data to be inserted (character string data) |
| S2 | IN | Data into which above data will be inserted (character string data) |
| POS | IN | Insertion position (BIN 16-bit data) |

Return value

| Return Value | Description |
|--------------|--|
| STRING | Insertion result (character string data) |

Remarks: This function cannot be used with the Basic model QCPU.

Secure the area of the number of characters after insertion + 1 character as the data area that will store the character string data after insertion.

Example of use

| Argument Type | ST Program | Con | version Result | Used Instruction |
|---------------|--------------------------------|--------|----------------|------------------|
| STRING | w_Str3 := | LD | SM400 | LD,\$+,AND<>,MOV |
| | INSERT(w_Str1,w_Str2,w_Word1); | \$+ | w_Str2 w_Str1 | ,-,MIDW,LEN |
| | | | w_Str3 | |
| | | AND<> | w_Word1 K1 | |
| | | MOV | K1 D10238 | |
| | | - | w_Word1 K1 | |
| | | | D10239 | |
| | | MIDW | w_Str1 w_Str3 | |
| | | D10238 | | |
| | | MOV | w_Word1 | |
| | | | D10238 | |
| | | LEN | w_Str2 | |
| | | | D10239 | |
| | | MIDW | w_Str2 w_Str3 | |
| | | | D10238 | |

■ Function definition

BOOL INSERT E(BOOL EN, STRING S1, STRING S2, INT POS, STRING D1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be inserted (character string data) |
| S2 | IN | Data into which above data will be inserted (character string data) |
| POS | IN | Insertion position (BIN 16-bit data) |
| D1 | OUT | Insertion result (character string data) |

Return value

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the character string data in sData2 is *)
- (* inserted into the iData position from the head of the character string data in
 * (* sData1, and the result is stored into Result.
 *

M0 := INSERT_E(X0, sData1, sData2, iData, Result);

6.10.7 Deletion of character string from specified position DELETE DELETE E

n characters of character string is deleted from the specified position and later of the specified character string.

■ Function definition STRING DELETE(STRING S1, INT n, INT POS);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|--|
| S1 | IN | Data to be deleted (character string data) |
| n | IN | Number of characters to be deleted (BIN 16-bit data) |
| POS | IN | Deletion position (BIN 16-bit data) |

Return value

| Return Value | Description |
|--------------|---|
| STRING | Deletion result (character string data) |

Remarks: This function cannot be used with the Basic model QCPU.

Secure the area of the number of characters after deletion + 1 character as the data area that will store the character string data after deletion. If the deletion position POS is 0, n characters of character string will be deleted, starting at the end (right) of the data to be deleted S1.

Example of use

| Argument Type | ST Program | Con | version Result | Used Instruction |
|---------------|-------------------------|-------|----------------|------------------|
| STRING | w_Str2 := | LD | SM400 | LD,LEN,-,RIGHT, |
| | DELETE(w_Str1,w_Word1, | LEN | w_Str1 | AND<>,MOV,MIDW |
| | w_Word2); | | D10238 | |
| | | - | w_Word1 | |
| | | | D10238 | |
| | | RIGHT | w_Str1 w_Str2 | |
| | | | D10238 | |
| | | - | w_Word2 K1 | |
| | | | D10239 | |
| | | AND<> | 10239 K0 | |
| | | MOV | K1 D10238 | |
| | | MIDW | w_Str1 | |
| | | | w_Str2 | |
| | | | D10238 | |

■ Function definition

BOOL DELETE E(BOOL EN, STRING S1, INT n, INT POS, STRING D1);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) |
| S1 | IN | Data to be deleted (character string data) |
| n | IN | Number of characters to be deleted (BIN 16-bit data) |
| POS | IN | Deletion position (BIN 16-bit data) |
| D1 | OUT | Deletion result (character string data) |

Remarks: Secure the area of the number of characters after deletion + 1 character as the data area that will store the character string data after deletion.

Return value

| Return Value | Description | | |
|--------------|---------------------|--|--|
| BOOL | Execution condition | | |

Example of use

- (* When execution condition X0 turns ON, the character string of the number of *)
- (* characters specified in iData1 is deleted, starting at iData2 from the head of
- (* the character string data in sData, and the result is stored into Result.)

 * M0 := DELETE E(X0, sData, iData1, iData2, Result);

6.10.8 Replacement of character string from specified position REPLACE REPLACE E

n characters of character string data starting at the specified position of the specified character string data is replaced by the specified character string.

■ Function definition

STRING REPLACE(STRING S1, STRING S2, INT n, INT POS);

Argument

| - 7 ti gairriorre | | | |
|-------------------|---|---|--|
| Argument Name | IN/OUT | Description | |
| S1 | S1 IN Data to be replaced (character string data) | | |
| S2 | IN | Data that will replace (character string data) | |
| n | IN | Number of characters to be replaced (BIN 16-bit data) | |
| POS | IN | Replacement start position (BIN 16-bit data) | |

Return value

| Return Value | Description | |
|--------------|--|--|
| STRING | Replacement result (character string data) | |

Remarks: This function cannot be used with the Basic model QCPU.

Secure the area of the number of characters after replacement + 1 character as the data area that will store the character string data after replacement.

Example of use

| Argument Type | ST Program | Conv | version Result | Used Instruction |
|---------------|-------------------------|-------|----------------|------------------|
| STRING | w_Str3 := | LD | SM400 | LD,\$MOV,MOV, |
| | REPLACE(w_Str1,w_Str2, | \$MOV | w_Str1 w_Str3 | MIDW |
| | w_Word1, | MOV | w_Word1 | |
| | w_Word2); | | D10239 | |
| | | MOV | w_Word2 | |
| | | | D10238 | |
| | | MIDW | w_Str2 w_Str3 | |
| | | | D10238 | |

■ Function definition

BOOL REPLACE_E(BOOL EN, STRING S1, STRING S2, INT n, INT POS, STRING D1);

Argument

| Argument Name | IN/OUT | Description | |
|---------------|--------|---|--|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) | |
| S1 | IN | Data to be replaced (character string data) | |
| S2 | IN | Data that will replace (character string data) | |
| n | IN | Number of characters to be replaced (BIN 16-bit data) | |
| POS | IN | Replacement start position (BIN 16-bit data) | |
| D1 | OUT | Replacement result (character string data) | |

Remarks: Secure the area of the number of characters after replacement + 1 character as the data area that will store the character string data after replacement.

Return value

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the character string data of the
- (* number of characters specified in iData1, starting at iData2 from the head of ...*
- (* the character string data in sData1, is replaced by the character string data in *)
- * sData2, and the result is stored into Result.

M0 := REPLACE_E(X0, sData1, sData2, iData1, iData2, Result);

6.10.9 Search for character string from specified position

FIND_E

The specified character string is searched for the specified character string.

■ Function definition

INT FIND(STRING S1, STRING S2);

Argument

| Argument Name | IN/OUT | Description |
|---------------|--------|---|
| S1 | IN | Character string to be searched (character string data) |
| S2 | IN | Character string to be searched for (character string data) |

Return value

| Return Value | Description |
|--------------|--|
| INT | Position where character string is found first (BIN 16-bit data) |

Remarks: This function cannot be used with the Basic model QCPU.

If the character string is not found, the return value turns to 0.

Example of use

| Argument Type | ST Program | Con | version Result | | Used Instruction |
|---------------|----------------------|-------|----------------|------|------------------|
| STRING | w_Word1:= | LD | SM400 | | LD,INSTR |
| | FIND(w_Str1,w_Str2); | INSTR | w_Str2 w_S | Str1 | |
| | | | w_Word1 K1 | | |

■ Function definition

BOOL FIND_E(BOOL EN, STRING S1, STRING S2, INT D1);

Argument

| Argument Name | IN/OUT | Description | |
|---------------|--------|---|--|
| EN | IN | Execution condition (Function is executed only when the result is TRUE) | |
| S1 | IN | Character string to be searched (character string data) | |
| S2 | IN | Character string to be searched for (character string data) | |
| D1 | OUT | Position where character string is found first (BIN 16-bit data) | |

Remarks: If the character string is not found, the return value turns to 0.

Return value

| Return Value | Description |
|--------------|---------------------|
| BOOL | Execution condition |

Example of use

- (* When execution condition X0 turns ON, the character string data in sData1 is *)
- (* searched for the character string data in sData2, and the position where the *)

*)

(* character string is found first is stored into Result.

M0 := FIND_E(X0, sData1, sData2, Result);

7 ERROR LIST

This chapter explains the errors that may occur during conversion of a created ST program.

For the execution errors that may occur when the ST program is written to the CPU module, refer to the "MELSEC-Q/L Programming Manual (Common Instruction)", "QCPU User's Manual (Hardware Design, Maintenance and Inspection)" or "MELSEC-L CPU Module User's Manual (Hardware Design, Maintenance and Inspection)".

When conversion error occurs

The error dialog corresponding to the error in the program is displayed. The maximum number of errors that may occur in a single program is 1000. Errors in excess of 1000 errors are not displayed in the error list.

 About conversion error indication
 More than one error may be displayed for a single program statement, or more than one message may be displayed for a single error.

Conversion error list (error message, cause, corrective action)

| No. | Error Message | Cause | Corrective Action |
|-----|--|--|--|
| 1 | An unanalyzable character exists. (C1009) | The character string that cannot be analyzed exists. As character strings that cannot be analyzed, there are the following examples. Example 1: 2## The format is wrong. Example 2: STRING type: STRV1 is defined. STRV1 := \$"abc"; The \$ symbol is used. Example 3: D0 := !10; The ! symbol is used. Example 4: J25 \K4X0 := 5; The symbol is used. | Correct the character string. |
| 2 | An unanalyzable operator exists. (C1010) | The operator that cannot be analyzed exists. Example 1: Y0 := M0 => M1; | Correct the operator. |
| 3 | The real number constant is wrong. (C1013) | The description of the real number constant is illegal. As illegal descriptions, there are the following examples. Example 1: REAL type : RealV1 is defined. RealV1 := 1.; The format of the real number constant is wrong. Example 2: RealV1 := 0.1E; The format of the real number constant is wrong. | Correct the description of the real number constant. |

7 - 1 7 - 1

| No. | Error Message | Cause | Corrective Action |
|-----|---|--|---|
| 4 | Description of a device is wrong. (C1014) | The description of the device is illegal. As illegal descriptions, there are the following examples. Example 1: D0.10 := TRUE; The bit No. specification of the word device is wrong. Example 2: D0@ := 0; | Correct the description of the device. |
| 5 | Description of a device is wrong. (C1017) | The description of the device is illegal. As an illegal description, there is the following example. Example 1: D0 := %MMW0.10; The device was described in an unusable format. | Correct the description of the device. |
| 6 | Description of a comment is wrong. (C1018) | The description of the comment is illegal. It is not written in the "(*" "*)" format. As illegal descriptions, there are the following examples. Example 1: (* * A parenthesis is insufficient. Example 2: (*(* The parenthesis and * format is wrong. Example 3: (* *) There is a space between "*" and ")". Example 4: (*aaaaa) * is insufficient. | Correct the description of the comment. |
| 7 | Description of a character constant is wrong. (C1019) | The description of the character string constant is illegal. As illegal descriptions, there are the following examples. Example 1: STRING type: STRV1 is defined. STRV1:= """; Example 2: STRV1:= "; " is insufficient. Example 3: STRV1:= " character "; There is ' within the character string "". Example 4: STRV1:= "\$"; The method of using the escape sequence is wrong. | Correct the description of the character string constant. |

| No. | Error Message | Cause | Corrective Action |
|-----|--|---|--|
| 8 | Description of a constant is wrong. (C1020 to C1023) | The unsupported data type was used, or the constant was described wrongly. As illegal descriptions, there are the following examples. Example 1: W_TMP := TIME#1100_0101; Example 2: W_TMP := T#0; Example 3: W_TMP := 2#0; Example 4: W_TMP := DT#1900-01-01, 00:00:00; Example 5: W_TMP := D#1994-06; Example 6: W_TMP := TOD#09:30:61; | The used data type is not supported. Correct the data type. Correct the description of the constant. |
| 9 | Variable '*1' undefined. (C1028) (Variable name enters *1.) | An undefined variable was used. There are the following examples of using undefined variables. Example 1: I_TEST := 1; The label is used without label setting being made. Example 2: D0 := HAAH; Characters other than A to F are used in hexadecimal. Example 3: D0 := 1234; | Define the used variable. |
| 10 | An error is in element specification of array. (C1033) | The method of specifying the array element is wrong. Example 1: Word type array label: W_ARY W_ARY[0,1] := 1; The array was described in the format different from the defined one. | Correct the description of the array. |
| 11 | Function '*1' is undefined. (C1049) (Function name enters *1.) | An undefined function was used. There is the following example of using an undefined function. Example 1: Real number type label: RE_1 M0 := OS_E_MD(TRUE,E1.0,RE_1); | Correct the description of the function name. |
| 12 | A variable name or a device name is too long. (C1077) | The variable name has more than 16 characters, or the device name is too long. There are the following program examples that will result in an error. Example 1: abcde678901234567 := D10; Example 2: D0 := D000000 • • • 000000000000001; The device name is too long. | Use the defined variable name. Correct the description of the device. |

| No. | Error Message | Cause | Corrective Action |
|-----|--|---|---|
| 13 | It is used except a constant for the %d argument. (C2021) (Argument error location enters *1.) | Other than a constant was used in the argument for which a constant should be specified. There are the following program examples that will result in an error. Example 1: M1 := ROL(M0,X0); Other than a constant was used in argument No. 2. Example 2: D100 := SHL(D0,D1); Other than a constant was used in argument No. 2. | Use a constant in the specified argument. |
| 14 | Syntax error. (C2054) | Wrong grammar was described. There are the following examples where grammar will be illegal. Example 1: D0: 0; "=" is not described in the assignment statement. Example 2: FOR ARY[0] := 0 TO D10 BY D20 DO D100 := D100+1; END_FOR; The array element was specified in the repeat variable. Example 3: FOR STR.W_TMP := 0 TO D10 BY D20 DO D100 := D100+1; END_FOR; The structure element was specified in the repeat variable. Example 4: D0 := 1+++++++++2; The method of using the + operator is wrong. Example 5: Word type array : IntAry1 D0 := IntAry1[[0; The method of describing the array is wrong. | Correct the grammar. |

| No. | Error Message | Cause | Corrective Action |
|-----|--|---|--|
| | '*1' missing. (C8006) (END FOR | The statement is not ended by ";". | Describe ";" at the end of the statement. |
| | | "END FOR" is not described in the FOR syntax. | Describe "END FOR" in the FOR syntax. |
| | ; END WHILE | "END WHILE" is not described in the WHILE syntax. | Describe "END WHILE" in the WHILE syntax. |
| 15 | END FOR END_REPEAT | "END_REPEAT" is not described in the REPEAT syntax. | Describe "END_REPEAT" in the REPEAT syntax. |
| | end_case or end_if enters *1.) | "END_CASE" is not described in the CASE conditional statement. | Describe "END_CASE" in the CASE conditional statement. |
| | enters 1.) | "END_IF" is not described in the IF conditional statement. | Describe "END_IF" in the IF conditional statement. |
| 16 | EXIT outside a loop statement. (C8009) | The EXIT syntax is described outside the loop syntax. | Describe the EXIT syntax in the loop syntax. |
| 17 | Description of a constant is wrong. (C8010) | The unsupported data type was used. Example 1: Timer label: wTime wTime := T#111111111111111111111111111111111111 | The used data type is not supported. Correct the data type. |
| 18 | Undefined FB was called. (C8011) | The undefined FB was called. There are the following examples of using undefined FBs. Example 1: FB_1(); The undefined FB is called. Example 2: Word type label: W_TMP W_TMP(); The variable other than FB is described. | Define the used FB. |
| 19 | The value is not specified to IN/IN_OUT variable '*1'. (C8012) (Input or I/O variable name enters *1.) | No value has been specified in the input or I/O variable of the FB. There are the following examples that will result in the above error. Example 1: I/O variable: IO_TEST1 Diverted FB name: FB1 FB1(); Example 2: I/O variable: IO_TEST1 Diverted FB name: FB1 FB1(IO_TEST); No value is assigned to the input variable. | Specify a value in the input or I/O variable of the FB. |

| No. | Error Message | Cause | Corrective Action |
|-----|--|---|--|
| 20 | Type mismatch at parameter '*1'. (C8013) (Argument name enters *1.) | The FB call argument does not match in type with the specified value or variable. There are the following examples that will result in the above error. Example 1: Input variable (word type): IN1 Diverted FB name: FB1 FB1(IN1 := TRUE); A bit type variable is specified in the word type input variable. Example 2: Input variable (word type): IN1 Output variable (word type): OUT1 Diverted FB name: FB1 Double word type: DIN1 FB1(IN1 := DIN1); A double word type variable is specified in the word type input variable. | Match the type with that of the FB call argument. |
| 21 | The variable which cannot substitute a value for IN_OUT/OUTPUT variable cannot be specified. ('*1') (C8014) (I/O or output variable name enters *1.) | The variable to which a value cannot be assigned has been specified as the I/O variable or output variable of the called FB. Example 1: I/O variable: IO_TEST1 IO_TEST1 := TRUE; Diverted FB name: FB1 A constant is passed to the I/O variable. Example 2: Input variable: IN1 Output variable: OUT1 Diverted FB name: FB1 Word type constant label: wCon FB1(IN1 :=1,OUT1 := wCon); A constant label is passed to the word type output variable. | Specify a variable to which a value can be assigned as the I/O variable or output variable of the called FB. |
| 22 | Variable '*1' which cannot be used as an argument of FB is used. (C8015) (Variable name enters *1.) | The value is passed to the variable other than the input, output or I/O variable of the called FB. There is the following example that will result in the above error. Example 1: Input variable IN1 Output variable OUT1 Variable TEST1 Diverted FB name: FB1 FB1(TEST1 := X10); | For an FB call, do not use the variable other than the input, output or I/O variable of the FB. |

| No. | Error Message | Cause | Corrective Action |
|-----|---|---|--|
| 23 | Input '*1' was multiply assigned. (C8016) (Argument name enters *1.) | The same argument is used two or more times for an FB call. Example 1: I/O variable (bit type): INOUT1 Diverted FB name: FB1 FB1(INOUT1 := TRUE,INOUT1 := FALSE); | Do not use the same argument more than once for an FB call. |
| 24 | Input '*1' unknown. (C8017) (Argument name enters *1.) | The argument of the FB to be called is not defined. Example 1: I/O variable (bit type): INOUT1 Diverted FB name: FB1 FB1(TMP_INOUT1 := TRUE); | Define the argument of the FB to be called. |
| 25 | Invalid integer literal '*1'. (C8018) (Integer value enters *1.) | The integer value is illegal. Example 1: D1 := 9999999999; The integer value is greater than the allowed range. | Correct the integer value to within the allowed range. |
| 26 | Constant '*1' is wrong. (C8019) (Constant enters *1.) | The Boolean constant is illegal. Example 1: D1 := 2##0011_0101; The wrong Boolean constant is described. Example 2: M0 := 2 #F; The wrong Boolean constant is described. | Change the description of the Boolean constant into the usable one. |
| 27 | It is used except the INT type for the element number of an array variable. (C8021) | Other than the word type is used for element specification. Example 1: Bit type array: BoolAry1 Real number type label: RealVal BoolAry1[RealVal] := x0; Example 2: Bit type array: BoolAry1 BoolAry1[D0 <d1] described.<="" element="" is="" specification="" td="" the="" wrong=""><td>Change the data type of the element into the word type.</td></d1]> | Change the data type of the element into the word type. |
| 28 | Array subscript is out of bounds. (C8022) | The specified element number exceeds the element range of the array definition. Example 1: Word type array label (number of elements 2): Kosu Unit_No[5] := D0; | Change the element number to the one within the element range of the array definition. |
| 29 | The variable which is non- array variable is used as array. (C8023) | The array format syntax was described in the variable that is not an array variable. Example 1: Word type label: W_TMP1 | Correct the description of the variable. |

| No. | Error Message | Cause | Corrective Action |
|-----|---|---|--|
| 30 | Member '*1' of '*2' is undefined. (C8024) (Structure element name or FB variable name enters *1, and structure name or FB name enters *2.) | The element name of the structure is wrong or the variable name of the FB is wrong. Example 1: Structure element name: mem1 | Correct the element name of the structure, or correct the variable name of the FB. |
| 31 | Member '*1' of '*2' which cannot be used as a FB output is used. (C8025) (FB variable name enters *1, and FB name enters *2.) | The FB variable that cannot be used as FB output was used. Example 1: Internal variable (word type): TEMP1 Diverted FB name: FB1 D100 := FB1.TEMP1; The internal variable is used as FB output. | Use the correct FB variable and describe it as FB output. |
| 32 | Variable '*1' (FB: *2) cannot be used other than an argument. (C8026) (FB variable name enters *1, and FB name enters *2.) | The FB variable using method is wrong. Example 1: [FB definition] Input variable: IN1 Output variable: OUT1 Diverted FB name: FB1 X1 := FB1.IN1; The input variable is used as FB output. | Use the correct FB variable in the argument of the FB. |
| 33 | It is a undefined structure. (C8027) | The structure name is illegal. Example 1: Structure: None Word type label: W_TMP2 W_TMP2.mem1 := 100; The wrong structure is described. | Correct the structure name. |

| No. | Error Message | Cause | Corrective Action |
|-----|---|---|--|
| 34 | The variable which cannot substitute a value for the *1 cannot be specified. 1*2'(C8028) (Error location enters *1, and function name, ":=" enters *2.) | The variable to which a constant, input variable or other value cannot be assigned is specified in the location where the value is assigned. Example 1: Label (constant type): cnt cnt := D10; Assigned to the label constant. Example 2: ABS_E(TRUE, d0, K10); The constant is described in the output variable of the function. Example 3: FB input variable (word type): IN1 BPLUS_3_M(M0, K1, D0, FB1.IN1); The input variable is specified in the argument where the value is output. | Change the value into the variable to which a value can be assigned. |
| 35 | Type mismatch at variable *1 of '*2'. (C8029) (Argument error location enters *1, and function name enters *2.) | The type of the variable does not match. Example 1: Word type array: IntAry1[01] M1 := BACOS_MD(TRUE, IntAry1, D1); | Correct the type in the specified error location of the function argument, or correct the variable type. |
| 36 | Type mismatch for '*1'. (C8030) (Operator, such as ":=" or "*" enters *1.) | The left member of the variable/device differs in data type from the right member. Example 1: D0 : =TRUE; The bit type is assigned to the word device. Example 2: D1 := D2*M1; The word type and bit type are operated. Example 3: M0 := d1 > M1; The word type and bit type are compared. | Specify the same data type in the left and right members of the variable/device. |
| 37 | No overload of '*1' takes *2 parameters. (C8031) (Function name enters *1, and the number of arguments that do not match the definition enters *2.) | The number of arguments for a function call does not match the definition. Example 1: ABS(); The number of arguments described is less than the number of arguments defined. Example 2: d0 := ABS(10, 10); The number of arguments described is greater than the number of arguments defined. | Correct the number of function arguments. |

| No. | Error Message | Cause | Corrective Action |
|-----|--|---|---|
| 38 | The type of a formula is illegal. (C8032) | The format type does not match in the control syntax. Example 1: Double word type: DwLBL FOR DwLBL := W1 TO W2 BY W3 DO W5 := W6; END_FOR; The data types of the repeat variable and last value expression/incremental expression do not match. Example 2: CASE W1 OF 1: D0 := 1; 2147483648 : D0 := 2; ELSE D0 := 10; END_CASE; The data types of the integer expression and selection value do not match. Example 3: IF W1 THEN D100 := 1; END_IF; The word type is specified for the Boolean expression. | Correct the format type. |
| 39 | Substitution is impossible for a constant variable (inside of FOR syntax). (C8033) | An attempt was made to write to the constant variable. There is the following program example for the above error. Example 1: Constant label : tei FOR tei := W10 TO W20 BY W30 DO R10 := R20; END_FOR; | Write to the constant variable (in FOR syntax) cannot be performed. |
| 40 | By FOR syntax, variables other than INT/DINT type are used. (C8034) | The variable of other than the word/double word type is used in the FOR syntax. (For example, when the character string, array or structure variable name is specified for the repeat variable) Example 1: Character string label: Str1, Str2, Str3, Str4 FOR Str1 := Str2 TO Str3 BY Str4 DO D0 := D100; END_FOR; The character string variable name was specified for the repeat variable. | Use the correct type in the FOR syntax. |

| No. | Error Message | Cause | Corrective Action |
|-----|--|--|--|
| | | "DO" is not described in the FOR syntax. | Describe "DO" in the FOR |
| | | Example 1: FOR D1 := D2 TO D3 BY D4 | syntax. |
| | The keyword '*1' is missing. (C8039) | "UNTIL" is not described in the REPEAT syntax. | Describe "UNTIL" in the REPEAT syntax. |
| | (DO | "OF" is not described in the CASE conditional | Describe "OF" in the CASE |
| | UNTIL | statement. | conditional statement. |
| 41 | OF THEN | "THEN" is not described in the IF conditional statement. | Describe "THEN" in the IF conditional statement. |
| | or | "TUFN" is not described in the FLOID conditional | Describe "THEN" in the |
| | DO | "THEN" is not described in the ELSIF conditional statement. | ELSIF conditional |
| | enters *1.) | statement. | statement. |
| | | "DO" is not described in the WAII E syntax | Describe "DO" in the |
| | | "DO" is not described in the WHILE syntax. | WHILE syntax. |
| 42 | Illegal parameter for call of *1. (C8040) (FB name enters *1.) | The description of the input, output or I/O variable of the called FB is illegal. Example 1: Diverted FB name: FB1 FB1(X10); Example 2: Input variable: IN1 Diverted FB name: FB1 FB1(FB1.IN1); | Correct the call description of the FB. |
| | | The return value or the variable that will store the | |
| 43 | The variable which stores the return value of a function is not specified. (C8041) | return value does not exist in the function that has no EN/EN0. There is the following example where the variable that will store the return value. Example 1: INT TO DINT(D0); | Describe the return value of the function. |

| No. | Error Message | Cause | Corrective Action |
|-----|---|---|--|
| 44 | There are many nesting and the conditions of control syntax, or between control syntax is too long. (C9017) | There are too many nesting levels or conditions in the control syntax, or the program of the control syntax is too long. Example 1: IF D0 = 0 THEN IF D1 = 0 THEN END_IF; END_IF; Nesting was performed to 598 or more levels in the IF statement. Example 2: FOR D0 := 0 TO 100 BY 1 DO FOR D1 := 0 TO 100 BY 1 DO FOR D1 := 0 TO 100 BY 1 DO END_FOR; END_FOR; Nesting was performed to 299 or more levels in the FOR statement. Example 3: WHILE D0 < 10 DO WHILE D1 < 10 DO END_WHILE; The WHILE; The WHILE; The WHILE; The WHILE statement was nested to 598 or more levels. Example 4: CASE W0 OF 0: D0 := 0; 1: D0 := 1; ••• 1491: D0 := 1491; END_CASE; 1492 or more integer selection values were used in the CASE statement. | The program of the control syntax is too long. Shorten the control syntax program, e.g. reduce the number of nesting level or reduce the number of conditions. |
| 45 | The value of the execution conditions EN of function '*1' is not right. (C9019) (Function name enters *1.) | In a specific function, TRUE must always be entered into execution condition EN but FALSE has been entered. Example 1: EI_M(FALSE); Example 2: DI_M(0); Example 3: COM_M (FALSE); | Specify the correct value in execution condition EN. |
| 46 | Failed to read a system file. (C9020) | The system file is corrupted. | Reinstall. |
| 47 | Since it is used by the system, Z0 and Z1 cannot be used. (C9035) | Z0 or Z1 is used. Example 1: INC_M(M10, D0Z1); Example 2: Z0 := 10; | Make correction so that Z0 or Z1 is not used. |
| 48 | Constant %d is outside the range of an element number (%d %d). (C9039) (Element number enters *1, and the numbers of elements enter *2 and *3.) | The element number of the array is illegal. Example 1: Word type array label: IntAry1[255] IntAry1[K255] := 0; | Correct the specified constant to within the element number range. |

| No. | Error Message | Cause | Corrective Action |
|-----|---|---|---|
| 49 | Division by zero. (C9065) | 0 is used as the divisor. Example 1: D0 := 10/0; Example 2: D1 := W1/K0; | Correct the portion where 0 is used as the divisor. |
| 50 | The return value of function '*1' cannot carry out direct reference. (C9066) (Function name enters *1.) | When operation could not be performed by directly referring to the return value of the character string function (indicates the ***_STR(), LEFT(), RIGHT() function). Example 1: M0 := INT_TO_STR(D0) < "AAA"; | Change the character string function that resulted in error into the other program, and correct the program to use the return value of that character string function. |
| 51 | Failed to read a system file. (C9072) | The system file is corrupted. | The system file is corrupted. Reinstall. |
| 52 | The error occurred at the conversion of function '*1'. (C9076) (Function name enters *1.) | The conversion result has an error. Example 1: TIMER_H_M(X0, TC0, -1); A negative value is used in the third argument. | In the argument of the function, use the specifiable data type or the data within the specifiable range. |
| 53 | The formula is used for the input variable. (C9118) | An operation expression or function was specified in the input variable that specifies the head device of the MELSEC function. The bit type array element whose element number is variable was specified in the specified input variable of the MELSEC function. The array element of other than bit type whose element number is variable was specified in the specified input variable of the MELSEC function. Example 1: BMOV_M(X0, MAX (D0, D1, D2), D100,D200); The function was used in the input variable. Example 2: TO_M(X0, D0+1, D1, D2, D3); The operation expression was used in the input variable. Example 3: DTO_M(X0, Dint1+K8X0, D1, D2, D3); The operation expression was used in the input variable. Example 4: BKRST_M(X0, ARY[D0], D1); The bit type array element whose element number is variable was specified in the input variable S1 that specifies the head device. Example 5: BKPLUS_M(M0, ARY[D1], ARY[D2], ARY[D3], ARY[D3], ARY[D4]); The array elements whose element number is variable were specified in the input variables S1, S2 that specify the head device. | When the operation expression or function was specified An operation expression or function cannot be specified in the input variable that specifies the head device. Specify a label name or device. When the bit type array element whose element number is variable was specified The bit type array element whose element number is variable cannot be specified in the argument that specifies the head of the device. Change the element number into a constant, or specify the label name or bit device. When the array element other than bit type whose element number is variable was specified If the array element whose element number is variable was specified If the array element mumber is variable is specified, there is a limit on the index registers used in the compiler. Therefore, make correction, e.g. change the element number into a constant, specify the label name or bit device, or reduce the number of specified array elements used in a single function. |

| No. | Error Message | Cause | Corrective Action |
|-----|--|---|---|
| 54 | An error is in a conversion result. (F0028)"*1" (Illegal conversion result is displayed in *1.) | The program is correct in ST grammar but an error occurs due to device specifications, etc. Example 1: TS0 := TRUE; | Check the contents of the list displayed in the error message, and correct the program. |
| 55 | The number of the maximum which can use a character is to 32 characters. (F0102) | The number of characters used is greater than the preset maximum value. There is the following error example that uses characters greater than the maximum value. Example 1: Character string label: Str1 Str1 := "123456789012345 678901234567890 123"; When the number of character string characters is 33 | Change the character string to within 32 characters. |
| 56 | The illegal device or value beyond the range is used. (F0137) "*1" (Illegal conversion result is displayed in *1.) | An illegal device or a numeric value outside the range is used. Example 1: M0 := COUNTER_M(TRUE, CC2, -1); | Correct the device or the numeric value to within the range. |
| 57 | Devices other than a timer are used for the argument of TIMER_M. (F0177) | The device other than the timer is used in the argument of TIMER_M. Example 1: TIMER_M(X0, CC0, 2); | Use the timer device in the argument of function TIMER_M. |
| 58 | Devices other than a counter are used for the argument of COUNTER_M. (F0178) | The device other than the counter is used in the argument of COUNTER_M. Example 1: COUNTER_M(X0, TC0, 2); | Use the counter device in the argument of function COUNTER_M. |

| No. | Error Message | Cause | Corrective Action |
|-----|---|--|--|
| 59 | With the CONCAT(_E) function, the argument and the same variable as a return value are used. (F0196) | The same variable is used in the argument and return value of the CONCAT(_E) function. Example 1: Character string label: Str1 • Str2 Str1 := CONCAT(Str2, Str1); | Use different variables in the argument and return value of the CONCAT(_E) function. |
| 60 | With the INSERT(_E) function, the argument and the same variable as a return value are used. (F0206) | The same variable is used in the argument and return value of the INSERT(_E) function. Example 1: Character string label: Str1 Str1 := INSERT (Str1, Str2, D0); The same variable is used in the argument and return value. | Use different variables in the argument and return value of the INSERT(_E) function. |
| 61 | An illegal device type is used. (C10000) | The illegal device type (timer, retentive timer, counter, pointer) is used. Example 1: Timer1 := 0; The device type timer was used. | The illegal device type (timer, retentive timer, counter, pointer) cannot be used. Change it into the applicable device type. |
| 62 | The device and numerical value which were specified can be over it, or cannot use the range. (C10001) | The device is greater than the applied range, the unusable device is specified, or the numeric value is greater than the applied range. Example 1: M0 := X2000; The device number greater than 1FFF was specified as the device number of X. Example 2: D0 := A0; The accumulator was used with the QCPU/LCPU Example 3: Double word type label: DW1 DW1 := K2147483648; | Correct the device number to within the applied range. Alternatively, change the device into the usable one, or correct the numeric value to within the applied range. |

| No. | Error Message | Cause | Corrective Action |
|-----|--|--|---|
| 63 | There is too much function or number of a operator. (C10002) | A total of 1025 or more functions or operators are used in a single statement. Example 1: D0 := 1+1+1+1++ • • • +1+1; 1025 or more operators "+" were used in a single statement. Example 2: d0 := ABS(ABS(ABS(ABS(Wlabel) • • • •)))); 1025 or more functions ABS were used in a single statement. | When functions or operators are used in a single statement, make correction to use less than 1025 functions or operators. |
| 64 | There is too much nesting of array element specification. (C10003) | When nesting was performed to 17 or more levels in the array element specification. Example 1: Array1[Array1[Array1[Array1 [Array1[Array1[Array1[]]]]]]; Nesting was performed to 17 or more levels in the array element specification. | Correct the nesting of the array element specification to up to five levels. Six or more levels are not supported. 17 or more levels will result in an error. |
| 65 | Specified FB name is already used. (C10004) | An FB call is made two or more times under the same FB name in the program. Example 1: Diverted FB name: FB1 I/O variable name: INOUT1 FB1(INOUT1 := D100); FB1(INOUT1 := D101); | Make an FB call under the same FB name only once. |
| 66 | An output variable is used before the call of FB. (C10005) | FB output is provided before an FB call. Example 1: Diverted FB name: FB1 I/O variable name: INOUT1 Output variable: OUT1 D0 := FB1.OUT1; FB1(INOUT1 := D100); | Put the FB output after the FB call. |
| 67 | The illegal type is used by '*1'. (C10006) (Operator enters *1.) | The value greater than the data type range was used in the double word or real number type assignment statement or operation. Example 1: Double word type label: w_Dword w_Dword := -2147483649; | Specify the correct range. |

| No. | Error Message | Cause | Corrective Action |
|-----|--|---|--|
| 68 | The illegal type is used at the function '*1'. (C10007) (Function name enters *1.) | The illegal data type was used for the argument of the MELSEC function. Example 1: RST_M(M0, ddev1); The double word type was specified in the second argument of function RST_M. Example 2: DECO_M(M0, Real1, K8, Real2); The real number type was specified in the second/fourth argument of function DECO_M. Example 3: COMRD_S_MD(M0, ddev1, Str32); The double word type was specified in the second argument of function COMRD_SD_MD. | Use the variable of correct data type in the argument. |

aaA

APPENDICES

Appendix 1 Character Strings that cannot be Used as Labels and FB Names

This section indicates the character strings that cannot be used as label and FB names during ST programming.

The character strings used in the device names, instruction names or function names cannot be used as labels and FB names.

If any of the character strings indicated in the following table is used, an error will occur at the execution of entry or compile.

Character strings that cannot be used as labels and FB names

| А | A, ACALL, ACJ, ACTION, ANB, ANY, ANY_BIT, ANY_DATE, ANY_DERIVED, ANY_ELEMENTARY, ANY_INT, ANY_MAGNITUDE, ANY_NUM, ANY_REAL, ANY_SIMPLE, ANY_STRING, ARRAY, AT |
|---|--|
| В | B, BEND, BL, BLOCK, BOOL, BOOL_TO_BYTE (DINT, DWORD, INT, REAL, SINT, UDINT, UINT, USINT, WORD), BY, BYTE, BYTE_TO_BOOL (DINT, DWORD, INT, REAL, SINT, STRING, UDINT, UINT, USINT, WORD), BWORKR, BWORKRP, BWORKW, BWORKWP, B_BCD_TO_DINT (INT, SINT) |
| С | C, CASE, CAL, CALC, CALCN, CONFIGURATION, CONSTANT, CTD, CTU, CTUD |
| D | D, DATE, DATE_AND_TIME, DINT, DINT_TO_BCD (BOOL, BYTE, DWORD, INT, REAL, SINT, STRING, TIME, UDINT, UINT, USINT, WORD), DO, DT, DWORD, DWORD_TO_BOOL (BYTE, DINT, INT, REAL, SINT, STRING, UDINT, UINT, USINT, WORD), DX, DY, D_BCD_TO_DINT (INT, SINT) |
| E | E, ELSE, ELSIF, EN, END, END_ACTION, END_CASE, END_FOR, END_FUNCTION, END_PROGRAM, END_IF, END_REPEAT, END_RESOURCE, END_STEP, END_STRUCT, END_TRANSITION, END_TYPE, END_VAR, END_WHILE, ENQ, EQ, EQ_STRING,EXIT |
| F | F, FALSE, FD, FOR, FROM, FUNCTION, FUNCTION_BLOCK, FX, FY, F_EDGE, F_TRIG |
| G | G, GE, GE_STRING, GT, GT_STRING |
| Н | Н |
| I | I, IF, INITIAL_STEP, INT, INT_TO_BOOL (BYTE, DINT, DWORD, REAL, SINT, STRING, UDINT, UINT, USINT, WORD) |
| J | J, JMPC, JMPCN |
| K | К |
| L | L, LDN, LE, LE_STRING, LIMIT_STRING, LINT, LREAL, LT, LT_STRING, LWORD |
| М | M, MAX_STRING, MIN_STRING, MOD, MPP, MPS, MRD |
| N | N, NE, NE_STRING, NOP, NOT |
| 0 | OF, ON, ORB, ORN |
| Р | P, PROGRAM |
| Q | Q |
| R | R, R1, RCALL, RCJ, READ, READ_ONLY, READ_WRITE, REAL, REAL_TO_BOOL (BYTE, DINT, DWORD, INT, SINT, STRING, UDINT, UINT, USINT, WORD), RECV, REPEAT, RESOURCE, RETAIN, RETC, RETCN, RETURN, REQ, RS, R_EDGE, R_TRIG |
| S | S, SB, SD, SEND, SEL_STRING, SFCP, SFCPEND, SG, SINT, SINT_TO_BOOL (BYTE, DINT, DWORD, INT, REAL, STRING, UDINT, UINT, USINT, WORD), SM, SR, SREAD, ST, STEP, STEPC, STEPD, STEPG, STEPII, STEPII, STEPIR, STEPISC, STEPISE, STEPIST, STEPN, STEPR, STEPSC, STEPSE, STEPST, STN, STRING, STRING_TO_BYTE (DINT, DWORD, INT, REAL, SINT, TIME, UDINT, UINT, USINT, WORD), STRUCT, SW, SWRITE, SZ |

App - 1 App - 1

| | Character strings that cannot be used as labels and FB names |
|---|--|
| Т | T, TASK, THEN, TIME, TIME_OF_DAY, TIME_TO_STRING, TO, TOD, TOF, TON, TP, TR, TRAN, TRANA, TRANC, TRANCA, TRANCO, TRANCOC, TRANCOCJ, TRUNC_DINT (INT, SINT), TRANJ, TRAND, TRANO, TRANOA, TRANOC, TRANOCA, TRANOCJ, TRANOJ, TRANSITION, TRUE, TYPE |
| U | U, UDINT, UDINT_TO_BOOL (BYTE, DINT, DWORD, INT, REAL, SINT, STRING, UINT, UNTIL, USINT, WORD), UINT, UINT_TO_BOOL (BYTE, DINT, DWORD, INT, REAL, SINT, STRING, UDINT, USINT, WORD), ULINT, UNTIL, USINT_TO_BOOL (BYTE, DINT, DWORD, INT, REAL, SINT, STRING, UDINT, UINT, WORD) |
| V | V, VAR, VAR_CONSTANT, VAR_EXT, VAR_EXTERNAL, VAR_EXTERNAL_FB, VAR_EXTERNAL_PG, VAR_GLOBAL, VAR_GLOBAL_FB, VAR_GLOBAL_PG, VAR_IN_OUT, VAR_INPUT, VAR_OUTPUT, VAR_TEMP, VD, VOID |
| W | W, WHILE, WITH, WORD, WORD_TO_BOOL (BYTE, DINT, DWORD, INT, REAL, SINT, STRING, UDINT, UINT, USINT), WORKR, WORKRP, WORKW, WORKWP, WRITE, WSTRING, W_BCD_TO_DINT (INT, SINT) |
| Х | X, XOR, XORN |
| Y | Υ |
| Z | Z, ZNRF, ZR |

Precaution on label name

- 1. A space cannot be used.
- 2. A numeral cannot be used as the first character.
- 3. The following characters cannot be used.

An error occurs if an underscore exists at the end of a character string or two or more underscores are used consecutively.

4. Device names cannot be used.

An error occurs if any of 0 to F is appended after a device name.

Examples: XFFF, M100

5. Do not use "EnDm" as a label name (Example: E001D9).

(n and m are any values.)

It may be recognized as a real number value and unavailable as a label name.

6. Instruction names (sequence instructions, basic instructions, application instructions) and function names (MELSEC functions, IEC functions) cannot be used.

App

App - 2

Appendix 2 ST instruction table for GX Developer and GX Works2

Instructions that can be used in ST programs of GX Developer may not be able to be used in GX Works2. As a result, an error may occur when a project that includes an ST program and is saved in GX Works2 format is read and compiled with GX Developer. In such case, correct the ST program in accordance with the following table.

| GX Works2 | GX Developer |
|-----------|--------------|
| BACOS | BACOS_MD |
| BAND | BAND_MD |
| BASIN | BASIN_MD |
| BATAN | BATAN_MD |
| BCD | BCD_M |
| BCOS | BCOS_MD |
| BDSQR | BDSQR_MD |
| BIN | BIN_M |
| BKAND | BKAND_M |
| BKBCD | BKBCD_M |
| BKBIN | BKBIN_M |
| BKOR | BKOR_M |
| BKRST | BKRST_M |
| BKXNR | BKXNR_M |
| BKXOR | BKXOR_M |
| BMOV | BMOV_M |
| BRST | BRST_M |
| BSET | BSET_M |
| BSFL | BSFL_M |
| BSFR | BSFR_M |
| BSIN | BSIN_MD |
| BSQR | BSQR_MD |
| BTAN | BTAN_MD |
| BTOW | BTOW_MD |
| вхсн | BXCH_M |
| CML | CML_M |
| COM | COM_M |
| DATERD | DATERD_MD |
| DATEWR | DATEWR_MD |
| DBAND | DBAND_MD |
| DBCD | DBCD_M |
| DBIN | DBIN_M |
| DBL | DBL_M |
| DCML | DCML_M |
| DDEC | DDEC_M |

| GX Works2 | GX Developer |
|-----------|--------------|
| DEC | DEC_M |
| DECO | DECO_M |
| DELTA | DELTA_M |
| DFLT | DFLT_M |
| DFRO | DFRO_M |
| DGRY | DGRY_M |
| DI | DI_M |
| DINC | DINC_M |
| DIS | DIS_M |
| DLIMIT | DLIMIT_MD |
| DMAX | DMAX_M |
| DMIN | DMIN_M |
| DNEG | DNEG_M |
| DOR | DOR_M |
| DRCL | DRCL_M |
| DRCR | DRCR_M |
| DROL | DROL_M |
| DROR | DROR_M |
| DSER | DSER_M |
| DSFL | DSFL_M |
| DSFR | DSFR_M |
| DSORT | DSORT_M |
| DSUM | DSUM_M |
| DTEST | DTEST_MD |
| DTO | DTO_M |
| DWSUM | DWSUM_M |
| DXCH | DXCH_M |
| DXNR | DXNR_M |
| DXOR | DXOR_M |
| DZONE | DZONE_MD |
| El | EI_M |
| EMOD | EMOD_M |
| ENCO | ENCO_M |
| ENEG | ENEG_M |
| EREXP | EREXP_M |

| | T |
|-----------|--------------|
| GX Works2 | GX Developer |
| ESTR | ESTR_M |
| EVAL | EVAL_M |
| FLT | FLT_M |
| FMOV | FMOV_M |
| FROM | FROM_M |
| GBIN | GBIN_M |
| GRY | GRY_M |
| HOUR | HOUR_M |
| INC | INC_M |
| MIDR | MIDR_M |
| NDIS | NDIS_M |
| NEG | NEG_M |
| NUNI | NUNI_M |
| OUT | OUT_M |
| PLOW | PLOW_M |
| POFF | POFF_M |
| PSCAN | PSCAN_M |
| PSTOP | PSTOP_M |
| QCDSET | QCDSET_M |
| QDRSET | QDRSET_M |
| RCL | RCL_M |
| RCR | RCR_M |
| RFS | RFS_M |
| RND | RND_M |
| RSET | RSET_MD |
| RST | RST_M |
| SECOND | SECOND_M |
| SEG | SEG_M |
| SER | SER_M |
| SET | SET_M |
| SFL | SFL_M |
| SFR | SFR_M |
| SFT | SFT_M |
| SORT | SORT_M |
| SRND | SRND_M |
| | (Nevt nage) |

(Next page)

App - 3

| GX Works2 | GX Developer |
|-----------|--------------|
| STOP | STOP_M |
| SUM | SUM_M |
| SWAP | SWAP_MD |
| TEST | TEST_MD |
| UNI | UNI_M |

| GX Works2 | GX Developer |
|-----------|--------------|
| WAND | WAND_M |
| WDT | WDT_M |
| WOR | WOR_M |
| WSUM | WSUM_M |
| WTOB | WTOB_MD |

| GX Works2 | GX Developer |
|-----------|--------------|
| WXNR | WXNR_M |
| WXOR | WXOR_M |
| XCH | XCH_M |
| ZONE | ZONE_MD |

App - 4

| [1] | |
|---|--|
| 1-bit shift of device (SFT_M) 5- 8 | |
| 1-word left shift (DSFL_M)5-55 | |
| 1-word right shift (DSFR_M)5-55 | |
| 16-bit BIN → 32-bit BIN conversion | |
| (DBL_M) 5-27 | |
| 16-bit data exchange (XCH_M)5-35 | |
| | |
| 16-bit data NOT transfer (CML_M) 5-33 | |
| [0] | |
| [2] | |
| 2' complement of 16-bit BIN (NEG_M) 5-30 | |
| 2' complement of 32-bit BIN (DNEG_M) 5-30 | |
| 2' complement of floating-point (ENEG_M) 5-31 | |
| | |
| [3] | |
| 32-bit BCD → BIN conversion (DBIN_M) 5-24 | |
| 32-bit BIN → 16-bit BIN conversion | |
| (WORD_M)5-27 | |
| 32-bit BIN → BCD conversion (DBCD_M) 5-23 | |
| 32-bit BIN → character string conversion | |
| (DSTR_S_MD) 5-80 | |
| 32-bit BIN decimal ASCII conversion | |
| (DBINDA_S_MD) 5-73 | |
| 32-bit BIN → decrement (DDEC_M) 5-22 | |
| 32-bit BIN → floating-point conversion | |
| (DFLT_M) 5-26 | |
| 32-bit BIN → gray code conversion | |
| (DGRY_M)5-28 | |
| 32-bit BIN → hexadecimal ASCII conversion | |
| | |
| (DBINHA_S_MD) | |
| 32-bit BIN increment (DINC_M) | |
| 32-bit data bit check (DSUM_M) 5-60 | |
| 32-bit data bit zone control | |
| (DZONE_MD)5-104 | |
| 32-bit data dead band control | |
| (DBAND_MD)5-102 | |
| 32-bit data exchange (DXCH_M) 5-35 | |
| 32-bit data exclusive OR (2 devices) | |
| (DXOR_M)5-45 | |
| 32-bit data exclusive OR (3 devices) | |
| (DXOR_3_M) 5-45 | |
| 32-bit data exclusive OR (3 devices) | |
| (DXOR_3_M)5-45 | |
| 32-bit data left rotation | |
| (carry flag not included) (DROL_M) 5-52 | |
| · · · · · · · · · · · · · · · · · · · | |

| 32-bit data logical product (2 devices) | |
|--|--------------|
| (DAND_M) | 5-40 |
| 32-bit data logical product (3 devices) | 5 40 |
| (DAND_3_M)(2 doubles) | 5-40 |
| 32-bit data logical sum (2 devices) | E 40 |
| (DOR_M)(2 dayless) | 5-42 |
| 32-bit data logical sum (3 devices) (DOR_3_M) | 5 / 2 |
| 32-bit data maximum value retrieval | 5-43 |
| (DMAX_M) | 5-66 |
| 32-bit data minimum value retrieval | |
| (DMIN_M) | 5-67 |
| 32-bit data NOT exclusive OR (2 devices) | 0 07 |
| (DXNR M) | 5-47 |
| 32-bit data NOT exclusive OR (3 devices) | |
| (DXNR_3_M) | |
| 32-bit data NOT transfer (DCML_M) | |
| 32-bit data right rotation | |
| (carry flag included) (DRCR_M) | 5-51 |
| 32-bit data right rotation | |
| (carry flag not included) (DROR_M) | 5-51 |
| 32-bit data search (DSER_M) | 5-59 |
| 32-bit data sort (DSORT_M) | 5-68 |
| 32-bit data upper/lower limit control | |
| (DLIMIT_MD) | .5-100 |
| 32-bit floating-point \rightarrow BIN conversion | |
| (DINT_E_MD) | 5-25 |
| 32-bit gray code → BIN conversion | |
| (DGBIN_M) | |
| 32-bit total value calculation (DWSUM_M) | 5-69 |
| [4] | |
| [4] | E 60 |
| 4-bit connection of 16-bit data (UNI_M) | |
| 4-bit disconnection of 16-bit data (DIS_M) | 5-62 |
| [7] | |
| 7-segment decode (SEG_M) | 5-62 |
| 7 deginerit decode (OLO_iw) | 0 02 |
| [A] | |
| ABS(_E) (Absolute value) | 6-21 |
| Absolute value (ABS(_E)) | |
| ACOS_E_MD | |
| (Floating-point COS-1 operation) | 5-90 |
| ACOS(_E) | |
| (Floating-point COS-1 operation) | 6-29 |
| | |

| Acquisition from end of character string | BCD format data → floating-point | E 0. |
|---|---|------|
| (RIGHT(_E)) | (EREXP_M) | |
| Acquisition from specified position of | BCD type COS operation (BCOS_MD) | |
| character string (MID(_E)) | BCD type COS-1 operation (BACOS_MD) | |
| Acquisition from start position of | BCD type SIN operation (BSIN_MD) | |
| character string (LEFT(_E))6-70 | BCD type SIN-1 operation (BASIN_MD) | |
| ADD_E (Addition) | BCD type TAN operation (BTAN_MD) | |
| Addition (ADD_E) | BCD type TAN-1 operation (BATAN_MD) | |
| Addition of BCD 4-digit data (2 devices) | BCD_M (BIN → BCD conversion) | |
| (BPLUS_M) 5-13 | BCDDA_S_MD (BCD 4-digit → decimal AS | |
| Addition of BCD 4-digit data (3 devices) | conversion) | |
| (BPLUS_3_M) 5-13 | BCOS_MD (BCD type COS operation) | |
| Addition of BCD 8-digit data (2 devices) | BDIVID_M (Division of BCD 4-digit data) | |
| (DBPLUS_M) 5-15 | BDSQR_MD (BCD 8-digit square root) | |
| Addition of BCD 8-digit data (3 devices) | $BIN \to ASCII \ conversion \ (ASC_S_MD)$ | 5-83 |
| (DBPLUS_3_M) 5-15 | $BIN \to BCD \ conversion \ (BCD_M)$ | 5-23 |
| Addition of clock data (DATEPLUS_M) 5-109 | BIN block addition (BKPLUS_M) | 5-20 |
| AND_E (Logical product)6-43 | BIN block subtraction (BKMINUS_M) | 5-20 |
| Any data fetch in character string | BIN → character string conversion | |
| (MIDR_M)5-85 | (STR_S_MD) | 5-80 |
| Any data replacement in character string | BIN → decimal ASCII conversion | |
| (MIDW_M)5-85 | (BINDA_S_MD) | 5-73 |
| ANY 3- 4 | BIN → floating-point conversion (FLT_M) | 5-26 |
| ARRAY 3- 3 | BIN → gray code conversion (GRY_M) | 5-28 |
| ASC_S_MD (BIN → ASCII conversion) 5-83 | BIN → hexadecimal ASCII conversion | |
| ASCII → BIN conversion (HEX_S_MD) 5-83 | (BINHA_S_MD) | 5-74 |
| ASIN_E_MD | BIN_M (BCD → BIN conversion) | |
| (Floating-point SIN-1 operation) 5-89 | Binary selection (SEL(_E)) | |
| ASIN(_E) | BINDA_S_MD | |
| (Floating-point SIN-1 operation) 6-28 | (BIN → decimal ASCII conversion) | 5-73 |
| Assignment (MOVE(_E)) 6-38 | BINHA_S_MD | |
| ATAN_E_MD | (BIN → hexadecimal ASCII conversion) | 5-74 |
| (Floating-point TAN-1 operation)5-90 | Bit check (SUM_M) | |
| ATAN(_E) | Bit connection of any data (NUNI_M) | |
| (Floating-point TAN-1 operation)6-30 | Bit device batch reset (BKRST_M) | |
| , , | Bit disconnection of any data (NDIS_M) | |
| [B] | Bit left shift (SHL(_E)) | |
| BACOS_MD (BCD type COS-1 operation) 5-97 | Bit specification | |
| BAND_MD (Dead band control) 5-101 | Bit reset of word device (BRST M) | |
| BASIN_MD (BCD type SIN-1 operation) 5-97 | Bit right shift (SHR(_E)) | |
| BATAN_MD (BCD type TAN-1 operation) 5-98 | Bit set of word device (BSET_M) | |
| BCD 4-digit → decimal ASCII conversion | Bit test of 32-bit data (DTEST_MD) | |
| (BCDDA_S_MD) 5-75 | Bit test of word device (TEST_MD) | |
| BCD 4-digit square root (BSQR_MD) 5-94 | Bit zone control (ZONE_MD) | |
| BCD 8-digit → decimal ASCII conversion | BKAND_M (Block data logical product) | |
| (DBCDDA_S_MD)5-75 | BKBCD_M (Block BIN → BCD conversion). | |
| BCD 8-digit square root (BDSQR_MD) 5-95 | BKBIN_M (Block BCD → BIN conversion) | |
| BCD → BIN conversion (BIN_M) 5-24 | 2 <u>-</u> (=.55 = 5 = 5 55 5 5 5 | |

| BKCMP_EQ_M |
|--|
| (Block data comparison (=)) 5-10 |
| BKCMP GT M |
| (Block data comparison (>)5-11 |
| BKCMP_LE_M |
| (Block data comparison (<=)) 5-11 |
| BKCMP_LT_M |
| (Block data comparison (<))5-12 |
| BKCMP_NE_M |
| (Block data comparison (<>)) |
| BKMINUS_M (BIN block subtraction) |
| BKOR_M (Block data logical sum)5-43 BKPLUS_M (BIN block addition)5-20 |
| BKRST_M (Bit device batch reset)5-58 |
| BKXNR M |
| (Block data NOT exclusive OR) 5-48 |
| BKXOR_M (Block data exclusive)5-46 |
| Block BCD → BIN conversion |
| (BKBIN_M) 5-32 |
| $Block\;BIN\toBCD\;conversion$ |
| (BKBCD_M)5-31 |
| Block data comparison (=) |
| (BKCMP_EQ_M)5-10 |
| Block data comparison (<) |
| (BKCMP_LT_M)5-12 |
| Block data comparison (<=) |
| (BKCMP_LE_M) |
| Block data comparison (<>) |
| (BKCMP_NE_M)5-10 Block data comparison (>) |
| (BKCMP_GT_M)5-11 |
| Block data comparison (>=) |
| (BKCMP_GE_M)5-12 |
| Block data exchange (BXCH_M)5-36 |
| Block data exclusive (BKXOR_M) 5-46 |
| Block data logical product (BKAND_M) 5-41 |
| Block data logical sum (BKOR_M) 5-43 |
| Block data NOT exclusive OR |
| (BKXNR_M)5-48 |
| Block transfer (BMOV_M) 5-34 |
| BMINUS_3_M (Subtraction of |
| BCD 4-digit data (3 devices))5-14 |
| BMINUS_M (Subtraction of |
| BCD 4-digit data (2 devices)) |
| BMOV_M (Block transfer)5-34 BMULTI_M |
| (Multiplication of BCD 4-digit data) 5-17 |
| (wataphoation of DOD +-uight data) 3-17 |

| BOOL_TO_DINT(_E) (Boolean type (BOO | L) |
|--|-------------|
| double precision integer type | |
| (DINT) conversion) | 6- 3 |
| BOOL_TO_INT(_E) (Boolean type | |
| (BOOL) integer type (INT) conversion) | 6- 4 |
| BOOL_TO_STR(_E) (Boolean type | |
| (BOOL) character string type | |
| (STRING) conversion) | |
| BOOL | 3- 3 |
| Boolean type (BOOL) character | |
| string type (STRING) conversion | |
| (BOOL_TO_STR(_E)) | 6- 5 |
| Boolean type (BOOL) double precision | |
| integer type (DINT) conversion | |
| (BOOL_TO_DINT(_E)) | 6- 3 |
| Boolean type (BOOL) integer type (INT) | |
| conversion (BOOL_TO_INT(_E)) | 6- 4 |
| BPLUS_3_M (Addition of | |
| BCD 4-digit data (3 devices)) | 5-13 |
| BPLUS_M (Addition of | |
| BCD 4-digit data (2 devices)) | 5-13 |
| BRST_M (Bit reset of word device) | 5-56 |
| BSET_M (Bit set of word device) | 5-56 |
| BSFL_M (n-bit data 1-bit left shift) | 5-54 |
| BSFR_M (n-bit data 1-bit right shift) | |
| BSIN_MD (BCD type SIN operation) | |
| BSQR_MD (BCD 4-digit square root) | |
| BTAN_MD (BCD type TAN operation) | |
| BTOW_MD (Byte unit data connection) | |
| BXCH_M (Block data exchange) | |
| Byte unit data connection (BTOW_MD) | |
| Byte unit data disconnection (WTOB_MD). | |
| byte and data discernication (VV 105_IND). | 0 0 1 |
| [C] | |
| Call of function block | 4-29 |
| CASE conditional statement | |
| Character string → 32-bit BIN conversion | 12 |
| (DVAL_S_MD) | 5 91 |
| Character string → BIN conversion | 5-0 1 |
| _ | E 01 |
| (VAL_S_MD) Character string → floating-point conversion | |
| | |
| (EVAL_M) | 5-82 |
| Character string data connection | 5 40 |
| (2 devices) (STRING_PLUS_M) | 5-19 |
| Character string data connection | |
| (3 devices) (STRING_PLUS_3_M) | 5-19 |
| Character string length acquisition | |
| (I EN/ E\) | 6 60 |

| | D |
|--|---|
| Character string length detection (LEN S MD)5-79 | Data maximum value retrieval (MAX_M)5-65 Data minimum value retrieval (MIN_M)5-65 |
| Character string search (INSTR_M)5-86 | Data search (SER_M)5-58 |
| Character string type (STRING) | Data search (SEIX_IV)5-67 |
| Boolean type (BOOL) conversion | DATEMINUS_M |
| (STR_TO_BOOL(_E))6-17 | (Subtraction of clock data)5-110 |
| Character string type (STRING) | , |
| | DATEPL MD (Addition of clock data)5-109 |
| double precision integer type | DATERD_MD (Read of clock data)5-107 |
| (DINT) conversion | DATEWR_MD (Write of clock data)5-108 |
| (STR_TO_DINT(_E)) | DBAND_MD |
| Character string type (STRING) | (32-bit data dead band control)5-102 |
| integer type (INT) conversion | DBCD_M (32-bit BIN → BCD conversion)5-23 |
| (STR_TO_INT(_E))6-19 | DBCDDA_S_MD |
| Character string type (STRING) | (BCD 8-digit → decimal ASCII conversion)5-75 |
| real number type (REAL) conversion | DBDIVID_M (Division of BCD 8-digit data)5-18 |
| (STR_TO_REAL(_E))6-20 | DBIN_M (32-bit BCD → BIN conversion)5-24 |
| Clock data format conversion | DBINDA_S_MD |
| (hour, minute, second → second) | (32-bit BIN → decimal ASCII conversion)5-73 |
| (SECOND_M)5-111 | DBINHA_S_MD (32-bit BIN → |
| Clock data format conversion | hexadecimal ASCII conversion)5-74 |
| $(second \to hour, minute, second)$ | DBL_M |
| (HOUR_M)5-111 | (16-bit BIN → 32-bit BIN conversion)5-27 |
| CML_M (16-bit data NOT transfer) 5-33 | DBMINUS_3_M Subtraction of |
| COM_M (Refresh)5-70 | BCD 8-digit data (3 devices))5-16 |
| Comment 4-32 | DBMINUS_M (Subtraction of |
| COMRD_S_MD | BCD 8-digit data (2 devices))5-16 |
| (Device comment data read) 5-79 | DBMULTI_M Multiplication of |
| CONCAT(_E) | BCD 8-digit data5-18 |
| (Concatenation of character strings) 6-73 | DBPLUS_3_M (Addition of |
| Concatenation of character strings | BCD 8-digit data (3 devices))5-15 |
| (CONCAT(_E))6-73 | DBPLUS_M (Addition of |
| Conversion of direct output into pulse | BCD 8-digit data (2 devices))5-15 |
| (DELTA_M) 5- 7 | DCML_M (32-bit data NOT transfer)5-33 |
| COS_E_MD | DDABCD_S_MD |
| (Floating-point COS operation) 5-88 | (Decimal ASCII → BCD 8-digit conversion)5-78 |
| COS(_E) (Floating-point COS operation) 6-26 | DDABIN_S_MD |
| Counter (COUNTER_M) 5- 5 | (Decimal ASCII → 32-bit BIN conversion) 5-76 |
| COUNTER_M (Counter) 5- 5 | DDEC_M (32-bit BIN decrement)5-22 |
| | Dead band control (BAND_MD)5-101 |
| [D] | DEC_M (Decrement)5-21 |
| DABCD_S_MD | Decimal ASCII → 32-bit BIN conversion |
| (Decimal ASCII → BCD 4-digit conversion) . 5-78 | (DDABIN_S_MD)5-76 |
| DABIN_S_MD | Decimal ASCII → BCD 4-digit conversion |
| (Decimal ASCII → BIN conversion) 5-76 | (DABCD_S_MD)5-78 |
| DAND_3_M | Decimal ASCII → BCD 8-digit conversion |
| (32-bit data logical product (3 devices)) 5-40 | (DDABCD_S_MD)5-78 |
| DAND_M | Decimal ASCII → BIN conversion |
| (32-bit data logical product (2 devices)) 5-40 | (DABIN_S_MD)5-76 |

| DECO_M (Decode)5-61 | DMAX_M |
|---|--|
| Decode (DECO_M)5-61 | (32-bit data maximum value retrieval)5-66 |
| Decrement (DEC_M) 5-21 | DMIN_M |
| DEG_E_MD | (32-bit data minimum value retrieval)5-67 |
| (Floating-point radian \rightarrow angle conversion) 5-91 | DNEG_M |
| DELETE(_E) (Deletion of character | (2' complement of 32-bit BIN)5-30 |
| string from specified position) 6-75 | DOR_3_M |
| Deletion of character string from | (32-bit data logical sum (3 devices))5-43 |
| specified position (DELETE(_E))6-75 | DOR_M |
| DELTA_M | (32-bit data logical sum (2 devices))5-42 |
| (Conversion of direct output into pulse) 5- 7 | Double precision integer type |
| Device comment data read | (DINT) Boolean type (BOOL) conversion |
| (COMRD_S_MD) 5-79 | (DINT_TO_BOOL(_E))6- 6 |
| DFLT_M | Double precision integer type (DINT) |
| (32-bit BIN \rightarrow floating-point conversion) 5-26 | character string type (STRING) conversion |
| DFRO_M (Intelligent function module | DINT_TO_STR(_E)6- 9 |
| 2-word data read) 5-71 | Double precision integer type (DINT) |
| DGBIN_M | integer type (INT) conversion |
| (32-bit gray → code BIN conversion) 5-29 | DINT_TO_INT(_E)6- 7 |
| DGRY_M | Double precision integer type (DINT) |
| (32-bit BIN \rightarrow gray code conversion) 5-28 | real number type (REAL) conversion |
| DHABIN_S_MD (Hexadecimal | DINT_TO_REAL(_E) 6- 8 |
| ASCII → 32-bit BIN conversion) 5-77 | DRCL_M (32-bit data left rotation |
| DI_M (Interrupt disable) 5-37 | (carry flag included))5-52 |
| Digit specification 3-16 | DRCR_M (32-bit data right rotation |
| DINC_M (32-bit BIN increment) 5-22 | (carry flag included))5-51 |
| DINT_E_MD | DROL_M (32-bit data left rotation |
| (32-bit floating-point \rightarrow BIN conversion) 5-25 | (carry flag not included))5-52 |
| DINT_TO_BOOL(_E) | DROR_M (32-bit data right rotation |
| (Double precision integer type | (carry flag not included))5-51 |
| (DINT) Boolean type (BOOL) conversion) 6- 6 | DSER_M (32-bit data search)5-59 |
| DINT_TO_INT(_E) | DSFL_M (1-word left shift)5-55 |
| (Double precision integer type | DSFR_M (1-word right shift)5-55 |
| (DINT) integer type (INT) conversion) 6-7 | DSORT_M (32-bit data sort)5-68 |
| DINT_TO_REAL(_E) | DSTR_S_MD |
| (Double precision integer type (DINT) | (32-bit BIN → haracter string conversion)5-80 |
| real number type (REAL) conversion) 6-8 | DSUM_M (32-bit data bit check)5-60 |
| DINT_TO_STR(_E) (Double precision | DTEST_MD (3Bit test of 32-bit data)5-57 |
| integer type (DINT) character string type | DTO_M (Intelligent function module |
| (STRING) conversion) 6- 9 | 2-word data write)5-72 |
| DINT 3- 3 | DVAL_S_MD |
| DIS_M (4-bit disconnection of 16-bit data) 5-62 | (Character string → 32-bit BIN conversion)5-81 |
| DIV_E (Division) 6-34 | DWSUM_M |
| Division (DIV_E) | (32-bit total value calculation)5-69 |
| Division of BCD 4-digit data (BDIVID_M) 5-17 | DXCH_M (32-bit data exchange)5-35 |
| Division of BCD 8-digit data (DBDIVID_M) 5-18 | DXNR_3_M (32-bit data NOT |
| DLIMIT_MD | exclusive OR (3 devices))5-48 |
| (32-bit data upper/lower limit control) 5-100 | |

| | DXNR_M (32-bit data NOT | |
|----|---|-------|
| | exclusive OR (2 devices)) | 5-47 |
| | DXOR_3_M | |
| | (32-bit data exclusive OR (3 devices)) | 5-45 |
| | DXOR_M | |
| | (32-bit data exclusive OR (2 devices)) | 5-45 |
| | DZONE_MD | |
| | (32-bit data bit zone control)5 | 5-104 |
| | | |
| [E |] | |
| - | EI_M (Interrupt enable) | 5-37 |
| | EMOD M | |
| | (Floating-point → BCD decomposition) | 5-86 |
| | ENCO_M (Encode) | |
| | Encode (ENCO_M) | |
| | ENEG M | |
| | (2' complement of floating-point) | 5-31 |
| | EQ_E (Equal (=)) | |
| | Equal (=) (EQ_E) | |
| | EREXP M | |
| | (BCD format data → floating-point) | 5-87 |
| | ESTR_M (Floating-point → character string | |
| | conversion) | 5-82 |
| | EVAL_M (Character string → floating-point | 0 02 |
| | conversion) | 5-82 |
| | Exclusive logical sum (XOR_E) | |
| | Exclusive OR (2 devices) (WXOR_M) | |
| | Exclusive OR (3 devices) (WXOR_3_M) | |
| | EXIT syntax | |
| | EXP_E_MD (Floating-point natural | |
| | exponential operation) | 5-92 |
| | EXP(_E) (Natural exponent) | |
| | EXPT(_E) (Natural exponential) | |
| | Ext (_E) (Natural exponential) | 0 00 |
| [F | n | |
| L, | Fetch from character string left side | |
| | (LEFT_M) | 5-84 |
| | Fetch from character string right side | 0 0-1 |
| | (RIGHT_M) | 5-84 |
| | File register block No. switching | J-0- |
| | (RSET_MD)5 | -105 |
| | FIND(_E) (Search for character | -100 |
| | string from specified position) | 6_77 |
| | First/last byte exchange (SWAP_MD) | |
| | Floating-point angle radian (RAD_E_MD) | |
| | Floating-point arigin radian (RAD_E_MD) | J-9 1 |
| | (INT_E_MD) | 5 25 |
| | | J-ZJ |

| Floating-point → character string conversio | n |
|--|------|
| (ESTR_M) | 5-82 |
| Floating-point COS operation (COS(_E)) | 6-26 |
| Floating-point COS-1 operation | |
| (ACOS_E_MD) | 5-90 |
| Floating-point COS-1 operation | |
| (ACOS(_E)) | |
| Floating-point natural exponential operation | า |
| (EXP_E_MD) | 5-92 |
| Floating-point natural logarithm operation | |
| (LOG_E_MD) | 5-93 |
| Floating-point radian → angle conversion | |
| (DEG_E_MD) | |
| Floating-point SIN operation (SIN_E_MD) | |
| Floating-point SIN operation (SIN(_E)) | 6-25 |
| Floating-point SIN-1 operation | |
| (ASIN_E_MD) | 5-89 |
| Floating-point SIN-1 operation | 0.00 |
| (ASIN(_E)) | |
| Floating-point square root (SQR_E_MD) | |
| Floating-point TAN operation (TAN(_E)) | 6-27 |
| Floating-point TAN operation (TAN_E_MD) | E 00 |
| Floating-point TAN-1 operation | ၁-ဝະ |
| (ATAN_E_MD) | 5-00 |
| Floating-point TAN-1 operation | 5-90 |
| (ATAN(_E)) | 6-30 |
| Floating-point → BCD decomposition | 0 00 |
| (EMOD_M) | 5-86 |
| FLT_M (BIN → floating-point conversion) | |
| FMOV_M (Same data block transfer) | |
| FORDO syntax | |
| FROM_M (Intelligent function module | |
| 1-word data read) | 5-71 |
| , | |
| [G] | |
| GBIN_M (Gray code → BIN conversion) | 5-29 |
| GE_E (Greater than or equal to | |
| right member (>=)) | 6-59 |
| Gray code \rightarrow BIN conversion (GBIN_M) | 5-29 |
| Greater than or equal to | |
| right member (>=) (GE_E) | 6-59 |
| Greater than right member (>)(GT_E) | 6-57 |
| $GRY_M \; (BIN \to gray \; code \; conversion) \ldots \ldots$ | 5-28 |
| GT_E (Greater than right member (>)) | 6-57 |

| [H] | Intelligent function module 1-word data write | |
|--|---|-------|
| HABIN_S_MD (Hexadecimal ASCII → BIN | (TO_M) | |
| conversion)5-77 | Intelligent function module 2-word data read | |
| HEX_S_MD (ASCII \rightarrow BIN conversion) 5-83 | (DFRO_M) | |
| Hexadecimal ASCII → 32-bit BIN conversion | Intelligent function module 2-word data write | |
| (DHABIN_S_MD) 5-77 | (DTO_M) | |
| Hexadecimal ASCII \rightarrow BIN conversion | Interrupt disable (DI_M) | |
| (HABIN_S_MD)5-77 | Interrupt enable (EI_M) | .5-37 |
| High-speed timer (TIMER_H_M)5- 5 | | |
| HOUR_M (Clock data format conversion | [L] | |
| (second \rightarrow hour, minute, second)) 5-111 | Labels | .3-11 |
| | LE_E (Less than or equal to | |
| [1] | right member (<=)) | |
| I/O refresh (RFS_M)5-38 | Left rotation (carry flag included) (RCL_M) | .5-50 |
| IF conditional statement 4- 7 | Left rotation (carry flag not included) | |
| INC_M (Increment)5-21 | (ROL_M) | |
| Increment (INC_M)5-21 | Left rotation (ROL(_E)) | .6-42 |
| Index modification | LEFT_M | |
| INSERT(_E) (Insertion of character | (Fetch from character string left side) | .5-84 |
| string into specified position)6-74 | LEFT(_E) (Acquisition from start | |
| Insertion of character string into | position of character string) | .6-70 |
| specified position (INSERT(_E))6-74 | LEN_S_MD | |
| INSTR_M (Character string search) 5-86 | (Character string length detection) | .5-79 |
| INT_E_MD | LEN(_E) | |
| (Floating-point → BIN conversion) 5-25 | (Character string length acquisition) | .6-69 |
| INT_TO_BOOL(_E) (Integer type | Less than or equal to right | |
| (INT) Boolean type (BOOL) conversion) 6-10 | member (<=) (LE_E) | |
| INT_TO_DINT(_E) (Integer type | Less than right member (<) (LT_E) | |
| (INT) double precision integer type | LIMIT_MD (Upper/lower limit control) | |
| (DINT) conversion) 6-11 | LIMIT(_E) (Limiter) | |
| INT_TO_REAL(_E) (Integer type (INT) | Limiter (LIMIT(_E)) | |
| real number type (REAL) conversion) 6-12 | LN(_E) (Natural logarithm) | .6-23 |
| INT_TO_STR(_E) (Integer type (INT) | LOG_E_MD (Floating-point natural | |
| character string type (STRING) | logarithm operation) | |
| conversion)6-13 | Logical NOT (NOT(_E)) | |
| INT 3- 3 | Logical product (AND_E) | |
| Integer type (INT) Boolean type (BOOL) | Logical product (2 devices) (WAND_M) | .5-39 |
| conversion (INT_TO_BOOL(_E))6-10 | Logical product (3 devices) | |
| Integer type (INT) character string type | (WAND_3_M) | |
| (STRING) conversion | Logical sum (OR_E) | |
| (INT_TO_STR(_E))6-13 | Logical sum (2 devices) (WOR_M) | |
| Integer type (INT) double precision | Logical sum (3 devices) (WOR_3_M) | |
| integer type (DINT) conversion | Low-speed timer (TIMER_M) | |
| (INT_TO_DINT(_E))6-11 | LT_E (Less than right member (<)) | .6-65 |
| Integer type (INT) real number type (REAL) | | |
| conversion (INT_TO_REAL(_E))6-12 | [M] | |
| Intelligent function module 1-word data read | MAX_M (Data maximum value retrieval) | |
| (FROM_M) 5-71 | MAX(_E) (Maximum value) | .6-49 |

| Maximum value (MAX(_E)) MID(_E) (Acquisition from specified | . 6-49 |
|---|----------------|
| position of character string) | . 6-72 |
| (Any data fetch in character string) | . 5-85 |
| MIDW_M (Any data replacement in | - 0- |
| character string) | |
| MIN_M (Data minimum value retrieval) | |
| MIN(_E) (Minimum value) | |
| Minimum value (MIN(_E)) | |
| MOD(_E) (Modulus operation) | |
| Modulus operation (MOD(_E)) | |
| MOVE(_E) (Assignment) | |
| MUL_E (Multiplication) | |
| Multiplexer (MUX(_E)) | |
| Multiplication (MUL_E) | . 6-32 |
| Multiplication of BCD 4-digit data | |
| (BMULTI_M) | . 5-17 |
| Multiplication of BCD 8-digit data | |
| (DBMULTI_M) | . 5-18 |
| MUX(_E) (Multiplexer) | . 6-55 |
| | |
| [N] | |
| n-bit data 1-bit left shift (BSFL_M) | . 5-54 |
| n-bit data 1-bit right shift (BSFR_M) | . 5-54 |
| n-bit left shift (SFL_M) | . 5-53 |
| n-bit right shift (SFR_M) | . 5-53 |
| Natural exponent (EXP(_E)) | . 6-24 |
| Natural exponential (EXPT(_E)) | . 6-36 |
| Natural logarithm (LN(_E)) | . 6-23 |
| NDIS_M (Bit disconnection of any data) | |
| NE_E (Unequal (<>)) | |
| NEG_M (2' complement of 16-bit BIN) | |
| NOT exclusive OR (2 devices) | |
| (WXNR_M) | 5-46 |
| NOT exclusive OR (3 devices) | . 0 .0 |
| (WXNR_3_M) | 5-47 |
| NOT(_E) (Logical NOT) | |
| NUNI_M (Bit connection of any data) | |
| NON_W (Bit connection or any data) | . 5-04 |
| [0] | |
| Operator | |
| | 4- 2 |
| OR F (Logical sum) | |
| OR_E (Logical sum) | . 6-44 |
| OUT_M (Output to device) | . 6-44 5- 4 |
| _ : - | . 6-44 5- 4 |

| | [P] | |
|----|--|-------|
| | PLOW_M (Program low-speed execution | |
| | registration) | 5-113 |
| | POFF_M | |
| | (Program output OFF standby) | 5-112 |
| | Program low-speed execution registration | |
| | (PLOW_M) | 5-113 |
| | Program output OFF standby (POFF_M) | |
| | Program scan execution registration | |
| | (PSCAN_M) | 5-113 |
| | Program standby (PSTOP M) | |
| | PSCAN M | |
| | (Program scan execution registration) | 5-113 |
| | PSTOP_M (Program standby) | |
| | _ (0 | |
| [(| ગ્ર | |
| • | QCDSET_M (Set of comment file) | 5-106 |
| | QDRSET_M (Set of file register file) | |
| | _ (| |
| ſF | र] | |
| • | RAD_E_MD (Floating-point angle radian) | 5-91 |
| | Random number generation (RND_M) | 5-93 |
| | RCL_M (Left rotation (carry flag included)). | 5-50 |
| | RCR M | |
| | (Right rotation (carry flag included)) | 5-49 |
| | Read of clock data (DATERD_MD) | |
| | Real number type (REAL) character | |
| | string type (STRING) conversion | |
| | (REAL_TO_STR(_E)) | 6-16 |
| | Real number type (REAL) | |
| | integer type (INT) conversion | |
| | (REAL_TO_INT(_E) | 6-15 |
| | REAL_TO_DINT (REAL_TO_DINT(_E)) | |
| | REAL_TO_DINT(_E) (REAL_TO_DINT) | |
| | REAL_TO_INT(_E) (Real number type | |
| | (REAL) integer type (INT) conversion) | 6-15 |
| | REAL TO STR(E) (Real number type | |
| | (REAL) character string type | |
| | (STRING) conversion) | 6-16 |
| | REAL | |
| | Refresh (COM_M) | |
| | REPEATUNTIL syntax | |
| | REPLACE(_E) (Replacement of character | 0 |
| | string from specified position) | 6-76 |
| | Replacement of character string from | |
| | specified position (REPLACE(_E)) | 6-76 |
| | Reset of device (RST_M) | |
| | RETURN syntax | |
| | | |

| RFS_M (I/O refresh)5-38 | Stop (STOP_M) | |
|---|---|------|
| Right rotation (ROR(_E))6-41 | STOP_M (Stop) | 5- 9 |
| Right rotation (carry flag included) | STR_S_MD | |
| (RCR_M) 5-49 | (BIN → character string conversion) | 5-80 |
| Right rotation (carry flag not included) | STR_TO_BOOL(_E) | |
| (ROR_M)5-49 | (Character string type (STRING) | |
| RIGHT_M | Boolean type (BOOL) conversion) | 6-17 |
| (Fetch from character string right side) 5-84 | STR_TO_DINT(_E) (Character string | |
| RIGHT(_E) | type (STRING) double precision integer | |
| (Acquisition from end of character string) 6-71 | type (DINT) conversion) | 6-18 |
| RND_M (Random number generation) 5-93 | STR_TO_INT(_E) (Character string | |
| ROL_M (Left rotation | type (STRING) integer type | |
| (carry flag not included)) 5-50 | (INT) conversion) | 6-19 |
| ROL(_E) (Left rotation)6-42 | STR_TO_REAL(_E) | |
| ROR_M (Right rotation | Character string type (STRING) real | |
| (carry flag not included)) 5-49 | number type (REAL) conversion) | 6-20 |
| ROR(_E) (Right rotation) 6-41 | STRING_PLUS_3_M (Character string | |
| RSET_MD | data connection (3 devices)) | 5-19 |
| (File register block No. switching) 5-105 | STRING_PLUS_M (Character string | |
| RST_M (Reset of device)5- 6 | data connection (2 devices)) | |
| | STRING | |
| [S] | STRING | |
| Same data block transfer (FMOV_M) 5-34 | STRUCT | |
| Search for character string from | Structured data type | |
| specified position (FIND(_E))6-77 | SUB_E (Subtraction) | |
| SECOND_M | Subtraction (SUB_E) | |
| (Clock data format conversion | Subtraction of BCD 4-digit data (2 devices | |
| (hour, minute, second → second)) 5-111 | (BMINUS_M) | |
| SEG_M (7-segment decode)5-62 | Subtraction of BCD 4-digit data (3 devices | |
| SEL(_E) (Binary selection)6-47 | (BMINUS_3_M) | |
| Sequence change (SRND_M)5-94 | Subtraction of BCD 8-digit data (2 devices) | |
| SER_M (Data search)5-59 | (DBMINUS_M) | |
| Set of comment file (QCDSET_M) 5-106 | Subtraction of BCD 8-digit data (3 devices | |
| Set of device (SET_M)5- 6 | (DBMINUS_3_M) | 5-16 |
| Set of file register file (QDRSET_M) 5-105 | Subtraction of clock data | |
| SET_M (Set of device)5- 6 | (DATEMINUS_M) | |
| SFL_M (n-bit left shift)5-53 | SUM_M (Bit check) | |
| SFR_M (n-bit right shift)5-53 | SWAP_MD (First/last byte exchange) | 5-36 |
| SFT_M (1-bit shift of device)5- 8 | | |
| SHL(_E) (Bit left shift) | [1] | |
| SHR(_E) (Bit right shift) | TAN_E_MD | |
| SIN_E_MD (Floating-point SIN operation) 5-88 | (Floating-point TAN operation) | |
| SIN(_E) (Floating-point SIN operation) 6-25 | TAN(_E) (Floating-point TAN operation) | |
| SORT_M (Data sort S) | TEST_MD (Bit test of word device) | |
| SQR_E_MD (Floating-point square root) 5-92 | TIMER_H_M (High-speed timer) | |
| SQRT(_E) (Square root) | TIMER_M (Low-speed timer) | 5- 4 |
| Square root (SQRT(_E)) | TO_M (Intelligent function module | |
| SRND_M (Sequence change)5-94 | 1-word data write) | 5-72 |

| Total value calculation (WSUM_M) 5-68 |
|---|
| [U] |
| Unequal (<>) (NE_E) 6-67 |
| UNI M (4-bit connection of 16-bit data) 5-63 |
| Upper/lower limit control (LIMIT_MD)5-99 |
| opper/lower minit control (Liwin _ivib) |
| [V] |
| VAL_S_MD |
| (Character string → BIN conversion) 5-81 |
| [W] |
| WAND 3 M |
| (Logical product (3 devices))5-39 |
| WAND_M (Logical product (2 devices)) 5-39 |
| WDT reset (WDT_M) 5-114 |
| WDT_M (WDT reset) 5-114 |
| WHILEDO syntax 4-17 |
| WOR_3_M (Logical sum (3 devices)) 5-42 |
| WOR_M (Logical sum (2 devices)) 5-41 |
| WORD_M |
| (32-bit BIN \rightarrow 16-bit BIN conversion) 5-27 |
| Write of clock data (DATEWR_MD) 5-108 |
| WSUM_M (Total value calculation) 5-68 |
| WTOB_MD |
| (Byte unit data disconnection) 5-64 |
| WXNR_3_M |
| (NOT exclusive OR (3 devices))5-47 |
| WXNR_M |
| (NOT exclusive OR (2 devices))5-46 |
| WXOR_3_M (Exclusive OR (3 devices)) 5-44 |
| WXOR_M (Exclusive OR (2 devices)) 5-44 |
| [X] |
| XCH_M (16-bit data exchange) 5-35 |
| XOR E (Exclusive logical sum)6-45 |
| SIN(_E) (Floating-point SIN operation) 6-25 |
| Cirt_L) (Floating-point only operation) 0-20 |
| [Z] |
| ZONE_MD (Bit zone control)5-103 |

WARRANTY

Please confirm the following product warranty details before using this product.

1. Gratis Warranty Term and Gratis Warranty Range

If any faults or defects (hereinafter "Failure") found to be the responsibility of Mitsubishi occurs during use of the product within the gratis warranty term, the product shall be repaired at no cost via the sales representative or Mitsubishi Service Company.

However, if repairs are required onsite at domestic or overseas location, expenses to send an engineer will be solely at the customer's discretion. Mitsubishi shall not be held responsible for any re-commissioning, maintenance, or testing onsite that involves replacement of the failed module.

[Gratis Warranty Term]

The gratis warranty term of the product shall be for one year after the date of purchase or delivery to a designated place.

Note that after manufacture and shipment from Mitsubishi, the maximum distribution period shall be six (6) months, and the longest gratis warranty term after manufacturing shall be eighteen (18) months. The gratis warranty term of repair parts shall not exceed the gratis warranty term before repairs.

[Gratis Warranty Range]

- (1) The range shall be limited to normal use within the usage state, usage methods and usage environment, etc., which follow the conditions and precautions, etc., given in the instruction manual, user's manual and caution labels on the product.
- (2) Even within the gratis warranty term, repairs shall be charged for in the following cases.
 - 1. Failure occurring from inappropriate storage or handling, carelessness or negligence by the user. Failure caused by the user's hardware or software design.
 - 2. Failure caused by unapproved modifications, etc., to the product by the user.
 - 3. When the Mitsubishi product is assembled into a user's device, Failure that could have been avoided if functions or structures, judged as necessary in the legal safety measures the user's device is subject to or as necessary by industry standards, had been provided.
 - 4. Failure that could have been avoided if consumable parts (battery, backlight, fuse, etc.) designated in the instruction manual had been correctly serviced or replaced.
 - 5. Failure caused by external irresistible forces such as fires or abnormal voltages, and Failure caused by force majeure such as earthquakes, lightning, wind and water damage.
 - 6. Failure caused by reasons unpredictable by scientific technology standards at time of shipment from Mitsubishi.
 - 7. Any other failure found not to be the responsibility of Mitsubishi or that admitted not to be so by the user.

2. Onerous repair term after discontinuation of production

- (1) Mitsubishi shall accept onerous product repairs for seven (7) years after production of the product is discontinued. Discontinuation of production shall be notified with Mitsubishi Technical Bulletins, etc.
- (2) Product supply (including repair parts) is not available after production is discontinued.

3. Overseas service

Overseas, repairs shall be accepted by Mitsubishi's local overseas FA Center. Note that the repair conditions at each FA Center may differ.

4. Exclusion of loss in opportunity and secondary loss from warranty liability

Regardless of the gratis warranty term, Mitsubishi shall not be liable for compensation of damages caused by any cause found not to be the responsibility of Mitsubishi, loss in opportunity, lost profits incurred to the user by Failures of Mitsubishi products, special damages and secondary damages whether foreseeable or not, compensation for accidents, and compensation for damages to products other than Mitsubishi products, replacement by the user, maintenance of on-site equipment, start-up test run and other tasks.

5. Changes in product specifications

The specifications given in the catalogs, manuals or technical documents are subject to change without prior notice.

6. Product application

- (1) In using the Mitsubishi MELSEC programmable controller, the usage conditions shall be that the application will not lead to a major accident even if any problem or fault should occur in the programmable controller device, and that backup and fail-safe functions are systematically provided outside of the device for any problem or fault.
- (2) The Mitsubishi programmable controller has been designed and manufactured for applications in general industries, etc. Thus, applications in which the public could be affected such as in nuclear power plants and other power plants operated by respective power companies, and applications in which a special quality assurance system is required, such as for Railway companies or Public service purposes shall be excluded from the programmable controller applications.

in addition, applications in which human life or property that could be greatly affected, such as in aircraft, medical applications, incineration and fuel devices, manned transportation, equipment for recreation and amusement, and safety devices, shall also be excluded from the programmable controller range of applications.

However, in certain cases, some applications may be possible, providing the user consults their local Mitsubishi representative outlining the special requirements of the project, and providing that all parties concerned agree to the special circumstances, solely at the users discretion.

SH(NA)-080366E-K(1902)KWIX MODEL: QCPU-P-ST-E MODEL CODE: 13JF68

MITSUBISHI ELECTRIC CORPORATION

HEAD OFFICE : TOKYO BUILDING, 2-7-3 MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN NAGOYA WORKS : 1-14 , YADA-MINAMI 5-CHOME , HIGASHI-KU, NAGOYA , JAPAN

When exported from Japan, this manual does not require application to the Ministry of Economy, Trade and Industry for service transaction permission.

Specifications subject to change without notice.