

articles quick answers discussions Articles / Desktop Programming / Windows Forms features community help Search for articles, questions, tip: P

Watch



## **Omron PLC Serial Interface**



Mahdi Mansouri

2 Aug 2011 CPOL 6 min read Rate me: 4.76/5 (22 votes)

Surpass Omron OCX OPC Component and use a user friendly .NET based class to interface Omron PLC Series



Is your email address OK? You are signed up for our newsletters or notifications but your email address is either unconfirmed, or has not been reconfirmed in a long time. Please click here to have a confirmation email sent so we can start sending you newsletters again.

Download Omron-Labview.zip - 342.4 KB

Download Omron-LabviewImplemetation.zip - 341.9 KB

Download TimeAverage-60Words-En.zip - 25.1 KB

Download TimeAverage-30Words-En.zip - 12 KB

Download OmronHostLinkUnit.zip - 768.8 KB

### Introduction

If you're tired of using some complex non-realtime COM/COM+ components (as I'm;D) that force you to connect Omron PLC series and are interested in an easy understanding, open source, real real-time .NET based object, you've just selected the right article.

This article introduces a purely code-based Host link protocol implementation, what you can easily add into your project ensures you a safe reliable RS232/485 PC-PLC communication.


## Background

OOP programming and using an accurate implementation in realtime hardware dependant is something I've done once in DeltaDTB PID Controller. You can refer to it from here.

# Using the Code

### 1. Wiring

With no doubt, the most confusing matter one may face, after reading the PDF file reduced from Omron describing the Host Link attributes, is physical connection (cable wiring). After first perusing, I made some wiring hoping it would work, but there was no success despite all my efforts. Finally, the old popular RS232 (2-2, 3-3, 5-5) was the thing answered properly (look at the below picture).



#### 2. Communication Protocol

#### 2.1 Basic Definitions

Host Computer

In host link communication protocol, the host computer (please note Omron refers to "computer" for its PLC series, please don't mix up!) has the transition priority, but for the case of peer to peer connection (e.g. you directly connected to a PLC via RS232 physical layer) noting this matter is not very important, but if you're very sensitive and scrupulous about, due to Omron definition "Data transfer between the host computer and the Host Link System is, therefore, initiated when the computer sends a command to a PC in the Host Link System." (part 3-2, Communication Protocol, page 62), the PC which runs the application assumed as Host Computer.

Block

A set of data in a transmission is called a block.

Command Block

The data block sent from the host computer to the Host Link System is called a command block.

Response Block

The block sent from the Host Link System to the computer is called a response block.

• Multiplex Communication versus Single Link Communication

In a multiple-link communications system, each block starts with a unit number and a header, and ends with a Frame Checksum (FCS) code and a terminator (\* and CR). In a single-link system, however, each block starts with only a header, and ends with only a terminator.


• Termination

The terminator in the command block enables the PC to send a response. The terminator in the response block enables the host computer to send another command.

#### 2.2 Block Formation

Below is a scheme of a formal data block. A block is usually made up of one unit called a frame, but long blocks of data (over 131 characters) must be divided into more than one frame before transmission. In a multiple-link system, the first frame can have up to 131 characters, and subsequent frames can have up to 128 characters.


In a single-link system, however, every frame (the first included) has up to 128 characters. The data must then be divided into more than one frame when there is a block consisting of more than 131 characters in a multiple-link system and of more than 128 characters in a single-link system. In this case, the beginning and intermediate blocks end with a delimiter (CR), instead of a terminator (\* CR).




**Note:** In this project, Multiple-link System is assumed as in-use method, so, inserting "@" and unit number is mandatory and done automatically when requests for reading/writing is demanded.

#### 2.2.1 Block Formation with more than one frame in Multi-Link System


First Frame (131 characters or less)



Intermediate Frame(s) (128 Characters or less)




Last Frame (128 characters or less)



#### 2.3 Sending Commands

To send a command block with more than one frame from the computer (host computer), initially send only the first frame in the block. We must wait for sending the next frame until the host computer has received the delimiter which should have been sent back from the PC.

Note: Do not separate data from a single word into different frames for any write command.




The best place of use is when you try to write a long stream of data in a sequence of registers (although I don't advice this matter).

Ð **VB.NET** Do str\_in = str\_in & Link.ReadExisting Loop While ((str\_in.Length < length\_predicted) And ((DateAndTime.Now.Ticks - tmr\_indicator) < lng\_length)) 'Checking FCS code 'Checking PLC Response code (No Command Error) 'Assume we're waiting for frame(s) 'The matter that must be checked is the penultimate and the last 'character received from PLC. if mid\$(str\_in,str\_int.length - 1,1)<>"\*" then 'Means some frame(s) 'are ready to be received 'First Process Data 'Clear RS232 Input Buffer str\_out = Link.readExisting 'str\_out = "" link.Write(vbCr)'Indicates Host Computer is ready to receive data end if

```
Loop While loop_condition
...
```

#### 2.4 Receiving Commands

To receive a response block consisting of more than one frame from the PC, the host computer must send the carriage return code (delimiter) to the PC after receiving the delimiter from the PC. This enables the PC to send the next frame.



Its obvious usage is in Read method, where for example, the user's demanded reading a more 30 consequence registers. After making the string indicates from what address and how many register(s) user requested, we entered a loop waiting for PLC response. Don't forget it's essential to keep the requested numbers in a variable.

VB.NET Shrink ▲ 🗗

```
Dim loop count As Integer = 0, count predicted As Integer = 0,
_As Long = 0, tmr_indicator As Long = 0,
As Integer = 0
Dim str_in As String = "", str_in_final As String = ""
str_in = Link.ReadExisting()
str_in = ""
Link.Write(str_out)
Do
    str_in = ""
    count predicted = IIf(count > 30, 30, count)
    If loop_count = 0 Then
        If count_predicted = count Then
            length_predicted = count_predicted * 4 + 11
            length_predicted = count_predicted * 4 + 10
        Fnd Tf
    Else
        If count_predicted = count Then
            length_predicted = count_predicted * 4 + 4
            length_predicted = count_predicted * 4 + 3
        End If
    lng_length = (length_predicted * ByteTime * 1000) + delay_ms
    lng length *= TimeSpan.TicksPerMillisecond
    tmr_indicator = DateAndTime.Now.Ticks
        str_in = str_in & Link.ReadExisting
    Loop While ((str_in.Length < length_predicted) And</pre>
    ((DateAndTime.Now.Ticks - tmr_indicator) < lng_length))</pre>
    If ((loop_count > 0) And (str_in.Length < length_predicted)) _</pre>
    Then Throw New OmronException("Error in Data line, Data corrupted!")
    If loop_count = 0 Then 'Indicates first frame
        p_response = Hex2Int(Mid$(str_in, 6, 2))
        If Mid$(str_in, str_in.Length, 1) <> vbCr Then
    Throw New OmronException("Error in Data line, Data corrupted!")
        If Not (FCSCode_Get(str_in)) Then Throw New OmronException_
    ("Comminucation Error, Please check the line!") If p_response <> _
    Omron_Response_Code.Command_Completed_Normally Then _
    Throw New OmronException(Response(p_response)(0))
        If count_predicted = count Then 'One block contains the whole response
            str_in_final = str_in_final & Mid$(str_in, 8, str_in.Length - 11)
```

#### 2.5 Data Representation

Unit Address, Register Address and number of registers to be read must be represented in Decimal format, Register contents which to be read/written must be presented in hexadecimal format and Boolean is represented as "1" (ASCII 49dec)(true) and "0" (ASCII 48dec)(false).

#### 2.6 Frame CheckSum (FCS) Calculation

The Frame Checksum is 8-bit data converted into two ASCII characters. The 8-bit data is the result of an EXCLUSIVE OR sequentially performed between each character, from the first character in the frame to the last character of the text in that frame.

```
00310001
                                  58
                                          * CR
@10
         RH
Unit no.
        Header
                                 FCS
                                         Terminator
@
        0100
                0000
            XOR
        0011
                0001
            XOR
0
        0011
                0000
            XOR
        0101
                0010
R
0
        0011
                0000
             XOR
        0011
                0001
        0101
                 1000
                        Calculation result
          Conversion
            FCS
```

```
Dim [xor] As Integer = IIf(is_last, 0, 64) '@ascii code
For I As Integer = 1 To Message.Length - 1
        [xor] = [xor] Xor Convert.ToInt32(Convert.ToChar(Message.Substring(I, 1)))
Next
Return ([String].Format("{0:X}",[xor]))
```


The FCS generator piece of code is mentioned above.

#### 3. Command Level


The tables on pages 60 to 62, give the commands and responses available for the Host Link Units, the command levels, and the modes in which they are applicable. Details of the command and response formats are given in Omron Document, Section 4 Commands and Responses.

## Using the Demo, Step by Step


#### 3.1 Running the program



#### 3.2 Checking whether any PLC is connected or not




Program could not find any PLC (No response from PLC).




 ${\it Program could find a PLC (Response is received)}.$ 

### 3.3 Reading PLC Status and Errors



#### 3.4 Reading 30 sequence Registers from PLC



## Acknowledgements

It's my appreciation to thank Prof. Kamalaldin Farzaneh, who is not only my manager, but also my teacher who has let me test, fall and rise again.

## History

- Creation Time: Wednesday Apr 27 2011
- First Release: Saturday Apr 30 2011
- Updated: Tuesday May 03 2011
- Updated: Sunday July 24 2011, Labview 7.0 Implementation added

### License

This article, along with any associated source code and files, is licensed under The Code Project Open License (CPOL)

Written By

### Mahdi Mansouri

Engineer

Sweden

**Embedded System Researcher** 





## Comments and Discussions

Add a Comment or Question		Email Alerts Search Comme	ents p
	Spacing Relaxed 🗸	Layout Normal Per pag	ge 25 ♥ Update
Write bit in working area memory (W) of Omron PLC			First Prev Next
how can i write W400.7 a true?		Member 11992923	14-Mar-17 9:29
<b>∂</b> omron serial port communication <i>&gt;</i>		© valtuntas	17-Mar-16 1:31
Serial Interface between OMRON CP1E- N to Another API(Softwa	ra) Å	© Member 11755298	10-Jun-15 16:29
© Communicating with Omron CP1H			9-Jan-15 5:04
		<b>☑</b> Member 11362415	
Write() not behaving		⊈ chriskat	27-Oct-14 11:25
Re: Write() not behaving		<b>⊈</b> chriskat	29-Oct-14 10:54
Re: Write() not behaving			2-Dec-14 8:55
Ø What PLC №			23-Jan-13 17:45
Re: What PLC A		<b>⊈</b> fab4real	23-Jan-13 20:03
☐ Re: What PLC 🌣		🙎 Mahdi Mansouri	25-Jan-13 18:32
☐ Re: What PLC 🌣		<b>⊈</b> Mr-H 2010	10-Jul-13 17:42
❷ Hie ễ		🗣 sajidconsultrics	27-Nov-12 4:01
Re: Hie A			25-Jan-13 18:25
🕡 deny 🖄		<b>⊈</b> poliku	13-Sep-12 7:34
▼ Re: deny   A  P  P  P  Re: deny   A  P  Re: deny   A  Re: deny   Re: deny   A  Re: deny   Re: d		Mahdi Mansouri	28-Oct-12 10:53
☐ My vote of 5 🖄		<b>⊈</b> NeXoR.aT	30-Jul-12 16:01
Re: My vote of 5 🌣		Mahdi Mansouri	28-Oct-12 11:41
🛾 Program could not find any PLC (No response from PLC). 🐣		<b>ਊ</b> COl2nSheZz	27-Jun-12 9:27
Re: Program could not find any PLC (No response from PLC).		Mahdi Mansouri	28-Oct-12 10:50
Error (LabVIEW2010): "This assembly contains no public controls	n 🖈	🗣 kanjoot	11-Apr-12 14:57
Re: Error (LabVIEW2010) : "This assembly contains no public control	S" 🖄		12-Apr-12 16:32
$\Box$ Transmission failed in progress $^{\not \sim}$		🗣 qnguyen5	23-Mar-12 11:21
Re: Transmission failed in progress 🖄		Mahdi Mansouri	23-Mar-12 17:23
Re: Transmission failed in progress		🗣 qnguyen5	25-Mar-12 11:15
ast Visit: 12-Oct-23 11:46		Refresh	1 2 Next Þ
General News Suggestion Question Bug Answer			
Use Ctrl+Left/Right to switch messages, Ctrl+Up/Down to switch threads, Ctrl+Shift  Permalink  Layo	+Left/Right to switch pages.	Article Copyright 20	11 by Mahdi Mansou

Advertise

Everything else Copyright © CodeProject, 1999-2023

Privacy Cookies Terms of Use

Web03 2.8:2023-09-29:1