△ STRING To HEX Converter

system

Sep ¹12 post #4

I'm pretty new beginner, please give me an example string "003C" to hex 0x003C

No. If you really have a string containing "003C", you should be able to google strtoul() to figure out that it takes three arguments (the string to convert, a place to store a pointer to the first non converted character, which can be NULL, and the base (16 for hex)), and that it returns one value - the result of the conversion as an unsigned long.

There is even an example of calling the function, but calling strtoul() is so trivial that an example is not needed.

pico Sep '12 post #5

PaulS:

How to convert a text string "003C" to Hex value 0x003C?

Lica etrtaul(

Skip to main content

Or even better -- don't use strtoul(). In fact, don't use the C++ string library at all, if you can possibly avoid it.

Assuming null delimited C-style strings (really character arrays declared like char s[] = "this is an C-style string";), you can write a simple conversion fn in a few lines like this:

```
int x2i(char *s)
 {
   int x = 0;
   for(;;) {
     char c = *s;
     if (c >= '0' && c <= '9') {
       x *= 16;
       x += c - '0';
     else if (c >= 'A' && c <= 'F') {
       x *= 16;
       x += (c - 'A') + 10;
     else break;
   }
   return x:
 }
Pass a string like
int v = x2i("003C");
```

or

int v = x2i(s);

and you will get a numeric conversion from a string of hexadecimal digits. Note this won't work for lower case letters (although easy to add -- I will leave as an exercise). It will stop converting on the first character it finds that is not 0-9 or A-F (hopefully that would be the null delimiter!), but be aware it would also return x2i("Can I have a slice of toast?") as 12 (i.e. 0x0C), for example.

(BTW, once an integer type variable holds a value, it makes no sense to describe it as decimal or hex or octal – those are string representations for human readability. The integer v will hold exactly the same value for int v = 12; and v = 0x0C; for example. So really, the title of the post should really be something like "hex string to int converter".)

Hope that helps.

system **①**

Sep '12 post #6

I use strtoul(). It puts my ASCII sting into a unsigned long HEX string that i can use for anything and is only one line of code.

system **①**

Sep '12 post #7

Pavilion1984:

I use strtoul(). It puts my ASCII sting into a unsigned long HEX string that i can use for anything and is only one line of code.

No, strtoul() doesn't put anything into any sort of string. It parses an unsigned long integer from a string.

Skip to main content

Sep '12 post #8

No, strtoul() doesn't put anything into any sort of string. It parses an unsigned long integer from a string.

I know it doen't. I was just saying thats how i use it and that it's easy to use.

system

May '13 post #9

Note that the above sample code works only for upper case hex. Not a big deal. Just add another else if:

```
else if (c >= 'a' && c <= 'f') {
    x *= 16;
    x += (c - 'a') + 10;
}</pre>
```

Sembazuru

May '13 post #10

Pavilion1984:

No, strtoul() doesn't put anything into any sort of string. It parses an unsigned long integer from a string.

I know it doen't. I was just saying thats how i use it and that it's easy to use.

It might be better to clarify your terminology. You had said:

I use strtoul(). It puts my ASCII sting into a unsigned long HEX string that i can use for anything and is only one line of code.

but you probably meant to say:

I use strtoul(). It puts my ASCII sting into a unsigned long HEX value that i can use for anything and is only one line of code.

or better:

I use strtoul(). It puts my ASCII sting into a unsigned long HEX variable that i can use for anything and is only one line of code.

The variable (at it's lowest level) only contains binary. It can be represented in many bases when output to the serial port (or other Stream device) with built in support for hex, octal, and decimal. You can create your own function to represent it in any base you like. (You could even write a function to represent it in roman numerals if you want.) But at the lowest level all variables are just plain binary.

(I actually read it the way you intended first until you were slapped down...)

system

May '13 post #11

nico

Skip to main content

PaulS:

How to convert a text string "003C" to Hex value 0x003C?

Use strtoul().

Or even better -- don't use strtoul(). In fact, don't use the C++ string library at all, if you can possibly avoid it.

strtoul was in C. What's wrong with it? It does the same thing as your code except probably faster because it's optimized and debugged.

Shruty19

Apr '18 post #12

I want to convert a string value which is coming from another board via UART [Serial.readString] to hex value. If the incoming value is "3A" then it should display "003A" . Tried strtoul n sprintf. Both are not working for me

Apr '18 post #13

Post what you tried, and we'll try to show you why it didn't work, and how to correct it.

system **①**

Apr '18 post #14

Tried strtoul n sprintf. Both are not working for me

Then you did something wrong. My crystal ball says that the problem is on line 5452546521465854296, but that is +/- 545882365496320635865.

Shruty19

Apr '18 post #15

METHOD 1:

```
char errortodisplay[10]={0};
while(Serial.available()) {
```

str=Serial.readString();
}

if(str.indexOf("ERROR")>=0) {
int x=str.indexOf("+");

int y=str.indexOf("#");
String nes=str.substring(x+1,y);

// err= nes.tolnt();

sprintf(errortodisplay,"%04X",nes.toInt()); Serial.println("er2dis=");

Serial.print(errortodisplay);

Skip to main content alues.

```
METHOD 2:

char errortodisplay[10]={0};

while(Serial.available()) {
    str=Serial.readString();
    }

if(str.indexOf("ERROR")>=0) {
    int x=str.indexOf("+");
    int y=str.indexOf("#");
    String nes=str.substring(x+1,y);
    // err= nes.toInt();
    char *ptr;
    long ret;
    ret = strtoul(nes, &ptr, 16);
    Serial.println("er2dis=");
```

This is showing error at ret = strtoul(nes,&ptr,16)

Shruty19

Serial.print(ret);

Apr '18 post #16

Also is there any way to left zero pad in string?

system

Apr '18 post #17

```
ret = strtoul(nes, &ptr, 16);
```

The strtoul() function does not take a String.

Also is there any way to left zero pad in string?

Yes.

You post code that won't compile. You don't show what is in the String instances. You don't show the output. ALL you do is whine "it doesn't work".

I'm convinced that you don't want help.

system **①**

Apr '18 post #18

nes is a String, but strtoul expects a char array.

That's why you get an eror.

The String class has a method to turn Strings into strings.

Or, you could cut out the middleman, and not bother using Strings in the first place.

bahram

Apr '19 post #19

.

Skip to main content

I tried your function int x2i(char *s). It works fine for 3 digits.

/23/23, 6:15 PM STRING To HEX Converter - Using Arduino / Programming Questions - Arduino Forum But my value is 6 digits like FC031A. How can I change your routine			
to do 6 digits.			
Thanks			
Ву			
Closed on May 6, '21			
			Back to top
Help Center		FOLLOW US	
Contact Us			
Trademark & Copyright			
Brand Guidelines			
Distributors			
Careers			

Security

Cookie Settings

Terms of Service

Privacy Policy

© 2020 Arduino