

A36871 Rear hydraulic outlets






www.avanttecno.com

A36871 Rear hydraulic outlets


This connector is between the loader chassis and valve segment. Use copper washers for sealing.



www.avanttecno.com

A36871 Rear hydraulic outlets

Use these connectors for the return to cooler.



The new pressure line is fitted here.

The new connector is fitted between these existing lines

www.avanttecno.com