

- With this instruction the L-cabin can be assembled on a Avant 500-700 loader
- This is a retrofit instruction



- Before assembling make sure that you find all of the components listed below in your retrofit kit
 - A33448 x1 Windscreen washer
 - A410091 x1 canopy, polycarbonat
 - A49446 x1 Rear window, complete
 - A49453 x1 Windscreen, complete
 - 64993 x1 Electric motor
 - 64572 x1 Arm, windscreen
 - 65170 x1 Wiper blade
 - A49451 x1 Window, right side
 - A416315 x1 Cover plate, front
 - 64986 x1 Emergency hammer
 - 64987 x1 Bracket, emergency hammer
 - A411021 x1 Decal emergency exit
 - A410111 x1 Wire harness
 - 72320 x1 Hexagonal nut M8
 - 73122 x2 Washer M8
 - 72133 x1 Hexagonal screw M8x30
 - 73766 x1 Hexagonal screw M6x16
 - 71680 x1 Washer M6



- Start the assembly by removing the loaders safety canopy also the cup holders need to be removed
- If loader has work lights remove them before removing the safety canopy so you can assemble them back when putting the safety canopy back
- If you have Avant 500 series or e series loader you need to change loaders safety canopy to Avant 600/700 series safety canopy p/n A33920 so you can assemble the L-cabin



- Safety canopy can be prepared before attaching it to loader
- Attach these brackets for windscreen and side window
- To the safety canopy need 2 of these double sided brackets and 4 of these one side brackets
- One side bracket
- Double sided bracket














Arrows in the picture tells where the brackets are to be attached








- When the brackets are on their places you can attach the windscreen on it's place
- When the windscreen is on it's place you can attach the elecctric motor to it



 Screws are M5x25 and nyloc hexagonal nuts







- Attach brackets seen on the picture to windscreen so you can attach the lower glass on it's place
- Attach the brackets to both side of the windscreen and again use the plastic covers and M5x25 screws for attaching





- Slide the plastic sealant on it's place like on the picture
- When the seal is on it's place you can attach the roof on it's place
- After this you can assemble the safety canopy to it's place





- Rear wall will be attached from the bottom
- Use the lower bracket to secure it in place
- Both screws here need to tighten just a little so the sideframes can be attached





- Rear wall will be attached from left side to seat bottom as on the picture
- Frame also supports the back wall
- Tightening spots are marked to picture with red circles






 In this picture the brackets for back wall and how the emergency hammer is attached to brackets





- Bracket needs to be attached to seat bottom from the right side like on the picture
- When all the screws are on their places you can tighten them up






- Make place for windscreen wiper switch
- Panel has some precutted pieces wich can be removed by stanley knive and pliers






- Windscreen wipers wire harness will route from the hole next to the panel inside the cabin
- Then route the wire together with the work light wires to front part of the safety canopy





- In the picture you can see how the wire harness is attached to electric motor
- Red wire goes to highest coupling, black to middle and the blue to lowest coupling






- Electric motor wire harness will be cover with these strips
- Cover strips are attached to safety canopy by using M6x30 screws






 Wire harness fuse wire will be attached to fuseboxes 25A fuse, fuse is for cabin.
Make sure to connect to the fused side of the connection bar.

Wire harness grounding wire is attached to machines grounding point in front part of the loader







- Attach wire harness wire X2 to windscreen washer tank
- Attach the contactors as in the picture:
 - Green wire goes to + hub
 - Black wire goes to hub






- Attach the hose for windscreen viper to viper arm
- Route the hose from top corner of the window and beside the safety canopy to the hole underneath the oil cooler
- When routing the hose you need to be sure that it won't affect to any other movement's when the hose it's on it's place





- Route the hose to left side of the loader on top of the hydraulic oil tank
- When you have the hose on the left side you can attach it to tank as in the picture








 When the hose is attached you can attach the washer tank to it's place as on the picture





- Next we can attach the sideglass
- You can attach the plastic covers to glass already
- To backside of the glass you need to attach brackets as in the picture
- Tighten the brackets with fingers so you can still rotate them







Attach the sideglass to loader with M5x25 screws






- When the glass is on it's place turn the brackets as in the picture
- After this tighten all the screws





- Drill 5mm hole to Back wall as in the picture, the hole also must go trough the panel
- When drilling the hole be careful not to drill too far and damage the switches
- After drilling the hole make an M6 thread to it.
- When you have made the thread to it you can attach a bracket to hold the sideglass







- You need to attach weather stripping to lower glass bracket
- Window fasteners can be attached to lower glass









 Bracket for lower glass is attached to loaders front frame

Lower glass is attached to windscreen lower brackets







- When the assembly is ready test the windscreen viper and the liquid flow before mounting the covers.
- When everything in the cab works as it should mount the covers back to the loader