**Wiring Harness** 24 690 02 Rev. I **EFI Wiring Diagram 6-Terminal Connector** F S **→M** 2 **Q** N N **←**(A) **◄**①  $\bigoplus_{\blacktriangledown}$ (B)→ **K**→ **(**√**(**) 000000000 <u>J</u>-(AK)-00 A 0 0 KohlerEngines.com **→**(W) **→**(**((()**) M G (K)  $M \oplus G$ Ē  $\bigcirc$ **©** ₿ ₿ **B**  $\bigcirc$  $\oplus$  $\oplus$   $\bigcirc$  $\mathbb{B} \oplus \mathbb{H} \mathbb{M}$ ABC 2 **A (Z)** (AE) (AF) (AI) (AJ)(AA) (AB) (AD) (AG) (AH) (AC)

		_							
Α	Red	В	Red/Black	С	Red/White	D	Yellow	Е	Light Green
F	Dark Green	G	Dark Blue	Н	Purple	I	Pink	J	Tan
K	White	L	Grey	M	Black	N	Stator	0	Rectifier-Regulator
Р	30A Fuse	Q	Battery	R	Fuel Pump	S	6-Terminal Connector	Т	Starter Motor
U	Oil Pressure Switch	V	MIL (Optional)	W	10A Fuse	X	Black Connector	Υ	Grey Connector
Z	Fuel Injector #1	AA	Fuel Injector #2	AB	Ignition Coil #1	AC	Ignition Coil #2	AD	Crankshaft Position Sensor
AE	Oxygen Sensor	AF	Throttle Position Sensor	AG	Manifold Absolute Pressure Sensor	АН	Oil Temperature Sensor	Al	Intake Air Temperature Sensor
Λ.Ι	Diagnostic Connector	٨K	Grov/Blue	ΔI	Electronic Governor				

only

Diagnostic Connector

ΑK

Grey/Blue

AL