

- With this instruction door can be assembled on Avant 200 series loader
- This is a retrofit instruction




- Before assembling make sure that you find all of the components listed below in your retrofit kit
 - A37153 Door frame
 - A421860 Door glass
 - 65026 Subplate door handle
 - 64981 Lockbody
 - 65025 Door handle
 - 65027 Subplate door handle
 - A422071 Fastening bracket
 - 64979 Pin door lock
 - A37154 Frame
 - 64989 Bracket holder
 - 64988 Holder belt
 - A422403 Decal
 - A422407 Finishing strip
 - 74503 Hexagonal screw M8x65
 - A422430 Adjusting plate
 - 74788 x4 Fastener, window
 - A422443 Rubber plate
 - A422462 Tiivistenauha



- Remov left side sideglass p/n A419839 and frame p/n A421262
- Cover behind the seat p/n A418873 needs to be removed to assemble the doorframe on it's right place




Frame is attached from top to machines safety canopy






Frame is attached from bottom to machines frame





- Safety canopy attaching point where the frame is attached
- Frame attaching spot







- Frame attaching point stays under the back cover plate
- The cover plate have to be modified for the frame fitment
- The modification is shown on this picture





Door will be lifted on it's place







- Door movement is reduced by rubber holder belt
- The movement is reduced so the door doesn't break the covers or the glass nor bend the frame





- Door is locked by this lock pin
- The lock pin is attached to lock frame and it has one of the machines windshield attaching points





- When everything is attached and installed on their places check that the door works
- If the pin is too far or too close you need to adjust it so the door works perfectly
- When it does you can put all removed covers back