Fitting Instruction, Socket Assemblies P/N 75036_75035:

It is recommendable to use the special AMP pliers tool, when installing the tiny sleeves to the ends of the leads.

Fitting in the leads to the 7-pole socket, notice that the small cylinder in which the leads have been pushed has a slot at the outer side, which must be pushed to the corresponding spline inside the socket. The position of the slot has been shown by an exclamation mark in the photo attached below.

The slot remains between the leads No: 6. and 7. That is between the green and the black lead.

The so-called 03.00 o'clock **MARKER** lump, at the outer radius of the socket, which must be fitted pointing to the right, against the stamped marker on the Faster multi-connector. That lump will be situated beneath the lead No:5 after the assembly has been completed.

In the picture below: Notice the small graphic picture indicating the color codes of each individual cable also.

