

- With this instruction Double acting extra auxiliary hydraulics outlet to front can be assembled on a Avant 400 series loader
- This is a retrofit instruction.



- Before assembling make sure that you find all of the components listed below in your retrofit kit
 - A414870 x2 Bracket for hydraulic pipe
 - A414873 x2 Hydraulic pipe
 - A414858 Mounting bracket
 - 64190 x2 Quick coupling part
 - 73754 Cover Black
 - 65566 Cover Blue
 - A414877 x2 Hydraulic hose
 - A47638 x2 Hydraulic hose
 - 65099 Selector valve
 - 64041 x2 Basic fitting
 - 64042 x3 Basic fitting
 - 65276 Switch
 - A411636 x2 Hydraulic hose
 - A49452 Wire harness rear auxiliary hydraulics
 - 71681 x2 Washer M6
 - 72318 x2 Hexagonal nut M6
 - 72127 x2 Hexagonal screw M6x90
 - 74768 x2 Washer M6
 - 64068 Elbow fitting 90°
 - 64134 Elbow fitting 90°
 - 74438 x8 Hexagonal head screw M6x40



- Remove the right side cover and both spirals from boom
- After removing the cover and spirals lower the boom to horizontal level to ease the assembly
- Wash the loader to avoid contaminating the hydraulic system




- Selector valve will be attached to loaders right side between the control valve and the hydraulic ooil cooler
- Usage between multiconnector or extra hydraulics can be choosen with the selector valve
- Attach the couplings to valve





- Remove the auxiliary hydraulic hoses from control valve and route them under the oil cooler
- Open the hoses from boom to avoid twisting the hoses





 Front auxiliary hydraulic hoses are attached to selector valve





- Attach the selector valve between the control valve and hydraulic oil cooler
- Right side plate has holes for this selector valve so its easy to find the assembly spot





- When the selector valve is on it's place tighten the booms hoses
- Extra auxiliary hydraulic hoses to front needs to be attached on top of the selector valve
- From control valve to selector valve comes two new hoses p/n A411636
- Attach these two new hoses from top fitting to top fitting and from lower fitting to lower fitting






 Route the new hoses same way as the old ones, this is the right way to route them





- Attach two new hydraulic pipes to loaders boom
- With the retrofit kit comes two new brackets for hydraulic pipes
- These brackets are attached on top of the old brackets
- Remove the plate wich holds the top pipes





- Under the faster multiconnector will be attached bracket
- Attach quick attachment couplings to this bracket





- Extra auxiliary hydraulic hoses p/n A414877 can be attached to other hoses with zipties to ease the assembly
- When the hoses are attached from both ends put covering spiral back on it's place
- Red line shows how hoses are routed trough the boom





- Remove the spiral to attach hoses p/n A47638 to hydraulic pipes
- When the hoses are connected you can route them to te selector valve
- When the hoses are tightened put the spiral back
- To help putting the spiral back tighten the hoses with zip ties and remove them when putting the spiral back






- Remove the cover from electric coupling
- Attach the wire harness for selecting rear or front auxiliary hydraulic outlet






Attach the wire harnesses grounding wire to loaders grounding point





- Wire harnesses fuse wire will be attached to fuse boxes lowest box
- Fuse is 25A
- If the wire has this plastic cover you need to remove it so you can attach it to fuse box
- Make sure to connect to the fused side of the connection bar





- With stanley knive cut the decal and with pliers remove the precutted piece
- Control switch will be pressed on it's place
- Control switch is attached to panel







- When everything is attached test the system
- If there are leaks when testing the system tighten the couplings
- This point the leaks are easier to remove and tighten the couplings
- When everything is ok attach the removed covers back to loader