
D1 - CYLINDER HEAD

D1 - CXI

HONDA04.ESTL00618010618D1




1 1 1						i
Pos.	POS. REF-NO.	Description	Engine No.	·	GX	
	SSO, IS AW 2028		ďn	0	390 X1<1>	
	12200-ZF6-W00	HEAD COMP., CYLINDER		•		
-	12204-ZE2-306	GUIDE, IN. VALVE <0.S.>				
m	12205-ZE2-305	GUIDE, EX. VALVE <0.5.>				
4	12216-ZE2-300	CLIP, VALVE GUIDE			н	
<u> </u>	V 5 12251-ZF6-W00	GASKET, CYLINDER HEAD			<u></u>	
•	6 12310-ZE2-020	COVER COMP., HEAD				
	7 95005-11105-30	TUBE, 11X105, <95005-11001-30M>			<u></u>	
7 8	V8 12391-ZE2-020	PACKING, HEAD COVER			<u>-</u>	_
11	90014-ZE2-000	BOLT, HEAD COVER				_
12	12 90042-ZE8-000	BOLT, STUD, 8X131.5			72	
13	13 90047-ZE2-000	BOLT, STUD, 8X47	_	2638033	7	
		EXHAUST STUD BROKEN AFTER 2ND	_		_	_
_		COUNTERMEASURE	_		_	_
_		EXHAUST STUD BROKEN AFTER 2ND			_	_
_		COUNTERMEASURE	_			
13	13 92900-08032-0E	BOLT, STUD, 8X32	2638034		7	_
14	14 90441-ZE2-010	WASHER COMP., HEAD COVER				_
16	16 94301-12200	PIN, DOWEL, 12X20		<u>«</u>	<u>~</u>	_
1.7	17 95725-10080-00	BOLT, FLANGE, 10X80			4	_
1.8	18 98079-56846	PIUG, SPARK <bprges ngk=""></bprges>				_
1.8	18 98079-56855	PLUG, SPARK <w20epr-u denso=""></w20epr-u>				_
18	18 98079-55846	SPARK PLUG <bpr jes="" ngk=""></bpr>			_	_

D1 - CYLINDER HEAD

HONDA04.ESTL00618010618D1


|PLUG, SPARK <W16EPR-U DENSO> |PLUG, SPARK <BP5ES NGK>

18 98079-55855 18 98079-55841



. Bos.	POS. REF-NO.	Description	Engine No.	0	GX 390 K1<1>
1 1 1 +					
	12000-ZF6-405	BARREL ASSY, CYLINDER			_
	15510-ZE2-023	SWITCH ASSY., OIL LEVEL		2334667	
	2 15510-ZE2-033	SWITCH ASSY., OIL LEVEL	2334668	2456575	
. 4	2 15510-ZE2-043	SWITCH ASSY., OIL LEVEL	2456576		
7	4 16541-ZE3-010	SHAFT, GOVERNOR ARM	_		
	5 32197-ZE2-003	SUB HARNESS	_	2334667	
	8 90013-883-000	BOLT FLANGE, 6X12 <ct200></ct200>	_	2334667	
٠ -	9 90131-883-000	BOLT, DRAIN PLUG			72
7	0 90446-KE1-000	WASHER, 8.2X17X0.8	_		<u> </u>
	.2 91201-ZE3-004	OIL SEAL, 35X52X8			<u> </u>
-	.3 91203-952-771	OIL SEAL, 8X14X5			
14	.4 91353-671-004	O-RING, 14MM <nok></nok>			<u></u>
1	.7 94050-10000	NUT, FLANGE, 10MM			
35	8 94109-12000	WASHER, DRAIN PLUG, 12MM			2
15	19 94251-10000	PIN, LOCK, 10MM			н
5	20 95701-06012-00	BOLT, FLANGE, 6X12			7
2	21 96100-62020-00	BEARING, RADIAL BALL, 6202	_		


D12 - CRANKCASE COVER



(1)

Pos.	POS. REF-NO.	Description	Engine No.	 to	390
			· ·		K1<1>
2	2 11300-ZE3-020	COVER ASSY., CRANKCASE	: : : : : : : : :	; ; ; ; ; ; ; ; ; ; ;	
4 3	3 11381-ZE3-800	PACKING, CASE COVER			
7.44	4 15600-ZG4-003	CAP ASSY., OIL FILLER			1
7.5	5 15600-735-003	CAP ASSY., OIL FILLER	_		
/ 8	8 15625-ZE1-003	PACKING, OIL FILLER CAP			7
7 9	/ 9 16510 - ZE3 - 000	GOVERNOR ASSY.			
10	10 16511-ZE8-000	WEIGHT, GOVERNOR			m
11	11 16512-ZE3-000	HOLDER, GOVERNOR WEIGHT			-1
12	12 16513-ZE2-000	PIN, GOVERNOR WEIGHT			m
13	13 16531-ZE2-000	SLIDER, GOVERNOR			Н
15	.5 90602-ZE1-000	CLIP, GOV. HOLDER		_	-1
16	.6 90701-HC4-000	PIN, DOWEL, 8X12			7
1 / 17	17 91201-ZE3-004	OIL SEAL, 35X52X8			۳.
18	.8 94101-06800	WASHER, PLAIN, 6MM			-4
19	19 95701-08040-00	BOLT, FLANGE, 8X40			7
20	20 96100-62020-00	BEARING, RADIAL BALL, 6202			ч
21	21 96100-62070-00	BEARING, RADIAL BALL, 6207			Н


E4 - CRANKSHAFT




[NEW SELECTION]

		up to 390 KIC1>	to	390 K1<1>
V 7 13310-ZF6-W70 CRANK 8 13351-ZB3-010 WEIGH	CRANKSHAFT COMP. WEIGHT, BALANCER			
10 90534-706-010 WASHE V11 90741-805-000 KEY,	WASHER, LOCK, 8MM KEY, 7X7X33			
	KEY, 7X7X33 <yellow> BEBRING, RADIAL BALL, 6207S</yellow>			
. <u></u>	BOLT, HEX., 8X25			

E6 - PISTON



GX 390 K1<1>	22 11 1 11
1 5 6 1 1	
- B	
Engine No.	
Description	RING SET, PISTON (STD.) , (NIPPON) RING SET, PISTON (STD.) , (TEIKOKU) RING SET, PISTON (0.25) , (NIPPON) RING SET, PISTON (0.25) , (TEIKOKU) RING SET, PISTON (0.50) , (NIPPON) RING SET, PISTON (0.50) , (TEIKOKU) RING SET, PISTON (0.75) , (TEIKOKU) PISTON (0.75) , (TEIKOKU) PISTON (0.25) PISTON (0.25) PISTON (0.25) PISTON (0.25) PISTON (0.50) PISTON (0.50) PISTON (0.50) PISTON (0.75) PIN, PISTON ROD ASSY, CONNECTING (STD.) BOLT, CONNECTING ROD CLIP, PISTON PIN, 20MM
POS. REF-NO.	




E10 - CAMSHAFT

HONDA04.ESTL00618010618E10

[NEW SELECTION]


	Pos.	POS. REF-NO.	Description	Engine No.		СХ	_
		-		an	to	390	-
	_ :					K1<1>	- 1
	-	1 14100-ZF6-W00	CAMSHAFT ASSY.		2391939		<u> </u>
		1 14100-ZF6-W01	CAMSHAFT ASSY.	2391940		<u>-</u>	—
	\ \ 2	2 14410-ZE3-013	ROD, PUSH			_ 8	-
	lm.	3 14431-ZE2-010	ARM, VALVE ROCKER	_		7	_
		4 14441-ZE2-000	LIFTER, VALVE			_	
	ហ	5 14451-ZE1-013	PIVOT, ROCKER ARM			2	_
	9	6 14568-ZE1-000	SPRING, WEIGHT RETURN			п	_
	7	7 14711-ZE3-000	VALVE, IN.			7	_
	- K	/ 8 14721-ZE3-000	VALVE, EX.				_
	6	9 14751-ZE2-003	SPRING, VALVE			77	_
	10	10 14771-ZE2-000	RETAINER, IN. VALVE SPRING				_
i,	13	11 14773-ZE2-000	RETAINER, EX. VALVE SPRING			<u>-</u>	_
	12	12 14775-ZE2-010	SEAT, VALVE SPRING				_
	V 13	V 13 14781-ZE2-000	ROTATOR, VALVE				_
	14	14 14791-ZE2-010	PLATE, PUSH ROD GUIDE				
	1 15	V 15 90012-ZE0-010	BOLT, PIVOT, 8MM			- 2	
	1/16	V16 90206-ZE1-000	NUT, PIVOT ADJUSTING			7	

1209 ZE8 Mg VINT WARD TIV.




Pos.	POS. REF-NO.	Description	Engine No.	O I	GX 390 X1<1>	:
\ \ 2	V 1 28400-ZE3-W01ZA 2 28410-ZE3-W01ZA	STARTER ASSY., RECOIL, *R8*, BRIGHT RED CASE COMP., RECOIL STARTER, *R8*, BRIGHT RED				
~	3 28421-ZE3-W01 4 28422-ZE2-W01	PULLEY, RECOIL STARTER RATCHET, STARTER			R	
< × 5	5 28441-ZEZ-W01	SPRING, FRICTION			-	
9/	6 28442-ZE2-W01	SPRING, STARTER RETURN				
7 7	7 28443-ZE2-W01	SPRING, RATCHET 7,0			7	
89	8 28444-ZE2-W01	RETAINER, SPRING'		_	7	
<u> </u>	10 28461-ZE2-W01	GRIP, STARTER		2584635	-	
100	.0 28461-ZE2-W02	GRIP, STARTER	2584636	_	-	_
1,	V11 28462-ZE3-W01	ROPE, RECOIL STARTER	_	_	<u> -</u>	_
7.5	.2 28469-ZE2-W01	GRIP, REINFORCEMENT	_	2584635	<u>-</u>	7
,13	13 90004-ZE2-W01	SCREW, CENTER	_	_	1	
1/14	√14 95701-06008-00	BOLT, FLANGE, 6X8	_	_	m	
++	T	 	* 6 2 6 6 4 1 C C C C C C C C C C C C C C C C C C	+11111111111	+	

F2 - FAN COVER




NO.		Engine No.	GX 390 K1<1>	
1 16731-ZE2-003 7 19610-ZE3-010ZA 10 19631-ZE3-W00 15 90013-883-000	03 CLIP, TUBE 110ZA COVER COMP., FAN, *R8*, BRIGHT RED 100 SHROUD 100 BOLT FLANGE, 6X12 <ct200></ct200>			

F6 - CARBURETOR




	\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \		1 1 1 1 1 1 1 1 1 1	7;14;12;4
POS. REF-NO.	Description	Engine No.	t2	390
1		-		VI<1>
1 1 16010-ZE2-812	GASKET SET	. —		
V 2 16011-ZA0-931	VALVE SET, FLOAT			
V3 16013-ZA0-931	FLOAT SET			1
4 16015-ZE2-005	CHAMBER SET, FLOAT	•	BE48B A	7
4 16015-ZE8-005	CHAMBER SET, FLOAT	BE48B B		r-1
V 5 16016-ZE0-005	SCREW SET, PILOT	. —	BE48B B	
V 5 16016-ZH7-W01	SCREW SET	BE85B B		
6 16024-ZE1-811	SCREW SET, DRAIN			
7 16028-ZE0-005	SCREW SET			-
8_16044-ZE3-W20	CHOKE SET 254 WIOL OVH.			٦
√9 16100-ZF6-W30	CARBURETOR ASSY. <be48b a=""></be48b>		2254363	
V9 16100-ZF6-W31	CARBURETOR ASSY. <be48b b=""></be48b>	2254364	2658574	
V9 16100-ZF6-V01	CARBURETOR ASSY. <be85b b=""></be85b>	2658575		7
10 16124-ZE0-005	SCREW THROTTLE, SET			
11 16166-ZF6-W20	NOZZLE, MAIN		BE49A B	
11 16166-ZF6-V00	NOZZLE, MAIN	BE85C B		-
V 12 16173-001-004	PACKING, FUEL STRAINER CUP			н
V 13 16211-ZF6-000	INSULATOR, CARBURETOR			п
V14 16220-ZA0-702	SPACER COMP., CARBURETOR	2256142		1
V 15 16221-ZF6-800	PACKING, CARBURETOR 64413			_
▶ V16 16223-ZE3-W00.	PACKING, INSULATOR 64422	_		
17 16576-891-000	HOLDER, CABLE	_		

F6 - CARBURETOR



STAY ASSY., CHOKE CONTROL, <remote></remote>		_	17
HOLDER, WIRE			
LEVER COMP., CHOKE <std.></std.>	2256142	_	
SPRING, RETURN			1
LEVER, COCK		BE48B A	
LEVER, COCK	BE48B B		-
PLATE, LEVER SETTING			н
SPRING, COCK LEVER			н
PACKING, FUEL COCK			
CUP, FUEL STRAINER			
CIRCLIP, SMM			1
SCREW, PAN, 3X8			m
SCREW, PAN, 3X6	BE48B B	BE49A B	3
SCREW, PAN, 3X6			
SCREW, PAN, 3X6	BE85C B		7
SCREW, PAN, 4X6			
SCREW-WASHER, 5X16			-
PIN, SPRING, 2X12	2256142		
MAIN,		BE48B B	_
		BE48B B	
JET, MAIN, #88	BE85B B	_	_
06#	BE85B B		_
JET, MAIN, #92	BE85B B		
JET, MAIN, #100		BE48B B	
JET SET, PILOT, #40		BE48B A	-
JET SET, PILOT, #40	BE48B B	BE48B B	
JET SET, PILOT, #45	BE85B B	_	
COLLAR SET	BE85B B		
<u> </u>			4: 4: 4: 4: 4:

G14 - AIR CLEANER



(SILENT)


Pos.	POS. REF-NO.	POS. REF-NO. Description GX GX	Engine No.		lgx	- -
			dn	0 	390 K1<1>	
+ —	1 16271-ZE2-000	PACKING, ELBOW		1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1		+ —
V 2	V 2 17210-ZE3-010	ELEMENT, AIR CLEANER				_
<u>ო</u>	3 17218-ZE3-000	FILTER, OUTER			1	_
<u>ம</u>	5 17231-ZE3-W00	COVER, AIR CLEANER				
φ	6 17232-891-000	GROMMET, AIR CLEANER				_
æ	17235-ZH9-N00	NOSE, SILENCER			-1	_
<u>م</u>	9 17238-ZE2-310	COLLAR, AIR CLEANER			2	_
10	LO 17239-ZE1-000	COLLAR B, AIR CLEANER		•	٦	_
11,	11 17410-ZH9-N00	ELBOW COMP., AIR CLEANER				_
V 14	V 14 90325-044-000	NUT, TOOL BOX SETTING			2	_
15	15 93404-06020-08	BOLT-WASHER, 6X20			7	_
1 16	16 94050-06000	NUT FLANGE, 6MM	_			_
1 1 1 1	++		+	++	-++	+

HONDA04.ESTL00618030618H7

POS. REF-NO.		Description	Engine No.	to	GX 390 K1<1>
1 17233-896-701	-701	COLLAR, AIR CLEANER CASE	i 	· · · · · · · · · · · · · · · · · · ·	- - - -
V 2 18310-ZE2-W60	-W60	MUFFLER COMP. <100DB>		2638033	Н
		EXHAUST STUD BROKEN AFTER 2ND COUNTERMEASURE			
		EXHAUST STUD BROKEN AFTER 2ND			
		COUNTERMEASURE			
V 2 18310 - ZE2	-W61	MUFFLER COMP. <100DB>_i	2638034		-
V 3 18320-ZEZ-W61	-W61	PROTECTOR COMP., MUFFLER			
V 5 18330-ZE2-W00	-W00	PIPE, EX.			Н
V7 18333-ZE3-800	-800	GASKET, EX. PIPE		2275744	н
7 18333-ZK6-Y00	-¥00	GASKET, EX. PIPE <wacker></wacker>	2275745	2638033	-
		EXHAUST STUD BROKEN AFTER 2ND	· · · ·		
		COUNTERMEASURE			
		EXHAUST STUD BROKEN AFTER 2ND			_
		COUNTERMEASURE			_
7 18333-ZF6	-W01	GASKET, EX. PIPE	2638034		Н
V 8 18355-ZEZ-WOO	-W00	ARRESTER, SPARK			-
V 9 18381-ZEZ	-W10	GASKET, MUFFLER <arrester></arrester>			
12 18433-ZF6	-W40	COVER COMP., MUFFLER			_
13 18434-ZF6	-W40	COVER COMP., RR. MUFFLER			
14 18436-ZH8-W40	-W40	BASE COMP., MUFFLER COVER			_
15 18437-7E6-W40	-W40	STAY MIBELER COURS			


r-4 \		
8 ± 1 ± 1 ± 1 ± 1 ± 1 ± 1 ± 1 ± 1 ± 1 ±		
		TTON)
	_	(NEW SELECTION)
	(1)	NE

H7 - MUFFLER



_				_				_	_			1
	Ŋ							Ŋ			-	1 1 1 1
												111111
_	_	_									_	+
												1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
	_											+
												11111
VER	83	125				_	110		_	Σ	89	
SPACER, MUFFLER COVER	SCREW, TAPPING, 5X8	SCREW, TAPPING, 5X25		MM	SCREW-WASHER, 5X12	SCREW-WASHER, 6X20	SCREW, TAPPING, 6X10	8MM	WASHER, PLAIN, SMM	WASHER, SPRING, SMM	SCREW, TAPPING, 5X8	11111
t, MUFE	TAPPI	TAPPI	NUT, U, 6MM	NUT, HEX., SMM	WASHEF	WASHER	TAPPI	NUT, FLANGE, 8MM	A, PLAI	R, SPRI	TAPPI	111111
SPACER	SCREW,	SCREW,	NUT, L	NUT, F	SCREW-	SCREW-	SCREW,	NUT, E	WASHER	WASHER	SCREW,	+
40	00	40	00	00	-00	-07	00				00	111111
- ZH8-W	-ZE1-0	-ZH8-W	-782-0	-KF9-9	-05012	-06020	-ZE2-0	-08000	-05700	-05000	-ZE1-0	
17 18466-ZH8-W40	19 90050-ZE1-000	21 90050-ZH8-W40	23 90301-782-000	24 90302-KF9-900	25 93891-05012-00	26 93891-06020-07	27 90006-ZE2-000	28 94050-08000	29 94103-05700	30 94111-05000	31 90050-ZE1-000	
1,	13	21	23	24	25	26	27	28	29	30	33	;


16 | 18438-ZF6-W40



(1)

- Pos.	POS. REF-NO.	POS. REF-NO. Description GX Up to 390	Engine No.	t O	GX 390 K1<1>
, , , , , , , , , , , , , , , , , , ,	1 16854-ZH8-000 3 16955-ZE1-000 7 4 17500-ZE3-811ZA 5 17505-ZE2-013 8 17620-ZH7-023 9 17620-ZH7-023 9 17631-ZH7-023 9 17631-ZH7-003 10 17672-ZE2-W01 14 87565-ZE2-A01 15 91533-671-004 16 93600-05010-0A 17 94050-08000 18 95001-45235-40	RUBBER, SUPPORTER <107MM> JOINT, FUEL TANK TANK ASSY., FUEL <gauge>,*NH31*,MCKINLEY WHITE GAUGE ASSY., FUEL CAP COMP., FUEL FILLER PACKING, FUEL FILLER FILTER, FUEL MARK, FUEL <internal> O-RING, 14MM <nok> SCREW, FLAUE NUT, FLAUGE, 8MM TUBE, FUEL, 4.5X235,>95001-45001-60M></nok></internal></gauge>	2336192	2336191	
22	20 95002-02080 22 95701-08025-00	20 95002-02080 CLIP B8, TUBE 22 95701-08025-00 BOLT, FLANGE, 8X25			<u> </u>

I9 - FLYWHEEL




(NEW SELECTION)

POS. REF-NO.	Description	Engine No.	_	ď
		dn	to	390
			, , , , , ,	K1<1>
V1 19511-ZE3-000	FAN, COOLING	-		
V 3 28450-ZE3-W11	PULLEY COMP., STARTER, <screen grid=""></screen>	_		_
V 5 31100-ZE3-W01	FLYWHEEL COMP. <4 POLE>	_	_	
10 90201-ZE3-790	NUT, SPECIAL, 16MM		2263434	
V 10 90201-ZE3-V00	NUT, SPECIAL, 16MM	2263435		
V11 90741-ZE2-000	KEY, SPECIAL WOODRUFF, 25X18			_ <u>-</u>
				4

HONDA04.ESTL00618030618111


4



[NEW SELECTION]

pos.	POS. REF-NO.	Description 	Engine No. up		t o	GX 390 K1<1>	
\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\	V 1 30500-ZF6-W01	COIL ASSY, IGNITION (40/11 6/40 C/ mallin humanis 67 -	11/2/11 137	1	1 1 1 1 1 1	; ; ; ; ;	· -
2 2	J 2 30700~ZE1-013 7 31511-ZE3-000	<nichiwa rtfm256="" y-ez=""> CLAMPER, CORD</nichiwa>	<u> </u>			<u>н</u> н	
8	8 31512 - ZE2 - 000	GROMMET, CORD					_
V 11	/11 31630-ZE2-861	COIL ASSY., CHARGE <10A>					_
12	12 36101-ZE2-701	CORD, STOP SWITCH <430MM>	_			+	
13	13 36103-ZE1-000	HOLDER, STOP SWITCH CORD				<u>1</u>	_
14	14 90012-888-000	BOLT, FLANGE, 6X40				4,	_
15	15 90013-883-000	BOLT FLANGE, 6X12 <ct200></ct200>	_	_		<u>~</u>	_
17	17 90015-883-000	BOLT, FLANGE, 6X28		_			_

(40 61) 76 - W PULL 61740 4670 - 263-103



502	POS. REF-NO.	Description	Engine No. up	to	390 X1<1>
1	7 -+	CONTACTOR ASSY.	<u> </u>	_	-
2	V 2 31206-ZE3-003	ARMATURE COMP.		_	
m	3 31207-ZE3-003	CLUTCH COMP., OVERRUNNING			
>	V 4 31210-ZE3-013	MOTOR UNIT, STARTER			-
20	31211-ZE2-003	BRACKET, CENTER			-4
9	31212-ZE3-003	BRACKET, FR.			
. 7	7 31213-ZE2-003	GEAR, DRIVE PINION	_		-
80	8 31215-ZE2-003	BRUSH			7
6	9 31218-ZE3-003	YOKE COMP.			1
7 10	V 10 31219 - ZE2 - 003	SPRING, BRUSH RETURN			4
11	11 31222-ZE3-791	GEAR, REDUCTION			-
7 12	V12 31231-ZE2-003	HOLDER, BRUSH			1
14	31232-ZE3-003	WIRE, WATER COVER			н
135	31233-ZE2-003	INSULATOR			Η.
16	16 90110-ZE2-003	SCREW-WASHER, 4X6			Н
17	17 91601-ZE2-003	PACKING			Ļ
18	18 93892-05014-18	SCREW-WASHER, 5X14	_	2326511	7
1.8	18 90007-ZE2-003	BOLT-WASHER, 5X14	2326512		7
19	19 93892-05032-18	SCREW-WASHER, 5X32	_		4
20	20 94070-06080	NUT-WASHER, 6MM	_		~
21	21 95701-08035-08	BOLT, FLANGE, 8X35			~

32 -26 -19 -25

J3 - CONTROL


HONDA04.ESTL00618040618J3

[NEW SELECTION]

(1)

2—**4**

					4 - 4 4
Pos	POS. REF-NO.		Engine No. up	т О	GX 390 K1<1>
+ -	2 16551-ZE3-000	ARM, GOVERNOR		 	11
	16555-ZE3-000	_		_	-
>	1 16561-ZE3-000	_		_	
<u>></u>	5 16562-ZE3-000	_		_	-
_	7 16570-ZE3-W10				-
~ _	0 16571-ZE3-W00				-
;; _	16574-ZE1-000				-
17	16575-ZE2-W00	WASHER, CONTROL LEVER			
≓ _	3 16576-891-000				
<u>-</u>	1 16578-ZE1-000				-
==	5 16581-ZE3-W00				
<u> </u>	7 16584-883-300	SPRING, CONTROL ADJUSTING			_
~ _	3 16592-883-310				r-1
<u>-</u>	3 16594-883-010				
<u>~</u>	0 16599-ZG1-M10				_
5	1 90013-883-000			_	2
	90015-ZE5-010				-1
5	3 90016-2G9-N30	_			_
7	1 90114-SA0-000	_		_	
22	5 90605-230-000	CIRCLIP, SMM			
2,	5 93500-04006-0H	_			
$\frac{2}{\sqrt{2}}$	7 93500-05032-0A	SCREW, PAN, 5X32			



J3 - CONTROL

HONDA04.ESTL00618040618J3

28|93500-05016-0A 29|94050-06000

SCREW PAN, 5X16 |NUT FLANGE, 6MM